



**ARB Approved**

**Installation, Operation and Maintenance Manual**

For

Executive Order

VR-203-W

Balance Phase II EVR Systems  
Not Including In-Station Diagnostics (ISD)



## **NOTICE:**

The **ARB Approved Installation, Operation and Maintenance Manual (IOM) for VR-203** describes the tools, methods, and skill levels required to install the **Balance Phase II EVR Systems**.

Unless specified in this IOM, only skilled technicians that are trained, certified, and licensed by VST, Inc. (i.e. VST Authorized Service Contractors) are able to perform installation, maintenance, or repairs of components manufactured by VST Inc. or the warranty will be void. Unless specified otherwise, only skilled technicians that are trained, certified, and licensed by the Veeder-Root Company are able to perform installation, maintenance, or repairs of components manufactured by the Veeder-Root Company or the warranty will be void. Unless specified otherwise, only skilled technicians that are trained, certified and licensed by Franklin Fueling Systems (i.e. Healy or INCON Certified Technicians) are able to perform installation, maintenance or repairs of components manufactured by Franklin Fueling Systems or warranty will be void. Unless specified otherwise, only skilled technicians that are trained, certified, and licensed by Hirt Combustion Engineers, Inc. (HCE or Hirt) are able to perform installation, maintenance, or repairs of components manufactured by HCE or the warranty will be void. Unless specified otherwise, only skilled technicians that are trained, certified and licensed by EMCO Wheaton Retail (i.e. EMCO Certified Technicians) are able to perform installation, maintenance or repairs of components manufactured by EMCO or ContiTech USA Inc. or warranty will be void.

NOTE: GDF Owner / Operator can remove and install hanging hardware (nozzle, curb hose, breakaway, flow limiter and whip hose). Additional certifications may be required in accordance with local district requirements.

It is the responsibility of each VST Authorized Service Contractor (ASC), Veeder-Root technician, Healy Certified Technician, Hirt Technician, and EMCO Certified Technician to be familiar with the current requirements of state, federal, and local codes for installation and repair of gasoline dispensing equipment.

It is also the responsibility of the VST ASC, Veeder-Root technician, Healy Certified Technician, Hirt Technician, and EMCO Certified Technician to be aware of all the manuals, necessary safety precautions, and site safety requirements to assure a safe and trouble-free installation.

To participate in a VST training class, a candidate will need to complete an enrollment form, which can be downloaded from the VST website at [www.vsthose.com](http://www.vsthose.com) or requested by phone at 937-704-9333. Once the enrollment form is approved by VST, the candidate can enroll in a VST training class.

To confirm a VST Authorized Service Contractor status, a person can go to the VST website at [www.vsthose.com](http://www.vsthose.com). This list is updated periodically.

**Vapor Systems Technologies, Inc.**  
650 Pleasant Valley Drive  
Springboro, Ohio 45066

PH: 937-704-9333  
FX: 937-704-9443  
[www.vsthose.com](http://www.vsthose.com)

To confirm Veeder-Root TLS or ISD training, a person should send an email to [technicaltraining@gilbarco.com](mailto:technicaltraining@gilbarco.com) with the name (and company) of the ASC to obtain verification of the ASC TLS/ISD training status or call 800-997-7725 and press “\*” to get to the Veeder-Root menu and “\*” again to speak to a representative.

To confirm a Healy or INCON Certified Technician training status, a person can access a searchable database at the following web site: <http://techlab.franklinfueling.com/mod/resource/view.php?id=64>

To confirm Hirt training, a person should contact Hirt below with the name (and company) of the technician.

*Contact Information:*  
Customer Service Department  
Hirt Combustion Engineers, Inc.  
Phone: (562) 692-6970  
email: [HirtVCS@aol.com](mailto:HirtVCS@aol.com)

To confirm the status of an EMCO Certified Technician, please visit the EMCO Wheaton Retail's website at [www.emcoretail.com](http://www.emcoretail.com) or contact:

Jose E. Rodriguez  
Manager of Technical Services & Support  
EMCO Wheaton Retail  
Phone: 619-421-1743  
Email: [JERodriguezSD@aol.com](mailto:JERodriguezSD@aol.com)

EMCO Wheaton Retail  
2300 Industrial Park Drive  
Wilson, North Carolina 27893  
Phone: 252-243-4394  
Fax: 252-243-4759  
Email: [ewrc@emcoretail.com](mailto:ewrc@emcoretail.com)

Table of Contents

|             |  |
|-------------|--|
| Section 1:  | Contractor Requirements  |
| Section 2:  | Weekly Inspections   |
| Section 3:  | Quarterly and Annual Inspections   |
| Section 4:  | Alarm Troubleshooting Summary  |
| Section 5:  | Drive-offs and Other Customer Abuse                                      |
| Section 6:  | Phase II Coaxial Balance EVR Dripleless Nozzles                          |
| Section 7:  | Phase II Coaxial EVR Nozzle Repair Kits                                  |
| Section 8:  | Phase II Coaxial EVR Balance Fuel Hose                                   |
| Section 9:  | Phase II Coaxial EVR Balance Safety Breakaway Device                     |
| Section 10: | VST ECS Membrane Processor: Installation                                 |
| Section 11: | VST ECS Membrane Processor: Operation, Maintenance, & Start-Up           |
| Section 12: | VST ECS Membrane Processor : Veeder-Root Pressure Management Control     |
| Section 13: | Veeder-Root Vapor Pressure Sensor: Installation Guide                    |
| Section 14: | Veeder-Root Vapor Polisher: Installation Instructions                    |
| Section 15: | Veeder-Root Vapor Polisher: Pressure Management Control                  |
| Section 16: | Hirt VCS 100: Vapor Processor and Indicator Panel: Installation Manual   |
| Section 17: | Healy Clean Air Separator: Installation                                  |
| Section 18: | VST Green Machine: Installation and Maintenance Manual                   |
| Section 19: | Veeder-Root TLS RF Wireless 2 System: Installation and Maintenance Guide |
| Section 20: | Liquid Condensate Trap: Installation, Operation, and Maintenance Manual  |
| Section 21: | Veeder-Root Vapor Pressure Sensor for Vent Stacks: Installation Guide    |

## Contractor Requirements

The following are contractor training requirements for installing, maintaining, and repairing manufacturer's enhanced vapor recovery (EVR) equipment. Unless otherwise specified below, installation, maintenance and repair of system components, including removal and installation of such components in the course of any required tests, shall be performed by technicians certified by the appropriate manufacturer.

In addition to the training requirements below, the contractor is responsible for providing the warranty tag, included with each component, to the service station owner/operator at the time of installation.

## VST Contractor Requirements

Due to the highly volatile nature of gasoline and its handling and storage, VST requires the following certifications for its Authorized Service Contractors (ASC's):

|                                | Level A<br>Re-cert every 2 years   | Level B<br>Re-cert every 2 years  | Level C<br>Re-cert every 2 years  | Level D<br>Re-cert every 2 years  |
|--------------------------------|--|---|---|---|
| <b>Component</b>               | <ul style="list-style-type: none"> <li>Hanging Hardware</li> </ul>   | <ul style="list-style-type: none"> <li>Hanging Hardware</li> <li>ECS Membrane Processor</li> </ul>  | <ul style="list-style-type: none"> <li>Hanging Hardware</li> <li>ECS Membrane Processor</li> </ul>  | <ul style="list-style-type: none"> <li>Hanging Hardware</li> <li>Green Machine</li> </ul>   |
| <b>Authorized Tasks</b>        | <ul style="list-style-type: none"> <li>Functional Testing</li> <li>Installation</li> <li>Maintenance &amp; Repair</li> </ul> | <ul style="list-style-type: none"> <li>Installation</li> </ul>  | <ul style="list-style-type: none"> <li>Installation</li> <li>Functional Testing</li> <li>Start-Up</li> <li>Troubleshooting</li> <li>Maintenance &amp; Repair</li> </ul> | <ul style="list-style-type: none"> <li>Installation</li> <li>Functional Testing</li> <li>Start-Up</li> <li>Troubleshooting</li> <li>Maintenance &amp; Repair</li> </ul> |
| <b>Training Pre-Requisites</b> | <ul style="list-style-type: none"> <li>None</li> </ul>   | <ul style="list-style-type: none"> <li>VST Level A</li> <li>*Veeder-Root Installer Certification<sup>1</sup> or ATG Technician Certification<sup>2</sup> or VR Vapor Products Certification<sup>3</sup>.</li> </ul> | <ul style="list-style-type: none"> <li>VST Level A/B</li> <li>Veeder-Root Vapor Products certification<sup>3</sup></li> </ul>   | <ul style="list-style-type: none"> <li>VST Level A</li> <li>Veeder-Root Vapor Products certification<sup>3</sup></li> </ul>   |

**NOTE:**

Depending on local codes, in addition to the VST and Veeder-Root training, contractors may be required to take air-district training or ICC certification as an approved vapor-recovery installer.

\*Veeder-Root Installer Certification is a pre-requisite for ATG Technician Certification.

Provided that there are no other local district requirements, a GDF owner/operator can, without obtaining contractor/installer certification from VST, remove and install ARB-certified VST nozzles, curb hoses, breakaways, and whip hoses.

<sup>1</sup> Installer Certification – Installation (Level 1) Course in Veeder-Root UST Monitoring Systems

<sup>2</sup> ATG Technician Certification – Veeder-Root Startup & Service Technician (Level 2/3/4) in TLS-3XX UST Monitoring Systems (including Secondary Containment Vacuum Sensing – CA Only)”

<sup>3</sup> Vapor Products Certification – Veeder-Root Vapor Products – In-Stage Diagnostics – Carbon Canister Vapor Polisher – PMC – Wireless ISD/PMC

- ASC's must be able to show proof of certification if asked. Carry the wallet card or have a copy of your certification on file with the GDF.
- The ASC must record his or her certification number on the applicable paperwork for all warranties to be deemed valid.
- Contractors should **ALWAYS** verify the training and certification requirements with the air-district staff **BEFORE** beginning installation of EVR systems.
- To verify contractor training go to the following website:  
[http://www.vsthose.com/cert\\_contractors.aspx](http://www.vsthose.com/cert_contractors.aspx)



*Veeder-Root Contractor Requirements*

| <b>Veeder-Root Contractor Certification Requirements</b>  | <b>Installer Certification<sup>6</sup></b> | <b>ATG Technician Certification<sup>7</sup></b> | <b>VR Vapor Products Certification<sup>8</sup></b> |
|---|--|---|--|
| Install <sup>1</sup> ISD  | √  | √   | √  |
| Install PMC   | √  | √   | √  |
| Install CCVP  | √  | √   | √  |
| Install Wireless ISD/PMC  | √  | √   | √  |
| Installation Checkout <sup>2</sup>  |  | √   | √  |
| ATG Startup <sup>3</sup> / Training <sup>4</sup> / Service <sup>5</sup>   |  | √   | √  |
| ISD Startup / Training / Service  |  |   | √  |
| PMC Startup / Training / Service  |  |   | √  |
| CCVP Startup / Training / Service   |  |   | √  |
| Wireless ISD/PMC Startup / Training / Service   |  |   | √  |
| Install Pressure Sensor (ATG)   | √  | √   | √  |
| Maintain Pressure Sensor (ATG)  |  | √   | √  |
| Calibrate Pressure Sensor (ATG)   |  | √   | √  |
| Clear ATG Pressure Sensor Alarm (ATG)   |  | √   | √  |
| Clear ISD/ PMC alarms (ISD/PMC)   |  |   | √  |
| <sup>1</sup> Perform wiring and conduit routing; equipment mounting<br><sup>2</sup> Inspect wiring and conduit routing; equipment mounting<br><sup>3</sup> Turn power on, program and test the systems<br><sup>4</sup> Provide supervised field experience in service techniques and operations<br><sup>5</sup> Troubleshoot and provide routine maintenance as specified in the IOM<br><sup>6</sup> UST Monitoring Systems – Installer (Level 1)<br><sup>7</sup> Certified UST Monitoring Technician<br><sup>8</sup> VR Vapor Products<br><br>A current Veeder-Root Installer Certification is a prerequisite for the ATG Technician Certification course. |  |   |  |

- Veeder-Root certification training is given in a classroom environment.
- To confirm TLS or ISD training a regulator should send an email to [technicaltraining@gilbarco.com](mailto:technicaltraining@gilbarco.com) with the name (and company) of the ASC to obtain verification of the ASC TLS/ISD training status or call 800-997-7725 and press “4” to get to the Veeder-Root menu and then “\*” to speak to a representative or sign on to the Gilbarco Learning Suite at <http://wise.gilbarco.com>.

*EMCO Contractor Requirements*

| Level  | Component  | Authorized Tasks   | Training Pre-Requisites |
|--|--|--|-------------------------|
| <p><b>A</b><br/>Must be re-certified every two-years</p>   | <ul style="list-style-type: none"> <li>• EMCO Hanging Hardware</li> <li>• ContiTech Maxxim Premier Plus or Ultra Hose</li> </ul> | <ul style="list-style-type: none"> <li>• Installation</li> <li>• Functional Testing</li> <li>• Preventive Maintenance</li> <li>• Repair</li> </ul> | <p>No pre-requisite</p> |
| <p style="text-align: center;"><b><u>Note:</u></b></p> <p>Depending on local codes, in addition to EMCO training, contractors may be required to take air district training or ICC certification as an approved vapor recovery installer.</p> <p>Provided that there are no other local district requirements, a GDF owner/operator can, without obtaining contractor/installer certification from EMCO, remove and install ARB-certified EMCO nozzles and breakaways and ContiTech curb hoses and whip hoses.</p> |  |  |                         |

- EMCO certification training is given in a classroom environment.
- EMCO Certified Technicians must be able to show proof of certification if asked. Carry the wallet card or have a copy of your certification on file with the gasoline dispensing facility.
- EMCO Certified Technicians must record his or her certification number on the applicable paperwork for all warranties to be deemed valid.
- To verify EMCO contractor training go to the following website and click on contractors: <http://www.emcoretail.com>

EMCO Certified Technician should **ALWAYS** verify training and certifications requirements with the air district staff **BEFORE** beginning installation of EVR systems or components.

*Hirt Contractor Requirements*

---

|   |  |
|---|--|
| <b>Technician Certification</b>   | Contractors holding valid Installer Certification are approved to perform VCS 100 processor and indicator panel installation; wiring and conduit routing; start-up; maintenance; troubleshooting; and parts replacement. |
| <b><u>NOTE:</u></b><br><b>Depending on local codes, in addition to the Hirt training, contractors may be required to take air-district training or ICC certification as an approved vapor-recovery installer.</b> |  |

- Hirt installer certification training is given in a classroom environment.
- To verify contractor training call (562) 692-1490.

*FFS/Healy Contractor Requirements (for CAS )*

---

- Unless specified otherwise, only skilled technicians that are trained, certified and licensed by Franklin Fueling Systems (i.e. Healy or INCON Certified Technicians) are able to perform installation, maintenance or repairs of components manufactured by Franklin Fueling Systems or warranty will be void.
- It is the responsibility of each Healy Certified Technician to be familiar with the current requirements of state, federal, local codes and air district rules and regulations for installation and repair of gasoline dispensing equipment.
- It is also the responsibility of the Healy Certified Technician to be aware of all the necessary safety precautions and site safety requirements to assure a safe and trouble free installation.
- To confirm a Healy or INCON Certified Technician training status, a regulator can access a searchable database at the following web site:

<http://techlab.franklinfueling.com/mod/resource/view.php?id=64>

---

*OPW Breakaway Contractor Requirements (for 66CLP)*

---

- OPW offers contractor training on the 66CLP breakaway, but the completion of a training course is not required to install, reconnect or repair the breakaway.
- OPW recommends that the GDF Owner/Operator or VST ASC Levels A, B, C technician or EMCO Level A technician review the latest 66CLP installation and maintenance manual on the OPW Internet site ([www.opwglobal.com](http://www.opwglobal.com)) prior to installing, reconnecting or repairing an OPW 66CLP breakaway.
- It is the responsibility of each GDF Owner/Operator or service technician to be familiar with the current requirements of federal, state and local codes.
- It is the responsibility of each GDF Owner/Operator or service technician to be familiar with the local air district rules and regulations for installation and repair of OPW breakaways.
- It is the responsibility of each GDF Owner/Operator or technician to be aware of all of the necessary safety precautions and site safety requirements to assure a safe and trouble free installation or repair.
- A current list of OPW EVR certified technicians is located at:  
<http://www.opwglobal.com/Contact/EVRTrainedTechnicians.aspx>

**[www.opwglobal.com](http://www.opwglobal.com)**

---

# Weekly Inspections –Hanging Hardware

| <b>HANGING HARDWARE SYSTEM</b> |   |   |   |                          |  |
|--------------------------------|---|---|---|--------------------------|--|
| <b>Component</b>               | <b>Procedure</b>  | <b>Fail Criteria</b>  | <b>Corrective Action</b>                        | <b>Reference Manuals</b> | <b>Authorized Personnel</b>  |
| Nozzle<br>Hose<br>Breakaway    | Inspect each hose, breakaway, and nozzle for loose connections or leaks         | Presence of a leak  | Tighten connections or replace with new product | IOM-6                    | <b>Nozzle, hose, or breakaway replacement:</b><br>GDF owner/operator or VST ASC Levels A, B, C, or D or EMCO Level A |
|                                |   | Presence of residue from a leak   | Tighten connections or replace with new product | IOM-8                    |  |
|                                |   | Visible o-ring between any component connection                           | Tighten connections or replace with new product | IOM-9                    |  |
| <b>CO-AXIAL HOSES</b>          |   |   |   |                          |  |
| <b>Component</b>               | <b>Procedure</b>  | <b>Fail Criteria</b>  | <b>Corrective Action</b>                        | <b>Reference Manuals</b> | <b>Authorized Personnel</b>  |
| Coaxial<br>Hose                | Inspect hoses for wear, severe kinks, cracks, splitting, and functional swivels | Kinks, cracks, splitting, non-functional swivels, or any visible openings | Replace with new hose                           | IOM-8                    | <b>Hose replacement:</b><br>GDF owner/operator or VST ASC Levels A, B, C, or D or EMCO Level A                       |
| <b>BREAKAWAY</b>               |   |   |   |                          |  |
| <b>Component</b>               | <b>Procedure</b>  | <b>Fail Criteria</b>  | <b>Corrective Action</b>                        | <b>Reference Manuals</b> | <b>Authorized Personnel</b>  |
| Breakaway                      | Inspect breakaway for leaks around the scuff                                    | Presence of a leak around the scuff                                       | Replace with new breakaway                      | IOM-9                    | <b>Replace breakaway:</b><br>GDF Owner/Operator or VST ASC Levels A, B, C, or D or EMCO Level A                      |

| <b>VST NOZZLE</b>                                      |   |  |   |                              |   |
|--|---|--|---|------------------------------|---|
| <b>Nozzle Component</b>                                | <b>Procedure</b>  | <b>Fail Criteria</b>   | <b>Corrective Action</b>  | <b>Reference Manuals</b>     | <b>Authorized Personnel</b>   |
| Nozzle lever, lever guard, lever lock                  | Inspect for imperfections, cuts, or damage to the:<br><br>Nozzle Lever<br>Lever Guard<br>Lever Lock<br>Spout<br>Spout Vent Hole<br>Face Seal<br>Interlock Rod<br>Vapor Collection Sleeve. | Damaged or missing   | Replace with new VST nozzle   | IOM-6                        | <b>Nozzle Replacement:</b><br>GDF Owner/Operator or<br>VST ASC Levels A, B, C, or D   |
| Nozzle Spout   |   | Sheared or bent  | Replace nozzle spout assembly with new VST Front-End Kit<br>or<br>Replace with new VST nozzle | IOM-7<br>IOM-6               | <b>Front-End Repair:</b><br>VST ASC Levels A, B, C, or D<br><b>Nozzle Replacement:</b><br>GDF Owner/Operator or<br>VST ASC Levels A, B, C, or D |
| Nozzle Vent Hole                                       |   | Vent hole blocked  | Clear blockage  | IOM-6                        | <b>Blockage Repair:</b><br>GDF Owner/Operator or<br>VST ASC Levels A, B, C, or D  |
| Nozzle Collection Sleeve                               |   | If greater than 18 inches total length of cuts (if greater than 0.4 sq. inches of material missing)                            | Replace vapor collection kit  | IOM-7                        | <b>Front-End Repair:</b><br>VST ASC Levels A, B, C, or D  |
|  |   |  | Replace nozzle with new VST nozzle  | IOM-6                        | <b>Nozzle Replacement:</b><br>GDF Owner/Operator or<br>VST ASC Levels A, B, C, or D   |
| Nozzle Face Seal                                       |   | Greater than 30% of the material is missing (if greater than 2.5 inches of the accumulated faceplate circumference is missing) | Replace vapor collection kit  | IOM-7                        | <b>Front-End Repair:</b><br>VST ASC Levels A, B, C, or D  |
|  |   |  | Replace nozzle with new VST nozzle  | IOM-6                        | <b>Nozzle Replacement:</b><br>GDF Owner/Operator or<br>VST ASC Levels A, B, C, or D   |
| Nozzle Front-End Kit (Collection sleeve and face seal) |   | Alignment lines are misaligned and/or the assembly is askew  | Replace vapor collection kit  | IOM-7                        | <b>Front-End Repair:</b><br>VST ASC Levels A, B, C, or D  |
|  |   |  | Replace nozzle with new VST nozzle  | IOM-6                        | <b>Nozzle Replacement:</b><br>GDF Owner/Operator or<br>VST ASC Levels A, B, C, or D   |
| Nozzle Interlock Rod                                   |   | Nozzle Inspection  | Interlock rod sticks during engagement or disengagement                                       | Replace vapor collection kit | IOM-7   |
|  |   |  | Replace nozzle with new VST nozzle  | IOM-6                        | <b>Nozzle Replacement:</b><br>GDF Owner/Operator or<br>VST ASC Levels A, B, C, or D   |

# Weekly Interlock Inspection – VST Nozzles

| Fueling Point # | Check A |      | Check B |      |
|-----------------|---------|------|---------|------|
|                 | Pass    | Fail | Pass    | Fail |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |

| Fueling Point # | Check A |      | Check B |      |
|-----------------|---------|------|---------|------|
|                 | Pass    | Fail | Pass    | Fail |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |
|                 |         |      |         |      |

Inspected by: \_\_\_\_\_ Date: \_\_\_\_\_ Inspected by: \_\_\_\_\_ Date: \_\_\_\_\_


**Check A**

- 1) Make sure dispenser is de-activated (**do not turn dispenser on**).
- 2) Lift the nozzle from the dispenser cradle without touching the lever.
- 3) If hold-open latch is engaged, the nozzle fails. Tag out this Fueling Point and have the nozzle immediately serviced or replaced.
- 4) Point nozzle spout into a gasoline compatible container. Do not compress vapor collection sleeve (VCS).
- 5) Pull lever to make sure there is no spring tension.  
 If the lever has **no** spring tension (dead lever), the nozzle passes.  
 If the lever has spring tension (live lever i.e. same as dispensing fuel), the nozzle fails.
- 6) If Check A fails, tag out this Fueling Point and have the nozzle immediately serviced or replaced. Reference nozzle installation or nozzle repair instructions in the ARB Approved Installation, Operation, and Maintenance Manual of the appropriate Executive Order.
- 7) If Check A passes, proceed to Check B.


**Check B**

- 1) While still pointing the nozzle spout in the gasoline compatible container and with the dispenser de-activated, compress the vapor collection sleeve (VCS) by pressing on the face seal, and confirm the lever has spring tension (live lever).
- 2) Release the VCS and the lever. Then pull the lever and confirm the lever has **no** spring tension (dead lever). Make sure that the face seal is not caught on the spout latch ring.
- 3) If lever goes live when the VCS is compressed, and goes dead after the VCS and lever are released, then the nozzle passes.
- 4) If lever stays dead (when the VCS is compressed) **or** stays live (after the VCS and lever are released), then the nozzle fails.
- 5) If check B fails, tag out this Fueling Point and have the nozzle immediately serviced or replaced. Reference nozzle installation or nozzle repair instructions in the ARB Approved Installation, Operation, and Maintenance Manual of the appropriate Executive Order.





**VST G2 Nozzle**




| EMCO NOZZLE                         |  |   |   |                    |  |
|-------------------------------------|--|---|---|--------------------|--|
| Nozzle Component                    | Procedure  | Fail Criteria   | Corrective Action                             | Reference Manuals  | Authorized Personnel   |
| Lever, Hold Open Latch, Lever Guard | Inspect for defects, cuts or damage to the:      | Damaged or missing  | Replace with new EMCO latch kit or nozzle     | IOM – 6            | <b>Latch Kit Repair:</b><br>EMCO Certified Technician Level A<br><br><b>Nozzle Replacement:</b><br>GDF Owner/Operator or EMCO Certified Technician Level A     |
| Spout                               | Lever<br>Hold Open Latch<br>Lever Guard<br>Spout | Sheared or bent   | Replace with new EMCO Spout Kit or nozzle     | IOM – 6<br>IOM - 7 | <b>Spout Kit Repair:</b><br>EMCO Certified Technician Level A<br><br><b>Nozzle Replacement:</b><br>GDF Owner/ Operator or EMCO Certified Technician Level A    |
| Spout Vent Hole                     |  | Vent hole blocked   | Clear blockage                                | IOM – 6            | <b>Blockage Repair:</b><br>GDF Owner/Operator or EMCO Certified Technician Level A   |
| Boot Face                           | Inspect for defects, cuts or damage to the:      | > than 0.4 sq. inches of boot face material is missing (e.g. A triangular or similar shape in which greater than 7/16 inches of the boot face circumference is missing [accumulated]) | Replace with new EMCO boot face kit or nozzle | IOM – 6<br>IOM - 7 | <b>Boot Face Kit Repair:</b><br>EMCO Certified Technician Level A<br><br><b>Nozzle Replacement:</b><br>GDF Owner/Operator or EMCO Certified Technician Level A |
| Bellows                             | Spout Vent Hole<br>Boot Face<br>Bellows          | A cut across 7 consecutive bellows convolutions   | Replace with new EMCO bellows kit or nozzle   | IOM – 6<br>IOM - 7 | <b>Bellows Kit Repair:</b><br>EMCO Certified Technician Level A<br><br><b>Nozzle Replacement:</b><br>GDF Owner/Operator or EMCO Certified Technician Level A   |

| EMCO NOZZLE                  |   |   |  |                    |   |
|------------------------------|---|---|--|--------------------|---|
| Insertion Interlock Rod      | Inspect for defects, cuts or damage to the:<br><br>Insertion Interlock Rod<br>Band Clamps<br>Serial Plate<br>Security Rivet | Insertion interlock rod sticks during engagement or disengagement | Replace with new EMCO Spout Kit or nozzle      | IOM – 6<br>IOM - 7 | <b>Spout Kit Repair:</b><br>EMCO Certified Technician Level A<br><br><b>Nozzle Replacement:</b><br>GDF Owner/Operator or EMCO Certified Technician Level A      |
| Band Clamps                  |   | Damaged or missing  | Replace with new EMCO band clamp kit or nozzle | IOM – 6<br>IOM - 7 | <b>Band Clamp Kit Repair:</b><br>EMCO Certified Technician Level A<br><br><b>Nozzle Replacement:</b><br>GDF Owner/Operator or EMCO Certified Technician Level A |
| Serial Plate, Security Rivet |   | Damaged or missing  | Replace with new EMCO nozzle                   | IOM – 6            | <b>Nozzle Replacement:</b><br>GDF Owner/Operator or EMCO Certified Technician Level A   |



## Models A4005EVR & RA4005EVR Balance Vapor Recovery Nozzles Weekly Insertion Interlock Test Procedure



**Objective:** The purpose of this test procedure is to verify proper field operation of the Model A4005EVR nozzle insertion interlock during engagement or disengagement.

### Service Tools Required:

- Gasoline Approved Container
- Protective Gloves

### **CAUTION:**

1. Always barricade work area to keep pedestrians and vehicles from accessing the dispenser during testing of the nozzle.
2. Always use a gasoline approved container when performing any type of testing or preventive maintenance on hanging hardware components. (nozzle, hose swivel, breakaway and hoses)
3. Always point the end of the spout downwards into a gasoline approved container when performing the Weekly Insertion Interlock Test Procedure. Failure may result in a hazardous gasoline spill or personal injury and/ or death.
4. Always make sure the dispenser is de-activated (off) while performing the Weekly Insertion Interlock Test Procedure. Failure may result in a hazardous gasoline spill or personal injury and/ or death.

### Lever Verification:



1. Remove the nozzle from the dispenser cradle without touching the lever. If the hold-open latch is engaged, the nozzle fails. The nozzle shall not be used and must be immediately taken out of service.



2. Point the end of the spout downwards into a gasoline approval container. Engage (squeeze) the lever without compressing the bellows. Perform this step a minimum of three times to assure the lever has free motion and no tension (dead lever).

**IMPORTANT:** If at any time while performing step 2 the lever exhibits tension (live lever), the nozzle fails. The nozzle shall not be used and must be immediately taken out of service.

3. If the lever exhibits no tension (dead lever) while performing step 2, the nozzle has successfully passed. Record the results on the Lever Verification Form and proceed to step 4.



## Models A4005EVR & RA4005EVR Balance Vapor Recovery Nozzles Weekly Insertion Interlock Test Procedure

### Insertion Interlock Verification:



4. While pointing the end of the spout downwards into a gasoline approved container compress the bellows from its "free" extended position, and engage (squeeze) the lever. If the lever exhibits no tension (dead lever), the nozzle fails. The nozzle shall not be used and must be immediately taken out of service.

**IMPORTANT:** When compressing the bellows, the lever will exhibit tension (live lever) allowing both the fuel and vapor valves inside the nozzle to open to atmosphere.

7. If the lever exhibits no tension (dead lever) while performing step 6, the nozzle has successfully passed. Place the nozzle back on the dispenser cradle and record the results on the Insertion Interlock Verification Form.



5. While keeping the lever engaged, slowly allow the bellows to extend to its "free" position in a controlled manner that simulates removing the nozzle from a vehicle fill pipe. Make sure that the boot face is not caught on the spout latch ring.

**IMPORTANT:** The fuel and vapor valves will close once the bellows reaches its extended position. A "click" will indicate both valves are closed and the insertion interlock is disengaged.



6. While pointing the end of the spout downwards into a gasoline approved container, engage (squeeze) the lever without compressing the bellows. Perform this step a minimum of three times to assure the lever has free motion and no tension (dead lever).

**IMPORTANT:** If at any time while performing step 6 the lever exhibits tension (live lever), the nozzle fails. The nozzle shall not be used and must be immediately taken out of service.

Emco Wheaton Retail Corp.

2300 Industrial Park Dr. • Wilson, NC 27893 • 252-243-0150 • 252-243-4759 (fax)  
619-421-1743 (Technical Services, California)

p/n 570166  
Rev. A, 11/12



Models A4005EVR & RA4005EVR Balance Vapor Recovery Nozzles  
Weekly Insertion Interlock Test Procedure

Facility: \_\_\_\_\_ Facility Address: \_\_\_\_\_

Lever Verification Form

|                 |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
|-----------------|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
| Fueling Point # |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
| Pass            |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
| Fail            |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |

Lever Verification Form

|                 |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
|-----------------|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
| Fueling Point # |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
| Pass            |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
| Fail            |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |

Insertion Interlock Verification Form

|                 |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
|-----------------|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
| Fueling Point # |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
| Pass            |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
| Fail            |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |

Insertion Interlock Verification Form

|                 |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
|-----------------|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
| Fueling Point # |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
| Pass            |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
| Fail            |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |

Date: \_\_\_\_\_ Performed by: \_\_\_\_\_

Date: \_\_\_\_\_ Performed by: \_\_\_\_\_

Lever Verification Form

|                 |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
|-----------------|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
| Fueling Point # |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
| Pass            |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
| Fail            |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |

Lever Verification Form

|                 |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
|-----------------|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
| Fueling Point # |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
| Pass            |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
| Fail            |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |

Insertion Interlock Verification Form

|                 |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
|-----------------|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
| Fueling Point # |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
| Pass            |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
| Fail            |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |

Insertion Interlock Verification Form

|                 |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
|-----------------|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
| Fueling Point # |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
| Pass            |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
| Fail            |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |

Date: \_\_\_\_\_ Performed by: \_\_\_\_\_

Date: \_\_\_\_\_ Performed by: \_\_\_\_\_

## Weekly Inspection and Testing Checklist

| Checklist results may be used to assist with filling out GDF maintenance log. |                                       |                                   | Date:                           | Page:<br>_____ of _____   |
|---|---------------------------------------|-----------------------------------|---------------------------------|---------------------------|
| Dispenser Number  | Unihose or Fuel Grade<br>(circle one) | Nozzle Inspection<br>(circle one) | Hose Inspection<br>(circle one) | Breakaway<br>(circle one) |
|   | Unihose 87 89 91 other _____          | Pass Fail                         | Pass Fail                       | Pass Fail                 |
|   | Unihose 87 89 91 other _____          | Pass Fail                         | Pass Fail                       | Pass Fail                 |
|   | Unihose 87 89 91 other _____          | Pass Fail                         | Pass Fail                       | Pass Fail                 |
|   | Unihose 87 89 91 other _____          | Pass Fail                         | Pass Fail                       | Pass Fail                 |
|   | Unihose 87 89 91 other _____          | Pass Fail                         | Pass Fail                       | Pass Fail                 |
|   | Unihose 87 89 91 other _____          | Pass Fail                         | Pass Fail                       | Pass Fail                 |
|   | Unihose 87 89 91 other _____          | Pass Fail                         | Pass Fail                       | Pass Fail                 |
|   | Unihose 87 89 91 other _____          | Pass Fail                         | Pass Fail                       | Pass Fail                 |
|   | Unihose 87 89 91 other _____          | Pass Fail                         | Pass Fail                       | Pass Fail                 |
|   | Unihose 87 89 91 other _____          | Pass Fail                         | Pass Fail                       | Pass Fail                 |
|   | Unihose 87 89 91 other _____          | Pass Fail                         | Pass Fail                       | Pass Fail                 |
|   | Unihose 87 89 91 other _____          | Pass Fail                         | Pass Fail                       | Pass Fail                 |
|   | Unihose 87 89 91 other _____          | Pass Fail                         | Pass Fail                       | Pass Fail                 |



### Table 1: Quarterly Inspections for FFS Healy Clean Air Separator Only

Inspect Clean Air Separator for proper operating configuration. See Executive Order VR-204, Exhibit 2, Figure 2B-16 or 2B-16H for guidance. Figure 2B-16 applies to vertical CAS installations. Figure 2B-16H applies to horizontal CAS installations.

| Quarterly Inspections for Healy Clean Air Separator   |            |                   |
|---|------------|-------------------|
| Checklist results may be used to assist with filling out GDF maintenance log.<br>This table may be also used for testing the Clean Air Separator. | Date _____ | Page ____ of ____ |
| Clean Air Separator Configuration (see Exhibit 2, Figures 2B-16 or 2B-16H)  |            |                   |
| Valve   | Circle One |                   |
| A   | Open       | Closed            |
| B   | Open       | Closed            |
| C   | Open       | Closed            |
| D   | Open       | Closed            |
| Plug  | Circle One |                   |
| E   | Installed  | Missing           |
| F   | Installed  | Missing           |

**Table 2: Annual Inspection Requirements for VST ECS Membrane Processor:**

| <b>Annual VST ECS Membrane <i>Processor</i> Inspections and Replacements</b> |  |   |  |                          |                             |
|--|--|---|--|--------------------------|-----------------------------|
| <b>Component</b>   | <b>Procedure</b>   | <b>Fail Criteria</b>  | <b>Corrective Action</b>                 | <b>Reference Manuals</b> | <b>Authorized Personnel</b> |
| Blower   | Replace the blower every ten years or 15,000 hrs. (whichever comes first).         |   |  | IOM - 11                 | VST ASC Level C             |
| Vacuum pump  | Replace pump every ten years or 15,000 hrs. (whichever comes first).               |   |  |                          |                             |
| Vacuum pump drive coupling - rubber insert                                   | Visually inspect the drive coupling between the vacuum pump and the motor for wear | Rubber debris is found on or around the vacuum-pump base.   | Replace the drive coupling rubber insert | IOM - 11                 |                             |
| Heat Trace Cable   | Check the continuity of the heat trace cable.                                      | If the heat trace cable circuit is open, the cable has failed.  | Replace the heat- trace cable            | IOM - 11                 |                             |
| HC Sensor  | Test the HC sensor   | The difference shall be within $\pm 1.0\%$ HC concentration from the calibration gas concentration for zero and mid-range gas and $\pm 2.0\%$ for the high-range gas. | Replace the HC Sensor                    | IOM – 11 and Exhibit 8   |                             |

**Table 3: Preventative Maintenance Checklist Form for VST ECS Membrane Processor**

| <b>Component</b>  | <b>Frequency</b> | <b>Date Inspected</b> | <b>Completed</b> | <b>Required Action Items</b> |
|---|------------------|-----------------------|------------------|------------------------------|
| <b>VST ECS PROCESSOR</b>  | <b>Yearly</b>    |                       |                  |                              |
| <ul style="list-style-type: none"> <li>Inspect drive coupling on the vacuum pump.</li> </ul>    |                  |                       | [ ]              |                              |
| <ul style="list-style-type: none"> <li>Check the continuity of the heat trace cable.</li> </ul> |                  |                       | [ ]              |                              |
| <b>RECIRCULATION BLOWER</b>   |                  |                       |                  |                              |
| Replace every 10 years or 15,000 hours, whichever comes first.                                  |                  |                       | [ ]              |                              |
| <b>VACUUM PUMP</b>  |                  |                       |                  |                              |
| Replace every 10 years or 15,000 hours, whichever comes first.                                  |                  |                       | [ ]              |                              |

## Table 4: Annual Inspection Requirements/Checklist for Hirt VCS 100 Vapor Processor:

### DATE OF TEST:

|  |  |   |           |
|--|--|---|-----------|
| SERVICE COMPANY NAME   |  | SERVICE COMPANY'S TELEPHONE   |           |
| SERVICE TECHNICIAN   |  | HIRT TECHNICIAN CERTIFICATION # (as applicable)<br>ICC or DISTRICT TRAINING CERTIFICATION (as applicable) |           |
| STATION NAME   |  | DISTRICT PERMIT #   |           |
| STATION ADDRESS  |  | CITY  | STATE ZIP |
| Instructions: Perform each step and check each box after step is completed. File completed checklist with station's Maintenance Records. |  |   |           |
| 1.   | Turn OFF electrical power to processor.<br><br><b>CAUTION:</b> The processor can be hot from operation. Use caution when removing Weather Cover, Shell, and raising Inner Stack; they are HOT! | <input type="checkbox"/>  |           |
| 2.   | Remove Weather Cover. Look inside stack and burner chamber to check for debris. Remove any debris.   | <input type="checkbox"/>  |           |
| 3.   | Remove padlocks, if any, and remove Shell from processor.  | <input type="checkbox"/>  |           |
| 4.   | Loosen stack bolt and raise Inner Stack. The pilot and igniter/sensor are now exposed. The internals should be checked for foreign material. Remove any foreign material.                      | <input type="checkbox"/>  |           |
| 5.   | Check igniter/sensor for carbon buildup. Replace Pilot Tip assembly if Excessive buildup. See instructions that come with replacement Pilot Tip for Installation details.                      | <input type="checkbox"/>  |           |

|                   |  |
|-------------------|--|
| <p><b>6.</b></p>  | <p>Visually check all processor piping and tubing for leaks (this is checked when conducting TP-201.3 and Exhibit 4 of Executive Orders VR-203 and VR-204). <input type="checkbox"/></p> <p>Check metal tubing and piping for kinks, worn areas, and cracks, or deterioration. Check piping and metal tubing fittings to insure that they are strong and tight sealing. Replace any components that show any wear, cracks, or deterioration.</p> |
| <p><b>7.</b></p>  | <p>Conduct Exhibit 13 of Executive Orders VR-203 and VR-204 “Hirt VCS 100 Process With Indicator Panel Operability Test Procedure” <input type="checkbox"/></p>  |
| <p><b>8.</b></p>  | <p>Check setting of Pilot Needle Valve adjustmet (section 8.8 of Hirt VCS 100 IOM). <input type="checkbox"/></p>   |
| <p><b>9.</b></p>  | <p>Lower Inner Stack and Tighten bolt. Replace Shell, Weather Cover, and padlocks removed for visual inspection. <input type="checkbox"/></p>  |
| <p><b>10.</b></p> | <p>Verify handle on 3-way valve is in down position – Processor to UST Ullage. <input type="checkbox"/></p>  |
| <p><b>11.</b></p> | <p>Turn ON electrical power to processor. <input type="checkbox"/></p>   |

### Table 5: Annual battery check for Veeder-Root wireless components

You can get the battery status from the TLS-350 (with software Version 30A or higher). The battery status is displayed for the wireless sensors from the Smart Sensor Diagnostics (see menu below). The wireless sensors' battery status can also be printed from this screen. The battery status for the wireless sensors is reported as Full, Medium, Low, or Replace.




Figure 24. Device Battery Status in SmartSensor Diagnostic Menu

| VR-203 and VR-204<br>Annual Battery Check for Veeder-Root Wireless Sensors |                 |            |                |        |     |             |
|--|-----------------|------------|----------------|--------|-----|-------------|
|  |                 |            |                |        |     | Date: _____ |
| Vapor Valve  | Pressure Sensor | Flow Meter | Battery Status |        |     |             |
|  |                 |            | Full           | Medium | Low | Replace     |
|  |                 |            |                |        |     |             |
|  |                 |            |                |        |     |             |
|  |                 |            |                |        |     |             |

**Table 6: Annual Inspection Requirements for VST Green Machine Processor:**

| <b>Annual <i>Green Machine</i> Inspections</b>     |  |  |   |                         |                             |
|--|--|--|---|-------------------------|-----------------------------|
| <b>Component</b>                                   | <b>Procedure</b>   | <b>Fail Criteria</b>   | <b>Corrective Action</b>  | <b>Reference Manual</b> | <b>Authorized Personnel</b> |
| Vacuum Pump Drive Coupling - Rubber Insert         | Visually inspect the Drive Coupling between the Vacuum Pump and the Motor for wear | Rubber debris is found on or around the Vacuum Pump base.  | Replace the drive coupling rubber insert                          | IOM-18                  | VST<br>ASC<br>Level D       |
| Vacuum Pump  | Replace pump every 10 years or 15,000 hours  |  |   | IOM-18                  |                             |
| VST <i>Green Machine</i> Annual Compliance Testing | Exhibit 15   | <p><u>Compliance Bag Test:</u> If the value of the NOVA reading is <math>\geq 17\%</math>, the <i>Green Machine</i> is not in compliance.</p> <p><u>Continuous Monitoring Test:</u> If a motor fault is not found then the <i>Green Machine</i> is not in compliance</p> | Refer to the Green Machine Troubleshooting Manual for maintenance | Exhibit 15              |                             |

## PMC Alarm Troubleshooting Summary for VST ECS Membrane Processor

| Displayed Message  | Description   | Light Indicator | Suggested Troubleshooting  |
|--------------------|---|-----------------|--|
| VP EMISSION WARN   | Mass emission exceeded the certified daily threshold.   | Yellow          | <ul style="list-style-type: none"> <li>• Troubleshooting Guide <a href="http://www.vsthose.com/carbs_components.aspx">http://www.vsthose.com/carbs_components.aspx</a></li> <li>• Exhibit 8</li> <li>• Exhibit 9</li> </ul>  |
| VP EMISSION FAIL   | 2 <sup>nd</sup> Consecutive mass emission failure.  | Red             |  |
| PMC SETUP FAIL     | PMC is not configured or missing components.  | Red             | <ul style="list-style-type: none"> <li>• Troubleshooting Guide <a href="http://www.vsthose.com/carbs_components.aspx">http://www.vsthose.com/carbs_components.aspx</a></li> <li>• See ISD Troubleshooting Guide, P/N 577013-819.</li> <li>• Exhibit 8</li> <li>• Exhibit 9</li> </ul>    |
| PMC SENSOR FAULT   | Component used by PMC has failed or reported an error condition. See Troubleshooting section for complete description of sensors and associated conditions that can cause a sensor fault. | Red             | <ul style="list-style-type: none"> <li>• Check for Smart Sensor Device Alarm or Fault.</li> </ul>  |
| VP DUTY CYCLE WARN | Duty cycle exceeds 18 hours per day or 75% of 24 hours.   | Yellow          | <ul style="list-style-type: none"> <li>• Troubleshooting Guide <a href="http://www.vsthose.com/carbs_components.aspx">http://www.vsthose.com/carbs_components.aspx</a></li> <li>• TLS 350 PMC Setup Procedure</li> <li>• Exhibit 10</li> <li>• Exhibit 9</li> <li>• Exhibit 4</li> </ul> |
| VP DUTY CYCLE FAIL | 2 <sup>nd</sup> Consecutive Duty Cycle Failure.   | Red             |  |



## PMC Alarm Troubleshooting Summary for Veeder-Root Vapor Polisher

| Displayed Message | Description   | Light Indicator | Suggested Troubleshooting <sup>1</sup>   |
|-------------------|---|-----------------|--|
| VP EMISSION WARN  | Mass emission exceeded the certified daily threshold.   | Yellow          | Ensure Polisher is in Automatic Mode. Resolve any Vapor Valve Sensor Fault Alarms. |
| VP EMISSION FAIL  | 2 <sup>nd</sup> consecutive mass emission failure.  | Red             |  |
| PMC SETUP FAIL    | PMC is not configured or missing components.  | Red             | Ensure that all required components are installed and operational.                 |
| PMC SENSOR FAULT  | Component used by PMC has failed or reported an error condition. See Troubleshooting section for complete description of sensors and associated conditions that can cause a sensor fault. | Red             | Check for Smart Sensor Device Alarm or Fault.                                      |

<sup>1</sup>Refer to Troubleshooting Section of IOM 15 and ISD/PMC Troubleshooting Guide 577013-819

**Wireless Related Sensor Warning for Veeder-Root Vapor Polisher (If Wireless Vapor Polisher or Vapor Pressure Sensor is Installed)**

| Displayed Message | Description   | Light Indicator | Suggested Troubleshooting   |
|-------------------|---|-----------------|-----------------------------|
| Battery Warning   | Vapor Valve transmitter reports battery status as "Replace" for 24 hours. | Yellow          | Remove and replace battery. |

## Alarm Troubleshooting Summary For Hirt VCS 100 Processor

| VCS 100 Indicator Panel | Description   | Light Indicator | Recommended Troubleshooting  |
|-------------------------|---|-----------------|--|
| MALFUNCTION Light       | UST ullage pressure is positive for at least 1 continuous hour. | Red             | <p>GDF Owner/Operator Responsibilities:</p> <ul style="list-style-type: none"> <li>• “Weekly Inspections” of Hanging Hardware as specified in section 2 of Installation, Operation, and Maintenance Manual.</li> <li>• “Drive-Offs and Other Customer Abuse” as specified in section 5 of Installation, Operation, and Maintenance Manual.</li> <li>• Exhibit 7 of Executive Order VR-203</li> <li>• Record findings in GDF Owner/Operator Maintenance Log.</li> </ul> <p>Certified Contractor Responsibilities:</p> <ul style="list-style-type: none"> <li>• Follow VCS 100 Troubleshooting Guide (Contact Hirt by either Phone: (562) 692-6970 or by email: <a href="mailto:HirtVCS@aol.com">HirtVCS@aol.com</a> to get Guide)</li> <li>• TP-201.3 and Exhibit 4 of Executive Order VR-203</li> <li>• Exhibit 7 of Executive Order VR-203</li> <li>• Exhibit 13 of Executive Order VR-203</li> <li>• Record findings in GDF Owner/Operator Maintenance Log.</li> </ul> |

## Alarm Troubleshooting Summary for Facilities Equipped with VST Green Machine Processor

| Displayed Message | Description   | Light Indicator | Suggested Troubleshooting   |
|-------------------|---|-----------------|---|
| VP EMISSION WARN  | Mass emission exceeded the certified daily threshold.   | Yellow          | <ul style="list-style-type: none"> <li>• Troubleshooting Manual<br/><a href="http://www.vsthose.com">www.vsthose.com</a>.</li> </ul>                      |
| VP EMISSION FAIL  | 2 <sup>nd</sup> Consecutive mass emission failure.  | Red             | <ul style="list-style-type: none"> <li>• Exhibit 9</li> </ul>   |
| PMC SETUP FAIL    | PMC is not configured or missing components.  | Red             | <ul style="list-style-type: none"> <li>• See ISD Troubleshooting Manual, P/N 577013-819</li> </ul>  |
| PMC SENSOR FAULT  | Component used by PMC has failed or reported an error condition. See Troubleshooting section for complete description of sensors and associated conditions that can cause a sensor fault. | Red             | <ul style="list-style-type: none"> <li>• Troubleshooting Manual<br/><a href="http://www.vsthose.com">www.vsthose.com</a>.</li> <li>• Exhibit 9</li> </ul> |

## Drive-Offs and Other Customer Abuse

---

If the hanging hardware components are involved in a drive-off or if they incur some customer abuse, and they are not replaced as new, each individual component of the hanging hardware **must be visually inspected and functionally tested** before the components can return to dispensing fuel.

- ▶ A visual assessment and functional tests are outlined in the following pages.

**ANY COMPONENT THAT DOES NOT PASS A VISUAL INSPECTION OR FUNCTIONAL TEST MUST BE REPLACED.**

**IF THE VST BREAKAWAY WITH THE BLACK RETENTION BAND (AND UL LABEL STATING NON-REATTACHABLE) OR THE EMCO BREAKAWAY IS INVOLVED IN A DRIVEOFF, IT MUST BE REPLACED. THESE BREAKAWAYS ARE NON-RECONNECTABLE.**

**IF THE VST BREAKAWAY WITH THE GRAY RETENTION BAND (AND UL LABEL THAT STATES REATTACHABLE) OR THE OPW BREAKAWAY IS INVOLVED IN A DRIVEOFF, IT MAY BE RECONNECTED. THESE BREAKAWAYS ARE RECONNECTABLE.**



Before beginning work, barricade the work area to block customer use.

## 1 Drive Offs & Other Customer Abuse: Perform a Visual Assessment

Visually inspect the hanging hardware system as follows to determine the extent of the damage:

| Action  | Test Procedure  | Corrective Action                            | Reference Material | Authorized Personnel  |
|---|---|--|--------------------|---|
| Perform a thorough visual examination of the exterior of the whip hose and the curb hose for any obvious imperfections. | Obvious imperfections include, but are not limited to:<br>Damage to the swivels<br>Damage to the couplings<br>Kinks / flat spots<br>Tears to the outer hose   | Replace with new hose(s).                    | IOM-8              | <b>Hose replacement:</b><br>GDF Owner/Operator or<br>VST ASC Levels A, B, C, or D<br>or<br>EMCO Level A for ContiTech<br>Hose |
|   | If there are no imperfections to the whip and curb hose, those hoses may be reused.   | Reassemble hose(s).                          | IOM-8              | GDF Owner/Operator or<br>VST ASC Levels A, B, C, or D<br>or<br>EMCO Level A for ContiTech<br>Hose                             |
| Perform a thorough visual inspection of the nozzle for any obvious imperfections.                                       | Obvious imperfections include, but are not limited to:<br><br><u>VST Nozzle:</u> Damaged spout (broken, bent);<br>Damage to the face seal, collection sleeve / interlock rod assembly; Broken face seal; Torn collection sleeve; Bent interlock rod; Nozzle alignment marks; Damage to the lever and lever guard. | Replace damaged components where applicable. | IOM-7              | <b>Nozzle repair:</b><br>VST ASC Levels A, B, C, or D<br>or<br>EMCO Level A   |
|   | <u>EMCO Nozzle:</u> Damage spout, broken or bent;<br>Damage to the insertion interlock rod; Torn boot face or bellows; Damage to the lever, hold open latch and lever guard; Missing band clamp, serial plate and security rivet.   | Replace with new nozzle.                     | IOM-6              | <b>Nozzle replacement:</b><br>GDF Owner/Operator or<br>VST ASC Levels A, B, C, or D<br>or<br>EMCO Level A                     |

|  |   |                             |       |   |
|--|---|-----------------------------|-------|---|
| Perform a thorough visual inspection of the breakaway for any obvious imperfections.   | <u>VST (Non-Reattachable ) / EMCO Breakaway</u><br>Non-re-connectable. Breakaway separated. | Replace with new breakaway  | IOM-9 | <b>Breakaway replacement:</b><br>GDF Owner/Operator or<br>VST ASC Levels A, B, C, or D<br>or<br>EMCO Level A          |
|  | <u>VST (Reattachable) / OPW Breakaway</u><br>Re-connectable. Breakaway separated,           | Replace or repair breakaway | IOM-9 | <b>Breakaway replacement / repair:</b><br>GDF Owner/Operator or<br>VST ASC Levels A, B, C, or D<br>or<br>EMCO Level A |
| <b>If no imperfection or damage is visibly evident, proceed to functional testing.</b> |   |                             |       |   |

## Function Testing Description

Perform the following functional tests prior to re-using a hose, breakaway or a nozzle following a drive-off:

| Test                                       | Test Procedure   | Corrective Action   | Authorized Personnel   |
|--|--|---|--|
| Leak Check                                 | <p>Verify that there are no liquid leaks in all components.</p> <p>Dispense fuel and check each connection between the components.</p> <p>A visual inspection of the nozzle can determine any obvious liquid leaks.</p>  | <p>Any component that does not pass the functional test must be replaced.</p> <p>Go to IOM 6, 8, and 9</p>  | <p>GDF Owner/Operator or VST ASC Levels A, B, C, or D or EMCO Level A</p>  |
| Meter Creep                                | <p>Checking for meter creep will verify the integrity of the connections.</p> <p>Dispense 1/10 to 2/10 of a gallon of fuel into an approved container then release lever and move components around and/or gently shake the hose and verify if the displace amount on the dispenser changes.</p> | <p>Any component that does not pass the functional test must be replaced.</p> <p>Go to IOMs 6, 8, and 9</p> | <p>GDF Owner/Operator or VST ASC Levels A, B, C, or D or EMCO Level A</p>  |
| Automatic Shut-Off and Insertion Interlock | <p>The insertion interlock mechanism shall not allow dispensing when the bellows is uncompressed as determined by direct observation or GDF-09 (See Vapor Recovery Defects list).</p>  | <p>Repair or replace the nozzle</p> <p>Go to IOM-6 or IOM-7</p>   | <p><b>Nozzle replacement</b><br/>GDF Owner/Operator or VST ASC Levels A, B, C, or D or EMCO Level A</p> <p><b>Nozzle repair</b><br/>VST ASC Levels A, B, C, or D<br/>or EMCO Level A</p> |
| Resistance                                 | IOM-6  | <p>Any component that does not pass the functional test must be replaced.</p> <p>Go to IOM 6, 8, and 9</p>  | <p>GDF Owner/Operator or VST ASC Levels A, B, C, or D or EMCO Level A</p>  |



# VST Installation Procedure for Phase II Coaxial EVR Balance Dripless Nozzles

Part Number Series: VST-EVR-NBcc, VST-EVR-NBccR  
cc = Scuff Guard Color Code and R = rebuilt



**Vapor Systems Technologies, Inc.**

650 Pleasant Valley Drive  
Springboro, Ohio 45066 (USA)

Toll Free: 1-888-878-4673

Phone: 937-704-9333

Fax: 937-704-9443

www.vsthose.com

## For VST Model #'s:

**VST-EVR-NB, VST-EVR-NB (Rebuilt),**

**VST-EVR-NB (G2), and VST-EVR-NB (G2 Rebuilt)**

## GENERAL INFORMATION

If hanging hardware components are involved in a drive-off or incur other customer abuse, each individual component must be functionally tested prior to customer dispensing activities.

## INSTALLATION PREPARATION

This procedure must be followed to insure leak-proof installation and operation of these nozzles.

1. Turn off and tag the power to the dispenser. Dispenser must be de-energized prior to service to avoid personal injury.
2. Barricade work area to block vehicle access to the dispenser.
3. Close the dispenser shear valve prior to removing hanging hardware (hoses, safety breakaways, and nozzles).
4. Drain liquid product from the hanging hardware set into an approved container prior to replacing any hanging hardware components.
5. Remove hanging hardware from the dispenser prior to making replacement component assembly connections. VST recommends connecting the whip hose to the dispenser as the last connection during the hanging hardware assembly.


## INSTALLATION AND FUNCTION TESTS

**STOP!** If this is a new facility installation, the fueling point must be flushed into an approved container before installing the nozzle. Using this nozzle to flush the system could result in foreign material becoming lodged in the nozzle's valve and cause it not to shut off.

1. Initial inspection and function tests:
  - a. Carefully unpack nozzle from shipping carton.
  - b. Inspect nozzle exterior for any damage.
  - c. Inspect threads, lever, lever lock, spout, collection sleeve, band clamps, and face seal to determine that they are present and undamaged.
  - d. Verify interlock rod alignment. Check interlock for engagement and release. Proper function of interlock rod requires the nozzle collection sleeve to be compressed  $\frac{1}{4}$ " to  $\frac{1}{2}$ " and the lever to be engaged into the dispensing position. Nozzle will not function without interlock rod properly engaged.
  - e. Inspect spout vent hole. It should be clear of debris.

**Figure 1.**

EVR Hanging Hardware Assembly



# VST Installation Procedure for Phase II Coaxial EVR Balance Dripless Nozzles

Part Number Series: VST-EVR-NBcc, VST-EVR-NBccR

cc = Scuff Guard Color Code and R = rebuilt

2. Lightly lubricate ALL O-Rings on mating connections with petroleum jelly or other suitable lubricant. DO NOT USE pipe dope or thread sealant.
3. Attach nozzle onto mating hose connection and tighten by hand.
4. Tighten the nozzle connection to 50 ft-lbs of torque. DO NOT OVER TIGHTEN. Use a torque wrench with an open-end attachment to fit the hose couplings and an open-end wrench to properly tighten coupling connections. DO NOT USE channellocks or pliers to tighten hose joints. Proper ft./lb. torque may not be achieved with these tools.
5. Purge air from the system by pumping one-tenth (1/10) to two-tenths (2/10) of a gallon of fuel into an approved container. Inspect the nozzle connection for liquid leaks and make proper adjustments at hose connection if necessary.
6. Check the nozzle shut-off action by dispensing fuel into an approved container at least three times to assure the proper automatic operation of the interlock rod. The fuel flow-rate must be greater than 3 gpm for the automatic shut-off mechanism to operate.

To test, operate the nozzle and submerge the spout tip in fuel until the fuel level covers the vent hole. The main valve of the nozzle automatically shuts off when the liquid covers the vent hole at the end of the spout. The nozzle is not designed to operate on gravity flow. The hold-open latch will disengage automatically when liquid covers the vent hole in the spout. Verify that the fuel flow stops when the nozzle collection sleeve is decompressed (e.g. interlock rod is disengaged). To test that the fuel flow stops, dispense some fuel into an approved container. Slowly remove the nozzle from the container while dispensing fuel. Fuel flow should stop when the nozzle collection sleeve is fully decompressed.

7. Measure the resistance between the dispenser outlet casting and the tip of the nozzle spout. Use an electronic multimeter set on the high range of the ohmmeter function. Resistance should not indicate more than 70,000 ohms per foot of hose. Example: The measured resistance for a 12-foot hose must not exceed 840,000 ohms (840 kilohms).

## MAINTENANCE

Inspect nozzles daily for damaged component parts: vapor collection sleeve, face seal, interlock rod, spout, lever, lever lock, etc. Damaged components must be replaced. Vent hole at the end of

the spout should be clear of debris. The nozzle will not operate properly if vent hole becomes clogged. The nozzle will not function properly without the interlock rod properly engaged. Keep the hose connections tight.

Should there be a drive-off or incidence of customer abuse, follow the initial inspection instructions found in the INSTALLATION section. The nozzle should be replaced when damaged. The nozzle is designed and constructed to give lasting service if properly handled and maintained. If for any reason it should need attention, contact your VST distributor for proper disposition.

## NOTE

Due to abuse, misuse, changing gasoline formulas, variation in maintenance practices, environmental conditions, and/or conditions beyond the manufacturer's control, dispensing equipment may need replacement before five (5) years. Inspections and proper maintenance procedures should be followed by the station manager to determine if replacement is required before five (5) years.

## WARNING

Unauthorized rebuilding or modifying of nozzles voids ALL approvals and warranties.

VST products must be used in compliance with applicable federal, state, and local laws and regulations.

If local regulatory codes prohibit use of the nozzle's hold-open clip, it must be removed prior to nozzle installation. Remove the nozzle to a safe work area.

Place the nozzle on a flat surface.

Locate the alloy rivet securing the hold-open clip and spring in the nozzle's handle. Use a drill with a 3/16" (5mm) drill bit, drill out the rivet securing the hold-open clip, and discard the clip, spring, and all other rivet debris.



## Vapor Systems Technologies, Inc.

650 Pleasant Valley Drive  
Springboro, Ohio 45066 (USA)

Toll Free: 1-888-878-4673

Phone: 937-704-9333

Fax: 937-704-9443


www.vsthose.com

**EMCO**®  
WHEATON RETAIL

**A4005EVR**  
Balance Vapor Recovery Nozzle  
RA4005EVR = Rebuilt  
XXX = Scuff Guard Color

For use with the Vapor  
Systems Technologies VST  
Coaxial Curb and Whip Hoses

**Permanent ID  
Information:**



**INSTALLATION INSTRUCTIONS**

**Service Tools Required:**

- 1 7/8" Crows Foot
- Torque Wrench w/ 50 ft-lbs Setting
- Pipe Wrench w/ Flat Jaws
- Gasoline Approved Container
- Petroleum Jelly or Other Suitable Lubricant


**CAUTION:**

1. Always barricade work area to keep pedestrians and vehicles from accessing the dispenser.
2. Always use a gasoline approved container or test can when performing any type of preventive maintenance.
3. Before attempting to install, remove or service the A4005EVR nozzle, turn off and tag out power to the corresponding dispenser.
4. Before attempting to install, remove or service the A4005EVR nozzle, close the emergency impact valves located inside the base of the dispenser. Relieve the line pressure and standing fuel through the nozzle spout into a gasoline approved container by compressing the bellows and squeezing the lever.

**IMPORTANT:** Failure to perform cautions 3 and 4 may result in a hazardous gasoline spill, damage to equipment, personal injury and/or death.

1

### Pre-Inspection:



1. Carefully unpack and remove the A4005EVR nozzle from the shipping container. Evaluate the following components for damage: scuff guard, lever guard, lever, hold open latch, serial number plate, security rivet, bellows, band clamps, boot face and spout.
2. Verify the automatic shutoff located at the end of the spout. The vent hole must be free and clear of all debris.
3. Verify the fuel path o-rings located at the hose end of the A4005EVR nozzle. Both o-rings must be properly secured inside the factory machined grooves.

### Pre-Functional Test:



4. Functional test the insertion interlock of the A4005EVR nozzle by compressing the bellows and then squeezing the lever. The A4005EVR nozzle will not function unless the insertion interlock is properly engaged.

### Pre-Installation:



5. Lightly lubricate both fuel path o-rings using petroleum jelly or other suitable lubricant.



6. Before attempting to install the A4005EVR nozzle onto the curb hose, verify the vapor path o-ring is properly secured onto the connector, and in good working condition. Lightly lubricate the o-ring using petroleum jelly or other suitable lubricant.

**IMPORTANT:** Do not use pipe thread sealant compound or Teflon tape when installing the A4005EVR nozzle. Failure to comply will void warranty.

**Installation:**

**IMPORTANT:** If this is a new facility installation, the fueling point must be flushed into a gasoline approved container before installing the A4005EVR nozzle. Failure to perform this procedure could result in foreign material becoming lodged inside the nozzle's fuel path causing it not to shut off or a reduction in fuel flow.



7. Attach the A4005EVR nozzle onto the curb hose connector. Tighten by hand to avoid cross threading. Take caution to avoid pinching the vapor path o-ring.



8. Using a 1 7/8" crows foot and torque wrench tighten the curb hose connector to 50 ft-lbs of torque.

**Post Functional Tests:**

9. Carefully purge the trapped air from the fueling point. Begin dispensing by compressing the bellows and then squeezing the lever. Dispense one gallon of fuel into a gasoline approved container.
10. Functional test the automatic shutoff of the A4005EVR nozzle. Begin dispensing by compressing the bellows and then squeezing the lever. Place the hold-open latch in "high" clip position to secure the lever. Dispense one gallon of fuel into a gasoline approved container. At the same time, lower the spout tip into the standing fuel until the vent hole is completely submersed. The main valve of the A4005EVR nozzle will automatically close causing fuel flow to stop.

**IMPORTANT: Perform step 10 a minimum of three times to assure the insertion interlock, hold open latch and the automatic shutoff of the A4005EVR nozzle are operating properly.**

**According to UL requirement 842, the fuel flow rate must be greater than 3 gallons per minute for the automatic shutoff to operate properly. A common cause of low flow rates are dirty or clogged dispenser filters.**

**Post Inspection:**

11. Before placing the A4005EVR nozzle onto the dispenser cradle, inspect all hanging hardware connections for potential fuel leaks. Make proper adjustments if necessary.

**PREVENTIVE MAINTENANCE**

1. Weekly inspect the A4005EVR nozzle, evaluate the following components for damage: scuff guard, lever guard, lever, hold open latch, serial number plate, security rivet, bellows, band clamps, boot face and spout. Damage components must be replaced with factory authorized service kits.

| <u>Part Number</u> | <u>Description</u>      |
|--------------------|-------------------------|
| 492775EVR          | Bellows & Boot Face Kit |
| 492776EVR          | Boot Face Kit           |
| 492834EVR          | Spout Kit               |
| 494150EVR          | Latch Kit               |
| 494748EVR          | Fuel Path O-ring Kit    |
| 494750EVR          | Bellows Band Clamps Kit |
| A0557EVR-XXX       | Scuff Guard Kit         |

**IMPORTANT: Do not remove the serial number plate and security rivet from the A4005EVR nozzle. Failure to comply will void warranty.**

2. Weekly inspect the automatic shutoff located at the end of the spout. The vent hole must be free and clear of all debris.
3. Weekly inspect all hanging hardware connections for potential fuel leaks.

**IMPORTANT: Should a drive-off or incidence of customer abuse occur, follow the initial inspection and function instructions found in the installation section.**

## **PERFORMANCE STANDARDS & SPECIFICATIONS**

This component was factory tested to, and met the following specifications:

1. Meets ARB Material Compatibility with Fuel Blends as per Section 3.8 of CP-201.
2. Meets ARB Capable of Refueling Any Vehicle Standards as per Section 4.7.1 of CP-201.
3. Meets ARB Spout Dimension Standards as per Section 4.7.3 of CP-201.
4. Meets ARB Nozzle and Dispenser Compatibility Standards as per Section 4.9 of CP-201.
5. Meets ARB Balance Nozzle Criteria Standards as per Section 5.1 of CP-201.
6. TP-201.2B – Complies with the maximum allowable leak rate of 0.07 CFH @ 2.00 inches of water column pressure.
7. TP-201.2C – Complies with the maximum allowable spillage factor of 0.24 pounds/ 1,000 gallons.
8. TP-201.2D – Complies with the maximum allowable average of 3 post fuel drips.
9. TP-201.2E – Complies with the maximum allowable average of 100mL liquid retention and 1mL liquid spit-back.
10. TP-201.2J – Complies with the maximum allowable component pressure drop of 0.08 inches of water column @ 60 CFH.

**IMPORTANT: Leave these installation instructions with the station owner and/or operator.**

# VST Installation Procedure for Phase II Coaxial EVR Balance Nozzle Repair Kits

Part Number Series: VST-FEK-300 (Front End Kit Included VCK and NSA)

VST-VCK-300 (Vapor Collection Kit)

VST-NSA-300 (Nozzle Spout Assembly)



**Vapor Systems Technologies, Inc.**

650 Pleasant Valley Drive  
Springboro, Ohio 45066 (USA)

Toll Free: 1-888-878-4673

Phone: 937-704-9333

Fax: 937-704-9443

www.vsthose.com

## Use ONLY on VST Nozzles:

**Model #: VST-EVR-NB (G2) and VST-EVR-NB (G2 Rebuilt)**

### TOOLS

- Torque Wrench
- VST-SRT-200 Torque Wrench Attachment
- Approved Fuel Container
- VST-BPT-100 Nozzle Band Clamp Pincers
- Wide Mouth Funnel
- Petroleum Jelly (or suitable lubricant)

### GENERAL INFORMATION

If hanging hardware components are involved in a drive-off or incur other customer abuse, each individual component must be functionally tested prior to customer dispensing activities.

### INSTALLATION PREPARATION

This procedure must be followed to ensure leak-proof installation and operation of these nozzles.

1. Turn off and tag the power to the dispenser. Dispenser must be de-energized prior to service to avoid personal injury.
2. Barricade work area to block vehicle access to the dispenser.
3. Close the dispenser shear valve prior to removing hanging hardware (hoses, safety breakaways, and nozzles).
4. Visually inspect and assess the extent of the damage to all hanging hardware components. If the spout is loose at all, replace the entire nozzle spout assembly with VST-NSA-300.
5. Drain liquid product from the hanging hardware set into an approved container prior to replacing any hanging hardware assembly.
6. Remove hanging hardware from the dispenser prior to making replacement component assembly connections. VST recommends connecting the whip hose to the dispenser as the last connection during the hanging hardware assembly.
7. To drain nozzle, engage nozzle interlock:
  - a. Push in face seal on nozzle boot assembly
  - b. Hold the backend of the nozzle over an approved container
  - c. Pull nozzle lever to fully drain the nozzle

### VAPOR COLLECTION KIT (VST-VCK-300) REMOVAL


(See Figure 1)

1. Remove large band clamp from the Vapor Collection Assembly with nozzle band clamp pincers (VST-BPT-100).
2. Pull the Vapor Collection Assembly (boot) off of the clamping groove of the nozzle body.

3. Pull Vapor Collection Assembly off of the spout by slightly twisting to go over the spout latch ring.
4. Properly discard the removed components.

**Figure 1**

Vapor Collection Assembly



### VAPOR COLLECTION KIT (VST-VCK-300) REPLACEMENT

1. Place the large band clamp on the collection sleeve. (See Figure 1)
2. Verify the interlock rod is properly inserted into the hole of the interlock sleeve located around the spout prior to pushing the VCK into place. The rod should be visible through the side hole of the sleeve. (See Figure 2)
3. Slide the VST-VCK-300 over the spout.
4. Align and center all alignment marks on top of the vapor collection kit and nozzle scuff. (See Figure 1)
5. Engage interlock a few times to check for correct alignment and functionality. (See Functional Test 3)
6. Tighten collection band clamp until collection sleeve will not rotate. (See Figure 1)



# VST Installation Procedure for Phase II Coaxial EVR Balance Nozzle Repair Kits


Part Number Series: VST-FEK-300 (Front End Kit Included VCK and NSA)

VST-VCK-300 (Vapor Collection Kit)

VST-NSA-300 (Nozzle Spout Assembly)


**Figure 2**

Nozzle Spout Assembly



**Figure 3**

Interlock Rod Removal




## NOZZLE SPOUT ASSEMBLY (VST-NSA-300) REMOVAL

(See Figures 3-4)

1. Remove Vapor Collection Assembly.
2. Hold the interlock rod in place to allow the rod to be disengaged from the hole of the sleeve that is located around the spout nut. (See Figure 3)
3. Slide and rotate the sleeve away from the spout nut and remove the interlock rod. (See Figure 3)
4. Loosen spout nut with the VST-SRT-200 Spout Nut Torque Wrench Attachment. (See Figure 4) **NOTE:** Do not use pipe wrench or locking-type pliers.
5. Once threads are completely disengaged, pull the spout straight out.
6. Properly discard the removed components.

**Figure 4**

Torque Wrench Attachment



## NOZZLE SPOUT ASSEMBLY (VST-NSA-300) REPLACEMENT

(See Figures 5-6)

1. Fuel chamber should remain in the nozzle casting with the vacuum sensing tube hole oriented at the top.
2. If the fuel chamber is pulled out of the nozzle casting:
  - a. Check O-ring for damage.
  - b. Replace O-ring if damaged (check for cuts, nicks, etc.).
  - c. Lubricate O-ring prior to re-assembly.
3. Insert fuel chamber into nozzle casting:
  - a. Poppet stem with spring goes through poppet hole in the fuel chamber (center hole).
  - b. Push fuel chamber until it is flush with casting.
  - c. Vacuum sensing tube in the fuel chamber should be oriented at the top.

# VST Installation Procedure for Phase II Coaxial EVR Balance Nozzle Repair Kits

Part Number Series: VST-FEK-300 (Front End Kit Included VCK and NSA)

VST-VCK-300 (Vapor Collection Kit)

VST-NSA-300 (Nozzle Spout Assembly)


4. Lightly lubricate ALL O-rings on the spout assembly. **NOTE:** Do not block vacuum sensing-tube hole with lubricant.
5. Align vacuum sensing tube with mating hole in the fuel chamber. (See Figure 5)
6. Align the anti-rotation bump on the spout with the casting notch. Be careful not to damage the spout O-ring. (See Figure 5)
7. Firmly insert spout assembly into the nozzle casting.
8. Apply a dab of Loctite®271 to the male thread of the nozzle casting. Be careful not to apply the Loctite® so that it would enter into the casting notch. (See Figure 6)
9. Thread spout nut onto the nozzle casting and tighten firmly. Torque to 34 foot-pounds. Use VST-SRT-200 Spout Nut Torque Wrench Attachment in order to apply the appropriate torque. Spout should be tight and not able to rotate. Do not over-tighten the spout nut.
10. After tightening the spout nut, place the interlock rod into the hole of the nozzle casting. Move the sleeve in place so the interlock rod is inserted into the recessed hole on the end of the sleeve. The interlock rod may be compressed into the nozzle to ease the insertion. The interlock rod should be visible through the side hole of the sleeve. (See Figure 2)
11. Re-install the Vapor Collection Kit Assembly per the Vapor Collection Kit Replacement instructions.

## FUNCTIONAL TESTS


1. Follow the VST Installation Procedure for each hanging hardware component. (Executive Order Procedures: Section 6, 8 and 9).
2. Purge air from the system by pumping one-tenth (1/10) to two-tenths (2/10) of a gallon of fuel into an approved container. Inspect the nozzle connection for liquid leaks and make proper adjustments at the hose connection if necessary.
3. Check the nozzle shut-off action by dispensing fuel into an approved container at least three times to assure the proper automatic operation of the interlock rod. The fuel flow-rate must be greater than 3 gpm for the automatic shut-off mechanism to operate.

To test, operate the nozzle and submerge the spout tip in fuel until the fuel level covers the vent hole. The main valve of the nozzle automatically shuts off when the liquid covers the

**Figure 5**  
Spout Assembly



**Figure 6**  
Application of Loctite® 271



vent hole at the end of the spout. The nozzle is not designed to operate on gravity flow. The hold-open latch will disengage automatically when liquid covers the vent hole in the spout. Verify that the fuel flow stops when the nozzle collection sleeve is decompressed (eg. Interlock rod is disengaged). To test that the fuel flow stops, dispense some fuel into an approved container. Slowly remove the nozzle from the container while dispensing fuel. Fuel flow should stop when the nozzle collection sleeve is fully decompressed.

4. Measure the resistance between the dispenser outlet casting and the tip of the nozzle spout. Use an electronic multimeter set on the high range of the ohmmeter function. Resistance should not indicate more than 70,000 ohms per foot of the hose. **Example:** The measured resistance of a 12 foot hose must not exceed 840,000 ohms (840 kilohms).

# VST Installation Procedure for Phase II Coaxial EVR Balance Nozzle Repair Kits

Part Number Series: VST-FEK-300 (Front End Kit Included VCK and NSA)

VST-VCK-300 (Vapor Collection Kit)

VST-NSA-300 (Nozzle Spout Assembly)



**Vapor Systems Technologies, Inc.**

650 Pleasant Valley Drive  
Springboro, Ohio 45066 (USA)

Toll Free: 1-888-878-4673

Phone: 937-704-9333

Fax: 937-704-9443

[www.vsthose.com](http://www.vsthose.com)

---

## **MAINTENANCE**

Inspect nozzles daily for damaged components parts: vapor collection sleeve, face seal, interlock rod, spout, lever, lever lock, etc. Damaged components must be replaced. Vent hole at the end of the spout should be clear of debris. The nozzle will not operate properly if vent hole becomes clogged. The nozzle will not function properly without the interlock rod properly engaged. Keep the hose connections tight.

Should there be a drive-off or incidence of customer abuse, follow the initial inspection instructions found in the VST Installation Procedure Section 6. The nozzle should be replaced when damaged. The nozzle is designed and constructed to give lasting service if properly handled and maintained. If for any reason it should need attention, contact your VST distributor for proper disposition.

## **NOTE**

Due to the abuse, misuse, changing gasoline formulas, variation in maintenance practices, environmental conditions, and/or conditions beyond the manufacturer's control, dispensing equipment may need replacement before five (5) years. Inspections and proper maintenance procedures should be followed by the station manager to determine if replacement is required before five (5) years.

## **WARNING**

Unauthorized rebuilding or modifying of nozzles voids ALL approvals and warranties. VST products must be used in compliance with applicable federal, state, and local laws and regulations. If local regulatory codes prohibit use of the nozzle's hold open clip, it must be removed prior to nozzle installation. Remove the nozzle to a safe work area.

Place the nozzle on a flat surface. Locate the alloy rivet securing the hold-open clip, and spring in the nozzle's handle. Use a drill with a 3/16" (5 mm) drill bit, drill out the rivet securing the hold-open clip, and discard the clip, spring, and all other rivet debris.

# VST Installation Procedure for Use of VST-FEK-300 Front End Kits On Pre-G2 Phase II Coaxial EVR Balance Nozzles

Part Number Series:

VST-FEK-300 (Front End Kit includes VCK and NSA)



**Vapor Systems Technologies, Inc.**

650 Pleasant Valley Drive  
Springboro, Ohio 45066 (USA)

Toll Free: 1-888-878-4673

Phone: 937-704-9333

Fax: 937-704-9443

www.vsthose.com

**Use ONLY on VST Nozzles when replacing with the above Kits on Model # VST-EVR-NB and VST-EVR-NB (Rebuilt)**

## TOOLS

- Torque Wrench
- Approved Fuel Container
- Wide Mouth Funnel
- Petroleum Jelly (or suitable lubricant)
- VST-BPT-100 Nozzle Band Clamp Pincers
- VST-SRT-200 Torque Wrench Attachment

## GENERAL INFORMATION

If hanging hardware components are involved in a drive-off or incur other customer abuse, each individual component must be functionally tested prior to customer dispensing activities.

## INSTALLATION PREPARATION

This procedure must be followed to ensure leak-proof installation and operation of these nozzles.

1. Turn off and tag the power to the dispenser. Dispenser must be de-energized prior to service to avoid personal injury.
2. Barricade work area to block vehicle access to the dispenser.
3. Close the dispenser shear valve prior to removing hanging hardware (hoses, safety breakaways, and nozzles).
4. Visually inspect and assess the extent of the damage to all hanging hardware components. If the spout is loose at all, replace the entire Front End Kit Assembly with VST-FEK-300.
5. Drain liquid product from the hanging hardware set into an approved container prior to replacing any hanging hardware assembly.
6. Remove hanging hardware from the dispenser prior to making replacement component assembly connections. VST recommends connecting the whip hose to the dispenser as the last connection during the hanging hardware assembly.
7. To drain nozzle, engage nozzle interlock:
  - a. Push in face seal on nozzle boot assembly
  - b. Hold the backend of the nozzle over an approved container
  - c. Pull nozzle lever to fully drain the nozzle

## VERIFY NOZZLE TYPE

Check nozzle name plate against Figure 1. The type on the nameplate should be in Black, without a "G2". If the type is Blue with "G2" then go to the G2 Nozzle Repair Kit Installation Procedures. If Black with no "G2", then proceed to the next step.

**Figure 1**

Nozzle Nameplates




## VAPOR COLLECTION KIT (VST-VCK-100) REMOVAL

(See Figure 2)

1. Remove large band clamp from the Vapor Collection Assembly with nozzle band clamp pincers (VST-BPT-100).
2. Pull the Vapor Collection Assembly (boot) off of the clamping groove of the nozzle body.
3. Pull Vapor Collection Assembly off of the spout by slightly twisting to go over the spout latch ring.
4. Properly discard the removed components.

**Figure 2**

Vapor Collection Assembly




# VST Installation Procedure for Use of VST-FEK-300 Front End Kits On Pre-G2 Phase II Coaxial EVR Balance Nozzles

Part Number Series:

VST-FEK-300 (Front End Kit includes VCK and NSA)


**Figure 3**

Compare Nozzle Spout Assembly - Top Pre-G2; Bottom G2



**Figure 4**

Spout Assembly



## NOZZLE SPOUT ASSEMBLY REMOVAL

1. Check nozzle spout assembly to verify that this is a Pre-G2 nozzle spout assembly. Compare spout assembly with the top picture (Pre-G2 assembly), the spout should only have a latch ring on the spout (see Figure 3). If there are no other components, then continue to step 2 of these instructions. If any other components are on the spout assembly, this is a G2 spout assembly. Proceed to the instructions on how to replace a G2 Front End Kit (VST-FEK-300).
2. Loosen spout nut with the VST-SRT-200 Spout Nut Torque Wrench Attachment (see Figure 6). **NOTE:** Do not use pipe wrench or locking-type pliers.
3. Once threads are completely disengaged, pull the spout straight out.
4. Properly discard the removed components.

## NOZZLE SPOUT ASSEMBLY (VST-NSA-300) REPLACEMENT

(See Figures 4-8)

1. Fuel chamber should remain in the nozzle casting with the vacuum-sensing tube hole oriented at the top.
2. If the fuel chamber is pulled out of the nozzle casting:
  - a. Check O-ring for damage.
  - b. Replace O-ring if damaged (check for cuts, nicks, etc.).
  - c. Lubricate O-ring prior to re-assembly.

3. Insert fuel chamber into nozzle casting:
  - a. Poppet stem with spring goes through poppet hole in the fuel chamber (center hole).
  - b. Push fuel chamber until it is flush with casting.
  - c. Vacuum-sensing tube in the fuel chamber should be oriented at the top.
4. Lightly lubricate **ALL** O-rings on the spout assembly. **NOTE:** Do not block vacuum-sensing-tube hole with lubricant.
5. Align vacuum-sensing tube with mating hole in the fuel chamber. (See Figure 4).
6. Align the anti-rotation bump on the spout with the casting notch. Be careful not to damage the spout O-ring. (See Figure 4).
7. Firmly insert spout assembly into the nozzle casting.
8. Apply a dab of Loctite® 271 to the male thread of the nozzle casting. Be careful not to apply the Loctite® so that it would enter into the casting notch. (See Figure 5).
9. Thread spout nut onto the nozzle casting and tighten firmly. Torque to 34 foot-pounds. Use VST-SRT-200 Spout Nut Torque Wrench Attachment in order to apply the appropriate torque. Spout should be tight and not able to rotate. Do not over-tighten the spout nut.
10. After tightening the spout nut, place the interlock rod into the hole of the nozzle casting. Move the sleeve in place so the


# VST Installation Procedure for Use of VST-FEK-300 Front End Kits On Pre-G2 Phase II Coaxial EVR Balance Nozzles

Part Number Series:

VST-FEK-300 (Front End Kit includes VCK and NSA)

**Figure 5**

Application of Loctite®



interlock rod is inserted into the recessed hole on the end of the sleeve. The interlock rod may be compressed into the nozzle to ease the insertion. The interlock rod should be visible through the side hole of the sleeve. (See Figures 7 and 8).

11. Re-install the Vapor Collection Kit Assembly per the Vapor Collection Kit Replacement instructions.

## VAPOR COLLECTION KIT (VST-VCK-300) REPLACEMENT


1. Place the large band clamp on the collection sleeve. (See Figure 2).
2. Verify the interlock rod is properly inserted into the hole of the interlock sleeve located around the spout prior to pushing the VCK into place. The rod should be visible through the side hole of the sleeve. (See Figure 7).
3. Slide the VST-VCK-300 over the spout.
4. Align and center all alignment marks on top of the vapor collection kit and nozzle scuff. (See Figure 2).
5. Engage interlock a few times to check for correct alignment and functionality (See Functional Test 3).
6. Tighten collection band clamp until collection sleeve will not rotate. (See Figure 2).

## FUNCTIONAL TESTS

1. Follow the VST Installation Procedure for each hanging hardware component. (Executive Order Procedures: Section 6, 8 and 9).

**Figure 6**

Torque Wrench Attachment



2. Purge air from the system by pumping one-tenth (1/10) to two-tenths (2/10) of a gallon of fuel into an approved container. Inspect the nozzle connection for liquid leaks and make proper adjustments at the hose connection if necessary.
3. Check the nozzle shut-off action by dispensing fuel into an approved container at least three times to assure the proper automatic operation of the interlock rod. The fuel flow-rate must be greater than 3 gpm for the automatic shut-off mechanism to operate.

To test, operate the nozzle and submerge the spout tip in fuel until the fuel level covers the vent hole. The main valve of the nozzle automatically shuts off when the liquid covers the vent hole at the end of the spout. The nozzle is not designed to operate on gravity flow.

The hold-open latch will disengage automatically when liquid covers the vent hold in the spout. Verify that the fuel flow stops when the nozzle collection sleeve is decompressed (eg. Interlock rod is disengaged). To test that the fuel flow stops, dispense some fuel into an approved container. Slowly remove the nozzle from the container while dispensing fuel. Fuel flow should stop when the nozzle collection sleeve is fully decompressed.


4. Measure the resistance between the dispenser outlet casting and the tip of the nozzle spout. Use an electronic multimeter set on the high range of the ohmmeter function. Resistance should not indicate more than 70,000 ohms per foot of the hose. Example: The measured resistance of a 12 foot hose must not exceed 840,000 ohms (840 kilohms).

# VST Installation Procedure for Use of VST-FEK-300 Front End Kits On Pre-G2 Phase II Coaxial EVR Balance Nozzles


Part Number Series:

VST-FEK-300 (Front End Kit includes VCK and NSA)

**Figure 7**  
Nozzle Spout Assembly



**Figure 8**  
Interlock Rod Replacement



## MAINTENANCE

Inspect nozzles daily for damaged components parts: vapor collection sleeve, face seal, interlock rod, spout, lever, lever lock, etc. Damaged components must be replaced. Vent hole at the end of the spout should be clear of debris. The nozzle will not operate properly if vent hole becomes clogged. The nozzle will not function properly without the interlock rod properly engaged. Keep the hose connections tight.

Should there be a drive-off or incidence of customer abuse, follow the initial inspection instructions found in the VST Installation Procedure Section 6. The nozzle should be replaced when damaged. The nozzle is designed and constructed to give lasting service if properly handled and maintained. If for any reason it should need attention, contact your VST distributor for proper disposition.

## NOTE

Due to the abuse, misuse, changing gasoline formulas, variation in maintenance practices, environmental conditions, and/or conditions beyond the manufacturer's control, dispensing equipment may need replacement before five (5) years. Inspections and proper maintenance procedures should be followed by the station manager to determine if replacement is required before five (5) years.

## WARNING

Unauthorized rebuilding or modifying of nozzles voids ALL approvals and warranties. VST products must be used in compliance with applicable federal, state, and local laws and regulations. If local regulatory codes prohibit use of the nozzle's hold-open clip, it must be removed prior to nozzle installation. Remove the nozzle to a safe work area. Place the nozzle on a flat surface. Locate the alloy rivet securing the hold-open clip, and spring in the nozzle's handle. Use a drill with a 3/16" (5 mm) drill bit, drill out the rivet securing the hold-open clip, and discard the clip, spring, and all other rivet debris.



## Vapor Systems Technologies, Inc.

650 Pleasant Valley Drive  
Springboro, Ohio 45066 (USA)

Toll Free: 1-888-878-4673

Phone: 937-704-9333

Fax: 937-704-9443

[www.vsthose.com](http://www.vsthose.com)

# VST Installation Procedure for Phase II Coaxial EVR Balance Nozzle Repair Kits

Part Number Series:

VST-FEK-100 (Front End Kit Included VCK and NSA)

VST-VCK-100 (Vapor Collection Kit)



**Vapor Systems Technologies, Inc.**

650 Pleasant Valley Drive  
Springboro, Ohio 45066 (USA)

Toll Free: 1-888-878-4673

Phone: 937-704-9333

Fax: 937-704-9443

www.vsthose.com

## Use ONLY on VST Nozzles:

### Model #: VST-EVR-NB and VST-EVR-NB (Rebuilt)

#### TOOLS

- Torque Wrench
- VST-SRT-200 Torque Wrench Attachment
- Approved Fuel Container
- VST-BPT-100 Nozzle Band Clamp Pincers
- Wide Mouth Funnel
- Petroleum Jelly (or suitable lubricant)

#### GENERAL INFORMATION

If hanging hardware components are involved in a drive-off or incur other customer abuse, each individual component must be functionally tested prior to customer dispensing activities.

#### INSTALLATION PREPARATION

This procedure must be followed to ensure leak-proof installation and operation of these nozzles.

1. Turn off and tag the power to the dispenser. Dispenser must be de-energized prior to service to avoid personal injury.
2. Barricade work area to block vehicle access to the dispenser.
3. Close the dispenser shear valve prior to removing hanging hardware (hoses, safety breakaways, and nozzles).
4. Visually inspect and assess the extent of the damage to all hanging hardware components. If the spout is loose at all, replace the entire front end kit assembly with VST-FEK-100.
5. Drain liquid product from the hanging hardware set into an approved container prior to replacing any hanging hardware assembly.
6. Remove hanging hardware from the dispenser prior to making replacement component assembly connections. VST recommends connecting the whip hose to the dispenser as the last connection during the hanging hardware assembly.
7. To drain nozzle, engage nozzle interlock:
  - a. Push in face seal on nozzle boot assembly
  - b. Hold the back end of the nozzle over an approved container
  - c. Pull nozzle lever to fully drain the nozzle

#### VAPOR COLLECTION KIT (VST-VCK-100) REMOVAL

(See Figure 1)

1. Remove large band clamp from the Vapor Collection Assembly with nozzle band clamp pincers (VST-BPT-100).
2. Pull the Vapor Collection Assembly (boot) off of the clamping groove of the nozzle body.
3. Pull Vapor Collection Assembly off of the spout by slightly twisting to go over the spout latch ring.
4. Properly discard the removed components.

#### VAPOR COLLECTION KIT (VST-VCK-100) REPLACEMENT

1. Place the large band clamp on the collection sleeve. (See Figure 1)
2. Check proper orientation of the interlock rod. (See Figure 2)

3. Slide VCK over the spout.
4. Align and insert the interlock rod into the interlock port. (See Figure 2)
5. Align and center all alignment marks on top of the vapor collection kit and nozzle scuff. (See Figure 1)
6. Engage interlock a few times to check for correct alignment and functionality. (See Function Test 3)
7. Tighten collection band clamp until collection sleeve will not rotate. (See Figure 1)

#### NOZZLE SPOUT ASSEMBLY REMOVAL


1. Remove Vapor Collection Assembly.
2. Loosen spout nut with the VST-SRT-200 Spout Nut Torque Wrench Attachment.  
**NOTE:** Do not use pipe wrench or locking-type pliers.
3. Once threads are completely disengaged, pull the spout straight out.
4. Properly discard the removed components.

#### NOZZLE SPOUT ASSEMBLY (NSA) REPLACEMENT

(See Figures 2-3)

1. Fuel chamber should remain in the nozzle casting with the vacuum sensing tube hole oriented at the top.
2. If the fuel chamber is pulled out of the nozzle casting:
  - a. Check O-ring for damage.
  - b. Replace O-ring if damaged (check for cuts, nicks, etc.).
  - c. Lubricate O-ring prior to re-assembly.
3. Insert fuel chamber into nozzle casting:
  - a. Poppet stem with spring goes through poppet hole in the fuel chamber (center hole).
  - b. Push fuel chamber until it is flush with casting.
  - c. Vacuum sensing tube in the fuel chamber should be oriented at the top.

**Figure 1**  
Vapor Collection Assembly





# VST Installation Procedure for Phase II Coaxial EVR Balance Nozzle Repair Kits

Part Number Series:

VST-FEK-100 (Front End Kit Included VCK and NSA)

VST-VCK-100 (Vapor Collection Kit)

4. Lightly lubricate **ALL** O-rings on the spout assembly. **NOTE:** Do not block vacuum sensing-tube hole with lubricant.
5. Align vacuum sensing tube with mating hole in the fuel chamber.
6. Align the anti-rotation bump on the spout with the casting notch. Be careful not to damage the spout O-ring.
7. Firmly insert spout assembly into the nozzle casting.
8. Apply a dab of Loctite®271 to the male thread of the nozzle casting. Be careful not to apply the Loctite® so that it would enter into the casting notch. (See Figure 3)
9. Thread spout nut onto the nozzle casting and tighten firmly. Torque to 34 foot-pounds. Use VST-SRT-200 Spout Nut Torque Wrench Attachment in order to apply the appropriate torque. Spout should be tight and not able to rotate. Do not over-tighten the spout nut.
10. After tightening the spout nut, place the Vapor Collection Kit onto the spout. Examine the location of the interlock rod to make sure it does not interfere or ride against the spout nut. If there is interference, tighten the spout nut a few degrees to allow the interlock rod to move freely.
11. Re-install the Vapor Collection Kit assembly per the Vapor Collection Kit Replacement instructions.

## FUNCTION TESTS

1. Follow the VST Installation Procedure for each hanging hardware component. (Executive Order Procedures: Section 6, 8 and 9).
2. Purge air from the system by pumping one-tenth (1/10) to two-tenths (2/10) of a gallon of fuel into an approved container. Inspect the nozzle connection for liquid leaks and make proper adjustments at the hose connection if necessary.
3. Check the nozzle shut-off action by dispensing fuel into an approved container at least three times to assure the proper automatic operation of the interlock rod. The fuel flow-rate must be greater than 3 gpm for the automatic shut-off mechanism to operate.

To test, operate the nozzle and submerge the spout tip in fuel until the fuel level covers the vent hole. The main valve of the nozzle automatically shuts off when the liquid covers the vent hole at the end of the spout. The nozzle is not designed to operate on gravity flow. The hold-open latch will disengage automatically when liquid covers the vent hole in the spout. Verify that the fuel flow stops when the nozzle collection sleeve is decompressed (eg. Interlock rod is disengaged). To test that the fuel flow stops, dispense some fuel into an approved container. Slowly remove the nozzle from the container while dispensing fuel. Fuel flow should stop when the nozzle collection sleeve is fully decompressed.


4. Measure the resistance between the dispenser outlet casting and the tip of the nozzle spout. Use an electronic multimeter set on the high range of the ohmmeter function. Resistance should not indicate more than 70,000 ohms per foot of the hose. Example: The measured resistance of a 12 foot hose must not exceed 840,000 ohms (840 kilohms).

## MAINTENANCE

Inspect nozzles daily for damaged components parts: vapor collection sleeve, face seal, interlock rod, spout, lever, lever lock, etc. Damaged components must be replaced. Vent hole at the end of the spout should be clear of debris.

**Figure 2**

Interlock Assembly




The nozzle will not operate properly if vent hole becomes clogged. The nozzle will not function properly without the interlock rod properly engaged. Keep the hose connections tight.

Should there be a drive-off or incidence of customer abuse, follow the initial inspection instructions found in the VST Installation Procedure Section 6. The nozzle should be replaced when damaged. The nozzle is designed and constructed to give lasting service if properly handled and maintained. If for any reason it should need attention, contact your VST distributor for proper disposition.

**FIGURE 3**

Spout Assembly



## NOTE

Due to the abuse, misuse, changing gasoline formulas, variation in maintenance practices, environmental conditions, and /or conditions beyond the manufacturer's control, dispensing equipment may need replacement before five (5) years. Inspections and proper maintenance procedures should be followed by the station manager to determine if replacement is required before five (5) years.

## WARNING


Unauthorized rebuilding or modifying of nozzles voids **ALL** approvals and warranties. VST products must be used in compliance with applicable federal, state, and local laws and regulations. If local regulatory codes prohibit use of the nozzle's hold open clip, it must be removed prior to nozzle installation. Remove the nozzle to a safe work area. Place the nozzle on a flat surface. Locate the alloy rivet securing the hold-open clip, and spring in the nozzle's handle. Use a drill with a 3/16" (5 mm) drill bit, drill out the rivet securing the hold-open clip, and discard the clip, spring, and all other rivet debris.

**Packing List:**

- (1) Bellows & Boot Face
- (1) Bellows O-ring
- (2) Bellows Band Clamps



**A4005EVR Balance  
Vapor Recovery Nozzle**



**INSTALLATION INSTRUCTIONS**

**Service Tools Required:**

- Flat Head Screw Driver w/ Fine Tip
- Bench Vise w/ 5" Jaw Width
- Bellows Retainer Plate Tool p/n 494712EVR
- Bellows Band Clamp Crimp Tool p/n 494652EVR
- Scribe Tool w/ 90 degree tip
- Gasoline Approved Container

**CAUTION:**

1. Always barricade work area to keep pedestrians and vehicles from accessing the dispenser.
2. Always use a gasoline approved container or test can when performing any type of preventive maintenance.
3. Before attempting to install, remove or service the A4005EVR nozzle, turn off and tag out power to the corresponding dispenser.
4. Before attempting to install, remove or service the A4005EVR nozzle, close the emergency impact valves located inside the base of the dispenser. Relieve the line pressure and standing fuel through the nozzle spout into a gasoline approved container by compressing the bellows and squeezing the lever.

**IMPORTANT: Failure to perform cautions 3 and 4 may result in a hazardous gasoline spill, damage to equipment, personal injury and/or death.**

**Pre-Inspection:**

1. Carefully unpack and remove all kitted parts from the shipping container and evaluate for any kind of damage. Verify that no parts are missing from the packing list before proceeding with the installation.

**Pre-Installation:**

2. Empty all standing fuel within the spout and bellows into a gasoline approved container before attempting to service the bellows and boot face.



3. It is unnecessary to remove the A4005EVR nozzle from the fueling point during the removal and installation of the bellows and boot face. Use the bench vise to properly secure the A4005EVR nozzle during service.

**Installation:**

**Removing the Existing Bellows & Boot Face**



4. Locate the top bellows band clamp. Use the flat head screw driver to dislodge the locking mechanism and remove the band clamp from the bellows.



5. Locate the bottom bellows band clamp. Use the flat head screw driver to dislodge the locking mechanism and remove the band clamp from the bellows.



6. Remove the bellows and boot face from the A4005EVR nozzle. Grab the bellows and pull away from the nozzle body.



7. Use the scribe tool to remove the bellows o-ring.

**IMPORTANT: Properly discard all removed components.**

### **Installing the New Bellows & Boot Face**



8. Before attempting to install the new bellows and boot face verify that the top of the interlock push rod is properly aligned with the bottom edge of the interlock guide.




9. Install the new bellows o-ring. Verify that the o-ring seats properly into the machined groove.



10. Slide the new bellows over the spout until the end reaches the nozzle body. Push down over the bellows o-ring until properly seated.




11. Use the bellows retainer plate tool p/n 494712EVR to secure and lock the bellows and boot face in place.



12. Slowly rotate the bellows until the parting line of the boot connector is aligned with the spout and automatic shut-off.

4



13. Install the new top bellows band clamp into the groove of the bellows. Lock and align the crimp portion with the parting line of the bellows.



14. Use the bellows band clamp crimp tool p/n 494652EVR to crimp and secure into place.



15. Install the new bottom bellows band clamp into the groove of the bellows. Lock and align the crimp portion with the parting line of the bellows.




16. Use the bellows band clamp crimp tool p/n 494652EVR to crimp and secure into place.



17. Remove the bellows retainer plate tool p/n 494712EVR from bellows and spout.
18. Remove the A4005EVR nozzle from the bench vise.

**Post-Functional Test:**



19. Functional test the insertion interlock of the A4005EVR nozzle by compressing the bellows and then squeezing the lever. The A4005EVR nozzle will not function unless the insertion interlock is properly engaged.

**Post-Installation:**

20. Place the A4005EVR nozzle back onto the dispenser cradle.

## PREVENTIVE MAINTENANCE

1. Weekly inspect the bellows & boot face for tears, cuts and slits.  
Replace with factory authorized service kits.

| <u>Part Number</u> | <u>Description</u>      |
|--------------------|-------------------------|
| 492775EVR          | Bellows & Boot Face Kit |

## PERFORMANCE STANDARDS & SPECIFICATIONS

This component was factory tested to, and met the following specifications:


1. Meets ARB Material Compatibility with Fuel Blends as per Section 3.8 of CP-201.
2. Meets ARB Capable of Refueling Any Vehicle Standards as per Section 4.7.1 of CP-201.

**IMPORTANT: Leave these installation instructions with the station owner and/ or operator.**



**Packing List:**

- (1) Boot Face
- (4) Mounting Screws



**A4005EVR**  
**Balance Vapor Recovery Nozzle**



**INSTALLATION INSTRUCTIONS**

**Service Tools Required:**

- Phillips Head Screw Driver w/ Fine Tip
- Bench Vise w/ 5" Jaw Width
- Gasoline Approved Container

**CAUTION:**

1. Always barricade work area to keep pedestrians and vehicles from accessing the dispenser.
2. Always use a gasoline approved container or test can when performing any type of preventive maintenance.
3. Before attempting to install, remove or service the A4005EVR nozzle, turn off and tag out power to the corresponding dispenser.
4. Before attempting to install, remove or service the A4005EVR nozzle, close the emergency impact valves located inside the base of the dispenser. Relieve the line pressure and standing fuel through the nozzle spout into a gasoline approved container by compressing the bellows and squeezing the lever.


**IMPORTANT: Failure to perform cautions 3 and 4 may result in a hazardous gasoline spill, damage to equipment, personal injury and/or death.**

**Pre-Inspection:**

1. Carefully unpack and remove all kitted parts from the shipping container and evaluate for any kind of damage. Verify that no parts are missing from the packing list before proceeding with the installation.

**Pre-Installation:**

2. Empty all standing fuel within the spout and bellows into a gasoline approved container before attempting to service the boot face.



3. It is unnecessary to remove the A4005EVR nozzle from the fueling point during the removal and installation of the boot face. Use the bench vise to properly secure the A4005EVR nozzle during service.

**Installation:**

**Removing the Existing Boot Face**



4. Use the philips screw driver to remove the four mounting screws located on the back of the boot connector.



5. Remove the existing boot face by pulling out of the boot connector.

2 **IMPORTANT: Properly discard all removed components.**

## Installing the New Boot Face



6. Install the new boot face into the boot connector by pressing evenly. Align the four mounting holes of the boot face with those of the boot connector.



7. Use the philips screw driver to install and tighten the four new mounting screws.
8. Remove the A4005EVR nozzle from the bench vise.

### **Post-Installation:**

9. Place the A4005EVR nozzle back onto the dispenser cradle.

## PREVENTIVE MAINTENANCE

1. Weekly inspect the boot face for tears, cuts and slits. Replace with factory authorized service kits.

| <u>Part Number</u> | <u>Description</u> |
|--------------------|--------------------|
| 492776EVR          | Boot Face Kit      |

## PERFORMANCE STANDARDS & SPECIFICATIONS

This component was factory tested to, and met the following specifications:


1. Meets ARB Material Compatibility with Fuel Blends as per Section 3.8 of CP-201.
2. Meets ARB Capable of Refueling Any Vehicle Standards as per Section 4.7.1 of CP-201.

**Packing List:**

- |                         |                        |
|-------------------------|------------------------|
| (1) Spout               | (1) Interlock Guide    |
| (1) Bellows O-ring      | (1) Interlock Push Rod |
| (2) Bellows Band Clamps |                        |



**A4005EVR Balance  
Vapor Recovery Nozzle**



**INSTALLATION INSTRUCTIONS**

**Service Tools Required:**

- |   |                                |
|---|--------------------------------|
| • Flat Head Screw Driver w/ Fine Tip          | • Scribe Tool w/ 90 Degree Tip |
| • 15" Crescent Wrench                         | • Needle Nose Pliers           |
| • Torque Wrench w/ 45-55 ft-lbs. Setting      | • 40mm Crows Foot              |
| • Bench Vise w/ 5" Jaw Width                  | • Snap Ring Pliers w/ Fine Tip |
| • Bellows Retainer Plate Tool p/n 494712EVR   |                                |
| • Bellows Band Clamp Crimp Tool p/n 494652EVR |                                |
| • Gasoline Approved Container                 |                                |

**CAUTION:**

1. Always barricade work area to keep pedestrians and vehicles from accessing the dispenser.
2. Always use a gasoline approved container or test can when performing any type of preventive maintenance.
3. Before attempting to install, remove or service the A4005EVR nozzle, turn off and tag out power to the corresponding dispenser.
4. Before attempting to install, remove or service the A4005EVR nozzle, close the emergency impact valves located inside the base of the dispenser. Relieve the line pressure and standing fuel through the nozzle spout into a gasoline approved container by compressing the bellows and squeezing the lever.

1

**IMPORTANT: Failure to perform cautions 3 and 4 may result in a hazardous gasoline spill, damage to equipment, personal injury and/or death.**

**Pre-Inspection:**

1. Carefully unpack and remove all kitted parts from the shipping container and evaluate for any kind of damage. Verify that no parts are missing from the packing list before proceeding with the installation.

**Pre-Installation:**

2. Empty all standing fuel within the spout and bellows into a gasoline approved container before attempting to service the spout.



3. It is unnecessary to remove the A4005EVR nozzle from the fueling point during the removal and installation of the spout. Use the bench vise to properly secure the A4005EVR nozzle during service.

**Installation:**

**Removing the Existing Bellows & Boot Face**



4. Locate the top bellows band clamp. Use the flat head screw driver to dislodge the locking mechanism and remove the band clamp from the bellows.



5. Locate the bottom bellows band clamp. Use the flat head screw driver to dislodge the locking mechanism and remove the band clamp from the bellows.



6. Remove the bellows and boot face from the A4005EVR nozzle. Grab the bellows and pull away from the nozzle body.



7. Use the scribe tool to remove the bellows o-ring.

**IMPORTANT: Properly discard bellows band clamps and bellows o-ring.**

### Removing the Existing Spout



8. Locate the snap ring on the spout. Use the snap ring and needle nose pliers to remove the snap ring from the machined groove. Slide the snap ring upward.



9. Disassemble the interlock guide. Remove the top piece by pulling upward and sliding over the spout. Remove the bottom piece by sliding over the spout.



10. Use the 15" crescent wrench to loosen the spout nut. Unfasten the spout nut by hand to avoid cross threading.



11. Remove the spout by slowly pulling upward.




12. Use the needle nose pliers to remove the interlock push rod.

**IMPORTANT: Properly discard all removed components.**

## Installing the New Spout



13. Use the needle nose pliers to install the new interlock push rod.



14. Install the new spout by inserting the vent tube connector into the nozzle vent port. Slowly push downward on the spout and align the dimple on the spout with the notch on the nozzle body.



15. Fasten the new spout nut by hand onto the nozzle threads to avoid cross threading. Use the 40mm crows foot and torque wrench to tighten the spout nut between 45 to 55 ft-lbs of torque.



16. Install the new interlock guide by sliding the top and bottom pieces over the spout. Press the top piece into the bottom piece.





17. Use the snap ring and needle nose pliers to install the new snap ring into the machined groove located on the spout. Slide the snap ring downward until seated properly.

### Installing the Existing Bellows & Boot Face



18. Before attempting to install the existing bellows & boot face verify that the top of the interlock push rod is properly aligned with the bottom edge of the interlock guide.



19. Install the new bellows o-ring. Verify that the o-ring seats properly into the machined groove.




20. Slide the bellows over the spout until the end reaches the nozzle body. Push down over the bellows o-ring until properly seated.


6



21. Use the bellows retainer plate tool p/n 494712EVR to secure and lock the bellows and boot face in place.



22. Slowly rotate the bellows until the parting line of the boot connector is aligned with the spout and automatic shut-off.



23. Install the new top bellows band clamp into the groove of the bellows. Lock and align the crimp portion with the parting line of the bellows.



24. Use the bellows band clamp crimp tool p/n 494652EVR to crimp and secure into place. 7



25. Install the new bottom bellows band clamp into the groove of the bellows. Lock and align the crimp portion with the parting line of the bellows.



26. Use the bellows band clamp crimp tool p/n 494652EVR to crimp and secure into place.



27. Remove the bellows retainer plate tool p/n 494712EVR from bellows and spout.

28. Remove the A4005EVR nozzle from the bench vise.

**Post-Functional Test:**



29. Functional test the insertion interlock of the A4005EVR nozzle by compressing the bellows and then squeezing the lever. The A4005EVR nozzle will not function unless the insertion interlock is properly engaged.
30. Functional test the automatic shutoff of the A4005EVR nozzle. Begin dispensing by compressing the bellows and then squeezing the lever. Place the hold-open latch in "high" clip position to secure the lever. Dispense one gallon of fuel into a gasoline approved container. At the same time, lower the spout tip into the standing fuel until the automatic shut is completely submersed. The main valve of the A4005EVR nozzle will automatically close causing fuel flow to stop.

**IMPORTANT: Perform step 30 a minimum of three times to assure the insertion interlock , hold open latch and the automatic shutoff of the A4005EVR nozzle are operating properly.**

**According to UL requirement 842, the fuel flow rate must be greater than 3 gallons per minute for the automatic shutoff to operate properly. A common cause of low flow rates are dirty or clogged dispenser filters.**

**Post-Installation:**

31. Place the A4005EVR nozzle back onto the dispenser cradle.

## **PREVENTIVE MAINTENANCE**

1. Weekly inspect the spout for sheared, bent or blocked vent hole. Replace with factory authorized service kits.

| <u>Part Number</u> | <u>Description</u> |
|--------------------|--------------------|
| 492834EVR          | Spout Kit          |

## **PERFORMANCE STANDARDS & SPECIFICATIONS**

This component was factory tested to, and met the following specifications:

1. Meets ARB Material Compatibility with Fuel Blends as per Section 3.8 of CP-201.
2. Meets ARB Capable of Refueling Any Vehicle Standards as per Section 4.7.1 of CP-201.
3. Meets ARB Spout Dimension Standards as per Section 4.7.3 of CP-201.

For use with Vapor Systems  
Technologies VST California Air  
Resources Board Executive  
Orders VR-203 and VR-204



**Packing List:**

(2) Fuel Path O-rings

**A4005EVR Balance  
Vapor Recovery Nozzle**



**A4119EVR Coaxial  
Safe Break Valve**



## INSTALLATION INSTRUCTIONS

**Service Tools Required:**

- Pipe Wrench w/ Flat Jaws
- Scribe Tool w/ 90 Degree Tip
- Bench Vise w/ 5" Jaw Width
- Gasoline Approved Container
- Petroleum Jelly or Other Suitable Lubricant

**CAUTION:**

1. Always barricade work area to keep pedestrians and vehicles from accessing the dispenser.
2. Always use a gasoline approved container or test can when performing any type of preventive maintenance.
3. Before attempting to install, remove or service the A4005EVR nozzle and A4119EVR safe break valve, turn off and tag out power to the corresponding dispenser.
4. Before attempting to install, remove or service the A4005EVR nozzle and A4119EVR safe break valve, close the emergency impact valves located inside the base of the dispenser. Relieve the line pressure and standing fuel through the nozzle spout into a gasoline approved container by compressing the bellows and squeezing the lever.

**IMPORTANT: Failure to perform cautions 3 and 4 may result in a hazardous gasoline spill, damage to equipment, personal injury and/or death.**

**Pre-Inspection:**

1. Carefully unpack and remove all kitted parts from the shipping container and evaluate for any kind of damage. Verify that no parts are missing from the packing list before proceeding with the installation.

**Pre-Installation:**

2. Empty all standing fuel within the spout and bellows into a gasoline approved container before attempting to service the fuel path o-rings.



3. It is necessary to remove the A4005EVR nozzle and A4119EVR safe break valve from the curb hose during the removal and installation of the fuel path o-rings. Use the pipe wrench with flat jaws to loosen the curb hose connector. Unfasten the curb hose connector by hand from the A4005EVR nozzle to avoid cross threading.

**IMPORTANT: Drain the fuel from the hanging hardware into a gasoline approved container when removing the A4005EVR nozzle from the curb hose.**



**A4005EVR Nozzle**



**A4119EVR  
Safe Break Valve**

4. Use the bench vise to properly secure the A4005EVR nozzle or A4119EVR safe break valve during service.

**Installation:**

**Removing the Existing Fuel Path O-rings**



**A4005EVR Nozzle**



**A4119EVR  
Safe Break Valve**

5. Use the scribe tool to remove the existing fuel path o-rings.
6. Clean and remove all existing grease, fuel residue, debris, etc. from within the machined grooves.

**IMPORTANT: Properly discard all removed components.**

**Installing the New Fuel Path O-rings**



**A4005EVR Nozzle**



**A4119EVR  
Safe Break Valve**

7. Use the scribe tool to install the new fuel path o-rings. Verify that both o-rings seat properly into the machined grooves.



**A4005EVR Nozzle**



**A4119EVR  
Safe Break Valve**

8. Lightly lubricate the fuel path o-rings using petroleum jelly or other suitable lubricant.

**Post-Installation:**

9. Before attempting to reinstall the A4005EVR nozzle or A4119EVR safe break valve, please refer to the following installation instructions below.

- A4005EVR Balance Vapor Recovery Nozzle p/n 570435
- A4119EVR Coaxial Safe Break Valve p/n 569043

**PREVENTIVE MAINTENANCE**

1. Weekly inspect the A4005EVR nozzle and A4119EVR safe break valve connections for leaks or fuel residue. Replace with factory authorized service kits.

| <u>Part Number</u> | <u>Description</u>   |
|--------------------|----------------------|
| 494748EVR          | Fuel Path O-ring Kit |

**PERFORMANCE STANDARDS & SPECIFICATIONS**

This component was factory tested to, and met the following specifications:

1. Meets ARB Material Compatibility with Fuel Blends as per Section 3.8 of CP-201.

**IMPORTANT: Leave these installation instructions with the station owner and/ or operator.**




**Packing List:**

(6) Bellows Band Clamps



**A4005EVR Balance  
Vapor Recovery Nozzle**



**INSTALLATION INSTRUCTIONS**

**Service Tools Required:**

- Flat Head Screw Driver w/ Fine Tip
- Bench Vise w/ 5" Jaw Width
- Bellows Retainer Plate Tool p/n 494712EVR
- Bellows Band Clamp Crimp Tool p/n 494652EVR
- Gasoline Approved Container

**CAUTION:**

1. Always barricade work area to keep pedestrians and vehicles from accessing the dispenser.
2. Always use a gasoline approved container or test can when performing any type of preventive maintenance.
3. Before attempting to install, remove or service the A4005EVR nozzle, turn off and tag out power to the corresponding dispenser.
4. Before attempting to install, remove or service the A4005EVR nozzle, close the emergency impact valves located inside the base of the dispenser. Relieve the line pressure and standing fuel through the nozzle spout into a gasoline approved container by compressing the bellows and squeezing the lever.

**IMPORTANT: Failure to perform cautions 3 and 4 may result in a hazardous gasoline spill, damage to equipment, personal injury and/or death.**

**Pre-Inspection:**

1. Carefully unpack and remove all kitted parts from the shipping container and evaluate for any kind of damage. Verify that no parts are missing from the packing list before proceeding with the installation.

**Pre-Installation:**

2. Empty all standing fuel within the spout and bellows into a gasoline approved container before attempting to service the bellows band clamps.



3. It is unnecessary to remove the A4005EVR nozzle from the fueling point during the removal and installation of the bellows band clamps. Use the bench vise to properly secure the A4005EVR nozzle during service.

**Installation:**

**Removing the Existing Bellows Band Clamps**



4. Locate the top bellows band clamp. Use the flat head screw driver to dislodge the locking mechanism and remove the band clamp from the bellows.




5. Locate the bottom bellows band clamp. Use the flat head screw driver to dislodge the locking mechanism and remove the band clamp from the bellows.

**IMPORTANT: Properly discard all removed components.**


### Installing the New Bellows Band Clamps



6. Use the bellows retainer plate tool p/n 494712EVR to secure and lock the bellows and boot face in place.



7. Slowly rotate the bellows until the parting line of the boot connector is aligned with the spout and automatic shut-off.



8. Install the new top bellows band clamp into the groove of the bellows. Lock and align the crimp portion with the parting line of the bellows.



9. Use the bellows band clamp crimp tool p/n 494652EVR to crimp and secure into place.



10. Install the new bottom bellows band clamp into the groove of the bellows. Lock and align the crimp portion with the parting line of the bellows.



11. Use the bellows band clamp crimp tool p/n 494652EVR to crimp and secure into place.



12. Remove the bellows retainer plate tool p/n 494712EVR from bellows and spout.
13. Remove the A4005EVR nozzle from the bench vise.

**Post-Functional Test:**



14. Functional test the insertion interlock of the A4005EVR nozzle by compressing the bellows and then squeezing the lever. The A4005EVR nozzle will not function unless the insertion interlock is properly engaged.

**Post-Installation:**

15. Place the A4005EVR nozzle back onto the dispenser cradle.

## PREVENTIVE MAINTENANCE

1. Weekly inspect the bellows band clamps for damage or if missing. Replace with factory authorized service kits.

| <u>Part Number</u> | <u>Description</u>     |
|--------------------|------------------------|
| 494750EVR          | Bellows Band Clamp Kit |

## PERFORMANCE STANDARDS & SPECIFICATIONS

This component was factory tested to, and met the following specifications:

1. Meets ARB Material Compatibility with Fuel Blends as per Section 3.8 of CP-201.
2. Meets ARB Capable of Refueling Any Vehicle Standards as per Section 4.7.1 of CP-201.

**IMPORTANT: Leave these installation instructions with the station owner and/ or operator.**


For use with Vapor Systems  
Technologies VST California Air  
Resources Board Executive  
Orders VR-203 and VR-204

**Packing List:**

- (1) Latch Assembly
- (2) Mounting Rivets
- (1) Dust Plug



**A4005EVR Balance  
Vapor Recovery Nozzle**



**INSTALLATION INSTRUCTIONS**

**Service Tools Required:**

- Pipe Wrench w/ Flat Jaws
- Flat Head Screw Driver w/ Wide Tip
- 1/8" Diameter Punch
- Bench Vise w/ 5" Jaw Width
- Lever Guard Rivet Installation Tool p/n 494653EVR
- Needle Nose Pliers
- Awl w/ 1/4" Tip
- Hammer
- 5/8" Diameter Punch
- Gasoline Approved Container

**CAUTION:**

1. Always barricade work area to keep pedestrians and vehicles from accessing the dispenser.
2. Always use a gasoline approved container or test can when performing any type of preventive maintenance.
3. Before attempting to install, remove or service the A4005EVR nozzle, turn off and tag out power to the corresponding dispenser.
4. Before attempting to install, remove or service the A4005EVR nozzle, close the emergency impact valves located inside the base of the dispenser. Relieve the line pressure and standing fuel through the nozzle spout into a gasoline approved container by compressing the bellows and squeezing the lever.

1

**IMPORTANT:** Failure to perform cautions 3 and 4 may result in a hazardous gasoline spill, damage to equipment, personal injury and/or death.

**Pre-Inspection:**

1. Carefully unpack and remove all kitted parts from the shipping container and evaluate for any kind of damage. Verify that no parts are missing from the packing list before proceeding with the installation.

**Pre-Installation:**

2. Empty all standing fuel within the spout and bellows into a gasoline approved container before attempting to service the latch.



3. It is necessary to remove the A4005EVR nozzle from the curb hose during the removal and installation of the latch. Use the pipe wrench with flat jaws to loosen the curb hose connector. Unfasten the curb hose connector by hand from the A4005EVR nozzle to avoid cross threading.

**IMPORTANT:** Drain the fuel from the hanging hardware into a gasoline approved container when removing the A4005EVR nozzle from the curb hose.

**Installation:**

**Removing the Existing Latch**



4. Pull the rear end of the scuff guard over the nozzle body unit the dust plug is visible. Use the bench vise to properly secure the A4005EVR nozzle during service.
- 2







5. Use the awl and hammer to lightly tap and remove the dust plug.



6. Use the flat head screw driver to loosen the brass screw. Use the needle nose pliers to remove the brass screw and spring from the nozzle body.



7. Remove the A4005EVR nozzle from the bench vise and place on a flat surface. Use the 1/8" diameter punch and hammer to lightly tap and remove both mounting rivets located on the lever guard.




8. Remove the lever guard from the nozzle body.



9. Remove the existing latch by slowly pulling upward until the square stem clears the nozzle body.

**IMPORTANT: Properly discard the dust plug and mounting rivets and latch.**

### Installing the New Latch



10. Locate the notch on the square stem and align to the right of the nozzle body. Install the new latch by pressing downward on the square stem.



11. Remove the A4005EVR nozzle from the bench vise and turn top side up. Install the existing spring around the square stem. Fasten the existing brass screw by hand onto the top of the square stem to avoid cross threading. Use the flat head screw driver to tighten.



12. Install the new dust plug. Use the 5/8 punch and hammer to light tap into place.



13. Remove the A4005EVR nozzle from the bench vise and place on flat surface. Install the existing lever guard onto the nozzle body using the new mounting rivets. Use the lever guard rivet installation tool p/n 494653EVR and hammer to properly flare the ends of the mounting rivets.



14. Install the existing scuff guard by pulling over the nozzle body.

**Post-Installation:**

15. Before attempting to reinstall the A4005EVR nozzle, please refer to the A4005EVR Balance Vapor Recovery Nozzle Installation Instructions p/n 570435.

## PREVENTIVE MAINTENANCE

1. Weekly inspect the latch for damage or if missing. Replace with factory authorized service kits.

| <u>Part Number</u> | <u>Description</u> |
|--------------------|--------------------|
| 494150EVR          | Latch Kit          |

## PERFORMANCE STANDARDS & SPECIFICATIONS

This component was factory tested to, and met the following specifications:

1. Meets ARB Material Compatibility with Fuel Blends as per Section 3.8 of CP-201.

**IMPORTANT: Leave these installation instructions with the station owner and/ or operator.**

For use with Vapor Systems  
Technologies VST California Air  
Resources Board Executive  
Orders VR-203 and VR-204



**Packing List:**

(1) Scuff Guard

**A4005EVR**  
Balance Vapor Recovery Nozzle



**INSTALLATION INSTRUCTIONS**

**Service Tools Required:**

- Pipe Wrench w/ Flat Jaws
- Gasoline Approved Container
- Utility Knife

**CAUTION:**

1. Always barricade work area to keep pedestrians and vehicles from accessing the dispenser.
2. Always use a gasoline approved container or test can when performing any type of preventive maintenance.
3. Before attempting to install, remove or service the A4005EVR nozzle, turn off and tag out power to the corresponding dispenser.
4. Before attempting to install, remove or service the A4005EVR nozzle, close the emergency impact valves located inside the base of the dispenser. Relieve the line pressure and standing fuel through the nozzle spout into a gasoline approved container by compressing the bellows and squeezing the lever.

**IMPORTANT: Failure to perform cautions 3 and 4 may result in a hazardous gasoline spill, damage to equipment, personal injury and/or death.**

**Pre-Inspection:**

1. Carefully unpack and remove all kitted parts from the shipping container and evaluate for any kind of damage. Verify that no parts are missing from the packing list before proceeding with the installation.

**Pre-Installation:**

2. Empty all standing fuel within the spout and bellows into a gasoline approved container before attempting to service the scuff guard.



3. It is necessary to remove the A4005EVR nozzle from the curb hose during the removal and installation of the scuff guard. Use the pipe wrench with flat jaws to loosen the curb hose connector. Unfasten the curb hose connector by hand from the A4005EVR nozzle to avoid cross threading.

**IMPORTANT:** Drain the fuel from the hanging hardware into a gasoline approved container when removing the A4005EVR nozzle from the curb hose.

**Installation:**

**Removing the Existing Scuff Guard**



4. Place the A4005EVR nozzle on a flat surface. Use the utility knife to make the first cut along the front side of the scuff guard.



5. Use the utility knife to make the second cut along the rear side of the scuff guard.



6. Remove the scuff guard from the nozzle body.

**IMPORTANT: Properly discard all removed components.**

### **Installing the New Scuff Guard**

7. Before attempting to install the new scuff guard. Soften the scuff guard by soaking in hot water and soap.



8. Install the new scuff guard by sliding over the spout and bellows. Pull the scuff guard completely over the nozzle body.

### **Post-Installation:**

9. Before attempting to reinstall the A4005EVR nozzle, please refer to the A4005EVR Balance Vapor Recovery Nozzle Installation Instructions p/n 570435.

## **PREVENTIVE MAINTENANCE**

1. Weekly inspect the scuff guard for the Emco Wheaton Retail manufacturer's logo. Replace with factory authorized service kits.

| <u>Part Number</u> | <u>Description</u> |
|--------------------|--------------------|
| A0557EVR           | Scuff Guard Kit    |

## PERFORMANCE STANDARDS & SPECIFICATIONS

This component was factory tested to, and met the following specifications:

1. Meets ARB Material Compatibility with Fuel Blends as per Section 3.8 of CP-201.

**IMPORTANT: Leave these installation instructions with the station owner and/ or operator.**



# VST Installation Procedure for Phase II Coaxial EVR Balance Fuel Hoses

Part Number Series: VSTA-EVR, VDV-EVR, VSTAP-EVR and VDVP-EVR



**Vapor Systems Technologies, Inc.**

650 Pleasant Valley Drive  
Springboro, Ohio 45066 (USA)

Toll Free: 1-888-878-4673


Phone: 937-704-9333

Fax: 937-704-9443

www.vsthose.com

**Figure 1.**

EVR Balance Hanging Hardware Assembly



## GENERAL INFORMATION

If hanging hardware components are involved in a drive-off or incur other customer abuse, each individual component must be functionally tested prior to customer dispensing activities.

## INSTALLATION PREPARATION

This procedure must be followed to insure leak-proof installation and operation of these hose products.

1. Turn off and tag the power to the dispenser. Dispenser must be de-energized prior to service to avoid personal injury.
2. Barricade work area to block vehicle access to the dispenser.
3. Close the dispenser shear valve prior to removing hanging hardware (hoses, safety breakaways, and nozzles).
4. Drain liquid product from the hanging hardware set into an approved container prior to replacing any hanging hardware components.
5. Remove hanging hardware from the dispenser prior to making replacement component assembly connections. VST recommends connecting the whip hose to the dispenser as the last connection during the hanging hardware assembly.

## INSTALLATION AND FUNCTION TESTS

1. Initial inspection:
  - a. Carefully unpack hose from shipping carton.
  - b. Inspect ALL O-Rings on each end of the hose to determine that they are present and undamaged.
  - c. Inspect hose exterior for any damage.
  - d. Inspect coupling threads for any damage.
2. Lightly lubricate ALL O-Rings on mating connections with petroleum jelly or other suitable lubricant. DO NOT USE pipe dope or thread sealant.
3. Insert the hose coupling into the mating connection and hand-tighten.
 

NOTE Flow direction arrows on whip and primary hoses, where applicable, are indicated on hose coupling cuffs.
4. Tighten all the hose-joint connections to 50 foot-pounds of torque. DO NOT OVER TIGHTEN. Use a torque wrench with an open-end attachment to fit the hose couplings and an open-end wrench to properly tighten coupling connections. DO NOT USE channel-locks or pliers to tighten hose joints. Proper ft./lb. torque may not be achieved with these tools.
5. Purge air from the system by pumping one-tenth (1/10) to two-tenths (2/10) of a gallon of fuel into an approved container. Inspect each hose-joint connection for liquid leaks and make proper adjustments if necessary.

6. Check the nozzle shut-off action by dispensing fuel into an approved container at least three times to assure the proper automatic operation of the interlock rod. The fuel flow-rate must be greater than 3 gpm for the automatic shut-off mechanism to operate.

To test, operate the nozzle and submerge the spout tip in fuel until the fuel level covers the vent hole. The main valve of the nozzle automatically shuts off when the liquid covers the vent hole at the end of the spout. The nozzle is not designed to operate on gravity flow. The hold-open latch will disengage automatically when liquid covers the vent hole in the spout. Verify that the fuel flow stops when the nozzle collection sleeve is decompressed (e.g. interlock rod is disengaged). To test that the fuel flow stops, dispense some fuel into an approved container. Slowly remove the nozzle from the container while dispensing fuel. Fuel flow should stop when the nozzle collection sleeve is fully decompressed.

7. Measure the resistance between the dispenser outlet casting and the tip of the nozzle spout. Use an electronic multimeter set on the high range of the ohmmeter function. Resistance should not indicate more than 70,000 ohms per foot of hose. Example: The measured resistance for a 12-foot hose must not exceed 840,000 ohms (840 kilohms)

### PROCEDURE FOR POSITIONING THE LIQUID REMOVAL DEVICE

This procedure must be followed to insure proper positioning for the liquid-removal device in Part Number Series: VDV-EVR and VDVP-EVR (See Figure 2).

1. After installing the VST hanging hardware, hold the nozzle straight out from the dispenser so that the compressed bellows is 48 inches away from the front face of the dispenser (simulate when the bellows is compressed in the filler neck of a vehicle) and the spout tip of the nozzle is 30 inches above the pavement. The nozzle spout is to be at a 30-degree angle above the horizontal plane.

2. When the hose and nozzle are held in position as shown in Figure 2, the factory installed liquid-removal device indicator-mark (striped line) on the vapor hose must be located:
  - In the bottom of the loop section within the tolerance range.
  - The allowable tolerance range is 3 inches left or right of the 6:00 o'clock position (lowest point of the loop) as measured along the center line of the hose

- In the bottom of the loop section within the tolerance range.
- The allowable tolerance range is 3 inches left or right of the 6:00 o'clock position (lowest point of the loop) as measured along the center line of the hose

If the liquid-removal device indicator-mark is not located within the tolerance range, the installer must choose one of the following options:

Adjust the hose retractor (if installed)

Use a different length whip hose

Use a different length primary hose

### IMPORTANT

It is the installing technician's responsibility to insure that the properly sized and marked hanging hardware is installed at the dispenser. Failure to

properly install and locate the liquid removal device may reduce the effectiveness of the product in application resulting in outer hose liquid blockage and failure of the liquid removal test procedure.


### MAINTENANCE

Inspect hoses daily for damage, loose connection, or leaks. Replace as necessary. Subject to customer abuse, hose should be replaced when damaged.

The hose is designed and constructed to give lasting service if properly handled and maintained. If for any reason it should need attention, contact your VST distributor for proper disposition.

**NOTE** Due to abuse, misuse, changing gasoline formulas, variation in maintenance practices, environmental conditions, and/or conditions beyond the manufacturer's control, dispensing equipment may need replacement before five (5) years. Inspections and proper maintenance procedures should be followed by the station manager to determine if replacement is required before five (5) years.

**WARNING** Unauthorized rebuilding or modifying of hoses voids **ALL** approvals and warranties. VST products must be used in compliance with applicable federal, state and local laws and regulations.



**Figure 2.** Procedure For Positioning the Liquid Removal Device

## Installation Instructions

**Whip Hose:** Maxxim Premier (532-365-640-XXXXX) or Maxxim Premier Ultra (532-366-640-XXXXX)

**Curb Hose:** Maxxim Premier Plus (532-365-641-XXXXX) or Maxxim Premier Ultra (532-366-641-XXXXX)

- 1 The last 5 digits of the part # determines the length of the hose assembly. Install the correct hose length and other hanging hardware on the dispenser. This will include whip hose, breakaway, curb hose, and nozzle.
  - a) When installing Maxxim Premier Plus or Maxxim Premier Ultra curb hoses, the end of the hose stamped "NOZZLE END" must be attached to the nozzle.
  - b) If a hose retractor is required, use retractor clamp; part # 532-365-105-000-00.
  - c) Do not use high retractor tension. High tension is difficult for customers to handle and it reduces the life of the hose. Retractor tension above 12 pounds will void the warranty.
  - d) Do not mix outer or inner hose components. The mixed assembly may not be grounded and could cause a serious fire hazard.
  - e) Make sure that the curb hose does not touch the pavement or the top of the island when the nozzle hangs on the dispenser hook.
- 2 Tighten the swivel nut to 50 ft. lbs. torque using an open end torque wrench. Do not use a pipe wrench because the teeth on the wrench will damage the fitting. This connection is sealed by an o-ring. Do not apply thread sealant.
  - Alternate method: If a torque wrench is not available, turn the swivel nut by hand until snug and the o-ring is seated. Then use a wrench to tighten the swivel nut ¼ turn past snug. This connection has straight threads and must be cinched tight to prevent the threads from unscrewing in service.

One source for an open end torque wrench is Belknap Tools, both part #'s are needed:

  - VB-0608005 open end wrench head
  - VB-100ST-I wrench handle preset at the factory to 50 ft lbs

After extended service, the swivel nut o-ring can be lubricated with front end bearing grease or Parker O-Lube
- 3 Function Test - Measure the resistance between the dispenser outlet casting and the tip of the nozzle spout. Use an electronic multimeter set on the high range of the ohmmeter function. Resistance should not indicate more than 70,000 ohms per foot of hose. Example: The measured resistance for a 12-foot hose must not exceed 840,000 ohms (840 kilohms)

## Curb Hose Venturi Pick-up Length Instructions

It is the responsibility of the installer to determine the optimum venturi pick-up length and verify that hoses installed on a dispenser have the optimum pick-up location. Failure to properly size the pick-up location will reduce the effectiveness of the venturi in removing liquid blockage from the outer vapor hose and may result in failure of the liquid removal test.

When the hose is assembled in the factory, a mark is placed on the outer hose to locate the venturi pick-up location. This mark will help the installer determine whether the hose has the optimum pick-up location for the installation.

- 4 Hold the nozzle straight out from the dispenser so that the end of the compressed bellows (simulate when the bellows is compressed in the filler neck of a car) is 48 inches away from the front face of the dispenser (see Figure 1). Hold the nozzle so that the tip of the spout is 30 inches above the pavement and the spout is at a 30° angle above the horizontal plane (see Figure 1). When the nozzle and hose are held in the position shown in Figure 1, the mark on the outer vapor hose should be within 3 inches of the bottom of the loop (see Figure 1).

5 If the mark on the hose is not within the tolerance shown in Figure 1, the installer may:

- Adjust the hose retractor (if installed);
- Install a different length whip hose; or
- Install a different long hose with the optimum venturi pick-up location. To determine the optimum venturi pick-up location (e.g., venturi pick-up tube length), conduct the following:
  - a) Hold the nozzle and hose in the position shown in Figure 1;
  - b) Measure the length from the back end of the nozzle (where the hose screws into the nozzle) to the bottom of the loop in the hose. This length is the optimum “pick-up” length for the balance venturi hose.
  - c) Contact your local distributor to obtain a balance hose with the optimum venturi pick-up tube length.




FIGURE 1

**Note:** It is the responsibility of the installer to be familiar with the current requirements of state, federal, local codes and air district rules and regulations for installation of gasoline dispensing equipment. It is also the responsibility of the installer to be aware of all the necessary safety precautions and site safety requirements to assure a safe and trouble free installation. The warranty tag provided with the component is to remain with component, and must be provided to the end-user.

Questions on installation should be directed to your local distributor or Customer Service.

ContiTech USA, Inc.  
703 S. Cleveland Massillon Rd.  
Fairlawn, OH 44333 USA  
Telephone: 1-800-235-4632

# VST Installation Procedure for Phase II Coaxial EVR Balance Safety Breakaway Devices

Reattachable Breakaway Part Number Series: VSTA-EVR-SBKA



**Vapor Systems Technologies, Inc.**

650 Pleasant Valley Drive  
Springboro, Ohio 45066 (USA)

Toll Free: 1-888-878-4673

Phone: 937-704-9333

Fax: 937-704-9443

www.vsthose.com

## APPLICATION

These VST Safety Breakaway devices are intended to prevent damage to the dispenser and hose in the event of a vehicle drive off. These devices separate at pull forces up to 350 lbs. Determine that 350 lbs. pull force will not damage the dispenser. After verifying that the dispenser is securely bolted to the island, it can be tested by using a spring scale and a length of rope. The rope must be connected at the dispenser outlet casting, which may require a threaded bushing with a hole for attaching the rope. Attach the scale to the rope and pull to 350 lbs. in several directions. Be sure to avoid damaging the dispenser.

## NOTE:

- The whip hose **ALWAYS** attaches to the dispenser. If a retractor is being used, the retractor clamp **MUST** be between the breakaway and dispenser.
- VST hoses are made to withstand 350 pounds tensile pull without damage. If another brand of hose is present at the dispenser, VST recommends that you contact the hose manufacturer regarding the compatibility with this breakaway device.

## General Information


If hanging hardware components are involved in a drive-off or incur other customer abuse, each individual component must be functionally tested prior to customer dispensing activities.

## Installation Preparation

These procedures must be followed to ensure leak-proof installation and operation of these safety breakaway products.

- Turn off and tag the power to the dispenser. Dispenser must be de-energized prior to service to avoid personal injury.
- Barricade work area to block vehicle access to the dispenser.
- Close dispenser shear valve prior to performing any service work with the hanging hardware (hoses, safety breakaways, and nozzles).
- Drain liquid product from the hanging hardware set into an approved container prior to replacing any hanging hardware component.

Figure 1.



# VST Installation Procedure for Phase II Coaxial EVR Balance Safety Breakaway Devices


Reattachable Breakaway Part Number Series: VSTA-EVR-SBKA

5. For the installation of a new breakaway, remove hanging hardware from the dispenser prior to making replacement component assembly connections. VST recommends connecting the whip hose to dispenser as the last connection during hanging hardware assembly.

## Installation and Function Tests

1. Initial inspection:
  - a. Carefully unpack safety breakaway from shipping carton.
  - b. Inspect safety breakaway for any damage to threads, O-rings, exterior, etc.
2. Lightly lubricate **ALL** O-rings on mating connections with petroleum jelly or other suitable lubricant. **DO NOT USE** pipe dope or thread sealant.
3. Attach breakaway on mating connection and tighten by hand. **NOTE FLOW DIRECTION ARROW** (where applicable). Use the hex on the breakaway body closest to the connection to tighten. **DO NOT USE** the breakaway body to tighten the unit.
4. Tighten breakaway connection to 50 foot-pounds of torque. **DO NOT OVER TIGHTEN**. Use the hex on the breakaway body closest to the connection to tighten. Use a torque wrench with an open-end attachment to fit the hose couplings and an open-end wrench to properly tighten breakaway connections. **DO NOT USE** channel-locks or pliers to tighten connections. Proper ft./lb. torque may not be achieved with these tools.
5. Purge air from the system by pumping one-tenth (1/10) to two-tenths (2/10) of a gallon of fuel into an approved container. Inspect each hose joint connection for liquid leaks and make proper adjustments if necessary. Checking for meter creep will verify the integrity of the connections. After dispensing the fuel, release the lever and move components around and/or gently shake the hose and verify if the displayed amount on the dispenser changes. If meter creep is experienced, check all components and replace as necessary.
6. Check the nozzle shut-off action by dispensing fuel into an approved container at least three times to assure proper automatic operation of the interlock rod. The fuel flow-rate must be greater than 3 gpm for the automatic shut-off mechanism to operate.

To test, operate the nozzle and submerge the spout tip in fuel until the fuel level covers the vent hole. The main valve of the



**Figure 2: Check each half for damage**

nozzle automatically shuts off when liquid covers the vent hole at the end of the spout. The nozzle is not designed to operate on gravity flow. The hold-open latch will disengage automatically when liquid covers the vent hole in the spout. Verify that the fuel flow stops when the nozzle collection sleeve is decompressed (e.g. interlock rod is disengaged). Slowly remove the nozzle from the container while dispensing fuel. Fuel flow should stop when the nozzle collection sleeve is fully decompressed.

7. Measure the resistance between the dispenser outlet casting and the tip of the nozzle spout. Use an electronic multimeter set on the high range of the ohmmeter function. Resistance should not indicate more than 70,000 ohms per foot of hose. Example: The measured resistance for a 12-foot hose must not exceed 840,000 ohms (840 kilohms).

## BREAKAWAY REATTACHMENT PROCEDURE


The VSTA-EVR-SBKA Safety Breakaway may be reconnected with the use of the VST Breakaway Assembly Tool (VST-BAT-100).

## BREAKAWAY REATTACHMENT PROCEDURE

1. Follow **INSTALLATION PREPARATION** steps 1-4.
2. Inspect both safety breakaway halves for damage that may have occurred during separation. Include looking for external damage to the product and missing alignment pin, etc. See **Figures 2 and 3. If damage or missing parts are detected, replace with new product.** Ensure that the retaining sleeve is placed on the breakaway half connected to the whip hose before reassembly.

# VST Installation Procedure for Phase II Coaxial EVR Balance Safety Breakaway Devices

Reattachable Breakaway Part Number Series: VSTA-EVR-SBKA



**Figure 3: Check for Alignment Pin**

3. Prior to reassembling, be sure the mating parts are undamaged and clean.
4. Replace all O-rings with those provided in the repair kit (VST-BRK-100).
  - a. Lightly lubricate the O-rings on mating connections with petroleum jelly or other suitable lubricant. **DO NOT USE** pipe dope or thread sealant.
  - b. Use the large O-ring provided in the repair kit to replace the outer O-ring on the curb hose side of the breakaway. See **Figure 5**.
  - c. Use the small O-ring provided in the repair kit to replace the inner O-ring on the whip side of the breakaway. Use a plastic pick provided in the kit to remove the old O-ring. See **Figure 3**.
5. Apply a liberal amount of lithium grease provided in the repair kit (VST-BRK-100) completely around the mating diameter surface of the curb hose side of the breakaway. The grease will need to cover the entire surface that will slide into the mating end of the breakaway. See **Figure 5**. **DO NOT USE** pipe dope or thread sealant.
6. Utilize the VST Breakaway Assembly Tool (VST-BAT-100) with the appropriate reassembly plates to reassemble the breakaway. The tool is used to provide appropriate leverage for the ease of reassembly of the breakaway and to secure the breakaway during replacement of the shear washers. This can be done without disassembling the hoses from the breakaway halves.
7. Press the button on the Breakaway Assembly Tool to spread the end clamps apart to allow the two separated breakaway halves


to fit between the top and bottom clamps. Slide the top clamp of the VST Breakaway Assembly Tool behind the hex on the breakaway half connected to the whip hose. See **Figure 4**.

8. Slide the separated bottom half of the breakaway (with curb hose and nozzle attached) onto the bottom clamp of the VST Breakaway Assembly Tool. Align the shear ring grooves away from the reassembly tool for ease of insertion of the shear washers. See **Figure 4**.
9. Slowly squeeze the VST Breakaway Assembly Tool trigger to bring the breakaway halves together.
10. Carefully align the two breakaway halves. Place the alignment pin from the breakaway upper half into the hole of the inner poppet on the lower half of the breakaway



**Figure 4: Attach Reassembly Tool**

**CAUTION:** Reconnection can cause a small amount of gasoline to leak out of the breakaway. A towel wrapped loosely around the breakaway can help to minimize spills.



**Figure 5: Align Poppet Pin from upper to lower half of breakaway and finish alignment**

# VST Installation Procedure for Phase II Coaxial EVR Balance Safety Breakaway Devices

Reattachable Breakaway Part Number Series: VSTA-EVR-SBKA



**Vapor Systems Technologies, Inc.**


650 Pleasant Valley Drive  
Springboro, Ohio 45066 (USA)

Toll Free: 1-888-878-4673

Phone: 937-704-9333

Fax: 937-704-9443

www.vsthose.com



**Figure 6: Add Shear Washer**



**Figure 7: Remove Grease**



**Figure 8: Reposition  
Retaining Sleeve**



**Figure 9: Verify  
Connection Integrity**

that is connected to the nozzle end. Continue squeezing the trigger of the VST Breakaway Assembly Tool while guiding the alignment slots together to finish reassembly. See **Figure 5**.

**NOTE:** Once the two breakaway halves come together close enough for placement of the shear washers, do not squeeze the tool trigger any further. Unnecessary pressure on the tool could damage or break the tool.

11. Once the two aligned halves are together place one shear washer into each of the shear washer grooves (2 total) from the repair kit (VST-BRK-100). See **Figure 6**. Ensure that the shear washer is completely seated into the groove before moving the retaining sleeve into place. See **Figure 7**. Wipe off excess grease after installation of the shear rings.
12. After the two breakaway halves are reattached, remove the Breakaway Assembly Tool (press the button on the tool to allow the plates to release). Reposition the retaining sleeve to the groove between the two halves of the breakaway. See **Figure 8**. Give the reassembled breakaway a strong pull to verify that it is properly connected. See **Figure 9**.
13. If successful, follow the **Installation and Functional Tests** steps 5 – 7 in this document.

## MAINTENANCE

Inspect safety breakaways regularly for damage, loose connections or leaks. Replace as necessary. Subject to customer abuse, safety breakaway should be replaced when damaged.

The safety breakaway is designed and constructed to give lasting service if properly handled and maintained. If for any reason it should need attention, contact your VST distributor for proper disposition.

**NOTE:** Due to abuse, misuse, changing gasoline formulas, variation in maintenance practices, environmental conditions and/or conditions beyond the manufacturer's control, dispensing equipment may need replacement before five (5) years. Inspections and proper maintenance procedures should be followed by the station manager to determine if replacement is required before five (5) years.

## WARNING

Unauthorized rebuilding or modifying of safety breakaways voids ALL approvals and warranties.

VST products must be used in compliance with applicable federal, state and local laws and regulations.



# VST Installation Procedure for Phase II Coaxial EVR Balance Safety Breakaway Devices

NON-Reattachable Breakaway Part Number Series: VSTA-EVR



**Vapor Systems Technologies, Inc.**

650 Pleasant Valley Drive  
Springboro, Ohio 45066 (USA)

Toll Free: 1-888-878-4673


Phone: 937-704-9333

Fax: 937-704-9443

www.vsthose.com

**Figure 1.**

EVR Balance Hanging Hardware Assembly



## APPLICATION

These VST Safety Breakaway devices are intended to prevent damage to the dispenser and hose in the event of a vehicle drive off. These devices separate at pull forces up to 350 lbs. Determine that 350 lbs. of pull force will not damage the dispenser. After verifying that the dispenser is securely bolted to the island, it can be tested by using a spring scale and a length of rope. The rope must be connected at the dispenser outlet casting, which may require a threaded bushing with a hole for attaching the rope. Attach the scale to the rope and pull to 350 lbs. in several directions. Be sure to avoid damaging the dispenser.

## NOTE

- The whip hose ALWAYS attaches to the dispenser. If a retractor is being used, the retractor clamp MUST be between the breakaway and the dispenser.
- VST hoses are made to withstand 350 pounds tensile pull without damage. If another brand of hose is present at the dispenser, VST recommends that you contact the hose manufacturer regarding the compatibility with this breakaway device.

## GENERAL INFORMATION

If hanging hardware components are involved in a drive-off or incur other customer abuse, each individual component must be functionally tested prior to customer dispensing activities.

## INSTALLATION PREPARATION

This procedure must be followed to insure leak-proof installation and operation of these safety breakaway products.

- Turn off and tag the power to the dispenser. Dispenser must be de-energized prior to service to avoid personal injury.
- Barricade work area to block vehicle access to the dispenser.
- Close the dispenser shear valve prior to removing hanging hardware (hoses, safety breakaways, and nozzles).
- Drain liquid product from the hanging hardware set into an approved container prior to replacing any hanging hardware components.
- Remove hanging hardware from the dispenser prior to making replacement component assembly connections. VST recommends connecting the whip hose to the dispenser as the last connection during the hanging hardware assembly

# VST Installation Procedure for Phase II Coaxial EVR Balance Safety Breakaway Devices

NON-Reattachable Breakaway Part Number Series: VSTA-EVR



**Vapor Systems Technologies, Inc.**

650 Pleasant Valley Drive  
Springboro, Ohio 45066 (USA)

Toll Free: 1-888-878-4673

Phone: 937-704-9333

Fax: 937-704-9443

www.vsthose.com

---

## INSTALLATION AND FUNCTION TESTS

1. Initial inspection:
  - a. Carefully unpack safety breakaway from shipping carton.
  - b. Inspect safety breakaway for any damage to threads, O-Rings, exterior, etc.
2. Lightly lubricate ALL O-Rings on mating connections with petroleum jelly or other suitable lubricant. DO NOT USE pipe dope or thread sealant.
3. Attach breakaway on mating connection and tighten by hand. NOTE THE FLOW DIRECTION ARROW (where applicable). Use the hex on the breakaway body to tighten. DO NOT USE the breakaway body to tighten the unit.
4. Tighten breakaway connection to 50 foot-pounds torque. DO NOT OVER TIGHTEN. Use the hex on the breakaway body to tighten. Use a torque wrench with an open-end attachment to fit the hose couplings and an open-end wrench to properly tighten breakaway connections. DO NOT USE channel-locks or pliers to tighten connections. Proper ft./lb. torque may not be achieved with these tools.
5. Purge air from the system by pumping one-tenth (1/10) to two-tenths (2/10) of a gallon of fuel into an approved container. Inspect each hose joint connection for liquid leaks and make proper adjustments if necessary.
6. Check the nozzle shut-off action by dispensing fuel into an approved container at least three times to assure the proper automatic operation of the interlock rod. According to U/L requirement 842, the fuel flow-rate must be greater than 3 gpm for the automatic shut-off mechanism to operate.

To test, operate the nozzle and submerge the spout tip in fuel until the fuel level covers the vent hole. The main valve of the nozzle automatically shuts off when liquid covers the vent hole at the end of the spout. The nozzle is not designed to operate on gravity flow. The hold-open latch will disengage automatically when liquid covers the vent hole in the spout. Verify that the fuel flow stops when the nozzle collection sleeve is decompressed (e.g. interlock rod is disengaged). To test that the fuel flow stops, dispense some fuel into an approved container. Slowly remove the nozzle from the container while dispensing fuel. Fuel flow should stop when the nozzle collection sleeve is fully decompressed.

7. Measure the resistance between the dispenser outlet casting and the tip of the nozzle spout. Use an electronic multimeter set on the high range of the ohmmeter function. Resistance should not indicate more than 70,000 ohms per foot of hose. Example: The measured resistance for a 12-foot hose must not exceed 840,000 ohms (840 kilohms).

## MAINTENANCE

Inspect safety breakaways daily for damage, loose connections or leaks. Replace as necessary. Subject to customer abuse, safety breakaway should be replaced when damaged.

The safety breakaway is designed and constructed to give lasting service if properly handled and maintained. If for any reason it should need attention, contact your VST distributor for proper disposition.

## NOTE

Due to abuse, misuse, changing gasoline formulas, variation in maintenance practices, environmental conditions and/or conditions beyond the manufacturer's control, dispensing equipment may need replacement before five (5) years. Inspections and proper maintenance procedures should be followed by the station manager to determine if replacement is required before five (5) years.

## WARNING

Unauthorized rebuilding or modifying of safety breakaways voids **ALL** approvals and warranties.

VST products must be used in compliance with applicable federal, state, and local laws and regulations.

# VST Installation Procedure for Phase II Coaxial EVR Balance Breakaway Scuff Guards

Part Number Series: VST-BBSG-100

**For Use On: VST-EVR-SBKA**



**Vapor Systems Technologies, Inc.**

650 Pleasant Valley Drive  
Springboro, Ohio 45066 (USA)

Toll Free: 1-888-878-4673

Phone: 937-704-9333

Fax: 937-704-9443

www.vsthose.com

## APPLICATION

These VST Safety Breakaway scuff guards are intended for use as an optional accessory on the VST-EVR-SBKA Balance Safety Breakaways to reduce defacement of the dispenser.

**Figure 1.**



## INSTALLATION PREPARATION

Follow all safety preparation procedures found in the VST Safety Breakaway Installation Procedure.

## INSTALLATION

1. These scuff guards must be installed onto the breakaway after it has been disconnected from the hoses.
2. Slide the scuff guards onto the hose. The reduced diameter ridge of the scuff guards should be positioned for proper fit onto the ends of the breakaway.
3. Prior to sliding the scuff guard into place, re-connect and tighten breakaway, with proper torque, to the hose while the breakaway hex flats are still accessible. **See Figure 2.**
4. Slide the scuff guard over the breakaway hex flats. **See Figure 3.**

**NOTE:** Do not cover warning or identification labels.


**Figure 2.**



**Figure 3.**



**Permanent ID  
Information:**



**INSTALLATION INSTRUCTIONS**

**Service Tools Required:**


- 1 7/8" Crows Foot
- Gasoline Approved Container
- Petroleum Jelly or Other Suitable Lubricant
- Torque Wrench w/ 50ft-lbs Setting
- Pipe Wrench w/ Flat Jaws

**CAUTION:**

1. Always barricade work area to keep pedestrians and vehicles from accessing the dispenser.
2. Always use a gasoline approved container or test can when performing any type of preventive maintenance.
3. Before attempting to install, remove or service the A4119EVR safe break valve, turn off and tag out power to the corresponding dispenser.
4. Before attempting to install, remove or service the A4119EVR safe break valve, close the emergency impact valves located inside the base of the dispenser. Relieve the line pressure and standing fuel through the nozzle spout into a gasoline approved container by compressing the bellows and squeezing the lever.
5. If a hose retractor is used, the A4119EVR safe break valve must be attached on the nozzle side of the retractor clamp.

**IMPORTANT:** Failure to perform cautions 3 and 4 may result in a hazardous gasoline spill, damage to equipment, personal injury and/ or death.

**Pre-Inspection:**



1. Carefully unpack and remove the A4119EVR safe break valve from the shipping container and evaluate for any kind of damage.
2. Verify the fuel path o-rings located on both ends of the A4119EVR safe break valve. All o-rings must be properly secured inside the factory machined grooves.

**Pre-Installation:**



3. Lightly lubricate the fuel path o-rings using petroleum jelly or other suitable lubricant.



4. Before attempting to install the A4119EVR safe break valve onto the whip hose, verify the word "NOZZLE", which is printed on the scuff guard of the safe break valve, is on the opposite end. Verify the vapor path o-ring is properly secured onto the connector, and in good working condition. Lightly lubricate the o-ring using petroleum jelly or other suitable lubricant.



5. Before attempting to install the A4119EVR safe break valve onto the curb hose, verify the vapor path o-ring is properly secured onto the connector, and in good working condition. Lightly lubricate the o-ring using petroleum jelly or other suitable lubricant.


**IMPORTANT:** Do not use pipe thread sealant compound or Teflon tape when installing the A4119EVR safe break valve. Failure to comply will void warranty.

**Installation:**

**IMPORTANT:** If this is a new facility installation, the fueling point must be flushed into a gasoline approved container before installing the A4119EVR safe break valve. Failure to perform this procedure could result in foreign material becoming lodged inside the safe break valve's fuel path causing a reduction in fuel flow.



6. Remove the scuff guard by sliding on to the whip hose. Attach the A4119EVR safe break valve onto the whip hose connector. Tighten by hand to avoid cross threading. Take caution to avoid pinching the vapor path o-ring.



**IMPORTANT:** Never tighten across the shear section of the A4119EVR safe break valve. Failure to comply will result in damage to the safe break valve and void warranty.



7. Using a 1 7/8" crows foot and torque wrench, tighten the whip hose connector to 50 ft-lbs of torque.



8. Remove the scuff guard by sliding on to the curb hose. Attach the A4119EVR safe break valve onto the curb hose connector. Tighten by hand to avoid cross threading. Take caution to avoid pinching the vapor path o-ring.



9. Using a 1 7/8" crows foot and torque wrench, tighten the curb hose connector to 50 ft-lbs of torque.

**Post Functional Tests:**

10. Carefully purge the trapped air from the fueling point. Begin dispensing by compressing the bellows and then squeezing the lever. Dispense one gallon of fuel into a gasoline approved container.
11. Functional test the automatic shutoff of the A4005EVR nozzle. Begin dispensing by compressing the bellows and then squeezing the lever. Place the hold open latch in "high" clip position to secure the lever. Dispense one gallon of fuel into a gasoline approved container. At the same time, lower the spout tip into the standing fuel until the vent hole is completely submersed. The main valve of the A4005EVR nozzle will automatically close causing fuel flow to stop.

**IMPORTANT:** Perform step 11 a minimum of three times to assure the insertion interlock, hold open latch and the automatic shutoff of the A4005EVR nozzle are operating properly.

According to UL requirement 842, the fuel flow rate must be greater than 3 gallons per minute for the automatic shutoff to operate properly. A common problem cause of low flow rates are dirty or clogged dispenser filters.

**Post Inspection:**

12. Before placing the A4005EVR nozzle onto the dispenser cradle, inspect all hanging hardware connections for potential fuel leaks. Make proper adjustments if necessary.

**PREVENTIVE MAINTENANCE**

1. Weekly inspect the A4119EVR safe break valve, evaluate for any kind of damage. Damaged components must be replaced with factory authorized service kits.

| <u>Part Number</u> | <u>Description</u>   |
|--------------------|----------------------|
| 494748EVR          | Fuel Path O-ring Kit |

2. Weekly inspect all hanging hardware connections for potential fuel leaks.

**IMPORTANT:** Should a drive-off or incidence of customer abuse occur, follow the initial inspection and function instructions found in the installation section.

**PERFORMANCE STANDARDS & SPECIFICATIONS**

This component was factory tested to, and met the following specifications:

1. Meets ARB Material Compatibility with Fuel Blends as per Section 3.8 of CP-201.
2. TP-201.2J – Complies with the maximum allowable component pressure drop of 0.04 inches of water column @ 60 CFH.

**IMPORTANT:** Leave these installation instructions with the station owner and/or operator.



For use with Vapor Systems  
Technologies VST California Air  
Resources Board Executive  
Orders VR-203 and VR-204



**Packing List:**

(2) Fuel Path O-rings

**A4005EVR Balance  
Vapor Recovery Nozzle**



**A4119EVR Coaxial  
Safe Break Valve**



**INSTALLATION INSTRUCTIONS**

**Service Tools Required:**

- Pipe Wrench w/ Flat Jaws
- Bench Vise w/ 5" Jaw Width
- Petroleum Jelly or Other Suitable Lubricant
- Scribe Tool w/ 90 Degree Tip
- Gasoline Approved Container

**CAUTION:**

1. Always barricade work area to keep pedestrians and vehicles from accessing the dispenser.
2. Always use a gasoline approved container or test can when performing any type of preventive maintenance.
3. Before attempting to install, remove or service the A4005EVR nozzle and A4119EVR safe break valve, turn off and tag out power to the corresponding dispenser.
4. Before attempting to install, remove or service the A4005EVR nozzle and A4119EVR safe break valve, close the emergency impact valves located inside the base of the dispenser. Relieve the line pressure and standing fuel through the nozzle spout into a gasoline approved container by compressing the bellows and squeezing the lever.

**IMPORTANT: Failure to perform cautions 3 and 4 may result in a hazardous gasoline spill, damage to equipment, personal injury and/or death.**

**Pre-Inspection:**

1. Carefully unpack and remove all kitted parts from the shipping container and evaluate for any kind of damage. Verify that no parts are missing from the packing list before proceeding with the installation.

**Pre-Installation:**

2. Empty all standing fuel within the spout and bellows into a gasoline approved container before attempting to service the fuel path o-rings.



3. It is necessary to remove the A4005EVR nozzle and A4119EVR safe break valve from the curb hose during the removal and installation of the fuel path o-rings. Use the pipe wrench with flat jaws to loosen the curb hose connector. Unfasten the curb hose connector by hand from the A4005EVR nozzle to avoid cross threading.

**IMPORTANT: Drain the fuel from the hanging hardware into a gasoline approved container when removing the A4005EVR nozzle from the curb hose.**



**A4005EVR Nozzle**



**A4119EVR  
Safe Break Valve**

4. Use the bench vise to properly secure the A4005EVR nozzle or A4119EVR safe break valve during service.

**Installation:**

**Removing the Existing Fuel Path O-rings**



**A4005EVR Nozzle**



**A4119EVR  
Safe Break Valve**

5. Use the scribe tool to remove the existing fuel path o-rings.
6. Clean and remove all existing grease, fuel residue, debris, etc. from within the machined grooves.

**IMPORTANT: Properly discard all removed components.**

**Installing the New Fuel Path O-rings**



**A4005EVR Nozzle**



**A4119EVR  
Safe Break Valve**

7. Use the scribe tool to install the new fuel path o-rings. Verify that both o-rings seat properly into the machined grooves.



**A4005EVR Nozzle**



**A4119EVR  
Safe Break Valve**

8. Lightly lubricate the fuel path o-rings using petroleum jelly or other suitable lubricant.

**Post-Installation:**

9. Before attempting to reinstall the A4005EVR nozzle or A4119EVR safe break valve, please refer to the following installation instructions below.

- A4005EVR Balance Vapor Recovery Nozzle p/n 570435
- A4119EVR Coaxial Safe Break Valve p/n 569043

**PREVENTIVE MAINTENANCE**

1. Weekly inspect the A4005EVR nozzle and A4119EVR safe break valve connections for leaks or fuel residue. Replace with factory authorized service kits.

| <u>Part Number</u> | <u>Description</u>   |
|--------------------|----------------------|
| 494748EVR          | Fuel Path O-ring Kit |

**PERFORMANCE STANDARDS & SPECIFICATIONS**

This component was factory tested to, and met the following specifications:

1. Meets ARB Material Compatibility with Fuel Blends as per Section 3.8 of CP-201.

**IMPORTANT: Leave these installation instructions with the station owner and/ or operator.**

# 66CLP BALANCED BREAKAWAY

ACOPLAMIENTOS DE SEGURIDAD EQUILIBRADOS TIPO "BREAKAWAY" 66CLP

## IMPORTANT SAFEGUARDS

- For your protection, please read these safety instructions completely before installing and operating this equipment.
- Keep this manual on file for future reference.
- This manual contains material that may be required by authorities having jurisdiction to be on site at all times.
- Carefully observe all warnings, precautions and instructions for this equipment and in the operating instructions and adhere to them.



## MEDIDAS PREVENTIVAS IMPORTANTES

- Para su protección, lea completamente estas instrucciones de seguridad antes de instalar y operar este equipo.
- Mantenga archivado este manual para futuras consultas.
- Las autoridades con jurisdicción pueden exigir que el material de este manual esté in situ en todo momento.
- Observe y cumpla cuidadosamente todas las advertencias, precauciones e instrucciones de este equipo, y siga las instrucciones para el funcionamiento del equipo.



**THIS MANUAL MUST BE LEFT WITH FACILITY MANAGEMENT  
 ESTE MANUAL DEBE ESTAR EN POSESIÓN DEL ENCARGADO DE LA INSTALACIÓN**

**WARNINGS & INSTRUCTIONS/ADVERTENCIAS E INSTRUCCIONES ..... Page/Página 2**

**INSTALLATION/INSTALACIÓN ..... Pages/Páginas 2**

**DRIVE OFF PROCEDURE/PROCEDIMIENTO DE PUESTA EN MARCHA .....Pages/Páginas 3-5**

**MAINTENANCE/MANTENIMIENTO ..... Page/Página 6**

|   |  |
|---|--|
| <b>SITE NAME:</b>                             |  |
| <b>NOMBRE DEL SITIO:</b>                      |  |
| <b>ADDRESS:</b>                               |  |
| <b>DIRECCIÓN:</b>                             |  |
| <b>SERIAL NUMBER OR BREAKAWAY:</b>            |  |
| <b>NÚMERO DE SERIE DE O BREAKAWAY:</b>        |  |
| <b>DATE OF INSTALLATION:</b>                  |  |
| <b>FECHA DE INSTALACIÓN:</b>                  |  |
| <b>CONTRACTOR IN CHARGE OF THE FACILITY:</b>  |  |
| <b>CONTRATISTA A CARGO DE LA INSTALACIÓN:</b> |  |

Please visit OPW's website: [www.opwglobal.com](http://www.opwglobal.com) for further information or contact OPW Customer Service at 1-800-422-2525 (US)  
 Visite el sitio web de OPW: [www.opwglobal.com](http://www.opwglobal.com) para más información o comuníquese con el Servicio al Cliente de OPW al 1-800-422-2525 (EE. UU.)

|   |   |
|---|---|
|   | <b>WARNING</b>  |
|   | <p>Failure to comply with the following warnings could result in property damage, injury or death.</p>  |
|   | <p><b>Fire Hazard</b><br/>Do not use power tools (Class I Division I and Class I Division II) during installation process and maintenance of equipment.</p> |
|   | <p><b>Chemical Exposure Hazard</b><br/>Always wear appropriate safety equipment during installation or maintenance of equipment.</p>                        |
| <p><b>Fire Hazard</b><br/>Do not install an unlisted ad/billboard or other unlisted after-market device on any automatic nozzle. Doing so may change the sensitivity of the shut-off mechanism. Nozzle may not shut off, causing a fuel spill. Reference: sensitivity test per Underwriters Laboratories specification UL842.</p> |   |

|  |   |
|--|---|
|  | <b>ADVERTENCIA</b>  |
|  | <p>El incumplimiento de las siguientes advertencias puede provocar daños a la propiedad, lesiones e incluso la muerte.</p>  |
|  | <p><b>Peligro de incendio</b><br/>No utilice herramientas eléctricas (Clase I División I y Clase I División II) durante el proceso de instalación y mantenimiento del equipo.</p> |
|  | <p><b>Peligro de exposición a sustancias químicas</b><br/>Use siempre equipo de seguridad adecuado durante la instalación o el mantenimiento del equipo.</p>                      |
| <p><b>Peligro de incendio</b><br/>No instale anuncios, carteleras ni dispositivos accesorios no autorizados en ninguna pistola surtidora automática. Si lo hace puede cambiar la sensibilidad del mecanismo de cierre. La pistola podría no cerrarse y provocar un derrame de combustible. Consultar: prueba de sensibilidad según la especificación UL842 de Underwriters Laboratories.</p> |   |

**WARNINGS**



- Dispensing system must be tested to determine if a maximum separation force of 350 pounds would damage it.
- Dispenser must be securely attached to the dispensing island.
- Keep gasoline away from your eyes and skin.
- Keep gasoline out of reach of children.

**PREPARATION AND TEST**

- Attach a spring scale to the location where the breakaway will be installed (see FIG 1).
- Apply a 350 pound pull-force at various angles to the dispenser.
- Check emergency valves, dispenser, and hose assemblies for damage.
- If there is no damage, the installation is ready for breakaways.

**INSTALLATION – HIGH HOSE MPD**

- Orient breakaway based on flow arrow on outside cover.
- Install breakaway into whip hose from the dispenser first (see FIG 2).
- Use flats at top of breakaway to tighten.
- Tighten breakaway connection to 50 foot-pounds torque.
- Install long hose into bottom of breakaway.
- Use flats at bottom of breakaway to tighten.
- Tighten breakaway connection to 50 foot-pounds torque.
- Do not wrench across the body of the breakaway.
- Do not over-tighten.
- If a separation occurs, see reconnection section on page 3.




Figure 1/Figura 1




Figure 2/Figura 2

**ADVERTENCIAS**

- El sistema de provisión debe comprobarse para determinar si una máxima fuerza de separación de 350 libras le ocasionaría daños.
- El surtidor deberá estar conectado firmemente a la plataforma de provisión.
- Mantenga la gasolina lejos de los ojos y la piel.
- Mantenga la gasolina fuera del alcance de los niños.

**PREPARACIÓN Y PRUEBA**

- Conecte una báscula a resorte en el lugar en donde se instalará el acoplamiento de seguridad tipo "breakaway" (consulte la FIG. 1).
- Aplique una fuerza de tracción de 350 libras a diversos ángulos al surtidor.
- Revise las válvulas de emergencia, el surtidor y los conjuntos de mangueras en busca de daños.
- Si no hay daños, la instalación está lista para la colocación de los acoplamientos de seguridad.

**INSTALACIÓN – ALTO MPD DE LA MANGUERA**

- Oriente el acoplamiento de seguridad tipo "breakaway" según la flecha de flujo sobre la cubierta externa.
- Instale el acoplamiento de seguridad tipo "breakaway" en la manguera flexible primero desde el surtidor (consulte la FIG. 2).
- Utilice las piezas planas en la parte superior del acoplamiento de seguridad tipo "breakaway" para apretarlo.
- Apriete la conexión del acoplamiento de seguridad tipo "breakaway" hasta una torsión de 50 pies-libras.
- Instale la manguera larga en la parte inferior del acoplamiento de seguridad tipo "breakaway".
- Utilice las piezas planas en la parte inferior del acoplamiento de seguridad tipo "breakaway" para apretarlo.
- Apriete la conexión del acoplamiento de seguridad tipo "breakaway" hasta una torsión de 50 pies-libras.
- No apriete con llave el cuerpo del acoplamiento de seguridad tipo "breakaway".
- No apriete demasiado.
- Si se produce una separación, consulte la sección de reconexión en la página 3.

The following maintenance may be performed by the GDF owner/operator or any authorized service contractor

El siguiente mantenimiento puede ser realizado por el propietario/operador del GDF o por cualquier contratista de servicio autorizado



**WARNING**

It will require at least 40-50 lbs. of effort to re-connect the breakaway. An optional clamping tool is available (purchased separately) to make the re-connection process easier. If you have any questions or concerns, STOP and contact an authorized service contractor.



**ADVERTENCIA**

Se requerirán al menos 40-50 lbs. de esfuerzo para reconectar el acoplamiento de seguridad tipo "breakaway". Se dispone de una herramienta opcional de apriete (se compra por separado) para facilitar el proceso de reconexión. Si tiene preguntas o inquietudes, DETÉNGASE y póngase en contacto con un contratista de servicio autorizado.



**WARNING**

Some residual pressure may be present on the dispenser side of the separated breakaway – use caution when removing. A small amount of gasoline may leak out of the connection – a towel wrapped loosely around the breakaway can help minimize fuel spills.



**ADVERTENCIA**

Puede haber alguna presión residual del lado del surtidor del acoplamiento de seguridad tipo "breakaway" separado – tenga cuidado al desmontarlo. Puede haber fugas de una pequeña cantidad de gasolina en la conexión – una toalla envuelta de manera floja alrededor del acoplamiento de seguridad tipo "breakaway" puede ayudar a minimizar los derrames de combustible.

**BREAKAWAY RECONNECTION PROCEDURE**

**PROCEDIMIENTO DE RECONEXIÓN DEL ACOPLAMIENTO DE SEGURIDAD TIPO "BREAKAWAY"**

1. Verify the dispenser is not authorized/activated.
2. Remove both halves of the breakaway from the hose.
3. Perform visual inspection of the breakaway body components.
  - a. If the "Spud" assembly (see FIG 3, page 4) is damaged beyond repair, the entire breakaway will need to be replaced.
  - b. If the "Body" assembly (see FIG 3, page 4) is damaged beyond repair, the entire breakaway must be replaced.
  - c. Ensure the "spring" is not damaged or missing (see FIG 3, page 4).
4. Replace damaged and missing breakaway components.
  - a. The O-ring will need to be replaced every time breakaway separation occurs, replace with part number 204870.
  - b. If the Spring is damaged (or missing), replace with part number 204872.
  - c. If the Plastic Sleeve is damaged, replace with part number 204811.


1. Verifique que el surtidor no esté autorizado/activado.
2. Desmante ambas mitades del acoplamiento de seguridad tipo "breakaway" de la manguera.
3. Realice una inspección visual de los componentes del cuerpo del acoplamiento de seguridad tipo "breakaway".
  - a. Si el ensamble con el "relieve" (consulte la FIG. 3, página 4) está dañado sin posibilidad de reparación, deberá reemplazarse todo el acoplamiento de seguridad tipo "breakaway".
  - b. Si el ensamble con el "cuerpo" (consulte la FIG. 3, página 4) está dañado sin posibilidad de reparación, deberá reemplazarse todo el acoplamiento de seguridad tipo "breakaway".
  - c. Asegúrese de que el "muelle" no esté dañado o falte (consulte la FIG. 3, página 4).
4. Reemplace los componentes dañados o faltantes del acoplamiento de seguridad tipo "breakaway".
  - a. El aro tórico deberá reemplazarse cada vez que ocurra una separación del acoplamiento de seguridad tipo "breakaway", reemplace con el número de pieza 204870.
  - b. Si el muelle está dañado (o falta), reemplace con el número de pieza 204872.
  - c. Si el manguito plástico está dañado, reemplace con el número de pieza 204811.

5. Re-connection procedure:

- a. Lubricate the O-ring with petroleum jelly or silicone grease.
  - b. Push the "spud" into the "body" by applying increasing force while wiggling the "spud" in a rotating motion until it enters the spring in the "body".
  - c. Align the pins with slots and continue pushing the "spud" into the "body" until they latch together. The pins should be in the bottom of the slot. See "connected" picture in FIG 3.
  - d. Use a ratchet style one-handed bar clamp such as Bessey part number DU030-8 (Grainger part number 6XE60) or equivalent to compress the two halves together (see FIG 4).
6. Reinstall the breakaway onto the hose ends, making sure that the arrow on the label is pointing toward the nozzle.
7. Authorize the dispenser and perform functional testing, refer to VST IOM 5.

5. Procedimiento de reconexión::

- a. Lubrique el aro tórico con vaselina o grasa silícónica.
  - b. Empuje el "relieve" en el "cuerpo" aplicando una fuerza creciente mientras desplaza suavemente el "relieve" con un movimiento rotativo hasta que ingrese el muelle en el interior del "cuerpo".
  - c. Alinee los pasadores con las ranuras y continúe empujando el "relieve" al interior del "cuerpo" hasta que se enganchen entre sí. Los pasadores deben llegar al fondo de la ranura. Consulte la ilustración del dispositivo "conectado" en la FIG. 3.
  - d. Utilice una abrazadera de barra de tipo trinquete, de uso con una mano, tal como el número de pieza de Bessey DU030-8 (número de pieza de Grainger 6XE60) o equivalente para comprimir las dos mitades entre sí (consulte la FIG. 4).
6. Vuelva a colocar el acoplamiento de seguridad tipo "breakaway" en los extremos de la manguera, asegurándose de que la flecha en la etiqueta esté orientada hacia la boquilla.
7. Autorice el surtidor y realice las pruebas funcionales; consulte VST IOM 5.



Please visit OPW's website: [www.opwglobal.com](http://www.opwglobal.com) for further information or contact OPW Customer Service at 1-800-422-2525 (US)  
Visite el sitio web de OPW: [www.opwglobal.com](http://www.opwglobal.com) para más información o comuníquese con el Servicio al Cliente de OPW al 1-800-422-2525 (EE. UU.)

9-20

ARB Approved IOM 9 -EVR Balance Breakaways VR-203 and VR-204  
IOM 9-EVR aprobado por ARB para acoplamientos de seguridad tipo "breakaway" equilibrados modelos VR-203 y VR-204





**Figure 4/Figura 4**

The following is to be completed by the individual reconnecting the breakaway:

I, \_\_\_\_\_, hereby declare that I have followed these instructions per the manufacturer's recommendations on this day \_\_\_\_\_, in the month of \_\_\_\_\_, 2012

Lo siguiente deberá ser completado por el individuo que reconecta el acoplamiento de seguridad tipo "breakaway":

Yo, \_\_\_\_\_, por este medio declaro que he seguido estas instrucciones de acuerdo con las recomendaciones del fabricante el día \_\_\_\_\_ del mes de \_\_\_\_\_ de 2012

| <b>Maintenance Log Instructions / Instrucciones del registro de mantenimiento</b>   |  |   |   |
|---|--|---|---|
| <ul style="list-style-type: none"> <li>• For each repair or product change out, complete an entry on this form. / Haga una anotación en este formulario para cada reparación o cambio de producto.</li> <li>• For each new alarm condition on the station's monitoring system, complete an entry on this form. / Haga una anotación en este formulario para cada condición de alarma del sistema de supervisión de la estación.</li> </ul>  |  |   |   |
| <p><b>Repair Logs</b>, which shall include: / <b>Registros de reparaciones</b>, que deben incluir:</p> <p>(i) Date and time of each repair. / Fecha y hora de cada reparación.</p> <p>(ii) The name of person(s) who performed the repair, and if applicable, the name, address and phone number of the person's employer. / Nombre de la(s) persona(s) encargada(s) de la reparación y, si corresponde, nombre, dirección y número de teléfono de la empresa.</p> <p>(iii) Description of services performed. / Descripción de los servicios realizados.</p> <p>(iv) Each component that was repaired, serviced, or removed, including the required component identification information. <i>Example: manufacturer and product serial number.</i> Componentes reparados, revisados o retirados, incluidos los datos de identificación de cada uno de ellos. <i>Ejemplo: fabricante y número de serie del producto.</i></p> <p>(v) Each component that was installed as replacement, if applicable, including the required component identification information. <i>Example: manufacturer and product serial number.</i> / Repuestos instalados (si corresponde), incluidos los datos de identificación de cada uno de ellos. <i>Ejemplo: fabricante y número de serie del producto.</i></p> <p>(vi) Receipts for parts used in the repair and, if applicable, work orders, which shall include the name and signature of the person responsible for performing the repairs. / Recibos de los repuestos utilizados y, si corresponde, órdenes de trabajo con nombre y firma de la persona responsable de la reparación.</p> |  |   |   |
| <p><b>ALL repairs should be logged! / Se deben anotar TODAS las reparaciones</b></p> <p>Whether the new equipment is from the station's own stock or from a maintenance company, everything should be entered into the daily repair log. / Haga todas las anotaciones necesarias en el registro diario de reparaciones, tanto si los repuestos proceden del almacén de la estación como de una empresa de mantenimiento.</p>  |  |   |   |
| Date of Problem (MM/DD/YY) / Fecha del problema (MM/DD/AA)  | Description of Defect, Alarm or Spill / Descripción del defecto, la alarma o el derrame  | Date/Time of Repair/Remedy (MM/DD/YY) / Fecha y hora de la reparación/intervención (MM/DD/AA) | Description of Repair or Remedy / Descripción de la reparación o intervención. Anote cada componente reparado, sustituido y/o instalado e incluya la marca, el modelo y el número de serie de los componentes antiguos y nuevos |
| 4/1/00  | Nozzle #: 3 / Pistola nº: 3<br>Grade of Gas: 87 / Octanaje: 87<br>Nozzle spout for 3-87 out of round, Called repair company on 4/1. / Pérdida de circularidad en la boquilla de la pistola 3-87, Llamada a la empresa de mantenimiento el 1/4. | 4/2/00<br>3:30 pm   | Replaced OPW 11VAI-69 nozzle serial #456789 with new OPW 11VAI-69 nozzle serial #458901. / Cambio de pistola OPW 11VAI-69 (nº serie 456789 por nueva pistola OPW 11VAI-69 (nº serie 458901).                                    |
|   | Nozzle #: / Pistola nº:<br>Grade of Gas: / Octanaje:   |   | Name/Company/Address / Who Performed the Repair / Nombre/Empresa/Dirección / Número de teléfono de la persona encargada de la reparación<br>Tom Smith, ABC Nozzle Co.<br>1111 E. Fourth Ave.<br>La Habra, CA<br>560-345-6789    |
|   | Nozzle #: / Pistola nº:<br>Grade of Gas: / Octanaje:   |   |   |

Please visit OPW's website: [www.opwglobal.com](http://www.opwglobal.com) for further information or contact OPW Customer Service at 1-800-422-2525 (US)  
Visite el sitio web de OPW: [www.opwglobal.com](http://www.opwglobal.com) para más información o comuníquese con el Servicio al Cliente de OPW al 1-800-422-2525 (EE. UU.)

# Installation Manual

ECS Membrane Processor: PMC and ISD

Part: VST ECS-CS3-310 – Three Phase  
VST-ECS-CS3-110 – Single Phase

Executive Orders: VR-203-P  
VR-204-P

Version: 4.5

*Vapor Systems Technologies, Inc.*  
650 Pleasant Valley Drive  
Springboro, Ohio 45066  
937-704-9333 PH  
937-704-9443 FX  
[www.vsthose.com](http://www.vsthose.com)

---

# Table of Contents

---

- Table of Figures .....5
- UL Declaration Notice.....6
- About VST.....7
- Notice .....7
- Safety Icons.....8
- Table of Terms & Abbreviations .....9
- 1 ECS Membrane Processor Overview.....10
  - 1.1 ECS Membrane Processor Theory of Operation .....10
  - 1.2 Overview of How the Processor Operates.....11
  - 1.3 Processor Dimensions and Weight.....11
  - 1.4 Processor Components .....12
  - 1.5 Processor Auxiliary Components.....13
  - 1.6 Explanation of VST Processor Model Numbers .....13
  - 1.7 Included with the Processor Package.....13
  - 1.8 Contractor-Supplied Components for the Processor .....13
- 2 Pre-Installation Site Survey .....19
- 3 How the Processor is Shipped .....19
- 4 Preparing the Processor for Installation .....19
- 5 Pre-Installation *Processor* Leak Test.....20
  - 5.1 Purpose .....20
  - 5.2 Preparation .....20
  - 5.3 Functional Test Procedures.....20
- 6 Site Requirements .....22
  - 6.1 Regulations / Jurisdiction.....22
  - 6.2 Snapshot of Site Requirements .....23

- 7 Ground Installation.....25
  - 7.1 Ground Installation Safety .....25
  - 7.2 Protecting the Processor .....25
  - 7.3 Ground-Mount Location .....26
  - 7.4 Setting the Concrete Pad .....28
    - 7.4.1 Processor Weight and Dimensions.....28
  - 7.5 Installing the Processor on the Concrete Pad .....29
    - 7.5.1 Soil Conditions .....29
    - 7.5.2 Following an Earthquake .....29
- 8 Roof-Top Installation.....32
  - 8.1 Roof-Top Installation Safety .....32
- 9 Canopy Top Installation .....34
  - 9.1 Canopy Top Installation Safety.....34
- 10 Vapor Piping .....36
  - 10.1 Vapor Piping Safety .....36
  - 10.2 Piping Connection Material.....36
  - 10.3 Piping Connections to the Processor.....36
    - 10.3.1 Flexible Connections.....37
  - 10.4 Trenching.....37
  - 10.5 Underground Vapor Piping Instructions .....38
  - 10.6 Vapor Inlet and Vapor Return Connections .....43
    - 10.6.1 Flexible Connections.....43
- 11 Air Outlet Connection.....44
  - 11.1 Flexible Connections .....45
  - 11.2 Underground Piping Connection.....49
  - 11.3 Storage Tank Vapor Manifolds .....49
  - 11.4 P/V Valves .....49
- 12 Electrical.....50
  - 12.1 Electrical Safety .....50
  - 12.2 Single-Phase Processor .....50
    - 12.2.1 Power Requirements for Single-Phase Electrical Service .....51
  - 12.3 Three-Phase Processor .....51
    - 12.3.1 Power Requirements for Three-Phase Electrical Service .....52
  - 12.4 Reference Information for Processor Power Requirements .....53
  - 12.5 Power for the Motors .....54
    - 12.5.1 Single-Phase Processor .....54

- 12.5.2 Three-Phase Processor ..... 54
- 12.5.3 Power for the HC Sensor in both the Single-Phase and the Three-Phase Processor ..... 54
- 12.6 Power for the Heat-Trace Cables in both Single-Phase and Three-Phase Processors..... 55
- 12.7 Power for the Motor Starter Relay Coil ..... 55
- 12.8 Optional Convenience Outlet at the Processor ..... 55
- 13 Electrical Installation..... 56**
  - 13.1 Electrical Safety ..... 56
  - 13.2 Electrical Installation Code Requirements ..... 56
    - 13.2.1 Single-Phase Processor Configuration ..... 56
    - 13.2.2 Three-Phase Processor Configuration..... 57
    - 13.2.3 Single and Three-Phase Processors ..... 58
    - 13.2.4 Wiring between the Processor and components: ..... 58
  - 13.3 Auxiliary Output Relay ..... 69
  - 13.4 HC Sensor / HC Sentry ..... 71
  - 13.5 Multiport Card for Vapor Processor Communication ..... 74
  - 13.6 Veeder-Root TLS 350 with PMC or ISD Controls ..... 76
- 14 Acceptable NEC Electrical Installation Examples ..... 77**
- 15 Post-Installation Checklist..... 85**

# Table of Figures

Figure 1: How the Processor fits into the GDF layout ..... 14

Figure 2: Processor Piping Diagram..... 15

Figure 3: ECS Vent Configurations..... 16

Figure 4: Processor Isometric Drawing (1 of 2)..... 17

Figure 5: Processor Isometric Drawing (2 of 2)..... 18

Figure 6: Processor Inlets & Outlets..... 21

Figure 7: Typical Leak Check Test Fixture..... 21

Figure 8: ECS Membrane Processor Hazardous Locations..... 27

Figure 9: Concrete Mounting Pad Dimensions..... 30

Figure 10: Processor Ground Mounting Pad..... 31

Figure 11: Processor Connections with Multiple Vent Risers ..... 39

Figure 12: Processor Connections with 2 Vent Risers..... 40

Figure 13: Processor Connections with Single Vent Riser ..... 41

Figure 14: Typical GDF Vapor Piping Diagram for Processor ..... 42

Figure 15: ECS Processor Piping Diagram ..... 46

Figure 16: ECS Vent Configuration..... 47

Figure 17: Processor Piping Connections..... 48

Figure 18: Single-Phase Wiring Schematic..... 59

Figure 19: Processor Single-Phase Wiring Diagram ..... 60

Figure 20: Processor Single-Phase ESO Wiring Diagram..... 61

Figure 21: Vacuum Pump: Single-Phase Motor Wiring Diagram..... 62

Figure 22: Blower: Single-Phase Motor Wiring Diagram..... 63

Figure 23: Processor Three-Phase Wiring Schematic..... 64

Figure 24: Processor Three-Phase Wiring Schematic..... 65

Figure 25: Processor Three-Phase ESO Wiring Diagram..... 66

Figure 26: Vacuum Pump: Three-Phase Motor Wiring Diagram..... 67

Figure 27: Blower: Three-Phase Motor Wiring Diagram..... 68

Figure 28: VR TLS Multi-Port Card Connection to HC Sentry Module ..... 70

Figure 29: HC Sentry Front & Back Views ..... 71

Figure 30: HC Sentry and HC Sensor Wiring Diagram ..... 72

Figure 31: HC Sensor and HC Sentry Pictures..... 73

Figure 32: VR TLS Multi-Port Card Connection to the HC Sentry Module ..... 74

Figure 33: HC Sentry RS-485 Cable Wiring Diagram ..... 75

Figure 34: VR TLS-350..... 76

Figure 35: Single phase electrical overview ..... 77

Figure 36: Single phase electrical room..... 78

Figure 37: Single phase electrical disconnect..... 79

Figure 38: Single phase elec. inside the ECS..... 80

Figure 39: 3-phase electrical overview..... 81

Figure 40: 3-phase electrical room ..... 82

Figure 41: 3-phase electrical disconnect ..... 83

Figure 42: 3-phase elec. inside ECS..... 84

## *UL Declaration Notice*

---

- Acceptability of the installation of the Vapor *Processor* and all associated piping, fittings, controls, etc. is not covered under the UL Listing of the ECS Membrane *Processor*.
  
- NOTE: All peripheral equipment required to activate / control these units is not covered under the UL Listing of this ECS Membrane *Processor*.
  - ▶ They should be UL Listed, have the appropriate communications protocol, not installed over or in a hazardous location, and are determined to be acceptable to the authority having jurisdiction with regards to suitability and overall installation.





## *About VST*

---

Vapor Systems Technologies, Inc. began in 1989 with the vision of One Company – One Integrated Solution.

Today, that philosophy is still in place and getting stronger. Recognizing that a healthier environment is a need and not an option, VST has dedicated its undivided attention to the ever-changing, stringent regulations that govern fugitive vapors at gasoline dispensing facilities (GDF). To this challenge, VST is committed to a continual R&D campaign of developing the most current, technologically advanced solutions to service not only the United States, but also the world.

VST specializes in the development, engineering, and manufacturing of products that are sold into the GDF segment of the petroleum industry. The VST focus provides our customers and users with exceptional products, services, and innovative solutions for improving the fueling-station experience as well as the world's air quality.

VST's product offering includes curb pump and vapor recovery hoses, safety breakaways, nozzles, and emission-control system *Processors*. The ENVIRO-LOC™ vapor-recovery product offering represents the most innovative concept in the industry for trapping fugitive vapors from the front end (vehicle refueling) to the back end (vent risers) of the GDF site.













## *Notice*

---

Vapor Systems Technologies, Inc. shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this publication.

No part of this publication may be translated to another language without the prior written consent of Vapor Systems Technologies, Inc.

## Safety Icons

|   |   |   |   |
|---|---|---|---|
|    | <p><b>ELECTRICITY</b><br/>A potential shock hazard exists. High voltage is supplied to and exists in this device.</p>   |    | <p><b>TURN POWER OFF</b><br/>Turn power off to the device and its accessories when installing and servicing the unit. Live power creates a potential spark hazard.</p>  |
|    | <p><b>EXPLOSIVE</b><br/>Gasoline and its vapors are extremely explosive if ignited.</p>                                 |    | <p><b>NO POWER TOOLS</b><br/>Sparks from electric power tools can ignite gasoline and its vapors.</p>   |
|    | <p><b>FLAMMABLE</b><br/>Gasoline and its vapors are extremely flammable.</p>  |    | <p><b>NO PEOPLE IN THE AREA</b><br/>Unauthorized people in the work area during installation and service of the device create a potential for personal injury.</p>  |
|  | <p><b>NO SMOKING</b><br/>Gasoline and its vapors can be ignited by sparks and embers of burning cigarettes.</p>         |  | <p><b>READ ALL RELATED MATERIALS</b><br/>Read, understand, and follow all instructions, warnings, and requirements before you begin work.</p>   |
|  | <p><b>NO OPEN FLAMES</b><br/>Open flames from sources like lighters and matches can ignite gasoline and its vapors.</p> |  | <p><b>USE SAFETY BARRICADES</b><br/>Unauthorized people in the work area during installation and service of the device create a potential for personal injury. Therefore, always isolate your work area by using safety cones, barricades, etc.</p> |
|  | <p><b>PINCH RISK</b><br/>Stay clear. Keeps hands and tools away from rotating machinery and moving parts.</p>           |  | <p><b>ROTATING MACHINERY</b><br/>Stay clear. Keep hands and tools away from rotating machinery.</p>   |

## *Table of Terms & Abbreviations*

|              |   |
|--------------|---|
| ASC:         | Authorized Service Contractor   |
| AQMD:        | Air Quality Management Districts  |
| ATG:         | Automatic Tank Gauge  |
| CARB:        | California Air Resources Board  |
| CDFA:        | California Department of Food & Agriculture                                   |
| CVLD:        | Continuous Vapor Leakage Detection, another name for Vapor Leak Detection     |
| ECS:         | Emissions Control System  |
| EO:          | Executive Order   |
| EVR:         | Enhanced Vapor Recovery   |
| GDF:         | Gasoline Dispensing Facility  |
| HC:          | Hydrocarbon   |
| HC IR:       | Hydrocarbon Infrared  |
| ISD:         | In-Station Diagnostics  |
| MAG Probe:   | A type (brand) of Tank Inventory Probe  |
| NEC:         | National Electric Code  |
| NFPA:        | National Fire Protection Association  |
| ORVR:        | On-Board Refueling Vapor Recovery   |
| OSHA:        | Occupational Safety Health Administration                                     |
| Permeate:    | Air return to atmosphere  |
| PLC:         | Programmable Logic Control  |
| PMC:         | Pressure Management Control   |
| Retentate:   | Vapor return to UST   |
| RVP:         | Reid Vapor Pressure   |
| TLS:         | Tank Level System   |
| TLS Console: | Veeder-Root's line of environmental monitoring consoles.                      |
| TS:          | Troubleshooting   |
| Ullage:      | Vapor space above liquid in a UST   |
| UST:         | Underground Storage Tank  |
| VCK:         | Vapor Collection Kit  |
| Veeder Root: | Manufacturer of the TLS-350   |
| VOC:         | Volatile Organic Compounds  |
| VST:         | Vapor Systems Technologies, Inc. - manufacturer of the ECS Membrane Processor |
| WC:          | Water Column  |

# 1 ECS Membrane Processor Overview

## 1.1 ECS Membrane Processor Theory of Operation

- The VST ECS membrane *Processor* does not interact directly with the other balance system hardware. It is in place to monitor and control the pressure in the UST to within limits specified by CARB.

Under conditions where the GDF is operational and the balance system hardware is functioning normally, the inherent ORVR compatibility of the balance system (when using VST's ENVIRO-LOC nozzle) will produce a predominately negative gauge pressure in the ullage space of the UST. Under these conditions the ECS membrane *Processor* will typically not need to operate.

During periods of less activity, the GDF being shut down overnight, winter fuels being present, or other conditions that promote the pressurization of the ullage space, the ECS membrane *Processor* will operate as needed to control the pressure in the ullage space to an accepted level. The ECS membrane *Processor* will turn on at an ullage pressure of +0.20 inches of water and turn it off at a pressure of -0.20 inches of water. Currently, the ECS membrane *Processor* unit is monitored and controlled through the PMC or ISD software.

- The ECS membrane *Processor* uses a type of membrane technology to enable it to selectively separate the components in the ullage vapor mixture.

Through a somewhat complex transport means, certain molecules will selectively travel in a stream from one side of the membrane to the other. This stream is referred to as the permeate stream.

In this case, predominate molecules transported across the membrane will be the primary constituents of air, which are oxygen, nitrogen, and water vapor. A small amount of the hydrocarbons present in the ullage mixture will also migrate across the membrane. Typically, permeate will contain less than 3.0% hydrocarbons. The result of this activity includes, fresh air vented to atmosphere, hydrocarbon vapors returned to the UST, and UST pressurization controlled to an acceptable level.

- The process of separation by the membrane is made possible by using two pumps, one low-pressure pump which circulates the ullage vapor mixture along one side of the membrane, and one high-vacuum pump, which creates the pressure differential needed to cause the permeate to transport across the membrane. These are the only moving parts in the system.

## 1.2 Overview of How the Processor Operates

- The Processor is a technology created for Gasoline Dispensing Facilities (GDF) to assist them in reducing the number of harmful emissions released to the atmosphere through the natural occurrence of gasoline vaporization.
- The table below lists the steps that the Veeder-Root TLS 350 and the software takes to control the Processor.

|    |  |
|----|--|
| 1. | <ul style="list-style-type: none"> <li>• When the UST system pressure rises above +0.2"WC, the <i>Processor</i> turns ON.</li> </ul>   |
| 2. | <ul style="list-style-type: none"> <li>• Through the vapor inlet pipe connection at the <i>Processor</i>, the VOC vapor is drawn into the suction side of the blower.</li> </ul>   |
| 3. | <ul style="list-style-type: none"> <li>• The blower discharges the VOC vapor into the membrane housing.</li> </ul>   |
| 4. | <ul style="list-style-type: none"> <li>• Inside the membrane housing, the VOC vapor is separated in to two air streams:                             <ul style="list-style-type: none"> <li>▶ VOC depleted air (referred to as "air")</li> <li>▶ Gasoline VOC vapor</li> </ul> </li> <li>• The membrane is designed specifically for separating air from gasoline VOC vapor.</li> </ul> |
| 5. | <ul style="list-style-type: none"> <li>• A vacuum pump draws the air from the membrane housing through a check valve.</li> </ul>   |
| 6. | <ul style="list-style-type: none"> <li>• A sample of the air flows through a hydrocarbon sensor to check the percent hydrocarbons.</li> </ul>  |
| 7. | <ul style="list-style-type: none"> <li>• From the vacuum pump, the air is vented to atmosphere via the air return.</li> </ul>  |
| 8. | <ul style="list-style-type: none"> <li>• The gasoline VOC vapor returns to the UST system via the vapor return.</li> </ul>   |
| 9. | <ul style="list-style-type: none"> <li>• When the UST system pressure drops below -0.2"WC, the <i>Processor</i> turns OFF.</li> </ul>  |

## 1.3 Processor Dimensions and Weight

| Part Number     | Unit         | Dimensions  | Weight                            |
|-----------------|--------------|---|-----------------------------------|
| VST-ECS-CS3-110 | Single-Phase | L-39" x W-27" x H-43"<br>Height includes 18" legs | 385 lbs.<br>Includes 24-lb. cover |
| VST-ECS-CS3-310 | Three-Phase  | L-39" x W-27" x H-43"<br>Height includes 18" legs | 350 lbs.<br>Includes 24-lb. cover |

## 1.4 Processor Components

| PART #   | DESCRIPTION  |
|----------|--|
| 5001-001 | Vacuum Pump/Three-Phase Motor - Shipped with Three-Phase <i>Processor</i>            |
| 5001-002 | Vacuum Pump/Single-Phase Motor - Shipped with Single-Phase <i>Processor</i>          |
| 5001-003 | Vacuum Pump Drive Coupling Rubber Insert   |
| 5002-001 | Circulating Blower / Three-Phase Motor - Shipped with Three-Phase <i>Processor</i>   |
| 5002-002 | Circulating Blower / Single-Phase Motor - Shipped with Single-Phase <i>Processor</i> |
| 5003-001 | Check-Valve Assembly   |
| 5005-001 | Membrane   |
| 5006-001 | Membrane Housing, Complete   |
| 5006-011 | O-Ring (2) Vertical Tube   |
| 5006-012 | O-Ring (2) Base Insert   |
| 5006-013 | O-Ring (2) Membrane  |
| 5007-004 | Hydrocarbon Sensor   |
| 5008-001 | Heat-Trace Cable   |
| 5008-002 | Heat Trace Power Connection Kit  |
| 5008-003 | Heat Trace End Seal Kit  |
| 5010-001 | ECS Aluminum Cover   |
| 5012-100 | Membrane Tubing  |
| 5012-101 | Blower Inlet Tubing  |
| 5012-102 | Blower Outlet Tubing   |
| 5012-103 | Vacuum Pump Inlet Tubing   |
| 5012-104 | Vacuum Pump Outlet Tubing  |
| 5012-105 | HC Return Tubing   |
| 5012-106 | HC Inlet Tubing  |
| 5012-107 | Membrane Outlet Tubing   |
| 5013-001 | Insulation   |

1.5 Processor Auxiliary Components

| PART #   | DESCRIPTION                                     |
|----------|---|
| 5015-001 | HC Sentry Interface Module w/24VDC power supply |
| 5015-002 | HC Sentry Interface Cable                       |

1.6 Explanation of VST Processor Model Numbers


- The GDF owner can choose the model number of the *Processor* based on the electrical availability at the GDF.
  - ▶ All the electrical requirements are the same, except for the motors, where the choice is between single-phase and three-phase power.
- There are two choices of Processors:
  - ▶ VST-ECS-CS3-110: Single-Phase: The single-phase refers to the motor requirements.
  - ▶ VST-ECS-CS3-310: Three-Phase: The three-phase refers to the motor requirements.

1.7 Included with the Processor Package

- ECS Membrane Processor
- Bolted to a skid
- (4) 18” attached legs
- Attached aluminum cover
- Packaged with the processor in a separate, smaller box:
  - ▶ HC Sentry Module
  - ▶ 24-volt Power Supply
  - ▶ HC Sentry Interface Cable
- Owner package with warranty paperwork to be filled out and returned to VST in order to activate the warranty

1.8 Contractor-Supplied Components for the Processor

|   |   |
|---|---|
| <p><b>NOTE:</b><br/>This is not an exhaustive list. There may be more components the contractor will have to supply.</p>  |   |
| <ul style="list-style-type: none"> <li>• Motor Starters</li> <li>• Locking Ball Valves</li> <li>• Locks</li> <li>• Tees</li> <li>• Piping</li> <li>• Pipe Fittings</li> <li>• Electrical</li> <li>• Electrical Fittings</li> <li>• Conduit</li> </ul> | <ul style="list-style-type: none"> <li>• Lockable Disconnect</li> <li>• Wires</li> <li>• Electrical Seal-Offs</li> <li>• Concrete</li> <li>• Veeder-Root TLS-350</li> <li>• Veeder-Root PMC or ISD Software</li> <li>• Veeder-Root Pressure Sensor</li> <li>• Veeder-Root Flow Meters (ISD only)</li> </ul> |



5567-001, Rev G

Figure 1: How the Processor fits into the GDF layout






Figure 2: Processor Piping Diagram




Figure 3: ECS Vent Configurations

Vapor Systems Technologies, Inc.  
Springboro, Ohio 45985 - www.vstnss.com

---

TITLE: Emissions Control system  
 ECS Vent Riser Configurations  
 SCALE: none  
 SHEET: 1 OF 1  
 DRAWING NO.: 5561-001  
 REV: E




Figure 4: Processor Isometric Drawing (1 of 2)




Figure 5: Processor Isometric Drawing (2 of 2)

## 2 Pre-Installation Site Survey

Vapor Systems Technologies, Inc. created a “Pre-Installation Site Survey,” as a guide to help certified installers and troubleshooters in the planning of an ECS Membrane *Processor* installation.

The “Pre-Installation Site Survey” is to be completely filled out in advance of an installation so that installation problems and delays are reduced or avoided.

You will find the “Pre-Installation Site Survey” on our website at [www.vsthose.com](http://www.vsthose.com).

## 3 How the Processor is Shipped

- The Processor is shipped with the following:
  - ▶ ECS Membrane Processor
  - ▶ Bolted to a skid
  - ▶ (4) 18” attached legs
  - ▶ Attached aluminum cover
  - ▶ HC Sentry Module
  - ▶ 24-volt power supply
  - ▶ HC Sentry Interface Cable
  - ▶ Owner package with warranty paperwork to be filled out and returned to VST in order to activate the warranty

## 4 Preparing the Processor for Installation

- Follow these steps to prepare the Processor for installation:
  1. Verify that all the items are in the shipping crate.
  2. Visually inspect all the items for any obvious damage.
  3. Before mounting the *Processor*, conduct the Pre-Installation *Processor* Leak Test.

**Be sure to conduct a Pre-Installation *Processor* Leak Test before mounting the *Processor* to verify that the *Processor* is leak tight.**

## 5 Pre-Installation *Processor* Leak Test

### 5.1 Purpose

- The purpose of the Pre-Installation Leak Test is to ensure that all of the tubing fittings and tubes located inside the ECS unit are leak-free prior to installation.

### 5.2 Preparation

- Follow these steps to prepare the ECS unit for the pre-installation leak test after the ECS unit is delivered to the GDF where it will be installed.
  1. Remove the packaging from the skid.
  2. Remove the cover from the ECS unit.

### 5.3 Functional Test Procedures

1. Place 2" NPT plugs in two of the pipe connection openings on the ECS unit. See Figure 6.
2. Install the Leak Test Fixture in the empty 2" pipe connection on the ECS unit. See Figure 7.
3. The leak check is conducted with 1.0 to 2.0 PSI nitrogen.
  - a. Make sure the isolation valve on the Leak Test Fixture is fully closed.
  - b. Make sure the Leak Test Fixture pressure regulator is fully closed.
  - c. Make sure the nitrogen regulator is set at a maximum of 10 PSI outlet pressure.
4. Slowly open the isolation valve on the test fixture to pressurize the ECS unit at 1.0 to 2.0 PSI compressed nitrogen.

**CAUTION:**

Pressurizing the ECS unit over a maximum of 5.0 PSI may cause damage to the ECS unit o-rings and/or pump seals, which will void all warranties of the ECS unit.

5. With the ECS unit pressurized between 1.0 to 2.0 PSI compressed nitrogen, spray a soapy solution on each fitting to check for bubbles:
  - a. If bubbles do not appear, the connection is tight.
  - b. If bubbles do appear, tighten the leaking fitting 1/8" turn (maximum) and re-check for leaks.
  - c. If the fitting cannot be tightened so that the connection is leak free, replace the 45° flare tube assembly that is leaking with a new tube assembly.
6. Continue this process until all the internal tube fittings have been checked and found leak free.
7. Once this test is complete and all the piping fittings are leak free, remove the compressed nitrogen connection to the Leak Test Fixture.
8. Remove the two 2" NPT plugs and the Leak Test Fixture.
9. The ECS Unit is now ready to install.



Figure 6: Processor Inlets & Outlets



Figure 7: Typical Leak Check Test Fixture

## 6 Site Requirements



Be sure to read and understand all site requirements before beginning an installation.

### 6.1 Regulations / Jurisdiction

- Under vapor recovery rules, air pollution control districts have primary authority for regulating GDF's.
  - ▶ Before modifying the facility, GDF operators should contact the local air district for specific information on local vapor-recovery requirements.
  - ▶ Contact information for local air pollution control districts is available on the air district permit to operate (PTO) and/or the California Air Pollution Control Officers Association (CAPCOA) website at <http://www.capcoa.org>.
- The area inside the *Processor* cover has been evaluated as a Class I, Division 2 hazardous area as defined by Underwriters Laboratory.
- The *Processor* must not be installed in a Class I, Division 1 or a Class I, Division 2 hazardous location as defined by the NEC (National Electric Code).
  - ▶ Because the area inside the *Processor* cover has been evaluated as a Class I, Division 2 hazardous location, be sure that all existing electrical seal-offs continue to meet NEC and NFPA requirements after installation of the *Processor*.

**CAUTION**

Always obtain approval from the local authority having jurisdiction.

Installation of the *Processor* must comply with (if applicable):

- CARB CP-201
- VST EVR E.O.
- Fire Marshal
- Water Board
- Local Air Pollution District
- ICC
- NEC
- NFPA 30 and 30A
- UL
- Any other applicable federal, state, and local codes



## 6.2 Snapshot of Site Requirements

|   |   |  |
|---|---|--|
| <p><b><u>Local Air Pollution Control District</u></b></p> <ul style="list-style-type: none"> <li>GDF must contact the local air pollution control district for specific local vapor-recovery requirements.</li> </ul> <p><b><u>Ground-Mount Location</u></b></p> <ul style="list-style-type: none"> <li>The local jurisdiction must allow the <i>Processor</i> to be placed on the ground.</li> <li>The <i>Processor</i> must be protected from damage.</li> <li><i>Processor</i> must be located at least 10' from the property line.</li> <li><i>Processor</i> must be within 100' of the vent risers.</li> </ul> <p><b><u>Roof-Mount Location</u></b></p> <ul style="list-style-type: none"> <li>The local jurisdiction must allow the <i>Processor</i> to be placed on the roof.</li> <li>Structure must be strong enough to hold the weight of the <i>Processor</i>:             <ul style="list-style-type: none"> <li>▶ Three-phase 350 lbs. (Incl. alum. cover wt.).</li> <li>▶ Single-phase 385 lbs. (Incl. alum. cover wt.).</li> </ul> </li> <li>VST recommends a 18" perimeter around the <i>Processor</i> for maintenance and testing.</li> <li>The height of the <i>Processor</i> must be above the building parapet to allow for the proper vapor-piping slope.</li> </ul> | <p><b><u>Canopy-Mount Location</u></b></p> <ul style="list-style-type: none"> <li>The local jurisdiction must allow the <i>Processor</i> to be placed on the canopy.</li> <li>Structure must be strong enough to hold the weight of the <i>Processor</i>:             <ul style="list-style-type: none"> <li>▶ Three-phase 350 lbs. (Incl. alum. cover wt.).</li> <li>▶ Single-phase 385 lbs. (Incl. alum. cover wt.).</li> </ul> </li> <li>VST recommends a 18" perimeter around the <i>Processor</i> for maintenance and testing.</li> <li>All safety and code concerns have been addressed.</li> </ul> <p><b><u>Three Phase Electric</u></b></p> <ul style="list-style-type: none"> <li>3 empty breaker spaces 208/230-460v panel for blower and vacuum pump motors.             <ul style="list-style-type: none"> <li>▶ (1) 115v breaker for the heat-trace cable.</li> <li>▶ (1) 115v outlet for the HC sentry.</li> <li>▶ GFCI protected, weatherproof, 115v convenience outlet located at the <i>Processor</i> is optional.</li> </ul> </li> <li>2-hp vacuum pump / 1/2-hp blower.</li> </ul> <p><b><u>Single Phase Electric</u></b></p> <ul style="list-style-type: none"> <li>2 empty 115v breaker spaces in the panel for the blower and vacuum pump motors.             <ul style="list-style-type: none"> <li>▶ (1) 115v breaker for the heat-trace cable.</li> <li>▶ (1) 115v outlet for the HC sentry.</li> <li>▶ GFCI protected, weatherproof, 115v convenience outlet located at the <i>Processor</i> is optional.</li> </ul> </li> <li>2-hp vacuum pump / 1/2-hp blower.</li> </ul> | <p><b><u>Vent Risers</u></b></p> <ul style="list-style-type: none"> <li>Recommended slope of 1/4" per foot on all vapor-piping connecting the <i>Processor</i> to the vent risers or to any other UST connection. (VST requires a minimum of 1/8" per foot minimum slope for all vapor piping.)</li> <li>The maximum distance the <i>Processor</i> can be from the vent risers is 100-feet.</li> <li>Any type of trap, regardless of the <i>Processor</i> location, is not permitted in any vapor lines connected to the <i>Processor</i>.</li> <li>To install the <i>Processor</i>, there must be two vent risers connected at different locations to the UST's or to the underground vapor piping.</li> <li>If only one vent riser exists, another one must be added. Trenching to a UST or underground vapor piping is required in order to add the second vent riser.</li> <li>A 5' radius around the vent riser P/V valve is a Class I, Div. 2 hazardous area as defined in NFPA 70.</li> </ul> |
|---|---|--|

Snapshot of Site Requirements, continued . . .

|   |  |   |
|---|--|---|
| <p><b><u>UST Manifolding</u></b></p> <ul style="list-style-type: none"> <li>• UST's must be manifolded below ground.</li> <li>• There must be at least two separate vent lines, which are not manifolded together.</li> </ul> | <p><b><u>Dispenser</u></b></p> <ul style="list-style-type: none"> <li>• Must be a Balance dispenser.</li> <li>• The dispenser vapor piping must be sized adequately to meet the maximum pressure drop requirement, Item 1 of the Vapor Collection section. A minimum one inch (1") nominal internal diameter for the vapor down-pipe is recommended.</li> </ul> <p><b><u>Veeder-Root Controls</u></b></p> <ul style="list-style-type: none"> <li>• Must have TLS-350 with Veeder-Root software installed.</li> </ul> | <p><b><u>CARB Requirements</u></b></p> <ul style="list-style-type: none"> <li>• VR-203 PMC</li> <li>• VR-204 ISD</li> </ul> |
|---|--|---|

## 7 Ground Installation

### 7.1 Ground Installation Safety



- The *Processor* will be installed near locations where highly flammable and explosive gasoline vapors may be present.
- Installation of the ECS Membrane *Processor* must comply with the National Electric Code, federal, state and local codes, as well as other applicable safety codes.
- Use extreme caution due to the risk of fire or explosion, which could result in serious injury or even death.
- If you are working in an area where vehicle traffic may occur, always block off the work area during installation, testing, and service to protect yourself and others.
- Do not use power tools that can generate sparks if there is a risk of flammable or explosive vapors being present.
- Read and understand all materials related to installing, testing, and operating the *Processor* prior to installation.

### 7.2 Protecting the Processor

- Take measures to protect the *Processor* and external vapor piping from damage in areas near vehicle traffic with guards, such as concrete-filled bollards or guardrails.
  - ▶ Check local codes for protective-device guidelines before setting the bollards or guardrails.
- A fence should not be required since there is a lockable cover on the *Processor* with lockable hasps to prevent tampering. The contractor will provide the locks for the hasps.
- VST requires lockable ball valves be used at the inlet and outlet connections at the *Processor*.
  - ▶ VST does not include any locks or lockable valves for the *Processor*; therefore, the contractor must provide them.
  - ▶ Lockable ball valves used in this application must be compatible with gasoline and gasoline vapor. For further requirements, consult the lockable-valve installation instructions provided by the manufacturer.
- The *Processor* cover is designed and built to withstand snow accumulation, rain, and landscaping sprinklers.

### 7.3 Ground-Mount Location

- Location to property line: according to NFPA 30A, Section 10.1.7.1  
“. . . in no case shall the vapor-processing equipment so protected be located within 3m (10-feet) of adjacent property lines that can be built upon.”
  - ▶ Local authorities may grant reduced distance depending on the specific circumstances
- To minimize the installation cost and to maximize operating efficiency, locate the *Processor* adjacent to the existing vent risers.
- All vapor-piping connecting to the *Processor* must be sloped away from the *Processor*. VST recommends  $\frac{1}{4}$ " per foot slope. (VST requires a minimum of  $\frac{1}{8}$ " per foot slope.)
- The *Processor* must be installed in accordance with the NEC and the NFPA standards.
- VST recommends a minimum clearance of 18" around the *Processor* for maintenance and testing.
- A new air outlet vent riser connected to the *Processor* must be installed to release air to the atmosphere.
- See Figure 3.

#### CAUTION

Always obtain approval from the local authority having jurisdiction. Installation of the *Processor* must comply with (if applicable):

- CARB CP-201
- VST EVR E.O.
- Fire Marshal
- Water Board
- Local Air Pollution District
- ICC
- NEC
- NFPA 30 and 30A
- UL
- Any other applicable federal, state, and local codes




Figure 8: ECS Membrane Processor Hazardous Locations

7.4 Setting the Concrete Pad

- The *Processor* must be installed on a concrete pad, on grade, and permanently anchored to the concrete pad.
- The Processor CANNOT be installed directly on or anchored directly to asphalt. It must be installed and anchored directly to a concrete pad.
- The *Processor* can be installed on existing concrete, provided:
  - ▶ The existing concrete is of sufficient strength and thickness to support the *Processor*.
    - VST recommends a minimum of 6-inch thick concrete to accommodate 3 1/2" expansion-type anchor bolts.
    - Cracked concrete without re-bar may NOT be of sufficient strength to properly support the *Processor*.
  - ▶ The *Processor* is installed level.
- **NOTE: VST CANNOT BE HELD RESPONSIBLE FOR DAMAGE CAUSED BY IMPROPER PROCESSOR FOUNDATION SUPPORT.**
- VST does not provide any hardware to install the *Processor* on the pad.
- VST recommends using the minimum clearances listed below for maintenance and service:
  - ▶ Back: 18"
  - ▶ Front: 18"
  - ▶ Left: 18"
  - ▶ Right: 18"
- Concrete pad minimum dimensions:
  - ▶ 3'6" long x 2'6" wide
  - ▶ 6" thick (minimum)
  - ▶ See figure 9.
- Use steel re-enforced rebar in the pad for additional strength.
- Install the pad level.
- Install expansion-type bolts after completing the concrete pad. The bolts must be:
  - ▶ 3/8" diameter
  - ▶ Embedded 3 1/2" to 4" into the slab
  - ▶ Extend approx. 1 1/2" above the top of the slab

7.4.1 Processor Weight and Dimensions

| Part Number     | Unit         | Dimensions  | Weight                            |
|-----------------|--------------|---|-----------------------------------|
| VST-ECS-CS3-110 | Single-Phase | L-39" x W-27" x H-43"<br>Height includes 18" legs | 385 lbs.<br>Includes 24-lb. cover |
| VST-ECS-CS3-310 | Three-Phase  | L-39" x W-27" x H-43"<br>Height includes 18" legs | 350 lbs.<br>Includes 24-lb. cover |

## 7.5 Installing the Processor on the Concrete Pad

### 7.5.1 Soil Conditions

- The soil must have the following capabilities:
  - ▶ Allowable bearing pressure: 1000 psf
  - ▶ Lateral bearing: 150 psf
  - ▶ Coefficient of sliding: 0.25

|   |  |
|---|--|
| 1 | After the concrete has properly cured, install the expansion anchor bolts according to the manufacturer's recommendations.   |
| 2 | For non-seismic applications, VST recommends using the HILTI KWIK BOLT, KB3 3/8" X 5" / item #00282524 as shown in Figure 10 or an approved equal.   |
| 3 | <p>For applications that require expansion anchors that are especially suited to seismic and cracked concrete, VST recommends using the HILTI KWIK TZ (KB-TZ) BOLT, KB-TZ 3/8" X 5", (item number 00304583) or approved equal.</p> <ul style="list-style-type: none"><li>▶ The contractor or design engineer is responsible for sizing the expansion anchors and the concrete pad to meet seismic and cracked concrete specifications required by local, state, and federal jurisdictions.</li><li>▶ Since seismic regulations may be different by location, VST has not included a specific drawing for this application.</li><li>▶ For seismic design reference, <a href="http://www.us.hilti.com">www.us.hilti.com</a>.</li></ul> |
| 4 | After the appropriate anchor bolts have been installed, position the <i>Processor</i> onto the anchor bolts in the cement slab.  |
| 5 | Bolt the <i>Processor</i> into place (according to the manufacturer recommended installation guidelines) with 3/8" galvanized lock washers and bolts that are included with the expansion bolt.  |

### 7.5.2 Following an Earthquake

- Insure the ECS unit is level.
- All piping fitting are leak free: conduct a leak check test as outlined in the ECS operations, maintenance, & startup manual.
- Check that all the electrical fitting and connections are tight.




Figure 9: Concrete Mounting Pad Dimensions






Figure 10: Processor Ground Mounting Pad

## 8 Roof-Top Installation

### 8.1 Roof-Top Installation Safety



- The *Processor* will be installed near locations where highly flammable and explosive gasoline vapors may be present.
- Installation of the ECS Membrane *Processor* must comply with the National Electric Code, federal, state and local codes, as well as other applicable safety codes.
- Use extreme caution due to the risk of fire or explosion, which could result in serious injury or even death.
- If you are working in an area where vehicle traffic may occur, always block off the work area during installation, testing, and service to protect yourself and others.
- Do not use power tools that can generate sparks if there is a risk of flammable or explosive vapors being present.
- Read and understand all materials related to installing, testing, and operating the *Processor* prior to installation.

- The *Processor* may be installed on a station’s roof provided the structure can support the weight of the *Processor*.

| Part Number     | Unit         | Dimensions  | Weight                            |
|-----------------|--------------|---|-----------------------------------|
| VST-ECS-CS3-110 | Single-Phase | L-39" x W-27" x D-43"<br>Height includes 18" legs | 385 lbs.<br>Includes 24-lb. cover |
| VST-ECS-CS3-310 | Three-Phase  | L-39" x W-27" x D-43"<br>Height includes 18" legs | 350 lbs.<br>Includes 24-lb. cover |

- Location to property line: according to 2003 Edition of NFPA 30A, Section 10.1.6: Vapor-processing equipment shall be located “At least 3m (10 ft) from adjacent property lines that can be built upon.”
  - ▶ Local authorities may grant reduced distance depending on the specific circumstances.
- The *Processor* must not be installed within 5' of a vent riser P/V valve.
- A 5' radius around the vent riser P/V valve is a Class I, Div. 2 hazardous area as defined in NFPA 70.
- All vapor-piping connecting to the *Processor* must be sloped away from the *Processor*. VST recommends 1/4" per foot slope. (VST requires a minimum of 1/8" per foot slope.)
- Any equipment located on the roof that is rated as Class I, Div. 2 cannot be located within 10' of the *Processor*, unless the equipment is at least 18" above the roof top.

**CAUTION**

Always obtain approval from the local authority having jurisdiction. Installation of the *Processor* must comply with (if applicable):

- CARB CP-201
- VST EVR E.O.
- Fire Marshal
- Water Board
- Local Air Pollution District
- ICC
- NEC
- NFPA 30 and 30A
- UL
- Any other applicable federal, state, and local codes

- The *Processor* must be installed in accordance with the NEC and the NFPA standards.
- VST recommends a minimum clearance of 18" around the *Processor* for maintenance and testing.
- Due to a variety of roof construction designs, VST cannot recommend how the *Processor* should be mounted on the roof; however, the *Processor* must be installed at a height allowing the piping inlet and outlets to be above or through the building parapet.
- The *Processor* is shipped on 18" legs bolted on the base, but the legs may be removed and the *Processor* secured to a steel structure attached to the roof.
- A new air outlet vent riser connected to the *Processor* must be installed to release air to the atmosphere.

## 9 Canopy Top Installation

### 9.1 Canopy Top Installation Safety



- The *Processor* will be installed near locations where highly flammable and explosive gasoline vapors may be present.
- Installation of the ECS Membrane *Processor* must comply with the National Electric Code, federal, state and local codes, as well as other applicable safety codes.
- Use extreme caution due to the risk of fire or explosion which could result in serious injury or even death.
- If you are working in an area where vehicle traffic may occur, always block off the work area during installation, testing, and service to protect yourself and others.
- Do not use power tools that can generate sparks if there is a risk of flammable or explosive vapors being present.
- Read and understand all materials related to installing, testing, and operating the *Processor* prior to installation.

- The *Processor* may be installed on a station's canopy provided the structure can support the weight of the *Processor*.

| Part Number     | Unit         | Dimensions  | Weight                            |
|-----------------|--------------|---|-----------------------------------|
| VST-ECS-CS3-110 | Single-Phase | L-39" x W-27" x D-43"<br>Height includes 18" legs | 385 lbs.<br>Includes 24-lb. cover |
| VST-ECS-CS3-310 | Three-Phase  | L-39" x W-27" x D-43"<br>Height includes 18" legs | 350 lbs.<br>Includes 24-lb. cover |

- Location to property line: according to 2003 Edition of NFPA 30A, Section 10.1.6: Vapor-processing equipment shall be located
  - ▶ "At least 3m (10 ft) from adjacent property lines that can be built upon." Local authorities may grant reduced distance depending on the specific circumstances.
- The *Processor* cannot be installed within 5' of a vent riser P/V valve.
- A 5' radius around the vent riser P/V valve is a Class I, Div. 2 hazardous area as defined in NFPA 70.
- All vapor-piping connecting to the *Processor* must be sloped away from the *Processor*. VST recommends 1/4" per foot slope. (VST requires a minimum of 1/8" per foot slope).
- The *Processor* must be installed in accordance with the NEC and the NFPA standards.

### CAUTION

Always obtain approval from the local authority having jurisdiction.

Installation of the *Processor* must comply with (if applicable):

- CARB CP-201
- VST EVR E.O.
- Fire Marshal
- Water Board
- Local Air Pollution District
- ICC
- NEC
- NFPA 30 and 30A
- UL
- Any other applicable federal, state, and local codes

- VST recommends a minimum clearance of 18" around the *Processor* for maintenance and testing.
- Due to a variety of canopy construction designs, VST cannot recommend how the *Processor* should be mounted on the canopy.
- All safety and code concerns should be taken into consideration prior to a canopy-top installation.
- The *Processor* is shipped on 18" legs bolted on the base, but the legs may be removed and the *Processor* secured to a steel structure attached to the canopy or to the roof top.

**NOTE: THE MINIMUM PIPING SLOPE MUST ALWAYS BE MAINTAINED.**

- A new air outlet vent riser connected to the *Processor* must be installed to release air to the atmosphere.

## 10 Vapor Piping

### 10.1 Vapor Piping Safety



- The *Processor* will be installed near locations where highly flammable and explosive gasoline vapors may be present.
- Installation of the ECS Membrane *Processor* must comply with the National Electric Code, federal, state and local codes, as well as other applicable safety codes.
- Use extreme caution due to the risk of fire or explosion which could result in serious injury or even death.
- If you are working in an area where vehicle traffic may occur, always block off the work area during installation, testing, and service to protect yourself and others.
- Do not use power tools that can generate sparks if there is a risk of flammable or explosive vapors being present.
- Read and understand all materials related to installing, testing, and operating the *Processor* prior to installation.

### 10.2 Piping Connection Material

- All connections to the *Processor* must be galvanized pipe.

### 10.3 Piping Connections to the Processor

- There are 3 piping connections to be made to the *Processor*:
  1. Vapor inlet from the UST vapor-piping system
  2. Vapor return back to the UST vapor-piping system
  3. Air outlet to atmosphere
- The typical installation will have:
  - ▶ The *Processor* vapor inlet connected to the high-grade UST vent.
  - ▶ The *Processor* vapor return connected to the low-grade UST vent.
  - ▶ The *Processor* vapor air outlet vent riser is to be added next to the existing UST vent risers if possible.

### CAUTION

Always obtain approval from the local authority having jurisdiction.

Installation of the *Processor* must comply with (if applicable):

- CARB CP-201
- VST EVR E.O.
- Fire Marshal
- Water Board
- Local Air Pollution District
- ICC
- NEC
- NFPA 30 and 30A
- UL
- Any other applicable federal, state, and local codes

### 10.3.1 Flexible Connections

- Flexible connections between the *Processor* locking ball valves and the vent riser(s) are allowable if required by the local Authority Having Jurisdiction to meet seismic requirements.
- Should the flex connection be installed such that it is not supported, the slope of the flex connection from the *Processor* back to the vent riser(s) shall be greater than the 1/8" / foot slope required for the rest of the one-inch galvanized piping.
- The flexible connector must be UL approved for a service station above-ground application.
- The local contractor is responsible to provide all necessary galvanized piping, non-hardening UL-classified pipe joint compound and plumbing fittings.
- This requirement may apply for ground, rooftop, and canopy-mount locations.

## 10.4 Trenching

- The *Processor* may be installed without any trenching provided:
  - ▶ There are at least 2 vent risers connected to the UST's.
  - ▶ The vent-riser piping connecting to the UST's will not short circuit the *Processor*.
- Trenching will be required if only one vent riser exists at the GDF to connect the *Processor* to the UST's.
  - ▶ When one vent riser exists at a GDF, trenching is required to return the concentrated vapor from the *Processor* to the UST's.
  - ▶ The existing vent riser will be used as the "Vapor Inlet" connection to the *Processor*.
  - ▶ A new vent riser must be installed that connects the *Processor* to the UST's.
    - The connection pipe must be a minimum of 2" ID for all underground piping.
    - All new piping must be sloped back to the UST's.
    - VST recommends a 1/4" per foot slope away from the *Processor* for all vapor piping connecting the *Processor* to the UST vent risers or to any other UST connection points. A minimum of 1/8" slope is required by VST.
    - The connection location to the UST's must be configured to prevent short-circuit of the inlet vapor piping to the *Processor*.
    - The connection should be used as the "Vapor Return" piping returning the concentrated vapor from the *Processor* to the Low Octane UST.

### 10.5 Underground Vapor Piping Instructions

- From the dispenser to the UST:
  - ▶ A minimum of 2" ID is acceptable unless the dispenser lines are manifolded together.
  - ▶ Manifolded dispenser lines require a minimum 3" ID piping, including the float-vent valve, if applicable.
  - ▶ Check the "Vapor-Recovery Piping Configurations" section of Exhibit 2 for Underground Piping Requirements.
  
- From the UST to the vent riser
  - ▶ Stations that use only one vent riser require a minimum of 3" ID vapor piping and will require trenching as well.
  - ▶ Stations that use multiple risers require a minimum of 2" ID vapor piping.
  
- From the *Processor* vapor return to the UST
  - ▶ When new underground piping is required from the *Processor* vapor return to the low octane UST, VST requires a minimum of 2" ID piping.

**CAUTION**

Always obtain approval from the local authority having jurisdiction.

Installation of the *Processor* must comply with (if applicable):

- CARB CP-201
- VST EVR E.O.
- Fire Marshal
- Water Board
- Local Air Pollution District
- ICC
- NEC
- NFPA 30 and 30A
- UL
- Any other applicable federal, state, and local codes






Figure 11: Processor Connections with Multiple Vent Risers




Figure 12: Processor Connections with 2 Vent Risers




Figure 13: Processor Connections with Single Vent Riser




Figure 14: Typical GDF Vapor Piping Diagram for Processor

## 10.6 Vapor Inlet and Vapor Return Connections

- Install a minimum 1" galvanized pipe between the *Processor* and the vent riser(s) if the distance between the *Processor* and the vent riser is less than 10'.
  - If the distance between the *Processor* and vent risers is greater than 10', use a minimum 1 ½" diameter pipe.
  - See Figure 15 for pipe size requirements.
  - When new underground piping is required from the *Processor* to the low-octane UST, a minimum of 2" ID piping is required.
  - Order of installation:
    1. Processor
    2. Tee (sized for the pipe diameter)
    3. Ball Valve (sized for the pipe diameter)
    4. Union (sized for the pipe diameter)
    5. Vent Riser
- The tee and the ball valve allow for isolation of the *Processor* from the vapor-piping system for maintenance and testing. See Figure 17.
- Provide a slope for the piping from the *Processor* of at least ¼" per foot.
    - ▶ VST requires a minimum slope of 1/8" per foot.
  - Verify that all piping connections are leak tight.
  - Connect the vapor inlet and vapor return for the *Processor* to existing vent risers provided there are multiple vent risers connecting to individual USTs.
  - Install new tees in the existing vent risers for connection to the *Processor* vapor inlet & outlet.
  - Take note that pipe connecting vent risers to the *Processor* **MUST** slope away from the *Processor* towards the vent risers.


### 10.6.1 Flexible Connections

- Flexible connections between the Processor locking ball valves and the vent riser(s) are allowable if required by the local Authority Having Jurisdiction to meet seismic requirements.
- Should the flex connection be installed such that it is not supported, the slope of the flex connection from the Processor back to the vent riser(s) shall be greater than the 1/8" / foot slope required for the rest of the one-inch galvanized piping.
- The flexible connector must be UL approved for a service station above-ground application.
- The local contractor is responsible to provide all necessary galvanized piping, non-hardening UL-classified pipe joint compound, and plumbing fittings.
- This requirement may apply for ground, rooftop, and canopy-mount locations.

## 11 Air Outlet Connection

- Install a minimum 1" tee and 1" lockable ball valve between the *Processor* and the new vent riser in the order of:

1. Processor
2. Tee (sized for the pipe diameter)
3. Ball Valve (sized for the pipe diameter)
4. Union (sized for the pipe diameter)
5. Vent Riser



See Figure 15.

- Be sure to follow the same height and location criteria for the additional vent riser that has been used for the existing vent pipes.
  - ▶ The tee and the valve allow for isolation of the *Processor* from the vapor-piping system for maintenance and/or testing as needed.
  - ▶ Verify that all piping connections are leak tight.
- Install a new tee with a cap at the bottom of the new air outlet vent riser to provide for drainage.
- Install the new dedicated vent riser so that the discharge opening is a minimum of 12-feet above grade and a minimum of 1" diameter.
- Be sure to slope the air outlet vent-riser discharge pipe downward away from the *Processor*.
  - ▶ VST recommends a  $\frac{1}{4}$ " per foot slope away from the *Processor* for all vapor piping connecting the *Processor* to the UST vent risers or to any other UST connection points. A minimum of  $\frac{1}{8}$ " slope is required by VST.
- A rain cap or equivalent valve must be installed on the air outlet vent riser to shield against rain and reduce noise. If a PV vent valve is used, the internal components should be removed to allow open venting to the atmosphere.
- The air outlet discharge creates a hazardous location per the NFPA 30A, therefore:
  - ▶ Class I, Group D, Division 1 is within 3 feet in all directions of the vent opening.
  - ▶ Class I, Group D, Division 2 is within 3 to 5 feet in all directions of the vent opening.
- The new vent riser may be installed next to the existing vent risers.

## 11.1 Flexible Connections

- Flexible connections between the Processor locking ball and the vent riser(s) are allowable if required by the local Authority Having Jurisdiction to meet seismic requirements.
- Should the flex connection be installed such that it is not supported, the slope of the flex connection from the Processor back to the vent riser(s) shall be greater than the 1/8" / foot slope required for the rest of the one-inch galvanized piping.
- The flexible connector must be UL approved for a service station above-ground application.
- The local contractor is responsible to provide all necessary galvanized piping, non-hardening UL-classified pipe joint compound and plumbing fittings.
- This requirement may apply for ground, rooftop, and canopy-mount locations.





Figure 15: ECS Processor Piping Diagram





|  |   |
|--|---|
| <b>VST</b>   | Vapor Systems Technologies, Inc.<br>Springboro, Ohio 45066<br>www.vstohio.com |
| TITLE<br>Emissions Control system<br>ECS Vent Riser Configurations |   |
| SCALE<br>1" = 1'   | DWG. NO.<br>5561-001  |
| SHEET<br>1   | REV<br>E  |

Figure 16: ECS Vent Configuration




Figure 17: Processor Piping Connections

## 11.2 Underground Piping Connection

- Provide a slope for the vapor piping for drainage. VST recommends a ¼” per foot slope for all vapor piping. A minimum of 1/8” slope is required by VST.
- Meet all CP-201 size and slope requirements for all underground piping.
  - ▶ To avoid the possibility of an underground liquid trap, never use flexible vapor piping.
  - ▶ VST recommends a Wet Blockage Test on the vent piping to guarantee there are no unknown traps in the vapor piping. Methodology 6 of TP-201.4.
- All underground vapor piping must be a minimum of 2” NPT.
  - ▶ Always check with local authorities for applicable requirements; larger pipe size may be required.
- Refer to pipe-size requirements in Exhibit 2, Executive Orders VR/203 and VR/204.

## 11.3 Storage Tank Vapor Manifolds

- Storage tanks must be vapor manifolded below ground.

## 11.4 P/V Valves

- The P/V valve for each vent riser (not including the *Processor* air outlet) is part of the Phase I system, and therefore must be a CARB-certified component.
- A rain cap or equivalent must be installed on the air outlet vent riser to shield against rain and reduce noise. If a P/V vent valve is used, the internal components must be removed to allow open venting to the atmosphere. The air outlet rain cap or equivalent is not regulated by CARB and does not need to be tested by AQMD’s.

### **CAUTION**

Always obtain approval from the local authority having jurisdiction.

Installation of the *Processor* must comply with (if applicable):

- CARB CP-201
- VST EVR E.O.
- Fire Marshal
- Water Board
- Local Air Pollution District
- ICC
- NEC
- NFPA 30 and 30A
- UL
- Any other applicable federal, state, and local codes

## 12 Electrical

### 12.1 Electrical Safety



- The *Processor* uses lethal voltages and operates in areas where gasoline vapor may be present.
- Serious injury or death from electrical shock, fire, or explosion may result if the power is ON during installation, testing, or maintenance.
- Be sure to use Lockout/Tag-Out procedures when working on or installing the *Processor* or while working on electrical components.
- Always power OFF any electrical components connected to the *Processor*. The *Processor* can start automatically.
- Do not use tools that can generate sparks if there is risk of flammable or explosive vapors being present.
- Read and understand all materials related to installing, testing, and operating the *Processor* prior to installation.

### 12.2 Single-Phase Processor

- A lockable, safety disconnect-switch is not included with the *Processor*.
  - ▶ NEC code requires that a readily accessible lockable, safety disconnect-switch be installed within sight of the *Processor*.
  - ▶ VST recommends installing the lockable, safety disconnect-switch approximately 3-feet from the *Processor* for testing and inspection reasons.
- At the main breaker, size the motor panel breaker according to the table below. Make sure the total amperage includes both motors.

| Single-Phase Power Requirements |    |        |         |          |
|---------------------------------|----|--------|---------|----------|
| Motor                           | HP | Phase  | Voltage | Amperage |
| Blower                          | .5 | Single | 115     | 9.8      |
|                                 |    |        | 230     | 4.9      |
| Vacuum Pump                     | 2  | Single | 115     | 24       |
|                                 |    |        | 230     | 12       |

Table 1: Single-Phase Motor Power Requirements

- The contractor is to supply a lockable circuit breaker in accordance with local, state, and national authorities.
- It is mandatory to follow standard lock-out/tag-out procedures when performing service on the *Processor*.

- Following such procedures may be required by local, state, and national authorities.
  - ▶ You must install the *Processor* in accordance with the National Electric Code (NEC), NFPA 70, and with the Automotive and Marine Service Station Code (NFPA30A).
  - ▶ According to NFPA 30A and the California Fire Code:

“Electrically energized vapor-recovery equipment shall be directly connected to and controlled by the emergency pump shut off in Section 5202.4.7.” See figure 20.
- The contractor shall supply 115v motor starter(s) with a 115v relay coil to start/stop the single-phase motors.

### 12.2.1 Power Requirements for Single-Phase Electrical Service

---

- 115v/230v, single-phase, 60Hz (blower and vacuum pump motors).
  - ▶ See Table 1 for the motor amperage.
- 115v breaker (heat-trace cable power).
  - ▶ 115v, 2-amp service to power the heat trace.
- 115v, 2-amp minimum service to power a dedicated outlet for the 24VDC power supply for the HC sensor and the HC sentry.
- The ECS motor-starter relay(s) connects to the TLS.
- The ECS motor-starter relay(s) can be located inside the GDF or at the *Processor*, depending on the electrical design.

### 12.3 Three-Phase Processor

- A circuit disconnect device is not included with the *Processor*.
  - ▶ NEC code requires that a readily accessible lockable, safety disconnect-switch be installed within sight of the *Processor*.
  - ▶ VST recommends installing the lockable, safety disconnect-switch approximately 3-feet from the *Processor* for testing and inspection reasons.
- At the main breaker use a 208/230-460v, 3-phase, 60Hz electric service.
  - ▶ See Table 2 for the motor amperage.
- The contractor is to supply a lockable circuit breaker in accordance with local, state, and national authorities.
  - ▶ It is mandatory practice to follow standard lock-out / tag-out procedures when performing service on the unit.
- Following such procedures may be required by local, state, and national authorities.
  - ▶ You must install the *Processor* in accordance with the National Electric Code (NEC), NFPA 70, and with the Automotive and Marine Service Station Code (NFPA30A).
  - ▶ According to NFPA 30A and the California Fire Code:

“Electrically energized vapor-recovery equipment shall be directly connected to and controlled by the emergency pump shut off in Section 5202.4.7.” See figure 25.

- The contractor shall supply a 208/230-460v motor starter(s) with a 115v relay coil to start / stop the three-phase motors.

12.3.1 Power Requirements for Three-Phase Electrical Service

- See Table 2 for the motor amperage.
  - ▶ 208/230-460v, 3-phase, 60Hz (blower and vacuum pump motors).
- Size the motor panel breaker according to the table below. Make sure the total amperage includes both motors.

| Three-Phase Power Requirements |    |       |         |          |
|--------------------------------|----|-------|---------|----------|
| Motor                          | HP | Phase | Voltage | Amperage |
| Blower                         | .5 | Three | 208     | 2.4      |
|                                |    |       | 230     | 2.2      |
|                                |    |       | 460     | 1.1      |
| Vacuum Pump                    | 2  | Three | 208     | 7.5      |
|                                |    |       | 230     | 6.8      |
|                                |    |       | 460     | 3.4      |

Table 2: Three Phase Motor Power Requirements

- 115v breaker (heat-trace cable power)
  - ▶ 115v, 2-amp minimum service to power the heat trace
- 115v, 2-amp service to power a dedicated outlet for the 24VDC power supply for the HC sensor and the HC sentry
- The ECS motor-starter relay(s) connects to the TLS.
  - ▶ 115V, 2 amp service to power the motor-starter relay coil.
- The ECS motor-starter relay(s) can be located inside the GDF or at the *Processor*, depending on the electrical design.

### 12.4 Reference Information for Processor Power Requirements

- The following information is for general reference and is not intended to replace recommended National Electric Code (NEC) procedures. It is important for the installer to understand that electrical equipment and wiring located in Class I, Division 2 installations shall comply with the latest appropriate Articles found in the National Electric Code (NFPA 70).

- The HC sentry must be installed indoors in the GDF's electrical room.
- All electrical/control components must be installed per the NEC, with clear access for personnel.
- The area inside the *Processor* cover is classified as a Class I, Division 2 hazardous area as defined by UL. All electrical components inside the *Processor* are rated for this hazardous area. The *Processor* must not be installed in a Class I, Division 1 or Class I, Division 2 hazardous location as defined by the NEC.
- Because the area inside the *Processor* cover is defined as a Class I, Division 2 hazardous location, be sure that all existing electrical seal-offs continue to meet NEC and NFPA requirements after installation of the *Processor*.
- NEC code requires a lockable, safety disconnect-switch be installed. VST does not provide an outside electrical disconnect for the *Processor*. The NEC requires an electrical lockable, safety disconnect-switch be connected to the *Processor* with respect to the panel location. Consult the NEC as to the correct location and type of disconnect.
- Install the *Processor* in accordance with the National Electrical Code (NFPA 70) and the Automotive and Marine Service Station Code (NFPA 30A).
- According to NFPA 30A and the California Fire Code:

**“Electrically energized vapor-recovery equipment shall be directly connected to and controlled by the emergency pump shut off in Section 5202.4.7.”**

See figure 20 and figure 25, which are the Processor ESO (Emergency Shut-Off) wiring diagrams.

- Because of multiple ways to install the electrical based on cost, the level of motor protection, electrical components used, placement of such electrical components, and local jurisdiction requirements, this manual presents just the basic electrical requirements for the ECS Membrane *Processor*.
- Internal motor automatic thermal re-sets or thermostat:

| Phase        | Included    |     |
|--------------|-------------|-----|
| Single Phase | Blower      | yes |
|              | Vacuum Pump | yes |
| Three Phase  | Blower      | yes |
|              | Vacuum Pump | yes |

## 12.5 Power for the Motors

### 12.5.1 Single-Phase Processor

---

- Breakers rated at 115v, single-phase power the two electric motors in the *Processor*.
  - ▶ This breaker should be a delayed-trip motor starting type.
  - ▶ See Figure 18.
  - ▶ See Figure 19.
  - ▶ See Figure 20.
  
- Single-phase motors wiring diagrams:
  - ▶ See Figure 21 for the vacuum pump single-phase motor wiring diagram
  - ▶ See Figure 22 for the blower single-phase motor wiring diagram

### 12.5.2 Three-Phase Processor

---

- Breakers rated at 208/230-460v (three-phase), power the two electric motors in the *Processor*.
  - ▶ This breaker should be a delayed-trip motor starting type.
  - ▶ See Figure 23.
  - ▶ See Figure 24.
  - ▶ See Figure 25.
  
- Three-phase motors wiring diagrams:
  - ▶ See Figure 26 for the vacuum pump three-phase motor wiring diagram.
  - ▶ See Figure 27 for the blower three-phase motor wiring diagram.

### 12.5.3 Power for the HC Sensor in both the Single-Phase and the Three-Phase Processor

---

- 115v, 2-amp dedicated service to power the 24VDC power supply for the HC sensor and HC sentry.

## CAUTION

Always obtain approval from the local authority having jurisdiction.

Installation of the *Processor* must comply with (if applicable):

- CARB CP-201
- VST EVR E.O.
- Fire Marshal
- Water Board
- Local Air Pollution District
- ICC
- NEC
- NFPA 30 and 30A
- UL
- Any other applicable federal, state, and local codes



## 12.6 Power for the Heat-Trace Cables in both Single-Phase and Three-Phase Processors

- 115v circuit powers the heat-trace cable.
  - ▶ The negative side of the circuit is off a common neutral with a common ground inside the electrical enclosure located inside the *Processor*.

## 12.7 Power for the Motor Starter Relay Coil

- 115v circuit provides power to the relay coil.

## 12.8 Optional Convenience Outlet at the **Processor**

- An optional convenience outlet located near the *Processor* may be installed for powering tools and test equipment.

**CAUTION:** The optional convenience outlet located near the Processor CANNOT be installed in a Class 1, Div. 2 hazardous area.

- ▶ The wires for the convenience outlet can go in the same conduit as the motor power wires.
- Seal-offs are required as per NFPA 70 for a conduit run leaving a Division 2 location to an unclassified location.
  - ▶ Install as required by the NEC and Local Authority having Jurisdiction.
- Other seal-offs may be necessary based on the installation and site specifics.

## 13 Electrical Installation

### 13.1 Electrical Safety



- The *Processor* uses lethal voltages and operates in areas where gasoline vapor may be present.
- Serious injury or death from electrical shock, fire, or explosion may result if the power is ON during installation, testing, or maintenance.
- Be sure to use Lockout/Tag-Out procedures when working on or installing the *Processor* or while working on electrical components.
- Always power OFF any electrical components connected to the *Processor*. The *Processor* can start automatically.
- Do not use tools that can generate sparks if there is risk of flammable or explosive vapors being present.
- Read and understand all materials related to installing, testing, and operating the *Processor* prior to installation.

### 13.2 Electrical Installation Code Requirements

- According to NFPA 30:  
“Electrical wiring and electrical utilization equipment shall be a type specified by and be installed in accordance with NFPA 70. Electrical wiring and electrical utilization equipment shall be approved for the locations in which they are installed.”
- All electrical wiring and electrical utilization equipment must be installed to meet federal, state, and local codes.
- Flexible electrical conduit connections to the Processor may be required by local jurisdictions to meet seismic code requirements.

#### 13.2.1 Single-Phase Processor Configuration

- The ECS motor-starter relay can be installed inside the GDF’s electrical room or at the *Processor*, depending on the electrical design.
- Install properly-sized conduit from the electrical room to a lockable, safety disconnect-switch (located near the *Processor*).
- From the disconnect switch to the *Processor*:
  - ▶ The first ¾” rigid conduit is for the 115v vacuum pump and blower motors. It is also for 115v power for the heat trace cable.
  - ▶ The second ¾” rigid conduit is for 24VDC and HC signal control wiring.

If you are using existing conduit, it is acceptable by VST to run the electrical and the communications through the same conduit, provided that the local jurisdiction authorizes doing so.

**BE SURE TO CHECK WITH LOCAL AUTHORITIES.**

### 13.2.2 Three-Phase Processor Configuration

---

- The ECS motor-starter relay can be installed inside the GDF's electrical room or at the *Processor*, depending on the electrical design.
- Install properly-sized conduit from the electrical room to a lockable, safety disconnect-switch (located near the *Processor*).
- From the disconnect switch to the *Processor*:
  - ▶ The first  $\frac{3}{4}$ " rigid conduit is for 208/230-460v vacuum pump and blower motors. It is also for 115v power for the heat trace cable.
  - ▶ The second  $\frac{3}{4}$ " rigid conduit is for 24VDC and HC signal control wiring.

If you are using existing conduit, it is acceptable by VST to run the electrical and the communications through the same conduit, provided that the local jurisdiction authorizes doing so.

**BE SURE TO CHECK WITH LOCAL AUTHORITIES.**

---

### 13.2.3 Single and Three-Phase Processors

---

- Install the electrical / communications conduit(s) sized to meet NEC and local code standards from the electrical room to a lockable, safety disconnect-switch.
  - ▶ THE NEC REQUIRES THAT A LOCKABLE, SAFETY DISCONNECT-SWITCH BE LOCATED NEAR THE PROCESSOR.
  - ▶ Flexible electrical conduit connections to the Processor may be required by local jurisdictions to meet seismic code requirements.
  
- Install either one or two  $\frac{3}{4}$ " diameter conduit connections on the *Processor*.
  - ▶ There are two  $\frac{3}{4}$ " diameter conduit connections on the *Processor*.
  - ▶ The contractor may decide to use either one or both of these conduits depending on:
    - The configuration of the electrical switch
    - Single phase or three phase *Processor*
    - Size of the wire used in the *Processor*

### 13.2.4 Wiring between the Processor and components:

---

- All wiring (208/203-460 VAC and 24 VDC) to be TFFN or THHN with 600 V insulation.
- All wiring must be gasoline and oil resistant.
- VST provides the 24VDC power supply for the HC Sentry module.
  - ▶ The 24VDC power-supply plugs into a dedicated 115v outlet.
  - ▶ The 115v outlet must be located within 3-feet of the HC sentry module.
- The HC sensor receives 24VDC power from the HC sentry module, and the HC sentry module receives 4-20 mA control signal from the HC sensor.
  - ▶ One cable contains the 24VDC power and 4-20 mA signals.
  - ▶ The cable must be a minimum 3 conductor, 18 AWG, twisted pair with a shielded ground.
  - ▶ The isolated ground is connected to the HC Sentry. The HC Sentry receives power from a separate 115V circuit.
- Run two ground wires from the electrical panel:
  - ▶ 1<sup>st</sup> ground wire is the equipment ground.
  - ▶ 2<sup>nd</sup> ground wire is an electrical ground.
  - ▶ Both grounds must be a minimum 12 AWG (follow all NEC requirements for equipment grounding).
  
- Wiring the 208/230-460v or 115/230V power for the motors is a minimum 14 AWG:
  - ▶ Sizing must comply with NEC requirements for motor load and wiring distance.
  - ▶ Larger gauge wire may be necessary based on conductor length and voltage supplied by the load center.
- NEC recommends a maximum conductor voltage drop of 3%, but notes that with a conductor voltage drop of 5%, most devices should operate with acceptable efficiency.




Figure 18: Single-Phase Wiring Schematic




Figure 19: Processor Single-Phase Wiring Diagram




Figure 20: Processor Single-Phase ESO Wiring Diagram





Figure 21: Vacuum Pump: Single-Phase Motor Wiring Diagram





FILENAME: 5564-001

Figure 22: Blower: Single-Phase Motor Wiring Diagram




Figure 23: Processor Three-Phase Wiring Schematic






Figure 24: Processor Three-Phase Wiring Schematic



Reference three-phase drawings:  
 5543-001, Processor wiring diagram  
 5541-001, Processor wiring diagram  
 5565-001, Blower motor wiring schematic  
 5563-001, Vacuum pump motor wiring schematic

(Refer to the VST website ([www.vsthouse.com](http://www.vsthouse.com)) for examples on how to completely wire the controls, motors, and other electrical components.

Figure 25: Processor Three-Phase ESO Wiring Diagram



FILENAME: 5563-001

Figure 26: Vacuum Pump: Three-Phase Motor Wiring Diagram




Figure 27: Blower: Three-Phase Motor Wiring Diagram

### 13.3 Auxiliary Output Relay

- Run two wires from motor relay contacts to the Veeder-Root TLS.

**DO NOT MAKE THIS FINAL CONNECTION.**

**THIS FINAL CONNECTION IS TO BE MADE AT THE TIME OF START-UP.**

**THIS ACTION REQUIRES THAT THE VST ASC (LEVEL C) BE A VEEDER-ROOT CERTIFIED CONTRACTOR WITH A MINIMUM OF VEEDER-ROOT LEVEL 1, OR 2/3, OR 4 CERTIFICATION.**

- ▶ The user interface is equipped with an Auxiliary Output Relay for external monitoring of the *Processor*.
- The 115V control voltage for the motor control contactor is from the 115V electrical panel.
- This relay will be used when the *Processor* is installed with a PMC or an ISD system as specified by CARB Enhanced Vapor Recovery Program.
- When the *Processor* is powered and operating normally, the auxiliary relay is energized (green LED on Auxiliary Relay is lit).
- In ISD, when the *Processor* is powered off (either manually or due to an alarm mode), or is in alarm mode, the auxiliary relay is de-energized.
- Auxiliary relay contact rating: 240V, 6A with 4000V isolation.
  - ▶ Connect the *Processor* motor control relay on either the 4-Relay Module or the I/O Combination Module.
  - ▶ DO NOT CONNECT TO POWER
  - ▶ See Figure 28.





Figure 28: VR TLS Multi-Port Card Connection to HC Sentry Module




### 13.4 HC Sensor / HC Sentry

- Using 24 VDC, the HC sentry provides power to the HC sensor.
- A 115V / 24 VDC converter from a 115V outlet powers the HC sentry.
- A 3-wire, 18 AWG shielded twisted-pair cable connects the HC sensor to the HC sentry for the 24 VDC power, the 4-20mA signal, and an isolated ground.
- Install an equipment ground to the HC sensor housing.



- ICD/ICSP: This connector provides a means for performing in-circuit-debug and in-circuit-serial-programming utilizing the programming and debugging tools from the processor manufacturer. This connector will typically be used in production to perform initial programming, and could be used as a simple field method for updating a device.
- RX: This led flashes to indicate received data via the RS485 link.
- TX: This led flashes to indicate transmitted data via the RS485 link.
- RS-485: This two-pin connector provides the link to the TLS, RS-485 network.
- POWER: This led indicates that the HC Sentry device is powered up.



- ON/OFF: Switch for turning the device power on and off.

Figure 29: HC Sentry Front & Back Views





Figure 30: HC Sentry and HC Sensor Wiring Diagram

| REV | ECN | DESCRIPTION | RELEASED BY | DATE    |
|-----|-----|-------------|-------------|---------|
| A   |     |             | T. Raterman | 4/23/07 |



Circuit board

HC Sensor Junction box



HC Sentry (Front)



HC Sentry (Back)

|  |          |     |
|--|----------|-----|
|  <b>Vapor Systems Technologies, Inc.</b><br>Springboro, Ohio 45066 www.vstthose.com |          |     |
| TITLE<br>Emission Control System<br>Hydrocarbon Sensor   |          |     |
| SCALE  | DWG NO.  | REV |
| none   | 5538-001 | A   |
| SHEET  | OF       |     |
| 1  | 1        |     |

Figure 31: HC Sensor and HC Sentry Pictures

### 13.5 Multiport Card for Vapor Processor Communication

- Run wire from HC sentry to TLS
  - ▶ This action requires that the VST ASC (Level B) be a Veeder-Root Certified Contractor with Level 1, or 2/3, or 4 certification.
- The HC sensor is powered by the HC Sentry Interface Module using 24VDC power.
- Power required for the HC Sentry Interface Module is 24VDC power supply plugged into an 115VAC outlet.
- A three-wire, 18 AWG, shielded twisted-pair cable connects the HC sensor to the HC Sentry Interface Module for the 24VDC power, the 4-20mA signal, and an isolated ground.
- The wiring from the HC sensor is connected to the two twisted pair wires inside the HC electrical housing.
- See Figure 32 TLS / HC Sentry RS-485 Cable for the wiring diagram.
- ▶ VST provides the HC Sentry Interface Cable.




Figure 32: VR TLS Multi-Port Card Connection to the HC Sentry Module




Figure 33: HC Sentry RS-485 Cable Wiring Diagram

### 13.6 Veeder-Root TLS 350 with PMC or ISD Controls

- The *Processor* is controlled by a Veeder-Root (VR) TLS-350 with a PMC or ISD software package.
- The pressure sensor is located in a dispenser closest to the UST's and is supplied by Veeder-Root as part of the Veeder-Root TLS-350 with an ISD control package.
- VST will supply the HC Sentry Interface Module with 115VAC/24VDC power supply as part of the *Processor*.
- The HC Sentry Interface Module converts the 4-20 mA signals from the HC sensor to a proprietary signal the TLS-350 will recognize.
- VST provides the HC Sentry Interface cable that connects the HC Sentry to the Multiport Card in the TLS Communication Bay.
- VST does not provide the TLS-350 controller or the software required by the TLS-350.



**5554-001**

Figure 34: VR TLS-350

### 14 Acceptable NEC Electrical Installation Examples

- The next 8 drawings show acceptable NEC electrical installation examples you may find helpful in the field.





Figure 35: Single phase electrical overview





| NO. | REV. | DESCRIPTION                | RELEASED BY | DATE   |
|-----|------|----------------------------|-------------|--------|
|     |      | Revised Electrical Diagram | T. Ratoman  | 7/6/10 |



UNDERGROUND ELECTRICAL TO ELECTRICAL ROOM

Rigid conduit  
 Can use either 1 or 2 conduits  
 Electrical conduit ( 3/4" Ø)  
 Communication conduit ( 3/4" Ø)

| No. | Description   |
|-----|---|
| 1   | Contactor, 40 Amp, 3-Pole:<br>600VAC Max<br>Inductive Full Load Current 30 Amps<br>Resistive Full Load 40 Amps<br>Single Phase: 120VAC 3-HP, 230VAC 7.5-HP<br>Three Phase: 230VAC 10-HP, 460VAC 20-HP<br>Coil Voltage: 120VAC, N.O.<br>Square-D Model #: 8910DPM43V02<br>Grainger Model #: 5B109 (\$55.15)  |
| 3   | Type 1 electrical enclosure:<br>NEMA 1, 16 Gauge Steel<br>12" x 12" x 6" with knockouts<br>WIEGMANN Model #: SC121206<br>Grainger Model #: 4KP33 (\$48.75)  |
| 4   | 110V Duplex outlet box and outlet   |
| 5   | Three-Wire Safety Fused Disconnect Switch, Single-Throw:<br>NEMA 3R (rain proof) , 3-pole, Dual Element Time-Delay Fuses<br>240VAC max., rated at 30 amps, max 3-HP Rating<br>Square-D model # H321NRB<br>Grainger model #: 1H337 (\$259.75)<br>Rain Proof Hubs: Square-D model # B075 (3/4")<br>Grainger model #: B9301 (\$14.11)<br>Electrical Interlock Switch: Square D EIK1, one contact<br>Grainger model #: 2CP56 (\$160.00) |

To the ECS Unit

Rigid conduit  
 Can use either 1 or 2 conduits  
 Electrical conduit ( 3/4" Ø)  
 Communication conduit ( 3/4" Ø)

**VST** Vapor Systems Technologies, Inc.  
 Springboro, Ohio 45068 www.vsthsos.com

TITLE: Emissions Control System  
 Electrical Single-Phase Disconnect

SCALE: 1/8" = 1"

SHEET NO: 5052-001

REV: C

Figure 37: Single phase electrical disconnect





Figure 38: Single phase elec. inside the ECS



|   |                         |
|---|-------------------------|
|   |                         |
| Vapor Systems Technologies, Inc.<br>Springfield, Ohio 45506    www.vstusa.com |                         |
| TITLE<br>Emissions Control System<br>Electrical Three-Phase Overview          | DRAWING NO.<br>5060-001 |
| SHEET<br>1 of 1   | REV.<br>A               |

Figure 39: 3-phase electrical overview




Figure 40: 3-phase electrical room




Figure 41: 3-phase electrical disconnect




Figure 42: 3-phase elec. inside ECS

# 15 Post-Installation Checklist

| Post-Installation Checklist   |                            |                            |                            |                          |                           |
|---|----------------------------|----------------------------|----------------------------|--------------------------|---------------------------|
| VST ASC #:  | Date:                      |                            |                            |                          |                           |
| ASC Name:   |                            |                            |                            |                          |                           |
| VST-ASC Certification Level   | <input type="checkbox"/> A | <input type="checkbox"/> B | <input type="checkbox"/> C |                          |                           |
| ASC Company:  |                            |                            |                            |                          |                           |
| GDF Name:   |                            |                            |                            |                          |                           |
| Address:  |                            |                            |                            |                          |                           |
| City:   | State:                     | Zip Code:                  |                            |                          |                           |
| GDF Contact Person Name:  |                            |                            |                            |                          |                           |
| GDF Contact Person Title:   |                            |                            |                            |                          |                           |
| GDF Contact Person Phone:   |                            |                            | E-mail:                    |                          |                           |
| <b>Notes: Use this form to note details of the post-installation tests</b>        |                            |                            |                            |                          |                           |
| Checkpoints   | Site Components            | Yes                        | No                         | Un-known                 | If No or Unknown, explain |
| Pressure sensor installed   |                            | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/> |                           |
| TLS-350 with ISD software installed   |                            | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/> |                           |
| HC sentry connected to the TLS  |                            | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/> |                           |
| Processor Leak Check  |                            | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/> |                           |
| All vapor piping sloped away from the Processor                                   |                            | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/> |                           |
| All vapor piping line size meets CP-201 requirements                              |                            | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/> |                           |
| All vapor piping slope meets CP-201 requirements                                  |                            | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/> |                           |
| Checkpoints   | Site Components            | Yes                        | No                         | Un-known                 | If No or Unknown, explain |
| All warranty information has been filled out and sent to VST                      |                            | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/> |                           |
| All connections from the Processor to the UST's are correct                       |                            | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/> |                           |
| The Processor has not been installed in a Class I, Div. 1 or Class I, Div. 2 area |                            | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/> |                           |
| The electrical installation meets NEC, federal, state, and local standards        |                            | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/> |                           |
| The Processor installation meets CP-201 requirements                              |                            | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/> |                           |
| The ECS Processor has been installed per installation instructions                |                            | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/> |                           |

Attach product sticker with bar code here

The above tests were performed in accordance with IOM found in the VST's Executive Orders.

\_\_\_\_\_  
ASC Signature

# Operation, Maintenance & Set-Up Manual

ECS Membrane Processor: PMC and ISD

Part: VST ECS-CS3-310 – Three Phase  
VST-ECS-CS3-110 – Single Phase

Executive Orders: VR-203-P  
VR-204-P

Version: 4.5

*Vapor Systems Technologies, Inc.*  
650 Pleasant Valley Drive  
Springboro, Ohio 45066  
937-704-9333 PH  
937-704-9443 FX  
[www.vsthose.com](http://www.vsthose.com)



---

# Table of Contents

---

- Table of Figures .....5
- About VST.....7
- Notice .....7
- Table of Terms & Abbreviations .....9
- 1 ECS Membrane Processor Overview.....10
  - 1.1 ECS Membrane Processor Theory of Operation .....10
  - 1.2 Overview of How the Processor Operates.....11
  - 1.3 Processor Dimensions and Weight.....11
  - 1.4 Processor Components and Their Purpose.....12
  - 1.5 Processor Auxiliary Components.....14
  - 1.6 Processor Manuals.....14
- 2 Processor Operation .....20
  - 2.1 TLS 350 Construction.....20
  - 2.2 Automatic Control .....21
  - 2.3 Manual Control of the Processor .....22
  - 2.4 TLS Alarms .....23
  - 2.5 Thresholds and Algorithms .....23
    - 2.5.1 TLS-350 (PMC): Alarm Troubleshooting Summary .....26
    - 2.5.2 TLS-350 (ISD): Alarm Troubleshooting Summary .....27
- 3 Post-Installation Power-Up Tests.....29
  - 3.1 Post-Installation Electrical Connections.....29
  - 3.2 Required Post-Installation Power-Up Tests.....31
  - 3.3 TLS Manual Mode .....33
  - 3.4 Electrical Connection Test.....35
  - 3.5 Motor-Rotation Test.....35
  - 3.6 Heat-Trace Continuity Test.....41
    - 3.6.1 Preparing the heat trace electrical junction box for the test: .....41
    - 3.6.2 Testing the heat trace circuit.....41
  - 3.7 HC Sensor and HC Sentry Power Test .....41
    - 3.7.1 Checking 24 VDC Power to the HC Sensor .....42
    - 3.7.2 Checking 24VDC Power to the HC Sentry Module.....43

- 3.8 Processor Leak Test: After Repair (Only) ECS Unit .....44
  - 3.8.1 Purpose of the Test ..... 44
  - 3.8.2 Preparation ..... 44
  - 3.8.3 Functional Test Procedures..... 44
- 3.9 Preparing the Processor for Field Operation .....46
  - 3.9.1 Setting the TLS-350 Threshold Values..... 46
  - 3.9.2 Processor Configuration Prior to Start Up ..... 46
- 3.10 Post-Installation Power-Up Checklist.....47
- 4 Processor Start-Up.....48
  - 4.1 Processor Shut-Down Procedure .....49
    - 4.1.1 Processor Shut-Down Procedure ..... 49
    - 4.1.2 HC Sensor and HC Sentry Module..... 49
    - 4.1.3 Heat-Trace Cable ..... 49
- 5 Processor Maintenance .....50
  - 5.1 Annual System Compliance Testing.....51
  - 5.2 Annual Inspections and Replacements .....52
  - 5.3 Preventative Maintenance Checklist Form .....53
  - 5.4 GDF Maintenance Record.....54
- 6 ECS Unit Purging Instructions Prior to Service or Maintenance .....55
  - 6.1 Purpose .....55
  - 6.2 Tools Required .....55
  - 6.3 Preparation .....55
  - 6.4 Procedures .....55
  - 6.5 Post Purging Procedures.....56
  - 6.6 Post Service or Maintenance.....56
- 7 Blower Replacement .....57
  - 7.1 Blower Replacement Safety .....57
  - 7.2 Removing the Blower .....57
  - 7.3 Installing the New Blower .....58
- 8 Vacuum Pump Replacement .....60
  - 8.1 Safety .....60
  - 8.2 Removing the Vacuum Pump.....60
  - 8.3 Installing the new Vacuum Pump and Vacuum Pump Motor Assembly .....61
- 9 Membrane Replacement .....64
  - 9.1 Safety .....64
  - 9.2 Removing the Membrane from the Membrane Housing.....64
  - 9.3 Installing the New Membrane .....66

- 10 Drive Coupling Rubber Insert Replacement .....67
  - 10.1 Safety .....67
  - 10.2 Removing the Drive Coupling Insert .....67
  - 10.3 Installing the Drive Coupling Insert .....69
- 11 Heat Trace Cable Replacement .....70
  - 11.1 Safety .....70
  - 11.2 Removing the Heat Trace Electrical Box .....70
  - 11.3 Overview for Installing the New Heat Trace Cable .....71
  - 11.4 Steps for Installing the New Heat Trace Cable .....71
- 12 Hydrocarbon Infrared (HC IR) Sensor Module Replacement .....82
  - 12.1 Safety .....82
  - 12.2 Removing HC IR Sensor from the HC IR Sensor Module Electrical Housing .....83
  - 12.3 Installing a New or Re-calibrated HC IR Sensor Module to the HC IR Sensor Module Electrical Housing .....85
- 13 Forms .....87
  - 13.1 Preventative Maintenance .....88
  - 13.2 Preventative Maintenance Checklist Form .....89

# Table of Figures

Figure 1: How the Processor fits into the GDF layout..... 15

Figure 2: Processor Piping Diagram..... 16

Figure 3: ECS Vent Configurations ..... 17

Figure 4: Processor Isometric Drawing (1 of 2) ..... 18

Figure 5: Processor Isometric Drawing (2 of 2) ..... 19

Figure 6: TLS-350 Face..... 20

Figure 7: Processor Run-Time Algorithm..... 25

*Figure 8: Wiring the Motor Starter Relay Coil..... 30*

Figure 9: ECS Piping Configuration..... 32

Figure 10: PMC Diagnostic Menu with PMC Software..... 33

Figure 11: PMC Diagnostic with ISD Software ..... 34

Figure 12: Vacuum Pump: Single-Phase Motor Wiring Diagram ..... 37

Figure 13: Vacuum Pump: Three-Phase Motor Wiring Diagram ..... 38

Figure 14: Blower: Single-Phase Motor Wiring Diagram ..... 39

Figure 15: Blower: Three-Phase Motor Wiring Diagram ..... 40

Figure 16: Heat Trace Circuit Test..... 41

Figure 17: HC Sentry Interface Module Front View: Power and ON/OFF Switch..... 42

Figure 18: HC Sentry Interface Module Back View: Power "ON" Light ..... 43

Figure 19: Processor Inlets & Outlets..... 45

Figure 20: Typical Leak Check Test Fixture ..... 45

Figure 21: Processor Inlets & Outlets..... 56

Figure 22: Typical leak-check fixture ..... 56

Figure 23: Blower electrical connection conduit ..... 59

Figure 24: Blower inlet and outlet tubing connections and mounting bolts..... 59

Figure 25: Vacuum pump outlet tubing connection ..... 62

Figure 26: Vacuum pump inlet tubing and fittings ..... 62

Figure 27: Vacuum pump electrical connection / vacuum pump outlet tubing / HC sensor inlet tubing..... 63

Figure 28: Air outlet / vacuum pump outlet / HC sensor inlet tubing ..... 63

Figure 29: Membrane Housing ..... 64

Figure 30: Exposed membrane with top plate removed. .... 64

Figure 31: Membrane extraction tool ..... 65

Figure 32: Membrane base insert..... 65

Figure 33: Vacuum pump with guard removed..... 67

Figure 34: Vacuum and motor assembly..... 67

Figure 35: Vacuum pump unbolted and moved away from the motor ..... 68

Figure 36: Drive coupling rubber insert..... 69

Figure 37: Termination block inside the electrical junction box ..... 72

Figure 38: Seam to cut to remove the insulation..... 72

Figure 39: End seal kit components ..... 72

Figure 40: End seal kit installation instructions, page 1 of 2 ..... 73

Figure 41: End seal kit installation instructions, page 2 of 2 ..... 74

Figure 42: Prepare the new heat trace cable for installation into the end seal kit ..... 75

Figure 43: Electrical junction box installation instructions, page 1 of 4 ..... 76

Figure 44: Electrical junction box installation instructions, page 2 of 4 ..... 77

Figure 45: Electrical junction box installation instructions, page 3 of 4 ..... 78

Figure 46: Electrical junction box installation instructions, page 4 of 4 ..... 79

Figure 47: End seal kit location and heat trace cable installation ..... 80

Figure 48: Installed electrical junction box with electrical connections ..... 81

Figure 49: HC IR Sensor Module and Electrical Housing Assembly ..... 82

Figure 50: HC IR Sensor Module 1/4" 45° tubing and fittings ..... 83

Figure 51: HC IR Sensor Electrical Housing Circuit Board ..... 84

Figure 52: HC IR Sensor Electrical Housing Circuit Board Wiring Diagram ..... 84

Figure 53: HC IR sensor installation orientation ..... 85



## *About VST*

---

Vapor Systems Technologies, Inc. began in 1989 with the vision of One Company – One Integrated Solution.

Today, that philosophy is still in place and getting stronger. Recognizing that a healthier environment is a need and not an option, VST has dedicated its undivided attention to the ever-changing, stringent regulations that govern fugitive vapors at gasoline dispensing facilities (GDF). To this challenge, VST is committed to a continual R&D campaign of developing the most current, technologically advanced solutions to service not only the United States, but also the world.

VST specializes in the development, engineering, and manufacturing of products that are sold into the GDF segment of the petroleum industry. The VST focus provides our customers and users with exceptional products, services, and innovative solutions for improving the fueling-station experience as well as the world's air quality.

VST's product offering includes curb pump and vapor recovery hoses, safety breakaways, nozzles, and emission-control system *Processors*. The ENVIRO-LOC™ vapor-recovery product offering represents the most innovative concept in the industry for trapping fugitive vapors from the front end (vehicle refueling) to the back end (vent risers) of the GDF site.













## *Notice*

---

Vapor Systems Technologies, Inc. shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this publication.

No part of this publication may be translated to another language without the prior written consent of Vapor Systems Technologies, Inc.

## Safety Icons

|   |   |   |   |
|---|---|---|---|
|    | <p><b>ELECTRICITY</b><br/>A potential shock hazard exists. High voltage is supplied to and exists in this device.</p>   |    | <p><b>TURN POWER OFF</b><br/>Turn power off to the device and its accessories when installing and servicing the unit. Live power creates a potential spark hazard.</p>  |
|    | <p><b>EXPLOSIVE</b><br/>Gasoline and its vapors are extremely explosive if ignited.</p>                                 |    | <p><b>NO POWER TOOLS</b><br/>Sparks from electric power tools can ignite gasoline and its vapors.</p>   |
|    | <p><b>FLAMMABLE</b><br/>Gasoline and its vapors are extremely flammable.</p>  |    | <p><b>NO PEOPLE IN THE AREA</b><br/>Unauthorized people in the work area during installation and service of the device create a potential for personal injury.</p>  |
|  | <p><b>NO SMOKING</b><br/>Gasoline and its vapors can be ignited by sparks and embers of burning cigarettes.</p>         |  | <p><b>READ ALL RELATED MATERIALS</b><br/>Read, understand, and follow all instructions, warnings, and requirements before you begin work.</p>   |
|  | <p><b>NO OPEN FLAMES</b><br/>Open flames from sources like lighters and matches can ignite gasoline and its vapors.</p> |  | <p><b>USE SAFETY BARRICADES</b><br/>Unauthorized people in the work area during installation and service of the device create a potential for personal injury. Therefore, always isolate your work area by using safety cones, barricades, etc.</p> |
|  | <p><b>PINCH RISK</b><br/>Stay clear. Keeps hands and tools away from rotating machinery and moving parts.</p>           |  | <p><b>ROTATING MACHINERY</b><br/>Stay clear. Keep hands and tools away from rotating machinery.</p>   |

## *Table of Terms & Abbreviations*

|              |  |
|--------------|--|
| ASC:         | Authorized Service Contractor  |
| AQMD:        | Air Quality Management Districts   |
| ATG:         | Automatic Tank Gauge   |
| CARB:        | California Air Resources Board   |
| CDFA:        | California Department of Food & Agriculture  |
| CVLD:        | Continuous Vapor Leakage Detection, another name for Vapor Leak Detection            |
| ECS:         | Emissions Control System   |
| EO:          | Executive Order  |
| EVR:         | Enhanced Vapor Recovery  |
| GDF:         | Gasoline Dispensing Facility   |
| HC:          | Hydrocarbon  |
| HC IR:       | Hydrocarbon Infrared   |
| ISD:         | In-Station Diagnostics   |
| MAG Probe:   | A type (brand) of Tank Inventory Probe   |
| NEC:         | National Electric Code   |
| NFPA:        | National Fire Protection Association   |
| ORVR:        | On-Board Refueling Vapor Recovery  |
| OSHA:        | Occupational Safety Health Administration  |
| Permeate:    | Air return to atmosphere   |
| PLC:         | Programmable Logic Control   |
| PMC:         | Pressure Management Control  |
| Retentate:   | Vapor return to UST  |
| RVP:         | Reid Vapor Pressure  |
| TLS:         | Tank Level System  |
| TLS Console: | Veeder-Root's line of environmental monitoring consoles.                             |
| TS:          | Troubleshooting  |
| Ullage:      | Vapor space above liquid in a UST  |
| UST:         | Underground Storage Tank   |
| VCK:         | Vapor Collection Kit   |
| Veeder Root: | Manufacturer of the TLS-350  |
| VOC:         | Volatile Organic Compounds   |
| VST:         | Vapor Systems Technologies, Inc. - manufacturer of the ECS Membrane <i>Processor</i> |
| WC:          | Water Column   |



# 1 ECS Membrane Processor Overview

## 1.1 ECS Membrane Processor Theory of Operation

- The VST ECS membrane *Processor* does not interact directly with the other balance system hardware. It is in place to monitor and control the pressure in the UST to within limits specified by CARB.

Under conditions where the GDF is operational and the balance system hardware is functioning normally, the inherent ORVR compatibility of the balance system (when using VST's ENVIRO-LOC nozzle) will produce a predominately negative gauge pressure in the ullage space of the UST. Under these conditions the ECS membrane *Processor* will typically not need to operate.

During periods of less activity, the GDF being shut down overnight, winter fuels being present, or other conditions that promote the pressurization of the ullage space, the ECS membrane *Processor* will operate as needed to control the pressure in the ullage space to an accepted level. The ECS membrane *Processor* will turn on at an ullage pressure of +0.20 inches of water and turn it off at a pressure of -0.20 inches of water. Currently, the ECS membrane *Processor* unit is monitored and controlled through the PMC or ISD software.

- The ECS membrane *Processor* uses a type of membrane technology to enable it to selectively separate the components in the ullage vapor mixture.

Through a somewhat complex transport means, certain molecules will selectively travel in a stream from one side of the membrane to the other. This stream is referred to as the permeate stream.

In this case, predominate molecules transported across the membrane will be the primary constituents of air, which are oxygen, nitrogen, and water vapor. A small amount of the hydrocarbons present in the ullage mixture will also migrate across the membrane. Typically, permeate will contain less than 3.0% hydrocarbons. The result of this activity includes, fresh air vented to atmosphere, hydrocarbon vapors returned to the UST, and UST pressurization controlled to an acceptable level.

- The process of separation by the membrane is made possible by using two pumps, one low-pressure pump which circulates the ullage vapor mixture along one side of the membrane, and one high-vacuum pump, which creates the pressure differential needed to cause the permeate to transport across the membrane. These are the only moving parts in the system.

## 1.2 Overview of How the Processor Operates

- The Processor is a technology created for Gasoline Dispensing Facilities (GDF) to assist them in reducing the number of harmful emissions released to the atmosphere through the natural occurrence of gasoline vaporization.
- The table below lists the steps that the Veeder-Root TLS 350 and the software takes to control the Processor.

|    |  |
|----|--|
| 1. | <ul style="list-style-type: none"> <li>• When the UST system pressure rises above +0.2"WC, the <i>Processor</i> turns ON.</li> </ul>   |
| 2. | <ul style="list-style-type: none"> <li>• Through the vapor inlet pipe connection at the <i>Processor</i>, the VOC vapor is drawn into the suction side of the blower.</li> </ul>   |
| 3. | <ul style="list-style-type: none"> <li>• The blower discharges the VOC vapor into the membrane housing.</li> </ul>   |
| 4. | <ul style="list-style-type: none"> <li>• Inside the membrane housing, the VOC vapor is separated in to two air streams:             <ul style="list-style-type: none"> <li>▶ VOC depleted air (referred to as "air")</li> <li>▶ Gasoline VOC vapor</li> </ul> </li> <li>• The membrane is designed specifically for separating air from gasoline VOC vapor.</li> </ul> |
| 5. | <ul style="list-style-type: none"> <li>• A vacuum pump draws the air from the membrane housing through a check valve.</li> </ul>   |
| 6. | <ul style="list-style-type: none"> <li>• A sample of the air flows through a hydrocarbon sensor to check the percent hydrocarbons.</li> </ul>  |
| 7. | <ul style="list-style-type: none"> <li>• From the vacuum pump, the air is vented to atmosphere via the air return.</li> </ul>  |
| 8. | <ul style="list-style-type: none"> <li>• The gasoline VOC vapor returns to the UST system via the vapor return.</li> </ul>   |
| 9. | <ul style="list-style-type: none"> <li>• When the UST system pressure drops below -0.2"WC, the <i>Processor</i> turns OFF.</li> </ul>  |

## 1.3 Processor Dimensions and Weight

| Part Number     | Unit         | Dimensions  | Weight                            |
|-----------------|--------------|---|-----------------------------------|
| VST-ECS-CS3-110 | Single-Phase | L-39" x W-27" x H-43"<br>Height includes 18" legs | 385 lbs.<br>Includes 24-lb. cover |
| VST-ECS-CS3-310 | Three-Phase  | L-39" x W-27" x H-43"<br>Height includes 18" legs | 350 lbs.<br>Includes 24-lb. cover |

## 1.4 Processor Components and Their Purpose

| PART #   | DESCRIPTION   | PURPOSE   |
|----------|---|---|
| 5001-001 | Vacuum Pump / Three-Phase Motor<br>Shipped with Three-Phase <i>Processor</i>          | Draws air through the membrane housing to the atmosphere.   |
| 5001-002 | Vacuum Pump / Single-Phase Motor<br>Shipped with Single-Phase <i>Processor</i>        |   |
| 5001-003 | Vacuum Pump Drive Coupling Rubber Insert  | Drive coupling rubber insert.   |
| 5002-001 | Circulating Blower / Three-Phase Motor<br>Shipped with Three-Phase <i>Processor</i>   | The blower circulates the vapor from the UST system through the separation membrane located inside the <i>Processor</i> back to the UST system.   |
| 5002-002 | Circulating Blower / Single-Phase Motor<br>Shipped with Single-Phase <i>Processor</i> |   |
| 5003-001 | Check-Valve Assembly  | Eliminates outside air from entering the UST's.   |
| 5005-001 | Membrane  | <p>By means of the circulating blower, the vapor from the UST system continuously flows through the membrane housing, which holds the membrane cartridge. This happens only while the <i>Processor</i> is running.</p> <p>The membrane cartridge separates the air from the VOC inlet vapor, returning a concentrated VOC stream back into the storage tank while the air is vented to the atmosphere.</p> <p>The membrane and housing use UL approved o-rings.</p> |
| 5006-001 | Membrane Housing, Complete  | Houses the membrane cartridge.  |
| 5006-011 | O-Ring (2) Vertical Tube  | Prevents hydrocarbons from leaking into the atmosphere.   |
| 5006-012 | O-Ring (2) Base Insert  | Prevents the separated air from mixing with concentrated hydrocarbons.  |
| 5006-013 | O-Ring (2) Membrane   |   |
| 5007-004 | Hydrocarbon Sensor  | <p>The HC Sensor continuously monitors the amount of hydrocarbons in the air stream being vented to the atmosphere. This happens only while the <i>Processor</i> is running.</p> <p>A 4-20mA signal is sent to the TLS-350 controller that monitors the hydrocarbon percentage by volume.</p> <p>24VDC power is required and is supplied from the HC sentry.</p>  |

| PART #   | DESCRIPTION                     | PURPOSE  |
|----------|---------------------------------|--|
| 5008-001 | Heat-Trace Cable                | <p>A self-regulating heat trace cable wraps around the membrane housing and is designed to keep the membrane housing temperature between 100°-150° F.</p> <p>Power is continuously applied to the heat-trace cable 100% of the time whether the <i>Processor</i> is running or not.</p> <p>The power requirements are 115 VAC at 130 watts per foot, with a maximum of 2 amps draw.</p> <p>On the end of the heat-trace cable is an end-seal kit to terminate the cable.</p> |
| 5008-002 | Heat Trace Power Connection Kit | Connection for 115V power.   |
| 5008-003 | Heat Trace End Seal Kit         | End circuit connection.  |
| 5010-001 | ECS Aluminum Cover              | Protective Cover   |
| 5012-100 | Membrane Tubing                 | Internal Vapor Tubing  |
| 5012-101 | Blower Inlet Tubing             |  |
| 5012-102 | Blower Outlet Tubing            |  |
| 5012-103 | Vacuum Pump Inlet Tubing        |  |
| 5012-104 | Vacuum Pump Outlet Tubing       |  |
| 5012-105 | HC Return Tubing                |  |
| 5012-106 | HC Inlet Tubing                 |  |
| 5012-107 | Membrane Outlet Tubing          |  |
| 5013-001 | Insulation                      | 1" thick insulation encases the membrane housing and the heat trace cable to preventing unnecessary heat loss.   |

## 1.5 Processor Auxiliary Components

| PART #   | COMPONENT                                       | DESCRIPTION  |
|----------|---|--|
| 5015-001 | HC Sentry Interface Module w/24VDC power supply | <p>The HC Sentry module acts as an interface between the TLS and the HC sensor.</p> <p>115v power is supplied to the HC sentry module, which supplies 24VDC power to the HC sensor.</p> <p>A 4-20 mA signal is sent from the HC sensor to the HC sentry module, which converts the signal to a proprietary code for the TLS-350.</p> |
| 5015-002 | HC Sentry Interface Cable                       | Connects the HC Sentry to the TLS-350.   |

## 1.6 Processor Manuals

| Manual # | Manual Name   | Section  |
|----------|---|--|
| 9520-001 | ECS Membrane Processor with PMC/ISD: Installation Manual          | IOM-10   |
| 9520-002 | ECS Membrane Processor with PMC/ISD: OM&S                         | IOM-11   |
| 9514-003 | ECS Membrane Processor with PMC/ISD: Troubleshooting Guide        | <a href="http://www.vsthose.com">www.vsthose.com</a> |
| 9514-004 | ECS Membrane Processor with PMC/ISD: Pre-Installation Site Survey | <a href="http://www.vsthose.com">www.vsthose.com</a> |




Figure 1: How the Processor fits into the GDF layout

5567-001, Rev C




Figure 2: Processor Piping Diagram




Figure 3: ECS Vent Configurations

|   |   |
|---|---|
| <b>VST</b>  | Vapor Systems Technologies, Inc.<br>Springboro, Ohio 45066<br>www.vsthoas.com |
| Emissions Control system<br>ECS Vent Riser Configurations |   |
| SCALE   | DWG. NO.  |
| 1   | 5561-001  |
| REV   | E   |






Figure 4: Processor Isometric Drawing (1 of 2)




Figure 5: Processor Isometric Drawing (2 of 2)

## 2 Processor Operation

- The Veeder-Root Pressure software controls the *Processor* and is located within the TLS-350 console. The TLS-350 is an automatic tank gauging, compliance, and fuel-management system.
- The TLS-350 will be configured for either PMC or ISD control software.
- Warnings and alarms are announced through the various lights on the panel as well as through a paper print-out.




Figure 6: TLS-350 Face

### 2.1 TLS 350 Construction

- The *TLS Console* is constructed with fuel compatible materials and is approved for use in GDF's by UL (Underwriters Laboratories, Inc.) where wetted components and materials are tested for durability and resistance to corrosion.
- The *TLS Console* is designed to withstand power outages by storing critical system parameters in nonvolatile memory.
- The pressure sensor (supplied by Veeder-Root) is installed inside a dispenser.

## 2.2 Automatic Control

- Under automatic control, vapor pressure readings are compared to the programmed ON/OFF thresholds to determine the appropriate *Processor* state.
  - ▶ When the *Processor* is OFF and the UST pressure equals or exceeds the programmed ON vapor pressure threshold, the *Processor* is turned ON and remains so until the pressure equals or is less than the programmed OFF vapor pressure threshold.
  - ▶ During periods when there are no deliveries, if the *Processor* is ON continuously for longer than the programmed max 30 minutes runtime, the *Processor* is turned OFF.
  - ▶ It will remain OFF for the same number of minutes programmed as max runtime minutes before turning back ON.
  - ▶ It will continue to cycle on and off until the vapor pressure drops below the low/off threshold limit.
- During a delivery, if the *Processor* ON time exceeds the maximum run time, the *Processor* will be shut OFF.
  - ▶ After 3 seconds the *Processor* will be turned back ON if the pressure is above the high pressure threshold limit.
  - ▶ This cycle will continue until the delivery has ended or until the pressure goes below the low pressure threshold and the *Processor* is turned OFF.

## 2.3 Manual Control of the Processor

- From the PMC diagnostic menu, the *Processor* mode can be changed from **Automatic** to **Manual**.
- When the *Processor* control mode is **Manual**, the diagnostic menu allows the *Processor* to be directly turned **ON** and **OFF**.
  - ▶ This feature is to support the testing functionality of the *Processor* or compliance testing without needing the pressure to be at operational set points.
  - ▶ This is especially useful if the vapor space has been disturbed through the course of repair or testing.
- The current vapor pressure threshold settings are available through the diagnostic menu.
- Note: If the *Processor* is **ON** and the control mode is **Automatic**, changing the control mode to **Manual** mode will turn the *Processor* **OFF**.
- This feature is to support testing functionality of the *Processor* without needing the pressure to be at operational set-points.
- This function is also to be used for conducting testing or at any time compliant-testing involves opening of the vapor space.
- The current vapor pressure reading will also be available through the diagnostic menu.

At the conclusion of any testing or repairs, verify that the *Processor* has been set to "AUTOMATIC mode" at the TLS-350.

## 2.4 TLS Alarms

- During normal operation when the system is functioning properly and no warning or alarm conditions exist, the “ALL FUNCTIONS NORMAL” message will appear in the system status (bottom) line of the console display.
- If a warning or alarm condition occurs, the system displays the condition type and its location.
- If more than one warning or alarm condition exists, the display will alternately flash the appropriate messages.
- The system automatically prints an alarm report showing the warning or alarm type, its location, and the date and time the warning or alarm condition occurred.
- Warning and alarm posting causes the TLS 350 to activate:
  - ▶ Warning lights
  - ▶ Failure-Alarm indicator lights
  - ▶ Audible alarm
  - ▶ Automatic strip paper printout documenting the warning or alarm

## 2.5 Thresholds and Algorithms

- Two thresholds (high and low pressure) are used to activate and deactivate the *Processor* internal TLS-350 relay.
- Three thresholds can be set via the TLS keypad or serial RS232 commands. These thresholds include:
  - ▶ Vapor *Processor* **LOW PRESSURE THRESHOLD** set at -0.2" WC
    - Maximum negative UST pressure required in order to turn OFF the *Processor*
  - ▶ Vapor *Processor* **HIGH PRESSURE THRESHOLD** set at +0.2" WC
    - Minimum positive UST pressure required in order to turn ON the *Processor*
  - ▶ Vapor *Processor* runtime set at 30 minutes
    - Maximum allowable runtime
- The TLS 350 control algorithm checks the current UST pressure level and turns the *Processor* **ON** and **OFF** according to the high and low pressure thresholds.
- All **WARNINGS** and **ALARMS** should be resolved and then followed by **CLEAR TEST AFTER REPAIR** (found in the TLS menu) regardless of PMC and ISD software.

- The Veeder-Root Pressure Sensor (VRPS) reads every 20 seconds, and this reading is compared to the vapor-pressure thresholds to determine the *Processor* state, which will be either **ON** or **OFF**.
- DUE TO THE SAMPLE RATE OF 20 SECONDS, SOME DELAY OCCURS IN POSTING. THE ACTUAL VALUES DISPLAYED ON THE TLS MAY BE SLIGHTLY HIGHER THAN THE +.2"WC AND SLIGHTLY LOWER THAN THE -.2"WC SET POINTS.
- When the *Processor* is **OFF** and the high-vapor pressure threshold (+0.2"WC) is exceeded, the relay is enabled (which starts the *Processor*), and the relay remains enabled until the pressure drops below the low-vapor pressure (-0.2"WC) threshold.
- Automatic control is the default mode.
- The internal relay must be programmed as a **VST VAPOR PROCESSOR (VP)** through the TLS 350 relay setup menu.
- The *Processor* control algorithm will not be engaged until at least one relay of this type is detected by the TLS 350.
- Whenever the *Processor* runs more than 30 minutes, (whether you're using PMC or ISD software) the *Processor* is *automatically* turned OFF.
  - ▶ During this 30-minute period, the *Processor* will not be controlled by UST pressure and will remain OFF for 30 minutes.
- The *Processor* will then restart assuming the UST pressure is still above the lower threshold setting and the TLS is in the automatic controlled mode.
- Figure 7 shows the *Processor Run-Time* Algorithm.




Figure 7: Processor Run-Time Algorithm



2.5.1 TLS-350 (PMC): Alarm Troubleshooting Summary

| Displayed Message  | Description   | Light Indicator | Suggested Troubleshooting  |
|--------------------|---|-----------------|--|
| VP EMISSION WARN   | Mass emission exceeded the certified daily threshold.   | Yellow          | <ul style="list-style-type: none"> <li>• Troubleshooting Guide <a href="http://www.vsthose.com">www.vsthose.com</a>.</li> <li>• Exhibit 8</li> <li>• Exhibit 9</li> </ul>  |
| VP EMISSION FAIL   | 2 <sup>nd</sup> Consecutive mass emission failure.  | Red             |  |
| PMC SETUP FAIL     | PMC is not configured or missing components.  | Red             | <ul style="list-style-type: none"> <li>• Troubleshooting Guide <a href="http://www.vsthose.com">www.vsthose.com</a>.</li> <li>• See ISD Troubleshooting Guide, P/N 577013-819.</li> <li>• Exhibit 8</li> <li>• Exhibit 9</li> </ul>    |
| PMC SENSOR FAULT   | Component used by PMC has failed or reported an error condition. See Troubleshooting section for complete description of sensors and associated conditions that can cause a sensor fault. | Red             | <ul style="list-style-type: none"> <li>• Check for Smart Sensor Device Alarm or Fault.</li> </ul>  |
| VP DUTY CYCLE WARN | Duty cycle exceeds 18 hours per day or 75% of 24 hours.   | Yellow          | <ul style="list-style-type: none"> <li>• Troubleshooting Guide <a href="http://www.vsthose.com">www.vsthose.com</a>.</li> <li>• TLS 350 PMC Setup Procedure</li> <li>• Exhibit 10</li> <li>• Exhibit 9</li> <li>• Exhibit 4</li> </ul> |
| VP DUTY CYCLE FAIL | 2 <sup>nd</sup> Consecutive Duty Cycle Failure.   | Red             |  |

2.5.2 TLS-350 (ISD): Alarm Troubleshooting Summary

| Displayed Message                    | ISD Monitoring Category | Light Indicator | Description  | Suggested Troubleshooting <sup>1</sup>  |
|--------------------------------------|-------------------------|-----------------|--|---|
| ISD VAPOR LEAKAGE WARN               | Containment             | Yellow          | Containment system leaks at 2 times the TP-201.3 standard.                               | <b>Exhibit 4<br/>TP-201.3 (or equivalent test procedure)</b>                              |
| ISD VAPOR LEAKAGE FAIL <sup>2</sup>  | Containment             | Red             | 8 <sup>th</sup> Consecutive Failure of Pressure Integrity (Vapor Leak) Test              |   |
| ISD GROSS PRESSURE WARN              | Containment             | Yellow          | 95 <sup>th</sup> percentile of 7-days' ullage pressure exceeds 1.3 IWC.                  | <b>Exhibit 9<br/>Exhibit 10</b>   |
| ISD GROSS PRESSURE FAIL <sup>2</sup> | Containment             | Red             | 8 <sup>th</sup> Consecutive Failure of Gross Containment Pressure Test                   |   |
| ISD DEGRD PRESSURE WARN              | Containment             | Yellow          | 75 <sup>th</sup> percentile of 30-days' ullage pressure exceeds 0.3 IWC.                 |   |
| ISD DEGRD PRESSURE FAIL <sup>2</sup> | Containment             | Red             | 31 <sup>st</sup> Consecutive Failure of Degradation Pressure Test                        |   |
| FLOW COLLECT WARN                    | Collection              | Yellow          | Vapor collection flow performance is less than 50%.                                      | <b>Exhibit 5<br/>Exhibit 6<br/>Exhibit 17<br/>TP-201.4 (or equivalent test procedure)</b> |
| FLOW COLLECT FAIL <sup>2</sup>       | Collection              | Red             | 2 <sup>nd</sup> Consecutive Failure of Vapor Collection Flow Performance Monitoring Test |   |
| VP EMISSION WARN <sup>3,4</sup>      | Processor               | Yellow          | Mass emission exceeded the certified threshold.  | <b>Exhibit 8<br/>Exhibit 9</b>  |
| VP EMISSION FAIL <sup>3,4</sup>      | Processor               | Red             | 2 <sup>nd</sup> Consecutive Mass emission test failure.                                  |   |

| Displayed Message               | ISD Monitoring Category | Light Indicator | Description   | Suggested Troubleshooting <sup>1</sup>   |
|---------------------------------|-------------------------|-----------------|---|--|
| VP DUTY CYCLE WARN <sup>3</sup> | Processor               | Yellow          | Duty cycle exceeds 18 hours per day or 75% of 24 hours. | <ul style="list-style-type: none"> <li>• PMC Setup Procedure</li> <li>• Exhibit 4</li> <li>• Exhibit 9</li> <li>• Exhibit 10</li> <li>• TP-201.3 (or equivalent test procedure)</li> </ul> |
| VP DUTY CYCLE FAIL              | Processor               | Red             | 2 <sup>nd</sup> Consecutive Duty Cycle Test Failure.    |  |
| ISD SENSOR OUT WARN             | Self-Test               | Yellow          | Failure of Sensor Self-Test                             | <ul style="list-style-type: none"> <li>• Confirm ISD sensor &amp; module installation / communication per VR 204 IOM Section 12, Chapter 2</li> </ul>                                      |
| ISD SENSOR OUT FAIL             | Self-Test               | Red             | 8 <sup>th</sup> Consecutive Failure of Sensor Self-Test |  |
| ISD SETUP WARN                  | Self-Test               | Yellow          | Failure of Setup Test                                   | <ul style="list-style-type: none"> <li>• Confirm EVR/ISD programming per VR 204 IOM Section 12</li> </ul>  |
| ISD SETUP FAIL <sup>2</sup>     | Self-Test               | Red             | 8 <sup>th</sup> Consecutive Failure of Setup Test       |  |

**Note: The alarms listed in above table will also activate an audible alarm**

<sup>1</sup>See ISD Troubleshooting Manual P/N 577013-819 found at <http://www.veeder.com/object/577013-819.html> and the VST ISD Troubleshooting Guide 9513-003 found at [http://www.vsthose.com/pdf/Troubleshooting\\_Guide\\_ECS\\_Membrane\\_Processor\\_Sept\\_2010.pdf](http://www.vsthose.com/pdf/Troubleshooting_Guide_ECS_Membrane_Processor_Sept_2010.pdf)

<sup>2</sup>ISD Shut Down Alarms – see Figure 48 of IOM Section 12

<sup>3</sup>This warning will result in an ISD VP Status Warn

<sup>4</sup>This failure will result in an ISD VP Status Fail

### 3 Post-Installation Power-Up Tests



During post-installation testing, the *Processor* will use outside air, not gasoline vapor from the USTs to conduct these tests.

- Close the 3 valves located on the inlet and the outlets of the *Processor*.
- Remove the plugs on the 3 tees located on the inlet and the outlets of the *Processor*.

#### 3.1 Post-Installation Electrical Connections

- Prior to starting the *Processor*, the Motor Starter Relay Coil must be wired to the TLS-350 4-Relay Module. The *Processor* cannot start until this connection is made.

**CAUTION: Make sure the TLS-350 is in the Manual OFF Mode prior to installing the wires. Make sure the power to the motors is OFF at the electrical panel.**

- Install two 18 AWG wires that connect the Motor Starter Relay Coil to the TLS-350 4-Relay Module.
- See Figure 8 for connections to the TLS-350.
- Leaving the TLS-350 in the Manual OFF Mode, the power to the motors can be turned ON at the electrical panel.
- After the connection has been made, proceed to the Post-Installation Power-Up Tests.
- See Section 3.2.




Figure 8: Wiring the Motor Starter Relay Coil

### 3.2 Required Post-Installation Power-Up Tests

- These tests are used for the Post-Installation Power-Up and Troubleshooting Test.
- Once you have properly prepared the Processor for testing, conduct tests 1 through 4 found in the table below.

|    | Test                                | Page  |
|----|-------------------------------------|-------|
| 1. | Electrical Connection Check         | 11-36 |
| 2. | Motor Rotation Test                 | 11-36 |
| 3. | Heat-Trace Continuity Test          | 11-42 |
| 4. | HC Sensor & HC Sentry 24 Power Test | 11-43 |




Figure 9: ECS Piping Configuration

### 3.3 TLS Manual Mode

- Follow the steps at the TLS console to put the TLS-350 in the Manual “OFF” Mode, as shown in Figure 10 for the PMC Diagnostic Menu and Figure 131 for the ISD Diagnostic Menu.
- After the post-installation power-up tests are complete, put the *Processor* in the Manual “OFF” position.
- ALWAYS BE SURE TO REFER TO THE MOST RECENT VEEDER-ROOT PMC MANUAL (Manual #577013-801).

#### PMC Diagnostic Menu with PMC Software (VR Reference Manual #577013-801)




Figure 10: PMC Diagnostic Menu with PMC Software






Figure 11: PMC Diagnostic with ISD Software

### 3.4 Electrical Connection Test

- Put the TLS-350 in the Manual OFF mode as shown in the Diagnostic Menus (See Figure 10 or Figure 11).
- Check all electrical and control connections prior to applying power to the *Processor*.
- Make sure that all connections have been made to the proper terminals and that all connections are tight.
  - ▶ In the electrical room:
    - HC Sentry 24VDC (output) / 115V power
    - Fused disconnects
    - Panel breaker wiring connections
    - Starter
    - TLS 4-relay module
    - HC Sentry Interface Cable
  - ▶ At the *Processor*:
    - Blower motor
    - Vacuum pump motor
    - Heat trace cable
    - HC sensor
    - All equipment grounds

### 3.5 Motor-Rotation Test

- The purpose of this test is to insure that the motors are rotating in the correct direction.
- Turn the power OFF at the disconnect switch located near the *Processor*.
- Put the *Processor* in the manual ON Mode at the TLS as shown in the diagnostic menu in Figure 10 or Figure 11.
  - ▶ Remove the cover from the *Processor*.
- Bump the power (briefly energize) the power at the disconnect switch.
  - ▶ Visually check the motor rotation for the vacuum pump and blower motors to be sure they are rotating according to the arrows that are shown on the equipment.
  - ▶ The rotation of the motors can be visually checked by looking at the rotation of the fan located on the end of each motor.

## CAUTION

Always obtain approval from the local authority having jurisdiction.

Installation of the *Processor* must comply with (if applicable):

- CARB CP-201
- VST EVR E.O.
- Fire Marshal
- Water Board
- Local Air Pollution District
- ICC
- NEC
- NFPA 30 and 30A
- UL
- Any other applicable federal, state, and local codes

**CAUTION: DO NOT RUN THE PUMP(S) FOR ANY EXTENDED PERIOD OF TIME UNTIL THE PROPER ROTATION IS VERIFIED OR YOU COULD CAUSE SERIOUS DAMAGE.**

Motor Rotation Test, continued . . .

- If the motors are rotating in the proper direction, put the TLS in the manual OFF mode.
- If either of the motors are not rotating in the correct direction:
  - ▶ Put the *Processor* in the manual “OFF” Mode at the TLS.
  - ▶ Follow safety regulations regarding lock-out / tag-out procedures to insure power cannot be turned on to the *Processor*.
- Three-Phase Motors:
  - ▶ At the motor junction box at the ECS *Processor*, switch any two of the three power circuits for the motor that is not rotating in the correct direction.
  - ▶ See Figure 13 and Figure 15.
- Single-Phase Motors:
  - ▶ Check the wiring connection diagrams for the specific motor that is not rotating in the correct rotation and correct as required.
  - ▶ See Figure 12 and Figure 14.
- Remove the lock from the lock-out and apply power to the *Processor*.
- Return the *Processor* to the manual ON Mode at the TLS-350.
- Bump the power (briefly energize) power at the disconnect switch.
- Re-check the equipment for proper rotation.
- Return the *Processor* to the manual OFF mode at the TLS.

*If either motor will not run, refer to the ECS Troubleshooting Guide found on the VST website at:  
[www.vsthose.com](http://www.vsthose.com).*




Figure 12: Vacuum Pump: Single-Phase Motor Wiring Diagram




Figure 13: Vacuum Pump: Three-Phase Motor Wiring Diagram

FILENAME: 5564-001




Figure 14: Blower: Single-Phase Motor Wiring Diagram




Figure 15: Blower: Three-Phase Motor Wiring Diagram

### 3.6 Heat-Trace Continuity Test

The purpose of the Heat Trace Continuity test is to insure there is not a short or damage to the Heat Trace cable. The self-regulating heating cable provides safe and reliable heat tracing for process temperature maintenance.

In electronics, a continuity test is the checking of an electric circuit to see if current flows (that it is in fact a complete circuit). A continuity test is performed by placing a small voltage (wired in series with an LED) across the chosen path. If the electron flow is inhibited by broken conductors, damaged components, or excessive resistance, the circuit is "open." Devices that can be used to perform continuity tests include multimeters or specialized continuity testers.

#### 3.6.1 Preparing the heat trace electrical junction box for the test:

- **CAUTION:** Be sure to use Lockout/Tag-Out procedures when performing work on the *Processor* or while working on electrical components.
1. Put the *Processor* in the manual OFF mode at the TLS-350.
  2. Trip the heat trace cable 115v circuit breaker in the electrical panel to remove the power from the heat trace cable.
  3. Remove the cover to the *Processor*.
  4. Remove the heat trace electrical junction box cover by removing the 4 hold-down screws and lifting the molded plastic cover off the base.

#### 3.6.2 Testing the heat trace circuit

1. Using a multimeter or continuity tester, check the continuity (current flow) across the heat trace circuit as shown in Figure 16.
2. Verify the circuit is complete between the positive terminal and the neutral at the three-position terminal block.
3. If the red light does not come on, the heat trace circuit is open. (If electron flow is inhibited by broken conductors, damaged components, or excessive resistance, the circuit is "open.):
  - a) Check that all wiring connections are correct.
  - b) Repair/replace the heat trace cable as required to correct the problem.
4. Replace the cover on the heat trace electrical junction box using the 4-hold down screws.
5. Replace the cover on the *Processor*.
6. The *Processor* can now be put back in the Automatic Mode at the TLS-350 provided all work is completed.



Figure 16: Heat Trace Circuit Test


### 3.7 HC Sensor and HC Sentry Power Test

- The purpose of this test is to insure there is 24VDC power to the HC sensor and the HC Sentry module.



### 3.7.1 Checking 24 VDC Power to the HC Sensor

- The 24VDC power to the HC sensor is from the HC Sentry Module.
- Using the multimeter, check the + to Gnd connection on the HC Sentry.
- If there is no 24VDC power, check power to the HC Sentry module.
- If the unit does not function properly, see the ECS Troubleshooting Guide found on the VST website at [www.vsthose.com](http://www.vsthose.com).



*Figure 17: HC Sentry Interface Module Front View: Power and ON/OFF Switch*

### 3.7.2 Checking 24VDC Power to the HC Sentry Module

- The HC Sentry is powered from a 115V outlet and uses a 115v/24VDC power converter, which is VST supplied.
- Check that the unit is ON.
- Check that the Power Light is ON.
- If the power light is not ON when the unit is ON:
  - ▶ Check to make sure there is 115v power to the outlet.
  - ▶ Check the ON switch on the HC Sentry module.
  - ▶ Check that the 115v/24VDC power converter is functioning.
  - ▶ If the unit does not function properly, see the ECS Troubleshooting Guide at [www.vsthose.com](http://www.vsthose.com).



Figure 18: HC Sentry Interface Module Back View: Power "ON" Light

### 3.8 Processor Leak Test: After Repair (Only) ECS Unit

#### 3.8.1 Purpose of the Test

---

- The purpose of the After Repair Leak Test is to insure that all of the ECS unit tubing fittings and tubes located inside the ECS unit are leak-free after the tubing has been disrupted for ECS unit repair.

#### 3.8.2 Preparation

---

- Follow these steps to prepare the ECS unit for the Leak Test after repairs have been made.
  1. Conduct this test with the Veeder-Root TLS-350 in the Manual "OFF" Mode.
  2. Turn OFF power to the ECS unit and motors

#### 3.8.3 Functional Test Procedures

---

1. Close the three (3) valves at the ECS unit.
2. Remove a 2" plug from one of the pipe tees at the ECS unit. (See Figure 10)
3. Install the Leak Test Fixture (See Figure 21) in the empty 2" pipe tee on the ECS unit.
4. The leak check is conducted with 1.0 to 2.0 PSI nitrogen.
5. Make sure the isolation valve on the Leak Test Fixture is fully closed.
6. Make sure the Leak Test Fixture pressure regulator is fully closed.
7. Make sure the nitrogen regulator is set at a maximum of 20 PSI outlet pressure.
8. Slowly open the valve on the test fixture to pressurize the ECS unit at 1.0 to 2.0 PSI compressed nitrogen.

**CAUTION: PRESSURIZING THE ECS UNIT OVER A MAXIMUM OF 5.0 PSI MAY CAUSE DAMAGE TO THE ECS UNIT O-RINGS AND/OR PUMP SEALS, WHICH WILL VOID ALL WARRANTIES OF THE ECS UNIT**

9. With the ECS unit pressurized between 1.0 to 2.0 PSI compressed nitrogen, spray a soapy solution on each fitting to check for bubbles:
  - If bubbles do not appear, the connection is tight.
  - If bubbles do appear, tighten the leaking fitting 1/8" turn (maximum) and re-check for leaks.
  - If the fitting cannot be tightened so that the connection is leak free, replace the 45° flare tube assembly that is leaking with a new tube assembly.
10. Continue this process until all the internal tube fittings have been checked and found leak free.
11. Once this test is complete and all the piping fittings are leak free, remove the compressed nitrogen connection to the Leak Test Fixture.
12. Remove the Leak Test Fixture.
13. Re-install the 2" pipe plug.
14. After ALL repairs are complete:
  - Open the three (3) valves at the ECS unit.
  - Turn ON the power to the ECS unit and motors.
  - Return the Veeder-Root TLS-350 to the "AUTOMATIC" Mode.



Figure 19: Processor Inlets & Outlets



Figure 20: Typical Leak Check Test Fixture

### 3.9 Preparing the Processor for Field Operation

#### 3.9.1 Setting the TLS-350 Threshold Values

- Although the threshold values are in the Veeder-Root posting reports, the Veeder-Root PMC and ISD manuals do not address changing the initial "Default" values to match the defaults that are prescribed in VST Executive Orders VR-203 and VR-204.
- In the PMC Set Up menu verify / set the TLS-350 to the following values:

|                        | Software  | Description   | Default    | Threshold Values |
|------------------------|-----------|---|------------|------------------|
| IN THE PMC SET UP MENU | PMC / ISD | Vapor Processor Max. Run-Time   | 60 minutes | 30 minutes       |
|                        | PMC / ISD | Over Pressure Limit   | 0.0"WC     | 1.0"WC           |
|                        | PMC / ISD | Analysis time   | 0.0        | 11:59 PM.        |
|                        | PMC / ISD | Turn off vapor processor threshold                                      | -0.2"WC    | NO CHANGE        |
|                        | PMC / ISD | Turn on vapor processor threshold                                       | +0.2"WC    | NO CHANGE        |
|                        | PMC Only  | Duty cycle limit  | 75%        | NO CHANGE        |
|                        | PMC / ISD | All the other associated threshold values are pre-set from the factory. |            |                  |

- **CAUTION:** These values MUST be set prior to putting the TLS-350 into the AUTOMATIC MODE.

#### 3.9.2 Processor Configuration Prior to Start Up



- After all the post-installation power-up tests are complete:
- Replace the plugs on the 3 tees located on the inlet and the outlet of the *Processor* and tighten.
- Lock in the open position the 3 valves located on the inlet and the outlet of the *Processor*.
- Leave the *Processor* in the manual "OFF" mode at the TLS 350.
- See Figure 10 or Figure 11.
- Complete the Post-Installation Power-Up checklist form (found on the next page of this document).

### 3.10 Post-Installation Power-Up Checklist

| Post-Installation Power-Up Checklist Form   |                            |                            |                            |                          |                          |
|---|----------------------------|----------------------------|----------------------------|--------------------------|--------------------------|
| VST-ASC #:  | Date:                      |                            |                            |                          |                          |
| ASC Name:   |                            |                            |                            |                          |                          |
| VST-ASC Certification Level   | <input type="checkbox"/> A | <input type="checkbox"/> B | <input type="checkbox"/> C |                          |                          |
| ASC Company:  |                            |                            |                            |                          |                          |
| GDF Name:   |                            |                            |                            |                          |                          |
| Address:  |                            |                            |                            |                          |                          |
| City:   |                            |                            | State:                     | Zip Code:                |                          |
| GDF Contact Person Name:  |                            |                            |                            |                          |                          |
| GDF Contact Person Title:   |                            |                            |                            |                          |                          |
| GDF Contact Person Phone:   |                            |                            |                            | E-mail:                  |                          |
| <b>Notes:</b> Use this form to note details of the note details of the power-up process |                            |                            |                            |                          |                          |
| Checkpoints   | Passed                     | Failed                     | Repaired                   | Replaced                 | Action Items if Required |
| ECS Processor Components  |                            |                            |                            |                          |                          |
| All electrical connections checked  | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/> |                          |
| Blower motor rotation checked   | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/> |                          |
| Vacuum pump motor rotation checked  | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/> |                          |
| Heat-trace continuity checked   | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/> |                          |
| HC sentry power checked   | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/> |                          |
| HC sensor power checked   | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/> |                          |
| Set threshold values  | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/>   | <input type="checkbox"/> |                          |

Attach product sticker with bar code here

The above post-installation power-up tests were performed in accordance with IOM found in the VST's Executive Orders.

\_\_\_\_\_  
ASC Signature

## 4 Processor Start-Up

- Use the following start-up procedure:
  - ▶ When initially starting the *Processor* or
  - ▶ When re-starting the *Processor* following maintenance or testing.

| START-UP PROCEDURE  |   |
|---|---|
| 1.  | <ul style="list-style-type: none"> <li>• Make sure the plugs are installed on the 3 tees at the <i>Processor</i>.</li> </ul>  |
| 2.  | <ul style="list-style-type: none"> <li>• Make sure all 3 valves are locked in the OPEN position at the <i>Processor</i>.</li> </ul>   |
| 3.  | <ul style="list-style-type: none"> <li>• Make sure power is on to the:                             <ul style="list-style-type: none"> <li>▪ Heat-trace cable</li> <li>▪ HC sentry</li> <li>▪ HC sensor</li> <li>▪ ECS vacuum pump</li> <li>▪ ECS recirculation blower</li> </ul> </li> </ul>  |
| 4.  | <ul style="list-style-type: none"> <li>• Make sure the pressure sensor is operational.</li> </ul>   |
| 5.  | <ul style="list-style-type: none"> <li>• Make sure that the GDF is vapor tight. (TP 201.3 and Exhibit 4)</li> </ul>   |
| 6.  | <ul style="list-style-type: none"> <li>• After the TLS is installed and configured and all EVR equipment has been installed, the <i>Processor</i> can become operational.</li> <li>• Put the TLS in the AUTOMATIC MODE.</li> <li>• If the pressure is above +0.2" WC, the <i>Processor</i> will start and the auxiliary relays will close.</li> <li>• If the pressure is below +0.2" WC, the <i>Processor</i> will not start because the UST system-pressure is below the high-pressure threshold.</li> </ul> |
| <p>NOTE: All exhibits can be found in Executive Orders VR-203 and VR-204. VR-203 is for those systems using PMC. VR-204 is for those systems using ISD.</p> |   |

**CAUTION:**

Locking ball valve handles at the *Processor* inlet and outlet must not be removed.

## 4.1 Processor Shut-Down Procedure

CAUTION: POWER TO THE HC SENSOR AND THE HEAT TRACE CABLE MUST BE TURNED OFF INDIVIDUALLY FROM DIFFERENT POWER SOURCES. THEY DO NOT RECEIVE THEIR POWER FROM THE SAME SOURCE AS THE MOTORS.

### 4.1.1 Processor Shut-Down Procedure

- The *Processor* must be **SHUT DOWN** for all testing and maintenance.
- The only exception is for the “Determination of VST Processor Activation Pressure Test” (exhibit 9).
- To turn the *Processor* **OFF**:
  - a) Through the front panel of the TLC console, access the PMC menu.
  - b) Select *Processor* **MANUAL** mode.
  - c) Verify that the status is **OFF**.
  - d) Remove power to the *Processor* by either turning **OFF** the breaker or by disconnecting power at the *Processor*.
- To return the *Processor* to the **AUTOMATIC** mode:
  - a) Through the front panel of the TLS console, access the PMC menu.
  - a) Select *Processor* **AUTOMATIC** mode.
  - b) Turn the power **ON** to the *Processor*.

### 4.1.2 HC Sensor and HC Sentry Module

- The 115VAC/24 VDC power supply for the HC Sentry Module / HC sensor can be unplugged, which will remove power to the HC Sensor in the *Processor*.

### 4.1.3 Heat-Trace Cable

- The heat trace cable should not be turned **OFF** unless maintenance is performed in an area that could cause electrical shock.
- Turn **OFF** power to the heat-trace cable from the 115v electrical-panel breaker.



## 5 Processor Maintenance

- The VST Emissions Control System consists of only two components having moving parts: a blower and a vacuum pump, which do not have any scheduled maintenance for 10 years.
- The remaining components are tested, but they require maintenance only if they fail their tests:
  - ▶ Heat trace cable
  - ▶ HC sensor
  - ▶ HC Sentry module
- Because the system continually monitors itself and notifies you of any problems or situations, it requires very little attention.
- The table on the following page outlines the required annual inspections and tests.
  - ▶ Preventative Maintenance Checklist Form
  - ▶ GDF Maintenance Records

## 5.1 Annual System Compliance Testing

| <b>Annual System Compliance Testing</b>  |                                      |
|--|--------------------------------------|
| Static Pressure Test:  | TP-201.3<br>Exhibit 4                |
| Dynamic Back Pressure Test:  | TP-201.4                             |
| Liquid Removal Test Procedure:   | Exhibit 5                            |
| Hydrocarbon Sensor Verification Test:  | Exhibit 8                            |
| Vapor Pressure Sensor Verification Test:   | Exhibit 10                           |
| VST <i>Processor</i> Activation Test:  | Exhibit 9                            |
| Nozzle Bag Test Procedure:   | Exhibit 7                            |
| ISD Operability Test:<br>(Flow Meter Operability Test)   | Exhibit 17 (Exec. Order VR-204 only) |
| <p><b>NOTE:</b> All exhibits can be found in Executive Orders VR-203 and VR-204. VR-203 is for those systems using PMC. VR-204 is for those systems using ISD.</p> |                                      |

## 5.2 Annual Inspections and Replacements

| Annual <i>Processor</i> Inspections and Replacements |  |   |  |   |                      |
|--|--|---|--|---|----------------------|
| Component  | Procedure  | Fail Criteria   | Corrective Action                        | Reference Manuals   | Authorized Personnel |
| Blower   | Replace the blower every ten years or 15,000 hrs. (whichever comes first).         |   |  | IOM – 11<br>Found in Executive Orders<br>VR-203 and VR-204                  | VST ASC Level C      |
| Vacuum pump  | Replace blower every ten years or 15,000 hrs. (whichever comes first).             |   |  |   |                      |
| Vacuum pump drive coupling - rubber insert           | Visually inspect the drive coupling between the vacuum pump and the motor for wear | Rubber debris is found on or around the vacuum-pump base.   | Replace the drive coupling rubber insert | IOM – 11<br>Found in Executive Orders<br>VR-203 and VR-204                  |                      |
| Heat Trace Cable                                     | Check the continuity of the heat trace cable.                                      | If the heat trace cable circuit is open, the cable has failed.  | Replace the heat- trace cable            | IOM – 11<br>Found in Executive Orders<br>VR-203 and VR-204                  |                      |
| HC Sensor  | Test the HC sensor   | The difference shall be within $\pm 1.0\%$ HC concentration from the calibration gas concentration for zero and mid-range gas and $\pm 2.0\%$ for the high-range gas. | Replace the HC Sensor                    | IOM – 11 and<br>Exhibit 8<br>Found in Executive Orders<br>VR-203 and VR-204 |                      |

5.3 Preventative Maintenance Checklist Form

| Component   | Frequency | Date Inspected | Completed | Required Action Items |
|---|-----------|----------------|-----------|-----------------------|
| <b>PROCESSOR</b>  |           |                |           |                       |
| <ul style="list-style-type: none"> <li>Inspect drive coupling on the vacuum pump.</li> </ul>    | Yearly    |                | [ ]       |                       |
| <ul style="list-style-type: none"> <li>Check the continuity of the heat trace cable.</li> </ul> |           |                | [ ]       |                       |
| <b>RECIRCULATION BLOWER</b>   |           |                |           |                       |
| Replace every 10 years or 15,000 hours, whichever comes first.                                  |           |                | [ ]       |                       |
| <b>VACUUM PUMP</b>  |           |                |           |                       |
| Replace every 10 years or 15,000 hours, whichever comes first.                                  |           |                | [ ]       |                       |

5.4 GDF Maintenance Record

| Date of Maintenance/<br>Test/Inspection/Failure<br>(including date and time of<br>maintenance call) | Repair<br>date to<br>correct<br>test<br>failure | Maintenance/Test/Inspection<br>Performed and Outcome | Affiliation | Name and<br>Technician ID<br>Number of Individual<br>Conducting<br>Maintenance or Test | Telephone<br>Number |
|---|---|--|-------------|--|---------------------|
|   |   |  |             |  |                     |
|   |   |  |             |  |                     |
|   |   |  |             |  |                     |
|   |   |  |             |  |                     |
|   |   |  |             |  |                     |
|   |   |  |             |  |                     |
|   |   |  |             |  |                     |
|   |   |  |             |  |                     |
|   |   |  |             |  |                     |
|   |   |  |             |  |                     |

# Component Replacement

---

## 6 ECS Unit Purging Instructions Prior to Service or Maintenance

### 6.1 Purpose

- Prior to disassembly of the ECS unit, the ECS must be purged of gasoline vapor when internal components or internal tubing are removed for service or maintenance.

### 6.2 Tools Required

- The following tools are needed to purge the ECS unit of gasoline vapors:
  1. Large crescent wrench
  2. A Leak Check Test Fixture
  3. 1-bottle of nitrogen
  4. ¼" tubing (to connect the nitrogen bottle to the leak check test fixture)

### 6.3 Preparation

**CAUTION: THE ECS UNIT IN THE TLS DIAGNOSTIC MENU MUST BE IN THE MANUAL "OFF" MODE AND THE POWER TO THE ECS MUST BE TURNED OFF BEFORE PURGING THE ECS UNIT. See Figure 12 or Figure 13.**

1. Close the Vapor Inlet and Vapor Return isolation valves
  - The air outlet isolation does not have to be closed
  - See Figure 21.
2. Remove the caps from the Vapor Inlet and Vapor Return tees
  - The cap on the Air Outlet tee does not have to be removed
  - See Figure 21.
3. Install the Leak Check Test Fixture at the Vapor Inlet tee
  - Make sure the valve on the fixture is closed
  - Make sure the pressure regulator is set to zero flow
  - See Figure 22.
4. Connect the nitrogen bottle to the Leak Check Test fixture using ¼" tubing
  - **CAUTION: Make sure the nitrogen regulator is set to 20 psi.**

### 6.4 Procedures

1. Open the nitrogen valve.
2. Check to make sure the nitrogen supply pressure is 20 psi.
3. Slowly open the isolation valve on the leak check fixture.
4. Slowly open the pressure regulator so the supply pressure is at 1-2 psi.
5. Allow the nitrogen to purge the ECS unit for 2 -3 minutes.

**PURGING OF THE ECS UNIT IS COMPLETE**

### 6.5 Post Purging Procedures

- 1. Close the nitrogen valve
- 2. Remove the 1/4" tubing from the nitrogen bottle to the leak check fixture
- 3. Close the pressure regulator valve
- 4. Close the isolation valve
- 5. Remove the leak check fixture from the ECS unit

THE ECS UNIT IS NOW READY FOR SERVICE OR MAINTENANCE

### 6.6 Post Service or Maintenance

- 1. Make sure the caps have been replaced in the tees
- 2. Make sure the valves on the Vapor Inlet and the Vapor Return are open
- 3. Make sure the ECS is set at the TLS to the AUTOMATIC MODE




Figure 21: Processor Inlets & Outlets




Figure 22: Typical leak-check fixture

## 7 Blower Replacement

### 7.1 Blower Replacement Safety



Use lockout / tagout procedures prior to starting work.

### 7.2 Removing the Blower

1. Put the TLS 350 in the manual "OFF" mode.
  - See Figure 10 or Figure 11.
2. Disconnect power to the blower and vacuum pump motors. Do this at both the breaker and at the disconnect switch. The disconnect switch is located near the *Processor*.
3. Close the ball valves between the *Processor* and the vents. See Figure 21.
4. Conduct ECS Unit Purge Procedure (See Section 6 of this document).
5. Completely remove the two blower  $\frac{3}{4}$ " - 45° flare inlet and out tubes.
  - See Figure 24
  - NOTE: The nuts on the tubing are  $\frac{3}{4}$ " 45° flare, use caution not to damage the flared ends on the tubing or the threads on the nuts after removal.
6. Remove the two 45° flare inlet and outlet connection fittings from the blower.
7. Disconnect and remove the blower electrical from the motor.
  - See Figure 23.
8. Remove (4)  $\frac{1}{4}$ " x  $\frac{3}{4}$ " mounting bolts.
  - The 4 holes in the blower stand are tapped  $\frac{1}{4}$ ".
  - Keep the (4)  $\frac{1}{4}$ " bolts for reuse or replace them with new ones.
  - CAUTION: The blower end of the blower/motor assembly is heavier than the motor end, which may cause the blower to fall off the stand. USE CAUTION when removing the bolts.
9. Remove the blower from the stand.



### 7.3 Installing the New Blower

1. Place the new blower on the blower stand.
2. Install and hand tighten the (4) ¼" x ¾" blower mounting bolts.
3. Install the two 45° flare inlet and outlet connection fittings into the blower.
4. Install the ¾" inlet and outlet tubing.
  - Do not use any thread-sealing compound when assembling the 45° flare nuts.
  - NOTE: When tightening the 45° flare nuts: Clamp the tube flare between nut and nose body of the tube by screwing the nut on finger tight. Tighten with a wrench an additional ¼ turn for a metal-to-metal seal.
5. After the tubing is installed and the 45° flare nuts tightened, tighten the (4) mounting bolts.
6. Reconnect the electrical power wires to the blower motor.
7. Remove the lock(s) and tags from the lockout & tagout.
8. Conduct a *Processor* Leak Check – see Section 3.8 of this manual.
9. Open the ball valves between the Processor and the vent risers.
10. Turn ON power to the blower and vacuum pump at the breaker.
11. Put the TLS-350 in the manual ON mode.
12. Bump the power (briefly energize) the power at the disconnect switch.
13. Check the rotation of the blower motor.
14. Engage the disconnect switch.
15. After work is completed, put the TLS-350 in the AUTOMATIC mode.

See Figure 10 or Figure 11.



Figure 23: Blower electrical connection conduit




Figure 24: Blower inlet and outlet tubing connections and mounting bolts

## 8 Vacuum Pump Replacement

### 8.1 Safety



Use lockout / tagout procedures prior to starting work.

### 8.2 Removing the Vacuum Pump

1. Put the TLS 350 in the manual "OFF" mode.
  - See Figure 10 or Figure 11.
2. Disconnect power to the blower and vacuum pump motors. Do this at both the breaker and at the disconnect switch. The disconnect switch is located near the *Processor*.
3. Close the ball valves between the Processor and the vent risers.
  - NOTE: Before you begin disassembling; note that the vacuum pump and the motor are attached to a common base plate.
4. Conduct ECS Unit Purge Procedure (See Section 6 of this document).
5. Completely remove the vacuum pump  $\frac{1}{2}$ " outlet tubing.
  - See Figure 25.
6. Completely remove the vacuum pump  $\frac{1}{2}$ " and  $\frac{1}{4}$ " inlet 45° flare tubing and all pipe fittings connected to the vacuum pump.
  - See Figure 26.
7. Completely remove the  $\frac{1}{4}$ " HC sensor inlet tubing at the air outlet and the HC sensor.
  - See Figures 27 and 28.
  - NOTE: The tube ends are a Parker 45° flare, use caution not to damage the flared ends on the tubing or the threads on the nuts after removal.
8. Disconnect and remove the vacuum pump electrical from the motor.
9. Remove (4)  $\frac{1}{4}$ " x 1- $\frac{1}{2}$ " mounting bolts from the vacuum pump motor assembly base plate.
  - Note: The vacuum pump and motor will stay connected to the base plate.
  - Keep the (4) bolts for reuse or replace with new.
10. Slide the vacuum pump out from under the blower stand.

### 8.3 Installing the new Vacuum Pump and Vacuum Pump Motor Assembly

1. Slide the new vacuum pump under the blower stand and align the mounting holes.
2. Install the (4) 1/4" x 1-1/2" vacuum pump base mounting bolts.
3. Tighten the mounting bolts so that the bottom of the vacuum pump base is 1/8" from the ECS base.
4. Re-install the 1/2" and 1/4" inlet 45° flare tubing and all pipe fittings connected to the vacuum pump.
5. Re-install the 1/2" outlet tubing.
6. Re-install the 1/4" HC sensor inlet tubing.  
Do not use any thread sealing compound when assembling the 45 ° flare nuts.

**NOTE:** When tightening the 45° flare nuts: Clamp the tube flare between nut and nose body of the tube by screwing the nut on finger tight. Tighten with a wrench an additional 1/4 turn for a metal-to-metal seal.

7. Reconnect the electrical power wires to the vacuum pump motor.
8. Conduct a Processor Leak Check – see Section 3.8 of this document.
9. Open the ball valves between the *Processor* and the vent risers.
10. Remove the lock(s) and tags from the lockout & tagout.
11. Turn ON power to the blower and vacuum pump at the breaker, but not at the disconnect switch.
12. Turn the Processor to the **MANUAL ON** mode.
13. Bump the power (briefly energize) the disconnect switch.
14. Check rotation of vacuum pump motor.
15. After work is completed, put the TLS-350 in the **AUTOMATIC** mode.

See Figure 10 or Figure 11.




Figure 25: Vacuum pump outlet tubing connection




Figure 26: Vacuum pump inlet tubing and fittings




Figure 27: Vacuum pump electrical connection / vacuum pump outlet tubing / HC sensor inlet tubing




Figure 28: Air outlet / vacuum pump outlet / HC sensor inlet tubing

## 9 Membrane Replacement

### 9.1 Safety



Use lockout / tagout procedures prior to starting work.

### 9.2 Removing the Membrane from the Membrane Housing

1. Put the TLS 350 in the manual "OFF" mode. See Figure 10 or Figure 11.
2. At the breaker and at the disconnect switch, disconnect power to the heat trace cable, the vacuum pump, and the blower.
3. Close the ball valves between the *Processor* and the vent risers.
4. Conduct ECS Unit Purge Procedure (See Section 6 of this document).
5. Disconnect and remove the  $\frac{1}{2}$ " 45° flare tubing from the top and side of the membrane housing:  
See Figure 29.

NOTE: The nuts on the tubing are  $\frac{3}{4}$ " 45° flare. Use caution not to damage the flared ends on the tubing or the threads on the nuts after removal.

6. Remove the (4)  $\frac{1}{4}$ " bolts from the top plate (on top of the membrane housing).
7. Keep the (4) bolts/washers/lock washers for reuse.
8. Remove the top plate. A small lever may have to be used to gently pry the top plate off the membrane housing.

The top plate seals against the vertical tube with an o-ring. Use caution when removing the top plate. The membrane is now exposed.

See Figure 30.



Figure 29:  
Membrane Housing



Figure 30: Exposed membrane with top plate removed.

Continued next page . . .

- 9. Gently screw the membrane extraction tool into the top of the membrane.  
Screw the extraction tool into the membrane until the threads bottom out.  
See Figure 31.

**CAUTION:** Do not over tighten the extraction tool when screwing into the membrane.

- 10. Gently move the extraction tool side-to-side while pulling up with moderate force until the membrane becomes loose.

**CAUTION:** Do not use excessive force or a twisting action to remove the membrane as these items may cause damage to the membrane epoxy potting.

There are two o-rings on the inside bottom of the vertical tube causing resistance in removing the membrane

An aluminum insert (Figure 32) may still be attached to the bottom of the membrane or will stay in the membrane-housing base.

**DO NOT LOSE THE INSERT AS IT WILL BE NEEDED TO COMPLETE THE MEMBRANE INSTALLATION AND MAKE THE MEMBRANE OPERATION FUNCTIONAL.**

- 11. Remove the extraction tool from the membrane.
- 12. Remove and discard the (4) o-rings:
  - (2) O-rings on the membrane
  - (2) O-rings on the base insert

Keep the vertical tube top o-ring for re-use.



*Figure 31: Membrane extraction tool*



*Figure 32: Membrane base insert*



### 9.3 Installing the New Membrane

1. Install (4) new O-rings:  
(2) O-rings on the membrane (VST Part #5006-013).  
(2) O-rings on the base insert (VST Part #5006-012).
2. Use only silicon grease (not hydrocarbon-based grease) on the o-rings prior to installation.  
  
Hydrocarbon-based grease or lubricant will emit hydrocarbon vapors, which will be measured by the HC sensor and will cause inaccurate gas-level readings.
3. With (2) new o-rings on the “insert” installed, place the “insert” into the bottom of the base as orientated in Figure 32.
4. With the (2) membrane o-rings installed, place the membrane into the membrane housing. Apply a moderate downward force with a mild side-to-side action to seat the membrane in the membrane base.
5. Install the existing top vertical tube o-ring (re-lubricated). Install the top plate.
  - The top plate will seat on the vertical tube o-ring while bolting the top plate in place.
  - **DO NOT USE FORCE TO SEAT THE TOP PLATE.**
6. Install the (4) ¼” bolts/washers/lock washers in the top plate/retaining ring to secure the top plate.
7. Tighten the (4) bolts to 85 in-lbs in a cross-pattern using 20%, 40%, 60%, 80%, 90%, 100% of torque.
  - This cross-pattern torque procedure will evenly seat the top plate to the vertical tube.
8. Re-install the ½” 45° flare tubing from the top/side of the membrane housing.
  - Note: When tightening the 45° flare nuts: Clamp the tube flare between nut and nose body of the tube by screwing the nut on finger tight. Tighten with a wench an additional ¼ turn for a metal-to-metal seal.
9. Perform a *Processor* Leak Test. See Section 3.8.
10. Open the ball valves between the *Processor* and the vent risers.
11. Remove the lock(s) and tags from the lockout & tagout.
12. Turn ON power to the heat trace, blower, and vacuum pump.
13. After work is completed, put the TLS-350 in the AUTOMATIC mode. See Figure 10 or Figure 11.

## 10 Drive Coupling Rubber Insert Replacement

- NOTE: The drive coupling rubber insert replacement is done with the vacuum pump and motor assembly still attached to the ECS base.

### 10.1 Safety



Use lockout / tagout procedures prior to starting work.

### 10.2 Removing the Drive Coupling Insert

- Prior to starting work, put the TLS-350 in the Manual OFF mode.
  - See Figure 10 or Figure 11
- Close the ball valves between the *Processor* and the vent risers.
- At the disconnect switch and at the breaker, disconnect the power to the blower and vacuum pump motors.
- Conduct ECS Unit Purge Procedure (See Section 6 of this document).
- With the vacuum pump and motor assembly in-place on the ECS base, remove the drive coupling guard and the pump fan guard.
  - See Figures 34-35.
- Completely remove the vacuum pump ½" outlet tubing.
  - See Figure 25.
- Completely remove the vacuum pump ½" and ¼" inlet 45° flare tubing and all pipe fittings connected to the vacuum pump. See Figure 27.
- Completely remove the ¼" HC sensor inlet tubing at the air outlet and the HC sensor.
  - See Figure 50.
  - NOTE: The tube ends are a Parker 45° flare, use caution not to damage the flared ends on the tubing or the threads on the nuts after removal.



Figure 34: Vacuum and motor assembly





Figure 33: Vacuum pump with guard removed

Continued next page. . .

9. Un-bolt the vacuum pump from the base and move the vacuum pump away from the motor.
- Moving the vacuum pump away from the motor will separate the drive coupling for removal of the rubber insert.
  - Be sure to mark and keep any shims used under the vacuum pump for re-use (the shims are used for aligning the vacuum pump with the motor).
  - Keep the bolts for re-use.
  - See Figure 37.



*Figure 35: Vacuum pump unbolted and moved away from the motor*

### 10.3 Installing the Drive Coupling Insert

1. Replace the rubber insert into the drive coupling.  
See Figure 36.
2. Slide the vacuum pump towards the motor.
  - Place any shims under the vacuum pump in their original location.
3. Bolt the vacuum pump to the vacuum pump base.
4. Install the drive coupling and fan guards.
5. Re-install the ½" and ¼" inlet 45° flare tubing and all pipe fittings connected to the vacuum pump.
6. Re-install the ½" outlet tubing.
7. Re-install the ¼" HC sensor inlet tubing.  
Do not use any thread sealing compound when assembling the 45 ° flare nuts.  
**NOTE:** When tightening the 45° flare nuts: Clamp the tube flare between nut and nose body of the tube by screwing the nut on finger tight. Tighten with a wrench an additional ¼ turn for a metal-to-metal seal.
8. Perform a *Processor* leak test – see Section 3.8 of this document.
9. Remove the lock(s) and tags from the lockout & tagout.
10. Open the ball valves between the *Processor* and the vent risers.
11. At the breaker, but not at the disconnect switch, turn ON power to the blower and vacuum pump.
12. Return the TLS-350 to the manual ON mode.
13. Using the disconnect switch near the Processor, briefly cycle the power to verify that there is no excessive vibration at the coupling.
14. After work is completed, put the TLS-350 in the AUTOMATIC mode and engage the disconnect.  
See Figures 12 or 13.



*Figure 36: Drive coupling rubber insert*

## 11 Heat Trace Cable Replacement

### 11.1 Safety



Use lockout / tagout procedures prior to starting work.  
Disconnect electricity to the *Processor*.

### 11.2 Removing the Heat Trace Electrical Box

1. Prior to starting work, put the TLS-350 in the Manual “OFF” mode
  - See Figure 10 or 11.
  - Remove power to the *Processor* by either turning OFF the breaker or by disconnecting power at the *Processor*.
2. At the breaker, disconnect power to the heat trace cable.
3. Remove the entire heat trace electrical box from the  $\frac{3}{4}$ ” tubing.
4. Disconnect and remove the heat trace cable from inside the electrical junction box.
  - Remove the top cover from the electrical junction box (be sure to keep the screws for reuse).
  - Remove the 115V and ground wires from the terminal block located inside the electrical junction box.
  - See Figure 37.
  - Remove the bottom plate (be sure to keep the screws for reuse).
  - Pull the heat trace cable out of the electrical box and bottom plate (be sure keep the rubber grommet for reuse).
5. Completely remove the 1” thick F/G insulation from the membrane housing.
  - Cutting on the insulation seam, remove the insulation (with the aluminum tape attached) in one piece and save for reuse.
  - See Figure 38.
6. Peel the aluminum tape off the heat trace cable and discard.
  - This will expose the heat trace cable and end seal kit.
7. Disassemble the seal kit and remove the heat trace cable.
  - Retain the end seal kit parts for re-use.

### 11.3 Overview for Installing the New Heat Trace Cable

1. VST has found that making both the end seal kit and electrical junction box connection first to the heat trace cable works the best.
2. After both connections are made to the heat trace cable, attach the electrical junction box to the  $\frac{3}{4}$ " tube.
3. After the electrical junction box is attached to the  $\frac{3}{4}$ " tube, wrap the heat trace cable around the vertical tube starting at the bottom and wrapping towards the top, applying aluminum tape on each revolution.
4. The last step is to secure the end seal kit to the vertical tube.

### 11.4 Steps for Installing the New Heat Trace Cable

1. Install the end seal kit on the heat trace cable:
  - Using a multimeter, check the heat trace cable electrical circuit continuity at the electrical junction box to insure the circuit is complete and is not in a ground fault condition.
  - See Figure 39. End Seal Kit Components
  - See the Figures 40-41. Chromalox End Seal Kit Installation Instruction (2-Pages - ) to install the heat trace cable on the end seal kit
  - Figure 42. Prepare the New Heat Trace Cable for installation into the End Seal Kit
2. Install the heat trace cable to the electrical junction box.
  - See Figures 43-46. Electrical Junction Box Installation Instructions, (4-Pages).
3. Attach the electrical junction box to the  $\frac{3}{4}$ " tube (attached to the membrane housing).
4. Wrap the heat trace cable around the vertical tube starting at the bottom and wrapping towards the top, applying aluminum tape on each revolution.
  - Be sure to install the heat trace cable flat against the membrane housing – free of twists.
  - Use nylon reinforced aluminum tape.
5. Secure the end seal kit/heat trace cable to the top section of the top section of the vertical tube.
  - See Figure 47 End Seal Kit Location and Heat Trace Cable Installation.
  - The heat trace cable on the vertical tube should be completely wrapped with aluminum tape. (Note: The nylon reinforced aluminum tape serves two purposes, it holds the heat trace cable in place while installing the heat trace cable on the vertical tube, and it insures the heat trace cable is held firmly in contact with the vertical tube).
6. The installation is now complete.
  - See Figure 48. Installed Electrical Junction Box with Electrical Connections.
7. Check all electrical connections for loose wires.

Continued next page . . .

- 8. Remove the lock(s) and tags from the lockout & tagout.
- 9. Turn ON power to the Heat Trace Cable and vacuum pump.
- 10. After work is completed, put the TLS-350 in the AUTOMATIC mode.
  - See Figure 10 or 11



Figure 37: Termination block inside the electrical junction box




Figure 38: Seam to cut to remove the insulation




Figure 39: End seal kit components  
Connection screws  
End cap  
Grommet  
Pressure plate  
Heat trace cable

# Chromalox®

## Installation Instructions

| SERVICE REFERENCE                    |             |
|--------------------------------------|-------------|
| DIVISION 4                           | SECTION RT  |
| SALES REFERENCE (Supersedes PJ450-9) | PJ450-10    |
| 161-562761-001                       |             |
| DATE                                 | MARCH, 2004 |

### Type RTES End Seal Kit for Self-Regulating and Constant Wattage Rapid-Trace Heating Cable



- RTES Kit Parts:**  
 1 - End Cap                      1 - Pressure Plate  
 2 - Screws                        1 - Grommet

#### GENERAL

The RTES kit is used for terminating braided (-C) and overcoated (-CR or -CT) versions of Self-Regulating and Fluoropolymer insulated Constant Wattage Rapid-Trace Heating Cable. The cable grommet is furnished with this kit such that the kit suffix number is the same as the grommet number (eg., an RTES-3 kit uses a GR3 grommet). Refer to the list below to insure you have the proper grommet for the cable you are installing.

- GR1 for SRL-C
- GR2 for SRL-CR or SRL-CT

- GR3 for CWM-C
- GR4 for CWM-CT
- GR5 for SRL-MC
- GR6 for SRL-MCR or SRL-MCT
- GR7 for SRM/E-C
- GR8 for SRM/E-CT

Each kit contains enough material to make one termination. Materials required include: standard electrical cutters, screwdriver and fiberglass tape.

#### INSTALLATION

##### WARNING

**ELECTRIC SHOCK HAZARD. Disconnect all power before installing or servicing heating cable and accessories. A qualified person must perform installation and service of heating cable and accessories. Heating cable must be effectively grounded in accordance with the National Electrical Code. Failure to comply can result in personal injury or property damage.**

**Note:** All electrical wiring, including GFCI (Ground Fault Circuit Interrupters), must be done in accordance with the National Electrical Code and local codes by a qualified person.

**Note:** These instructions are for all Self-Regulating and Constant Wattage heating cables in ordinary locations. Consult factory for

installation of braided cable in hazardous locations. Not all instructions, are for all cables. Each step has a boldface heading stating what type of cable that instruction is for.

##### 1. FOR CONSTANT WATTAGE CABLE:

Using standard electrical cutters, make a perpendicular cut across the cable four inches from the last module point.

**Note:** Cutting the cable between module points (indentions in cable) creates a non-heated cold lead. See Figure 1.




Figure 1

© 2004 Chromalox, Inc.

Figure 40: End seal kit installation instructions, page 1 of 2



**INSTALLATION**

**2. FOR CABLE WITH EXPOSED METAL BRAID (-C):**  
Push the braid back three inches to expose the base cable insulation. See Figure 2.



Figure 2

**3. FOR ALL CABLE:**  
Slide the pressure plate and grommet over the end of the cable. **Note:** The pressure plate and end cap have different size curved surfaces on the top and bottom of each piece. These curved surfaces are designed to give a better fit on process equipment. The side with the smaller radius curve is for use on pipes with diameters up to three inches or on flat surfaces. The other side is for use on pipes with diameters of three inches or more. See Figure 3 and Figure 8.




Figure 3

**4. FOR OVERCOATED CABLES (-CR or -CT):**  
Score the outer jacket one inch from the end of the cable. Remove the jacket to expose the braid. Unravel and trim the braid flush with the outer jacket. Pull any strands of braid back towards the outer jacket. See Figure 4.



Figure 4

**5. FOR ALL CABLE:**  
Using standard electrical cutters, cut a "VEE" notch between the buss wires. See Figure 5.




Figure 5

**6. FOR ALL CABLE:**  
Slide the pressure plate and grommet towards the end of the cable leaving 5/8" of the cable extending past the end of the grommet. See Figure 6.



Figure 6

**7. FOR ALL CABLE:**  
Slide the end cap over the grommet. Using a screwdriver, connect the pressure plate to the end cap. See Figure 7.



Figure 7

**8. FOR ALL CABLE:**  
Using a fastening device, fiber re-inforced electrical tape (Chromalox FT-1 or equal), secure the assembly to the pipe. Wrap the tape around the assembly between the legs. See Figure 8.



Figure 8

**WARRANTY AND LIMITATION OF REMEDY AND LIABILITY**

Chromalox warrants only that the Products and parts manufactured by Chromalox, when shipped, and the work performed by Chromalox when performed, will meet all applicable specification and other specific product and work requirements (including those of performance), if any, and will be free from defects in material and workmanship under normal conditions of use. All claims for defective or nonconforming (both hereinafter called defective) Products, parts or work under this warranty must be made in writing immediately upon discovery, and in any event, within one (1) year from delivery, provided, however all claims for defective Products and parts must be made in writing no later than eighteen (18) months after shipment by Chromalox. Defective and nonconforming items must be held for Chromalox's inspections and returned to the original f.o.b. point upon request. THE FOREGOING IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES WHATSOEVER, EXPRESS, IMPLIED AND STATUTORY, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Notwithstanding the provisions of this WARRANTY AND LIMITATION Clause, it is specifically understood that Products and parts not manufactured and work not performed by Chromalox are warranted only to the extent and in the manner that the same are warranted to Chromalox by Chromalox's vendors, and then only to the extent that Chromalox is reasonably able to enforce such warranty, it being understood Chromalox shall have no obligation to initiate litigation unless Buyer undertakes to pay all cost and expenses therefor, including but not limited to attorney's fees, and indemnifies Chromalox against any liability to Chromalox's vendors arising out of such litigation.

Upon Buyer's submission of a claim as provided above and its substantiation, Chromalox shall at its option either (i) repair or replace its Products, parts or work at the original f.o.b. point of delivery or (ii) refund an equitable portion of the purchase price.


THE FOREGOING IS CHROMALOX'S ONLY OBLIGATION AND BUYER'S EXCLUSIVE REMEDY FOR BREACH OF WARRANTY, AND IS BUYER'S EXCLUSIVE REMEDY AGAINST CHROMALOX FOR ALL CLAIMS ARISING HEREUNDER OR RELATING HERETO WHETHER SUCH CLAIMS ARE BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE AND STRICT LIABILITY) OR OTHER THEORIES. BUYER'S FAILURE TO SUBMIT A CLAIM AS PROVIDED ABOVE SHALL SPECIFICALLY WAIVE ALL CLAIMS FOR DAMAGES OR OTHER RELIEF, INCLUDING BUT NOT LIMITED TO CLAIMS BASED ON LATENT DEFECTS. IN NO EVENT SHALL BUYER BE ENTITLED TO INCIDENTAL OR CONSEQUENTIAL DAMAGES AND BUYER SHALL HOLD CHROMALOX HARMLESS THEREFROM. ANY ACTION BY BUYER ARISING HEREUNDER OR RELATING HERETO, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE AND STRICT LIABILITY) OR OTHER THEORIES, MUST BE COMMENCED WITHIN ONE (1) YEAR AFTER THE DATE OF SHIPMENT OR IT SHALL BE BARRED.

W2008M

**Chromalox**  
PRECISION HEAT AND CONTROL  
1382 HEIL CLAKER BLVD., LAVERGNE, TN 37086  
Phone: (615) 793-3900 www.chromalox.com

98 - 068  
TA - Q4 - EF  
Litho in U.S.A.

Figure 41: End seal kit installation instructions, page 2 of 2



- A. Twin 14 AWG copper buss wires
- B. Semi-conductive polymer core
- C. High temp. fluoropolymer jacket
- D. Metallic braid ground
- E. High temperature fluoropolymer jacket

Figure 42: Prepare the new heat trace cable for installation into the end seal kit

# Chromalox®

## Installation Instructions

| SERVICE REFERENCE                    |             |
|--------------------------------------|-------------|
| DIVISION 4                           | SECTION RT  |
| SALES REFERENCE (Supersedes PJ451-9) | PJ451-10    |
| 161-562762-001                       |             |
| DATE                                 | MARCH, 2004 |

### RTPC Power Connection Kit for Self-Regulating and Constant Wattage Rapid-Trace Heating Cable



- RTPC Power Connection Kit Parts:**
- 1 - Molded Junction Box consisting of:
    - Base - Box - Lid - Hardware
  - 1 - Three Position Terminal Block
  - 1 - Mounting Screw for Terminal Block
  - 1 - Cable Grommet
  - 1 - Cover Gasket

#### GENERAL

#### **⚠WARNING**

**ELECTRIC SHOCK HAZARD. Disconnect all power before installing or servicing heating cable and accessories. A qualified person must perform installation and service of heating cable and accessories. Heating cable must be effectively grounded in accordance with the National Electrical Code. Failure to comply can result in personal injury or property damage.**

**NOTE:** All electrical wiring, including GFCI (Ground Fault Circuit Interrupters), must be done according to National Electrical or local codes by a qualified person.

The RTPC Kit is used to connect base, braided (-C) and over-coated (-CR or -CT) versions of Self-Regulating and Fluoropolymer insulated Constant Wattage Rapid-Trace Heating Cables to power. The cable grommet is furnished with this kit, such that the kit suffix number is the same as the grommet number (eg., an RTPC-3 kit uses a GR3 grommet). Refer to the list below to insure you have the proper grommet for the cable you are installing.

- GR1 for SRL-C
- GR2 for SRL-CR or SRL-CT
- GR3 for CWM-C
- GR4 for CWM-CT
- GR5 for SRL-MC
- GR6 for SRL-MCR or SRL-MCT
- GR7 for SRM/E-C
- GR8 for SRM/E-CT

Each kit contains enough material to make one power connection point. It is possible to connect up to three Self-Regulating or two Constant Wattage Cables in the same box. (One grommet required for each cable.)

Materials required for installation include: standard electrical cutters, screwdriver, sharp utility knife and a pipe strap (Chromalox PS or equal).

Wipe inside lip of cover with a clean cloth. Remove protective backing from the gasket and affix it to the cover lip. Press firmly all around for proper adhesion.

Figure 43: Electrical junction box installation instructions, page 1 of 4

**INSTALLATION**

**NOTE:** These instructions are for all Self-Regulating and Constant Wattage heating cables in ordinary locations. Consult factory for installation of braided cable in hazardous locations. Not all instructions are for all cables. Each step of the instructions will have a heading in boldface stating what type of cable each instruction is intended for.

- 1. FOR CONSTANT WATTAGE CABLES:**  
Cut the cable 12 inches past the last module point (indentation in cable). **NOTE:** Cutting the cable between module points creates a non-heating cold lead. See Figure 1.




Figure 1

- 2. FOR CABLE WITH EXPOSED METAL BRAID (-C):**  
Push the braid back 12 inches on the cable. See Figure 2.



Figure 2

- 3. FOR ALL CABLES:**  
Feed the ends of the cables through the appropriate hole in the base. Allow eight (8) inches of cable to extend above the top of the base. See Figure 3.




Figure 3

- 4. FOR ALL CABLES:**  
Slide cable grommet over the end of the cable and insert it into the opening in the base. Secure the base to the pipe by threading the appropriate sized pipestrap through the slot in the mounting plate. Tighten the pipestrap until the base is securely attached to the pipe. See Figure 4.



Figure 4

- 5. FOR OVERCOATED CABLES (-CR or -CT):**  
Score the outer insulation seven (7) inches from the end of cable. Remove the jacket to expose the metal braid. See Figure 5. **CAUTION: When removing the outer jacket, be careful not to damage the braid or the base cable insulation.**




Figure 5

- 6. FOR ALL CABLES:**  
Punch out the knockouts on the bottom of the box which correspond to the openings in the base through which the heating cable passes. Be careful to punch out only those knockouts to be used. If one is mistakenly punched, blank grommets can be ordered to re-establish the water tight seal. See Figure 6.




Figure 6

Figure 44: Electrical junction box installation instructions, page 2 of 4


**INSTALLATION**

**7. FOR ALL CABLES:**  
Feed the cables through the corresponding holes in the box. Secure box to base using all four (8-32) screws. See Figure 7.




**Figure 7**

**8. FOR OVERCOATED CABLES:**  
Starting from the end of the cable, unravel 2-1/2 inches of the braid. Twist the strands together to form a pigtail. See Figure 8.



**Figure 8**


**9. FOR SELF-REGULATING CABLES:**  
Using standard electrical cutters, cut a 3/4 inch long notch out of the cable between the conductor wires. Bare a 3/8 inch length of each conductor by stripping off the outside insulation and the inner black core material. See Figure 9.



**Figure 9**

**10. FOR CONSTANT WATTAGE CABLES:**  
Score the outer jacket 3/4 inch from the end of the cable and remove the jacket. Cut off the exposed nichrome wire, pushing any remainder back under the jacket. These cables have an inner layer of insulation which is also to be removed as

described above. Separate the buss wires and strip off the last 3/8 inch of insulation from both buss wires. See Figure 10.



**Figure 10**

**11. FOR ALL CABLES:**  
Insert the bared ends of the conductors into the openings in the terminal block. Tighten screws firmly to hold conductors in place. See Figure 11.




**Figure 11**

**12. FOR OVERCOATED CABLES (-CR or -CT):**  
Insert the end of the braid pigtail into the remaining opening in the terminal block. Tighten screw firmly to hold the braid in place. See Figure 12.



**Figure 12**

**13. FOR ALL CABLES:**  
Connect conduit hub (Chromalox CCH or equal) to the box. Attach conduit to hub and bring power leads into box. See Figure 13.



**Figure 13**

Figure 45: Electrical junction box installation instructions, page 3 of 4

**INSTALLATION**

**14. FOR ALL CABLES:**

Strip 3/8 inch length of each conductor of the power cord. Insert the bared ends of the conductors into the corresponding openings on the unused side of the terminal block. Remember, the green (ground) wire must be opposite of the opening of the terminal block which is either empty or contains the metal braid. See Figure 14.



Figure 14

**15. FOR ALL CABLES:**

Mount terminal block to bottom of the box by driving the 6/32 self-tapping screw into the mounting hole as shown. See Figure 15.




Figure 15

**16. FOR ALL CABLES:**

Carefully push the wires into the box. Secure the lid to box. See Figure 16.



Figure 16

**17. FOR CABLE WITH EXPOSED METAL BRAID (-C):**  
Unravel four (4) inches of braid from the cable and twist into a pigtail.

**⚠WARNING**

**ELECTRIC SHOCK HAZARD. The twisted braid must be effectively grounded in accordance with the National Electrical Code to eliminate electric shock hazard.**



Figure 17

**WARRANTY AND LIMITATION OF REMEDY AND LIABILITY**

Chromalox warrants only that the Products and parts manufactured by Chromalox, when shipped, and the work performed by Chromalox when performed, will meet all applicable specification and other specific product and work requirements (including those of performance), if any, and will be free from defects in material and workmanship under normal conditions of use. All claims for defective or nonconforming (both hereinafter called defective) Products, parts or work under this warranty must be made in writing immediately upon discovery, and in any event, within one (1) year from delivery, provided, however all claims for defective Products and parts must be made in writing no later than eighteen (18) months after shipment by Chromalox. Defective and nonconforming items must be held for Chromalox's inspections and returned to the original f.o.b. point upon request. THE FOREGOING IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES WHATSOEVER, EXPRESS, IMPLIED AND STATUTORY, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Notwithstanding the provisions of this WARRANTY AND LIMITATION Clause, it is specifically understood that Products and parts not manufactured and work not performed by Chromalox are warranted only to the extent and in the manner that the same are warranted to Chromalox by Chromalox's vendors, and then only to the extent that Chromalox is reasonably able to enforce such warranty, it being understood Chromalox shall have no obligation to initiate litigation unless Buyer undertakes to pay all cost and expenses

therefor, including but not limited to attorney's fees, and indemnifies Chromalox against any liability to Chromalox's vendors arising out of such litigation. Upon Buyer's submission of a claim as provided above and its substantiation, Chromalox shall at its option either (i) repair or replace its Products, parts or work at the original f.o.b. point of delivery or (ii) refund an equitable portion of the purchase price.

THE FOREGOING IS CHROMALOX'S ONLY OBLIGATION AND BUYER'S EXCLUSIVE REMEDY FOR BREACH OF WARRANTY, AND IS BUYER'S EXCLUSIVE REMEDY AGAINST CHROMALOX FOR ALL CLAIMS ARISING HEREUNDER OR RELATING HERETO WHETHER SUCH CLAIMS ARE BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE AND STRICT LIABILITY) OR OTHER THEORIES. BUYER'S FAILURE TO SUBMIT A CLAIM AS PROVIDED ABOVE SHALL SPECIFICALLY WAIVE ALL CLAIMS FOR DAMAGES OR OTHER RELIEF, INCLUDING BUT NOT LIMITED TO CLAIMS BASED ON LATENT DEFECTS. IN NO EVENT SHALL BUYER BE ENTITLED TO INCIDENTAL OR CONSEQUENTIAL DAMAGES AND BUYER SHALL HOLD CHROMALOX HARMLESS THEREFROM. ANY ACTION BY BUYER ARISING HEREUNDER OR RELATING HERETO, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE AND STRICT LIABILITY) OR OTHER THEORIES, MUST BE COMMENCED WITHIN ONE (1) YEAR AFTER THE DATE OF SHIPMENT OR IT SHALL BE BARRED.

W2008M

**Chromalox®**  
**PRECISION HEAT AND CONTROL**

1382 HEIL QUAKER BLVD., LAVERGNE, TN 37086  
Phone: (615) 793-3900      www.chromalox.com

98 - 025  
TA - Q4 - EF  
Litho in U.S.A.

Figure 46: Electrical junction box installation instructions, page 4 of 4



Figure 47: End seal kit location and heat trace cable installation



Figure 48: Installed electrical junction box with electrical connections




## 12 Hydrocarbon Infrared (HC IR) Sensor Module Replacement

### 12.1 Safety



Use lockout / tagout procedures prior to starting work.



*Figure 49: HC IR Sensor Module and Electrical Housing Assembly*

## 12.2 Removing HC IR Sensor from the HC IR Sensor Module Electrical Housing

1. Prior to starting work, put the TLS-350 in the Manual "OFF" mode.  
See Figure 10 or Figure 11.
2. At the disconnect switch or the breaker, disconnect power to the heat trace cable, the vacuum pump, and the blower motors.
3. Conduct ECS Unit Purge Procedure (See Section 6 of this document).
4. In the electrical room, turn off the HC Sensor power by disconnecting the 115V power to the HC Sentry Module.
5. Disconnect and completely remove the 1/4" 45° flare tubing from the top and bottom sides of the HC IR Sensor Module.
  - See Figure 50.
  - NOTE: The nuts on the tubing are 1/4" 45° flare. Use caution to avoid damaging the flared ends on the tubing or the threads on the nuts after removal.
5. Remove the cover on the electrical house and keep for re-use.
  - NOTE: Do not remove the HC sensor electrical housing.

Continued next page . . .



Figure 50: HC IR Sensor Module 1/4" 45° tubing and fittings

- 6. Disconnect the following HC IR sensor wires from the electrical housing circuit board:
  - White: 4-20 mA signal wire
  - Black: -(common) RET wire
  - Red: +24VDC power wire
  - NOTE: The yellow and green wires are not used in this application.
  - See Figures 53 and 54.
  
- 7. Unscrew and remove the HC IR Sensor Module from the electrical housing.
  - Package the used HC IR Sensor Module in the anti-static bag and box that came with the new / recalibrated HC IR Sensor Module unit.
  - The used HC IR Sensor Module can be sent back to VST for re-calibration.




Figure 51: HC IR Sensor Electrical Housing Circuit Board





Figure 52: HC IR Sensor Electrical Housing Circuit Board Wiring Diagram

### 12.3 Installing a New or Re-calibrated HC IR Sensor Module to the HC IR Sensor Module Electrical Housing

1. Use only silicon grease (not hydrocarbon-based grease) to lubricate the HC IR sensor threads prior to installation.
  - Hydrocarbon-based grease or lubricant will emit hydrocarbon vapors, which will be measured by the HC sensor and will cause inaccurate gas-level readings.
2. Screw the new / re-calibrated HC IR sensor module to the electrical housing.
  - Remove the aluminum cover from the HC IR sensor.
  - While screwing on the sensor, orient the optics in the vertical position.
  - See Figure 53.
3. Replace the aluminum cover on the HC IR sensor.



*Figure 53: HC IR sensor installation orientation*

4. Connect the following HC IR sensor wires to the electrical housing circuit board:
  - White: 4-20 mA signal wire
  - Black: -(common) RET wire
  - Red: +24VDC power wire
  - NOTE: the yellow and green wires are not used in this application.
  - See Figures 53 and 54.
5. Install the cover on the electrical housing.
  - Use only silicon grease (not hydrocarbon-based grease) to lubricate the cover threads prior to installation.
  - Hydrocarbon-based grease or lubricant will emit hydrocarbon vapors, which will be measured by the HC sensor and will cause inaccurate gas-level readings.
6. Re-install the (2) ¼" 45° flare tubing on the top and bottom sides of the HC IR sensor module.
  - NOTE: When tightening the 45° flare nuts, clamp the tube flare between the nut and the nose body of the tube by screwing the nut on finger-tight. Tighten with a wrench an additional ¼-turn for a metal-to-metal seal.
7. Remove the lock(s) and tags from the lockout/tagout.
8. At the breaker and at the disconnect switch, turn ON power to the heat trace, blower, and vacuum pump.
9. In the electrical room, turn ON power to the HC Sentry Module.
10. Perform a *Processor* Leak Test – see Section 3.8 of this document.
11. After the installation is complete, put the TLS-350 in the AUTOMATIC ON mode.
  - See Figure 10 or 11.

## 13 Forms

- The following pages contain forms for:
  - ▶ Scheduled preventative maintenance list
  - ▶ Scheduled preventative maintenance checklist

13.1 Preventative Maintenance

| Preventative Maintenance   |        |           |
|--|--------|-----------|
| ASC #:   | Date:  |           |
| ASC Name:  |        |           |
| ASC Certification Level:   |        |           |
| ASC Company:   |        |           |
| GDF Name:  |        |           |
| Address:   |        |           |
| City:  | State: | ZIP Code: |
| GDF Contact Person Name:   |        |           |
| GDF Contact Person Title:  |        |           |
| GDF Contact Person Phone:  |        |           |
| GDF Contact Person E-mail:   |        |           |
| Notes  |        |           |
| Use the form on the following page to note details of Preventative Maintenance activities. |        |           |

13.2 Preventative Maintenance Checklist Form

| Component  | Frequency | Date Inspected | Completed | Required Action Items |
|--|-----------|----------------|-----------|-----------------------|
| <b>PROCESSOR</b>   |           |                |           |                       |
| <ul style="list-style-type: none"> <li>Inspect drive coupling on vacuum pump.</li> </ul>                               | Yearly    |                | ☐         |                       |
| <ul style="list-style-type: none"> <li>Check the continuity of the heat trace cable.</li> </ul>                        |           |                | ☐         |                       |
| <b>RECIRCULATION BLOWER</b>  |           |                |           |                       |
| <ul style="list-style-type: none"> <li>Replace every 10 years or every 15,000 hours, whichever comes first.</li> </ul> |           |                | ☐         |                       |
| <b>VACUUM PUMP</b>   |           |                |           |                       |
| <ul style="list-style-type: none"> <li>Replace every 10 years or every 15,000 hours, whichever comes first.</li> </ul> |           |                | ☐         |                       |



# Pressure Management Control

## Install, Setup, & Operation Manual

*For VST Processors*

---



# Notice

---

Veeder-Root makes no warranty of any kind with regard to this publication, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Veeder-Root shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this publication.

Veeder-Root reserves the right to change system options or features, or the information contained in this publication as approved by ARB.

This publication contains proprietary information which is protected by copyright. All rights reserved. No part of this publication may be modified or translated to another language without the prior written consent of Veeder-Root. Contact TLS Systems Technical Support for additional troubleshooting information at 800-323-1799.

## **DAMAGE CLAIMS / LOST EQUIPMENT**

Thoroughly examine all components and units as soon as they are received. If any cartons are damaged or missing, write a complete and detailed description of the damage or shortage on the face of the freight bill. The carrier's agent must verify the inspection and sign the description. Refuse only the damaged product, not the entire shipment.

Veeder-Root must be notified of any damages and/or shortages within 30 days of receipt of the shipment, as stated in our Terms and Conditions.

## **VEEDER-ROOT'S PREFERRED CARRIER**

1. Contact Veeder-Root Customer Service at 800-873-3313 with the specific part numbers and quantities that were missing or received damaged.
2. Fax signed Bill of Lading (BOL) to Veeder-Root Customer Service at 800-234-5350.
3. Veeder-Root will file the claim with the carrier and replace the damaged/missing product at no charge to the customer. Customer Service will work with production facility to have the replacement product shipped as soon as possible.

## **CUSTOMER'S PREFERRED CARRIER**

1. It is the customer's responsibility to file a claim with their carrier.
2. Customer may submit a replacement purchase order. Customer is responsible for all charges and freight associated with replacement order. Customer Service will work with production facility to have the replacement product shipped as soon as possible.
3. If "lost" equipment is delivered at a later date and is not needed, Veeder-Root will allow a Return to Stock without a restocking fee.
4. Veeder-Root will NOT be responsible for any compensation when a customer chooses their own carrier.

## **RETURN SHIPPING**

For the parts return procedure, please follow the appropriate instructions in the "General Returned Goods Policy" pages in the "Policies and Literature" section of the Veeder-Root **North American Environmental Products** price list. Veeder-Root will not accept any return product without a Return Goods Authorization (RGA) number clearly printed on the outside of the package.

## **FCC INFORMATION**

This equipment complies with the requirements in Part 15 of the FCC rules for a Class A computing device. Operation of this equipment in a residential area may cause unacceptable interference to radio and TV reception requiring the operator to take whatever steps are necessary to correct the interference.

**WARRANTY - Please see next page, iii.**

©Veeder-Root 2012. All rights reserved.

# Warranty

---

This warranty applies only when the product is installed in accordance with Veeder-Root's specifications by Veeder-Root certified installers. This warranty will not apply to any product which has been subjected to misuse, negligence, accidents, systems that are misapplied or are not installed per Veeder-Root specifications, modified or repaired by unauthorized persons, or damage related to acts of God. Veeder-Root is not liable for incidental, consequential, or indirect damages or loss, including, without limitation, personal injury, death, property damage, environmental damages, cost of labor, clean-up, downtime, installation and removal, product damages, loss of product, or loss of revenue or profits. This warranty applies to the initial purchaser and any subsequent purchaser for the duration of the warranty period. **THE WARRANTY CONTAINED HEREIN IS EXCLUSIVE AND THERE ARE NO OTHER EXPRESS, IMPLIED, OR STATUTORY WARRANTIES. WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY EXCLUDED.**

## **TLS-350R, TLS-350 PLUS, TLS-350J AND TLS-300I/C, AND TLS2 MONITORING SYSTEMS**

We warrant that this product shall be free from defects in material and workmanship and is compliant with all applicable performance standards and specifications for which it has been certified, for a period of one (1) year from the date of installation when proof of date of installation is provided or twenty-four (24 months) from the date of manufacture when proof of date of installation is not provided. During the warranty period, we or our representative will repair or replace the product, if determined by us to be defective, at the location where the product is in use and at no charge to the purchaser. **LAMPS, FUSES, AND LITHIUM BATTERIES ARE NOT COVERED UNDER THIS WARRANTY.**

If "Warranty" is purchased as part of the Fuel Management Service, Veeder-Root will maintain the equipment for the life of the contract in accordance with the written warranty provided with the equipment. A Veeder-Root Fuel Management Services Contractor shall have free site access during Customer's regular working hours to work on the equipment. Veeder-Root has no obligation to monitor federal, state or local laws, or modify the equipment based on developments or changes in such laws.

## **MODULES, KITS, OTHER COMPONENTS (PARTS PURCHASED SEPARATE OF A COMPLETE CONSOLE)**

We warrant that this product shall be free from defects in material and workmanship and is compliant with all applicable performance standards and specifications for which it has been certified, for a period of one (1) year from the date of installation when proof of the date of installation is provided or fifteen (15) months from the date of manufacture when proof of date of installation is not provided. We warrant that the lithium batteries (excluding EVR BATTERY PACK) shall be free from defects in material and workmanship for a period of three (3) months from date of invoice. We will repair or replace the product if the product is returned to us; transportation prepaid by user, within the warranty period, and is determined by us to be defective. **LAMPS AND FUSES ARE NOT COVERED UNDER THIS WARRANTY.**

**Introduction**

Site Requirements ..... 1  
 Contractor Certification Requirements ..... 1  
 Related Manuals ..... 2  
 Safety Precautions ..... 2

**Installation**

Installing TLS Console Modules - General Notes ..... 3  
     Circuit Directory ..... 4  
 Vapor Pressure Sensor ..... 4  
 Smart Sensor Interface Module ..... 4  
 NVMEM203 Board ..... 5  
 Probe Interface Module ..... 5  
 I/O Combination or 4-Relay Module ..... 5  
 Multiport Card for Vapor Processor Communication ..... 5  
 TLS Console with VST ECS Membrane Processor ..... 5

**Setup**

Introduction ..... 7  
 Smart Sensor Setup ..... 7  
 Output Relay Setup - VST ECS Membrane Processor & VST Green Machine ..... 8  
 PMC Setup ..... 9

**Operation**

Alarms ..... 10  
     Overview of TLS console Interface ..... 10  
     Warning Posting ..... 11  
     Alarm Posting ..... 11  
 PMC Alarm Summary ..... 12  
 PMC Status Report ..... 13  
 Viewing PMC Reports Via RS-232 Connection ..... 13  
     Connecting Laptop to Console ..... 13  
     Connecting Laptop to Console ..... 14  
     Sending Console Commands ..... 17

**Diagnostics**

Automatic Control ..... 22  
 Manual control ..... 22  
 PMC Diagnostic Menu ..... 22

## Figures

|            |  |    |
|------------|--|----|
| Figure 1.  | TLS console Interface Module Bays.....   | 3  |
| Figure 2.  | VST ECS Membrane Processor or VST Green Machine<br>Connections to TLS Console..... | 6  |
| Figure 3.  | Smart Sensor Setup .....   | 7  |
| Figure 4.  | Output Relay Setup for VST ECS Membrane Processor .....                            | 8  |
| Figure 5.  | Output Relay Setup Printout Examples for TLS Console<br>Controlled Processor.....  | 8  |
| Figure 6.  | PMC Setup .....  | 9  |
| Figure 7.  | TLS console alarm interface.....   | 10 |
| Figure 8.  | TLS console warning example .....  | 11 |
| Figure 9.  | TLS console alarm example.....   | 11 |
| Figure 10. | PMC Status Report .....  | 13 |
| Figure 11. | Connecting laptop to TLS console for serial communication .....                    | 14 |
| Figure 12. | Connection Description window .....  | 15 |
| Figure 13. | Connect To window.....   | 15 |
| Figure 14. | Console comm port settings printout example .....                                  | 16 |
| Figure 15. | HyperTerminal main window .....  | 17 |
| Figure 16. | Vapor Processor Status Report Details - Serial to PC Format .....                  | 18 |
| Figure 17. | Vapor Processor Runtime Diagnostic Report - Serial to PC Format.....               | 19 |
| Figure 18. | Percent Hydrocarbon Diagnostic Report - Serial to PC Format.....                   | 20 |
| Figure 19. | Priority Alarm History Report - Serial to PC Format.....                           | 20 |
| Figure 20. | Non-Priority Alarm History Report - Serial to PC Format .....                      | 21 |
| Figure 21. | PMC Diagnostic Menus.....  | 22 |

## Tables

|          |   |    |
|----------|---|----|
| Table 1. | Related Manuals .....                             | 2  |
| Table 2. | TLS-350 (PMC) Alarm Troubleshooting Summary ..... | 12 |
| Table 3. | Serial Commands for PMC Diagnostic Reports .....  | 18 |

# Introduction

This manual provides instructions to install, setup, and operate the components of Veeder-Root Pressure Management Control (PMC) equipment. The PMC feature is an option for the TLS console platform, and as such, many of the installation/setup/operation instructions for non-PMC specific tasks are covered in TLS-3XX supplied literature. Do not use this manual when PMC is installed with ISD. Use the ISD Setup & Operation Manual, 577021-800.

## Site Requirements

Below are the requirements for all PMC installations:

- V-R TLS-350R/EMC w/BIR, TLS-350 Plus/EMC Enhanced, TLS-350/EMC and ProMax consoles with ECPU2 - install as per TLS-3XX Site Prep manual, setup following instructions in TLS-3XX System Setup Manual.
- A flash memory board (NVMEM203) for PMC software storage - installed on the ECPU2 board in place of the console's 1/2 Meg RAM board - install as per TLS-350 Series Board and Software Replacement Manual, no setup required.
- Smart Sensor Module and Vapor Pressure Sensor. Install and connect following instructions in the Vapor Pressure Sensor installation Guide.
- Multiport card connected to a hydrocarbon sensor module installed according to processor manufacturers specifications.
- A 4-Relay or I/O Combination Module to control the vapor processor motor and setup as instructed in this manual.
- An RS-232 Port will be available for use by contractor or government inspectors.

## Contractor Certification Requirements

| Veeder-Root Contractor Certification Requirements                                     | Installer Certification <sup>6</sup> | ATG Technician Certification <sup>7</sup>                 | VR Vapor Products Certification <sup>8</sup> |
|---|--------------------------------------|---|--|
| Install <sup>1</sup> ISD  | X                                    | X   | X  |
| Install PMC   | X                                    | X   | X  |
| Install CCVP  | X                                    | X   | X  |
| Install Wireless ISD/PMC  | X                                    | X   | X  |
| Installation Checkout <sup>2</sup>  |                                      | X   | X  |
| ATG Startup <sup>3</sup> / Training <sup>4</sup> / Service <sup>5</sup>               |                                      | X   | X  |
| ISD Startup / Training / Service  |                                      |   | X  |
| PMC Startup / Training / Service  |                                      |   | X  |
| CCVP Startup / Training / Service   |                                      |   | X  |
| Wireless ISD/PMC Startup / Training / Service   |                                      |   | X  |
| Install Pressure Sensor (ATG)   | X                                    | X   | X  |
| Maintain Pressure Sensor (ATG)  |                                      | X   | X  |
| Calibrate Pressure Sensor (ATG)   |                                      | X   | X  |
| Clear ATG Pressure Sensor Alarm (ATG)   |                                      | X   | X  |
| Clear ISD/PMC Alarms (ISD/PMC)  |                                      |   | X  |
| <sup>1</sup> Perform wiring and conduit routing; equipment mounting                   |                                      | <sup>6</sup> UST Monitoring Systems – Installer (Level 1) |  |
| <sup>2</sup> Inspect wiring and conduit routing; equipment mounting                   |                                      | <sup>7</sup> Certified UST Monitoring Technician          |  |
| <sup>3</sup> Turn power on, program and test the systems                              |                                      | <sup>8</sup> VR Vapor Products                            |  |
| <sup>4</sup> Provide supervised field experience in service techniques and operations |                                      |   |  |
| <sup>5</sup> Troubleshoot and provide routing maintenance                             |                                      |   |  |

**Warranty Registrations** may only be submitted by selected Distributors. Certified installers are required to provide the GDF operator with the completed Equipment Warranty Notice, form 577013-868, for their records.

## Related Manuals





The manuals in Table 1 below are shipped with the equipment on the V-R Tech Docs CD-ROM and will be needed to install specific equipment.

**Table 1. Related Manuals**



| V-R Manual  | Part Number                   |
|---|-------------------------------|
| TLS-3XX Site Prep Manual  | 576013-879                    |
| Vapor Pressure Sensor For Vent Stacks Installation Guide<br>(For Sensor P/N 861190-X0X) | IOM 21 VR-203 & IOM 27 VR-204 |
| Pressure Sensor Installation Guide<br>(For Sensor P/N 331946-001)                       | IOM 13 VR-203 & VR-204        |
| TLS-3XX Series Consoles System Setup Manual   | 576013-623                    |
| TLS-3XX Series Consoles Operator's Manual   | 576013-610                    |
| Serial Comm Modules Installation Guide  | 577013-528                    |
| TLS-350 Series Board and Software Replacement Manual                                    | 576013-637                    |

## Safety Precautions

The following symbols may be used throughout this manual to alert you to important safety hazards.

|  |  |
|--|--|
|  <p><b>ELECTRICITY</b><br/>High voltage exists in, and is supplied to, the device. A potential shock hazard exists.</p>   |  <p><b>TURN POWER OFF</b><br/>Live power to a device creates a potential shock hazard. Turn Off power to the device and associated accessories when servicing the unit.</p> |
|  <p><b>READ ALL RELATED MANUALS</b><br/>Knowledge of all related procedures before you begin work is important. Read and understand all manuals thoroughly. If you do not understand a procedure, ask someone who does.</p> |  <p><b>WARNING</b><br/>Heed the adjacent instructions to avoid equipment damage or personal injury.</p>   |

**⚠ WARNING**

|   |  |
|---|--|
|   | <p><b>The console contains high voltages which can be lethal. It is also connected to low power devices that must be kept intrinsically safe.</b></p> <p><b>Turn power Off at the circuit breaker. Do not connect the console AC power supply until all devices are installed.</b></p> <p><b>FAILURE TO COMPLY WITH THE FOLLOWING WARNINGS AND SAFETY PRECAUTIONS COULD CAUSE DAMAGE TO PROPERTY, ENVIRONMENT, RESULTING IN SERIOUS INJURY OR DEATH.</b></p> |
|---|--|

## Installation

This section discusses the installation and wiring of the hardware required to enable the TLS console to perform pressure management of the site's gasoline vapor processor equipment:

- Vapor Pressure Sensor
- Smart Sensor Interface Module
- NVMEM203 board
- Multiport Card
- 4-Relay or I/O Combination Module



All field wiring, its type, its length, etc., used for TLS console sensors must conform to the requirements outlined in the Veeder-Root TLS-3XX Site Prep manual (P/N 576013-879) and to additional field wiring requirements specified in related connected components, such as for Pressure Sensors.

### Installing TLS Console Modules - General Notes

TLS consoles have three bays in which interface modules can be installed; Comm bay, Power bay and Intrinsically-Safe bay (ref. Figure 1). Probe Interface modules and Smart Sensor modules are installed in the Intrinsically-Safe bay and the Mod Bus module is installed in the Comm bay.

**In all cases, the position of the modules, their respective connectors and the devices wired to the connectors must be recorded to prevent improper replacement during installation or service. A circuit directory for Power and I.S. bay Interface Modules is adhered to the back of the right-hand door for this purpose.**



Switch off power to the TLS console before you install modules and connect sensor wiring.




Figure 1. TLS console Interface Module Bays





**CAUTION!** During programming, module positions and the devices wired to each module are identified and stored in memory. If a connector is removed and reinstalled on a different module after programming, or if an entire module with its connector is removed and reinstalled in a different module slot, the TLS console will not identify correctly the data being received.

### Module Position

1. Record on the circuit directory the type of module in each slot location.
2. If a system contains multiple modules of a single type (i.e., two Smart Sensor Modules), they may be swapped between their respective slot locations, **however, the connectors must remain with their original locations, not with the original modules.**

### Connector Position

1. Identify all connectors according to their slot location using the self-adhesive numbering labels furnished with each module. Accurately record on the circuit directory the location of each device wired to the connector **as you attach wires** to the module.
2. Once a device has been wired to certain terminals on a connector and the system has been programmed, the wires from that device may not be relocated to other terminals without reprogramming the system.

### Grounding Probe and Sensor Shields

Connect probe and sensor cable shields to ground at the console only. Do not ground both ends of the shield.

## CIRCUIT DIRECTORY

A circuit directory is adhered to the inside of the right-hand door. It should be filled out by the installer as the module's connectors are being wired.

The following information should be recorded for each slot:

- Module Type: record what type of module has been installed in the slot, e.g., Smart Sensor Module.
- Position Record: record the physical location and/or type of device wired to each terminal of the module connector in the slot, e.g., VPS: FP1&2.

## Vapor Pressure Sensor

---

Install one vapor pressure sensor as detailed in the applicable Pressure Sensor Installation Guide shown in Table 1.

## Smart Sensor Interface Module

---

The Smart Sensor Interface Module 8 input or 7 input w/embedded pressure versions monitor the Vapor Pressure Sensor (VPS) inputs.



Switch off power to the TLS console while you install modules and connect sensor wiring.

Open the right door of the console and slide the necessary Smart Sensor modules into empty I.S. Bay slots. Connect the field wiring from the sensor following instructions in the Vapor Pressure Sensor manual. Setup the Smart Sensor module(s) following instructions in this manual.

---

## NVMEM203 Board

---

Verify that a NVMEM203 board is installed in the TLS console (ref. Figure 2-7 in the V-R TLS-3XX Series Consoles Troubleshooting Manual P/N 576013-818, Rev Q or later). This board contains flash EEPROM and RAM needed to run PMC software. No setup is required.

---

## Probe Interface Module

---

Verify that a Probe Interface Module(s) is installed (Intrinsically-Safe bay) and that a Mag probe is in each gasoline tank and is connected to the module(s). Program the Mag probes following instructions in the TLS-3XX System Setup manual.

---

## I/O Combination or 4-Relay Module

---

Connect the vapor processor motor control relay to two relays on either the 4-Relay or I/O Combination module as shown in Figure 2.

---

## Multiport Card for Vapor Processor Communication

---



A Multiport card is needed for RS-485 communication with the TLS console and is required with VST ECS membrane processor installations. Verify that a Multiport card is installed in slot 4 of the card cage in the communications bay of the TLS console (ref. Figure 2). When installing this card, refer to the V-R Serial Comm Modules Installation Guide (577013-528) for instructions. Connect this card to the vapor processor as shown in Figure 2. Program the card as instructed in this manual.

---

## TLS Console with VST ECS Membrane Processor

---

Figure 2 shows the interconnection wiring between a TLS console and a VST ECS Membrane Processor.




Figure 2. VST ECS Membrane Processor Connections to TLS Console

# Setup

## Introduction

This section describes how to perform PMC setup using the TLS console's front panel buttons and display. The procedures in this manual follow standard TLS console setup programming input, i.e., keypad/display interaction. If necessary, refer to Section 2 of the TLS-3XX System Setup manual (P/N 576013-623) to review entering data via the front panel keypads.

All PMC-related equipment must be installed in the site and connected to the TLS console prior to beginning the setups covered in this section. As with all TLS connections, you cannot change sensor wiring or module slots after programming or the console may not operate properly. Reference the section entitled "Connecting Probe/Sensor Wiring to Consoles" in the TLS-3XX Site Prep and Installation manual (P/N 576013-879) for rewiring precautions.

## Smart Sensor Setup

The Smart Sensor Interface Module is installed in the Intrinsically-Safe bay of the TLS console. This module monitors the Vapor Pressure Sensor. Figure 3 diagrams the Smart Sensor setup procedure.




Figure 3. Smart Sensor Setup

## Output Relay Setup - VST ECS Membrane Processor & VST Green Machine

The Output Relay setup programs an output relay so that the TLS console can switch a controlled vapor processor on and off as shown in Figure 4.




Figure 4. Output Relay Setup for VST ECS Membrane Processor

Figure 5 shows example setup printouts of the Output Relays setup.




Figure 5. Output Relay Setup Printout Examples for TLS Console Controlled Processor

# PMC Setup

Figure 6 diagrams the PMC setup programming.




Figure 6. PMC Setup

# Operation

## Alarms

### OVERVIEW OF TLS CONSOLE INTERFACE

The TLS console is continuously monitoring the vapor recovery system and PMC sensors for alarm conditions. During normal operation when the TLS console and monitored PMC equipment is functioning properly and no alarm conditions exist, the "ALL FUNCTIONS NORMAL" message will appear in the system status (bottom) line of the console display, and the green Power light will be On (see Figure 7).




Figure 7. TLS console alarm interface

If an alarm condition occurs the system displays the condition type and its location. If more than one condition exists, the display will continuously cycle through the appropriate alarm messages. The system automatically prints an alarm report showing the alarm type, its location and the date and time the alarm condition occurred.

Warning and alarm posting causes the TLS console-based system to activate warning or failure indicator lights, an audible alarm, and an automatic strip paper printout documenting the warning or alarm.

### WARNING POSTING

Displayed messages alert you to the type of warning. Printed messages show the type of warning and the time the warning was posted (see Figure 8). Warnings are logged into the Non-Priority Alarm History in the TLS.




Figure 8. TLS console warning example

### ALARM POSTING

Displayed Messages alert you to the type of alarm. Printed messages show the type of alarm and the time the alarm was posted. Alarm example in Figure 9. PMC Alarms are logged into the Priority Alarm History in the TLS.




Figure 9. TLS console alarm example



## PMC Alarm Summary

Table 2 contains a listing of the PMC generated alarms including their displayed message and cause. TLS Console PMC alarms may be interspersed amongst non-PMC alarms, please see TLS-350 Series manuals for more information.

**Table 2. TLS-350 (PMC) Alarm Troubleshooting Summary**

| Displayed Message               | Description   | Light Indicator | Suggested Troubleshooting   |
|---------------------------------|---|-----------------|---|
| VP EMISSION WARN                | Mass emission exceeded the certified daily threshold  | Yellow          | <ul style="list-style-type: none"> <li>• Troubleshooting Guide <a href="http://www.vsthose.com">www.vsthose.com</a>.</li> </ul>   |
| VP EMISSION FAIL                | 2nd Consecutive mass emission failure   | Red             | <ul style="list-style-type: none"> <li>• Exhibit 8</li> <li>• Exhibit 9</li> </ul>  |
| PMC SETUP FAIL                  | PMC is not configured or missing components.  | Red             | <ul style="list-style-type: none"> <li>• Troubleshooting Guide <a href="http://www.vsthose.com">www.vsthose.com</a></li> <li>• See ISD Troubleshooting Guide, P/N 577013-819</li> <li>• Exhibit 8</li> <li>• Exhibit 9</li> </ul> |
| VP DUTY CYCLE WARN <sup>1</sup> | Duty cycle exceeds 18 hours per day Or 75% of 24 hours  | Yellow          | <ul style="list-style-type: none"> <li>• Troubleshooting Guide <a href="http://www.vsthose.com">www.vsthose.com</a>.</li> </ul>   |
| VP DUTY CYCLE FAIL <sup>1</sup> | 2nd Consecutive Duty Cycle Failure  | Red             | <ul style="list-style-type: none"> <li>• TLS-350 PMC Setup Procedure</li> <li>• Exhibit 4</li> <li>• Exhibit 9</li> <li>• Exhibit 10</li> </ul>   |
| PMC SENSOR FAULT                | Component used by PMC has failed or reported an error condition. See Troubleshooting section for complete description of sensors and associated conditions that can cause a sensor fault. | Red             | Check for Smart Sensor Device Alarm or Fault.   |

<sup>1</sup>VST ECS Membrane Processor Only

## PMC Status Report




Figure 10. PMC Status Report

## Viewing PMC Reports Via RS-232 Connection

### CONNECTING LAPTOP TO CONSOLE

Connect your laptop to the TLS console's RS-232 or Multiport card using one of the methods shown in the examples in Figure 11 below.




Figure 11. Connecting laptop to TLS console for serial communication

### CONNECTING LAPTOP TO CONSOLE

1. Open your laptop's serial communication program, e.g., HyperTerminal. You can typically find HyperTerminal under: Start/Programs/Accessories/Communications.

2. After opening the terminal software program, ignore (cancel) any modem/dialing related request windows since you will be directly connecting to the console via serial communications. When the Connection Description window appears (Figure 12), enter a connection name, e.g., TSLSDIRECT, and click the OK button.




Figure 12. Connection Description window

3. After clicking the OK button, you may see a repeat of the modem/dialing windows, in which case ignore (cancel) them all.
4. When the Connect To window appears (Figure 13), depending on your connection method, select either COM1 (If RS-232 port on laptop), USB-Serial Controller (if using USB port on laptop), or Serial I/O PC Card (if using PCMCIA port on laptop) in the 'Connect using' drop down box, then click OK button.




Figure 13. Connect To window



5. Next you should see the 'Port Settings' window.

**IMPORTANT! The settings of the laptop's com port must match those of the console's com port to which you are connected.**

- a. Go to the console front panel press the MODE key until you see:

```

SETUP MODE
PRESS <FUNCTION> TO CONT
    
```

- b. Press the FUNCTION key until you see the message:

```


COMMUNICATIONS SETUP
PRESS <STEP> TO CONTINUE
    
```

- c. Press the STEP key until you see the message:

```

PORT SETTINGS
PRESS <ENTER>
    
```

- d. Press the PRINT key to printout the port settings for all communication modules installed in the console. Figure 14 shows an example port settings printout with the RS-232 module installed. Using the console port settings in the example below, your HyperTerminal 'Port Settings' window entries would be Bits per second - 2400, Data bits - 7, Parity - Odd, Stop Bits - 1. For the 'Flow Control' entry select None. Click OK.



**Figure 14. Console comm port settings printout example**

In the example port settings printout above, the RS-232 Security Code is disabled. If the code was enabled you would see a 6-digit number which you will need to enter to access the console (refer to the 'Sending Console Commands' paragraph below for more information).

6. After entering your port settings, the program's main window appears (Figure 15).




Figure 15. HyperTerminal main window

### SENDING CONSOLE COMMANDS

Table 3 shows four important PMC console commands: IV8200, IV8000, IV8100 and I11100. The <SOH> shown in the table means that you must press and hold the **Ctrl** key while you press the **A** key.

For example, let's say you want to see the Vapor Processor Status Report.



Note: If you want to see the characters of the command as you type them in, click on File menu, then select Properties/Settings (tab)/ASCII Setup and click the check box for 'Echo typed characters locally', then click OK to close the window(s) and return to the main screen.

If the RS-232 Security Code is disabled - press and hold the Ctrl key while you press the A key, then type in IV8200. If the RS-232 Security Code is enabled (e.g., 000016) you must enter the security code before the command - press and hold the Ctrl key while you press the A key, then type in 000016IV8200.

You will see the typed command on the screen: ☺IV8200 followed by the response (report) from the console. The ☺ symbol indicates CtrlA and the ♥ symbol indicates the end of the response.

If the console recognizes the command the response displays as soon as the command is typed in.

If the console does not recognize the command you would see something like ☺IV8200☺9999FF1B♥ which indicates the console did not recognize the command.

All responses (Reports) can be printed or saved to a file. See the terminal program's help file for instructions.

**Table 3. Serial Commands for PMC Diagnostic Reports**

| Report Type  | Serial Command (PC to Console)* |
|--|---------------------------------|
| Vapor Processor Status Report<br>(See example Figure 16)             | <SOH>IV8200                     |
| Vapor Processor Runtime Diagnostic Report<br>(See example Figure 17) | <SOH>IV8000                     |
| Percent Hydrocarbon Diagnostic Report (See example Figure 18)        | <SOH>IV8100                     |
| Priority Alarm History Report<br>(See example Figure 19)             | <SOH>I11100                     |
| Non-Priority Alarm History Report<br>(See example Figure 20)         | <SOH>I11200                     |

\*<SOH> = Control A. For more information on TLS console serial commands, refer to the V-R Serial Interface Manual.

```

<SOH>
  IV8200
  JUN 1, 2002 8:07 AM

  (SITE NAME)
  (SITE STREET)
  (CITY, STATE)
  (PHONE NUMBER)

VAPOR PROCESSOR STATUS REPORT

PMC VERSION: 01.04
VAPOR PROCESSOR TYPE: VST ECS PROCESSOR

PMC MONITORING TEST PASS/FAIL THRESHOLDS
H2O
PERIOD      BELOW  ABOVE
VST ECS Membrane Processor Only → VAPOR PROCESSOR MASS EMISSION FAIL    1DAYS    ----    0.32 LBS/1KG
VAPOR PROCESSOR DUTY CYCLE FAIL        1DAYS    ----    75.00 %

VST ECS Membrane Processor Only → EFFLUENT EMISSIONS TEST : PASS    (0.15 LBS/1KG)
VP DUTY CYCLE TEST : PASS    (17.54%)
VP INPUT STATUS : NOTEST

RUN TIME HOURS : 4.2
DAILY THROUGHPUT : 8421 GALS
AVG HC PERCENT : 8.85 %
    
```

**Figure 16. Vapor Processor Status Report Details - Serial to PC Format**

IV8000  
 AUG 30, 2007 11:52 AM

(SITE NAME)  
 (SITE STREET)  
 (CITY, STATE)  
 (PHONE NUMBER)

VAPOR PROCESSOR

| DATE-TIME | ON      | ELAPSED<br>MINUTES | PRESSURE INCHES H2O |        | RUNTIME<br>FAULT |
|-----------|---------|--------------------|---------------------|--------|------------------|
|           |         |                    | ON                  | OFF    |                  |
| 3-08-07   | 8:52PM  | 5.53               | 0.209               | -0.211 | NO               |
| 3-08-07   | 8:58PM  | 0.98               | 0.303               | -0.203 | NO               |
| 3-09-07   | 5:03AM  | 26.60              | 0.221               | -0.205 | NO               |
| 3-09-07   | 1:15PM  | 17.92              | 0.278               | -0.268 | NO               |
| 3-10-07   | 3:01AM  | 7.70               | 0.200               | -0.223 | NO               |
| 3-10-07   | 4:30AM  | 4.02               | 0.202               | -0.224 | NO               |
| 3-10-07   | 7:54PM  | 23.62              | 0.306               | -0.245 | NO               |
| 3-11-07   | 11:24PM | 6.55               | 0.256               | -0.213 | NO               |
| 3-12-07   | 11:31PM | 21.23              | 0.228               | -0.203 | NO               |
| 3-13-07   | 3:44PM  | 23.95              | 0.926               | -0.230 | NO               |
| 3-15-07   | 1:35AM  | 30.00              | 0.202               | 0.154  | YES              |
| 3-15-07   | 2:36AM  | 6.87               | 0.200               | -0.205 | NO               |
| 3-15-07   | 3:24AM  | 30.00              | 0.201               | 0.442  | YES              |
| 3-16-07   | 3:10AM  | 4.33               | 0.202               | -0.205 | NO               |
| 3-16-07   | 1:28PM  | 20.78              | 0.234               | -0.264 | NO               |
| 3-16-07   | 2:38PM  | 1.30               | 0.220               | -0.219 | NO               |
| 3-17-07   | 12:44AM | 6.52               | 0.206               | -0.200 | NO               |
| 3-17-07   | 2:00PM  | 27.47              | 0.254               | -.210  | NO               |

Figure 17. Vapor Processor Runtime Diagnostic Report - Serial to PC Format



```

IV800
SEP 21, 2010 8:52 AM
HYDROCARBON SENSOR DIAGNOSTIC
DATE/TIME      READING%
9-25-10 8:57 AM 1.174
9-25-10 8:57 AM 1.188
9-25-10 8:57 AM 1.168
9-25-10 8:57 AM 1.182
9-25-10 8:57 AM 1.182
9-25-10 8:57 AM 1.182
9-25-10 8:57 AM 1.174
9-25-10 8:57 AM 1.188
9-25-10 8:57 AM 1.182
9-25-10 8:57 AM 1.194
9-25-10 8:57 AM 1.188
9-25-10 8:57 AM 1.200
9-25-10 8:56 AM 1.188
    
```

**Figure 18. Percent Hydrocarbon Diagnostic Report - Serial to PC Format**

```

I11100
APR 17, 2008 12:30 AM

<Site Name>
<Site Address>
<Site Address>
<Site Address>

PRIORITY ALARM HISTORY
ID  CATEGORY  DESCRIPTION          ALARM TYPE          STATE  DATE    TIME
T 2  TANK      Premium 91          PROBE OUT           CLEAR  4-04-08 12:14PM
T 2  TANK      Premium 91          PROBE OUT           ALARM  4-04-08 12:14PM
T 2  TANK      Premium 91          LOW PRODUCT ALARM   CLEAR  4-04-08 12:04PM
T 2  TANK      Premium 91          PROBE OUT           CLEAR  4-04-08 12:04PM
T 1  TANK      Unlead 87          PROBE OUT           CLEAR  4-04-08 11:37AM
T 1  TANK      Unlead 87          PROBE OUT           ALARM  4-04-08 10:51AM
T 2  TANK      Premium 91          PROBE OUT           ALARM  4-04-08 10:42AM
T 2  TANK      Premium 91          LOW PRODUCT ALARM   ALARM  4-04-08 10:42AM
s 8  OTHER    PRES SEN 2 DISP 1-2 COMMUNICATION ALARM CLEAR  3-26-08  1:39PM
s 8  OTHER    PRES SEN 2 DISP 1-2 COMMUNICATION ALARM ALARM  3-26-08  1:37PM
      SYSTEM          BATTERY IS OFF     CLEAR  3-10-08  8:00AM
      SYSTEM          BATTERY IS OFF     ALARM  3-10-08  8:00AM
    
```

**Figure 19. Priority Alarm History Report - Serial to PC Format**

```

I11200
DEC 9, 2010 4:20 AM

<Site Name>
<Site Address>
<Site Address>
<Site Address>

NON-PRIORITY ALARM HISTORY
ID CATEGORY DESCRIPTION ALARM TYPE STATE DATE TIME
T 3 TANK DIESEL LOW TEMP WARNING CLEAR 12-08-10 3:00PM
T 3 TANK DIESEL LOW TEMP WARNING ALARM 12-08-10 3:00PM
T 3 TANK DIESEL HIGH PRODUCT ALARM CLEAR 12-08-10 3:00PM
T 3 TANK DIESEL HIGH PRODUCT ALARM ALARM 12-08-10 2:56PM
SYSTEM PRINTER ERROR CLEAR 11-17-10 10:51AM
SYSTEM PAPER OUT CLEAR 11-17-10 10:51AM
SYSTEM PAPER OUT ALARM 11-17-10 10:50AM
SYSTEM PRINTER ERROR ALARM 11-17-10 10:50AM
    
```

Figure 20. Non-Priority Alarm History Report - Serial to PC Format

# Diagnostics

## Automatic Control

Under Automatic control, vapor pressure readings are compared to user programmable thresholds to determine the appropriate Pressure Management Device (PMD) state. When the PMD is off and the TURN ON VAPOR PROCESSOR is exceeded, an internal relay is enabled and remains so until the pressure drops below the TURN OFF VAPOR PROCESSOR threshold. Automatic control is the default mode.

## Manual control

If PMC mode is Manual, the diagnostic menu allows the PMD to be directly turned on/off through the relay. This feature is to support unit operational testing without waiting for the pressure to hit limits. The current UST ullage space vapor pressure will also be available through the diagnostic menu. The VC1 RS232 command allows for remote control of the PMD when the PMD control is manual. Note: If the PMD is on and the PMC mode is Automatic, changing the control mode to Manual mode will turn the PMD off.

When set to Manual mode, the system will revert to Automatic mode after 4 hours.

## PMC Diagnostic Menu





Figure 21. PMC Diagnostic Menus



# Pressure Sensor

## Installation Guide



# Notice

---

Veeder-Root makes no warranty of any kind with regard to this publication, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Veeder-Root shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this publication.

Veeder-Root reserves the right to change system options or features, or the information contained in this publication as approved by ARB.

This publication contains proprietary information which is protected by copyright. All rights reserved. No part of this publication may be modified or translated to another language without the prior written consent of Veeder-Root. Contact TLS Systems Technical Support for additional troubleshooting information at 800-323-1799.

## **DAMAGE CLAIMS / LOST EQUIPMENT**

Thoroughly examine all components and units as soon as they are received. If any cartons are damaged or missing, write a complete and detailed description of the damage or shortage on the face of the freight bill. The carrier's agent must verify the inspection and sign the description. Refuse only the damaged product, not the entire shipment.

Veeder-Root must be notified of any damages and/or shortages within 30 days of receipt of the shipment, as stated in our Terms and Conditions.

## **VEEDER-ROOT'S PREFERRED CARRIER**

1. Contact Veeder-Root Customer Service at 800-873-3313 with the specific part numbers and quantities that were missing or received damaged.
2. Fax signed Bill of Lading (BOL) to Veeder-Root Customer Service at 800-234-5350.
3. Veeder-Root will file the claim with the carrier and replace the damaged/missing product at no charge to the customer. Customer Service will work with production facility to have the replacement product shipped as soon as possible.

## **CUSTOMER'S PREFERRED CARRIER**

1. It is the customer's responsibility to file a claim with their carrier.
2. Customer may submit a replacement purchase order. Customer is responsible for all charges and freight associated with replacement order. Customer Service will work with production facility to have the replacement product shipped as soon as possible.
3. If "lost" equipment is delivered at a later date and is not needed, Veeder-Root will allow a Return to Stock without a restocking fee.
4. Veeder-Root will NOT be responsible for any compensation when a customer chooses their own carrier.

## **RETURN SHIPPING**

For the parts return procedure, please follow the appropriate instructions in the "General Returned Goods Policy" pages in the "Policies and Literature" section of the Veeder-Root **North American Environmental Products** price list. Veeder-Root will not accept any return product without a Return Goods Authorization (RGA) number clearly printed on the outside of the package.

## **INSTALLATION IN THE STATE OF CALIFORNIA**

Please refer to the California Air Resources Board Vapor Recover Certification Phase II EVR Executive Order web site ([www.arb.ca.gov/vapor/eo-evrphasell.htm](http://www.arb.ca.gov/vapor/eo-evrphasell.htm)) for the latest manual revisions pertaining to VR 204 (VST Phase II EVR System Including ISD System).

©Veeder-Root 2016. All rights reserved.

## Pressure Sensor Installation

|   |    |
|---|----|
| Contractor Certification Requirements ..... | 1  |
| Related Documents .....                     | 1  |
| Safety Precautions .....                    | 2  |
| Before You Begin .....                      | 3  |
| Veeder-Root Parts .....                     | 3  |
| Tools Required .....                        | 5  |
| Under Dispenser Installation Steps .....    | 5  |
| Vapor Vent Stack Installation Step .....    | 13 |

## Figures

|   |    |
|---|----|
| Figure 1. Table 2 Component Pictorial .....   | 5  |
| Figure 2. Example Pressure Sensor Install In Shear Valve Port - Preferred Non-ISD Installation (Without Vapor Flow Meter) .....                                 | 7  |
| Figure 3. Example Pressure Sensor Install In Vapor Return Line - Non-ISD Installation (Without Vapor Flow Meter) .....  | 8  |
| Figure 4. Example Pressure Sensor Install In Shear Valve Port - Preferred ISD Installation .....  | 9  |
| Figure 5. Example Pressure Sensor Install In Horizontal Access Fitting Or Vapor Return Line - ISD Installation (With Vapor Flow Meter Below Shear Valve) .....  | 10 |
| Figure 6. Example Pressure Sensor Install Below Vertical Access Fitting Or Vapor Return Line - ISD Installation (With Vapor Flow Meter Below Shear Valve) ..... | 11 |
| Figure 7. Field wiring Pressure Sensor - Observe Polarity .....   | 12 |
| Figure 8. Epoxy sealing field wiring .....  | 12 |
| Figure 9. Connecting Pressure Sensor to TLS-3XX Smart Sensor Interface Module .....   | 13 |
| Figure 10. Locating Pressure Sensor Enclosure in Vapor Vent Stack .....   | 15 |
| Figure 11. Mounting Pressure Sensor Assembly onto Composite Panel .....   | 16 |

## Tables

|   |   |
|---|---|
| Table 1. Under Dispenser - Pressure Sensor Installation Kit (P/N 330020-515) .....  | 3 |
| Table 2. Vapor Vent Stack - Pressure Sensor Installation Kit (P/N 330020-630) ..... | 4 |

## Pressure Sensor Installation

This manual contains instructions to install a Veeder-Root (In-Station Diagnostic) Pressure Sensor in a dispenser's vapor return line or in a vapor vent stack.

This manual assumes all preliminary site preparation is completed, and that wiring from the console to the Pressure Sensor junction box is in place and meets the requirements set out in the console's Site Prep manual.

### Contractor Certification Requirements

| Veeder-Root Contractor Certification Requirements  | Installer Certification <sup>6</sup> | ATG Technician Certification <sup>7</sup>   | VR Vapor Products Certification <sup>8</sup> |
|--|--------------------------------------|---|--|
| Install <sup>1</sup> ISD   | X                                    | X   | X  |
| Install PMC  | X                                    | X   | X  |
| Install CCVP   | X                                    | X   | X  |
| Install Wireless ISD/PMC   | X                                    | X   | X  |
| Installation Checkout <sup>2</sup>   |                                      | X   | X  |
| ATG Startup <sup>3</sup> / Training <sup>4</sup> / Service <sup>5</sup>  |                                      | X   | X  |
| ISD Startup / Training / Service   |                                      |   | X  |
| PMC Startup / Training / Service   |                                      |   | X  |
| CCVP Startup / Training / Service  |                                      |   | X  |
| Wireless ISD/PMC Startup / Training / Service  |                                      |   | X  |
| Install Pressure Sensor (ATG)  | X                                    | X   | X  |
| Maintain Pressure Sensor (ATG)   |                                      | X   | X  |
| Calibrate Pressure Sensor (ATG)  |                                      | X   | X  |
| Clear ATG Pressure Sensor Alarm (ATG)  |                                      | X   | X  |
| Clear ISD/PMC Alarms (ISD/PMC)   |                                      |   | X  |
| <sup>1</sup> Perform wiring and conduit routing; equipment mounting<br><sup>2</sup> Inspect wiring and conduit routing; equipment mounting<br><sup>3</sup> Turn power on, program and test the systems<br><sup>4</sup> Provide supervised field experience in service techniques and operations<br><sup>5</sup> Troubleshoot and provide routing maintenance |                                      | <sup>6</sup> UST Monitoring Systems – Installer (Level 1)<br><sup>7</sup> Certified UST Monitoring Technician<br><sup>8</sup> VR Vapor Products |  |

**Warranty Registrations** may only be submitted by selected Distributors. Certified installers are required to provide the GDF operator with the completed Equipment Warranty Notice, form 577013-868, for their records.








### Related Documents

- 576013-879 TLS-3XX Series Consoles Site Prep and Installation Manual
- 577013-800 ISD Setup and Operation Manual
- 577013-801 PMC Setup and Operation Manual
- 577013-937 In-Station Diagnostics (ISD) Install, Setup, & Operation Manual
- 331940-012 TLS-RF System Control Drawing
- 577013-964 TLS RF Wireless 2 System (W2) Installation and Maintenance Guide









## Safety Precautions

The following safety symbols may be used throughout this manual to alert you to important safety hazards and precautions.

|  |  |
|--|--|
|  <p><b>EXPLOSIVE</b><br/>Fuels and their vapors are extremely explosive if ignited.</p>   |  <p><b>FLAMMABLE</b><br/>Fuels and their vapors are extremely flammable.</p>  |
|  <p><b>ELECTRICITY</b><br/>High voltage exists in, and is supplied to, the device. A potential shock hazard exists.</p>   |  <p><b>TURN POWER OFF</b><br/>Live power to a device creates a potential shock hazard. Turn Off power to the device and associated accessories when servicing the unit.</p>                           |
|  <p><b>WARNING</b><br/>Heed the adjacent instructions to avoid damage to equipment, property, environment or personal injury.</p>   |  <p><b>USE SAFETY BARRICADES</b><br/>Unauthorized people or vehicles in the work area are dangerous. Always use safety cones or barricades, safety tape, and your vehicle to block the work area.</p> |
|  <p><b>READ ALL RELATED MANUALS</b><br/>Knowledge of all related procedures before you begin work is important. Read and understand all manuals thoroughly. If you do not understand a procedure, ask someone who does.</p> |  |

# ⚠ WARNING

|  |  |
|--|--|
|  <br><br><br><br><br><br>  | <p><b>This product is to be installed and operated in the highly combustible environment of a gasoline dispenser where flammable liquids and explosive vapors may be present.</b></p> <p><b>FAILURE TO COMPLY WITH THE FOLLOWING WARNINGS AND SAFETY PRECAUTIONS COULD CAUSE DAMAGE TO PROPERTY, ENVIRONMENT, RESULTING IN SERIOUS INJURY OR DEATH.</b></p> <p><b>The following hazards exist:</b></p> <ol style="list-style-type: none"> <li><b>1. Electrical shock resulting in serious injury or death may result if power is on during installation and the device is improperly installed.</b></li> <li><b>2. Product leakage could cause severe environmental damage or explosion resulting in death, serious personal injury, property loss and equipment damage.</b></li> </ol> <p><b>Observe the following precautions:</b></p> <ol style="list-style-type: none"> <li><b>1. Read and follow all instructions in this manual, including all safety warnings.</b></li> <li><b>2. To be installed in accordance with the National Electrical Code (NFPA 70) and the Code for Motor Fuel Dispensing Facilities and Repair Garages (NFPA 30A).</b></li> <li><b>3. Before installing this device, turn Off, tag/lock out power to the system, including console and submersible pumps.</b></li> <li><b>4. To protect yourself and others from being struck by vehicles, block off your work area during installation or service.</b></li> <li><b>5. Substitution of components may impair intrinsic safety.</b></li> </ol> |
|--|--|

## Before You Begin

---

- Comply with all recommended safety practices identified by OSHA (Occupational Safety and Health Administration) and your employer.
- Review and comply with all the safety warnings in the installation manuals and any other national, State or Local requirements.
- When direct wiring to a TLS console, a 2-conductor, 18 AWG shielded cable must be installed in intrinsically safe conduit from the dispenser or from the vapor vent stack to the TLS console.
- The Pressure Sensor must be installed in a VERTICAL position with the sensing port pointing down. Its connection in the base of the dispenser to the vapor return line must be made BELOW the vapor return line shear valve mechanism, AND BELOW the Vapor Flow Meter outlet (if a flow meter is installed).
- For all connections requiring sealant, use only UL classified yellow Gas/TFE Teflon tape.
- When installing on a vent stack, customer supplied pipe and pipe fittings shall be standard full-weight (ASTM Schedule 40) wrought iron or steel.
- Customer supplied copper tubing shall be soft tempered, 1/4-inch O.D., with a minimum wall thickness of 0.0265 inches.
- Pipe threads shall be in accordance with the Standard for Pipe Threads, General Purpose (Inch) ANSI/ASME B1.20.1-1983.

## Veeder-Root Parts

---

Veeder-Root parts and kits required to install the Pressure Sensor are listed in Table 1 and Table 2.

**Table 1. Under Dispenser - Pressure Sensor Installation Kit (P/N 330020-515)**

| Item | Qty. | Description  | P/N                      |
|------|------|--|--------------------------|
| 1    | 1    | Pressure sensor  | 331946-001 or 861190-201 |
| 2    | 4    | Male connector 68CA-4-4, brass 1/4" tube to 1/4" pipe  | 514100-430               |
| 3    | 1    | Union 62CA-4, brass 1/4" tube size   | 514100-431               |
| 4    | 1    | Plug 59CA-4, brass 1/4" tube size  | 514100-432               |
| 5    | 1    | Universal sensor mounting kit - miscellaneous assortment of U-bolts, brackets, clamps, and fasteners | 330020-012               |
| 6    | 2    | Wire nut   | 576008-461               |
| 7    | 1    | Sealing pack   | 514100-304               |
| 8    | 1    | Cord grip  | 331028-011               |
| 9    | 2    | Tie wrap   | 510901-337               |
| 10   | 1    | Shim   | 332061-001               |
| 11   | 1    | Ball Valve, 3-way, 1/4"  | 576008-649               |
| 12   | 1    | Copper tube, soft, 1/4" OD, 36" length   | 332151-001               |

**Table 2. Vapor Vent Stack - Pressure Sensor Installation Kit (P/N 330020-630)**

| Item | Qty. | Description   | P/N                      |
|------|------|---|--------------------------|
| 1    | 1    | Pressure sensor                                       | 331946-001 or 861190-201 |
| 2    | 1    | Enclosure, NEMA 4X- modified                          | 333004-001               |
| 3    | 1    | Panel, composite, modified                            | 333005-001               |
| 4    | 2    | Male elbow 169CA-4-4, brass 1/4" tube to 1/4" pipe    | 579066-001               |
| 5    | 2    | Male connector 68CA-4-4, brass 1/4" tube to 1/4" pipe | 514100-430               |
| 6    | 1    | Plug 59CA-4, brass 1/4" tube size                     | 514100-432               |
| 7    | 1    | Bulkhead union 62CABH-4, brass 1/4" tube size         | 514100-476               |
| 8    | 2    | Washer, 0.469 x 1.125 x 0.063", zinc                  | 510904-573               |
| 9    | 1    | Tube - copper, 1/4" OD, short S bend                  | 333006-001               |
| 10   | 1    | Tube - copper, 1/4" OD x 8" length                    | 333018-001               |
| 11   | 1    | Ball valve, 3-way, 1/4"                               | 576008-649               |
| 12   | 1    | Hub, conduit, liquid tight, 1/2", zinc                | 576010-715               |
| 13   | 3    | Conduit clamp, 2", steel - std duty                   | 514100-478               |
| 14   | 3    | 1/4-20 x 0 .75" hex bolt - steel                      | 026-620-1                |
| 15   | 3    | Washer, flat, 1/4", zinc                              | 514100-374               |
| 16   | 3    | 1/4-20, hex nut w/lock washer                         | 511000-251               |
| 17   | 1    | Vent, porous, flanged, 0.17 x 0.42"                   | 514100-477               |
| 18   | 2    | Wire nut  | 576008-461               |
| 19   | 1    | Sealing pack  | 514100-304               |
| 20   | 1    | Cord grip   | 331028-011               |
| 21   | 2    | Tie wrap  | 510901-337               |
| 22   | 1    | Shim  | 332061-001               |
| 23   | 1    | Manual, Installation VR Pressure Sensor               | 577013-797               |
| 24   | 1    | Manual, ISD Setup & Operation                         | 577013-800               |
| 25   | 1    | Manual, PMC Setup & Operation                         | 577013-801               |
| 26   | 1    | ISD Quick Reference Guide                             | 577013-842               |
| 27   | 1    | Warranty card, ISD system                             | 577013-868               |
| 28   | 1    | Manual, ISD Setup & Operation, VST                    | 577013-937               |
| 29   | 2    | Conduit clamp, 3", steel, std duty                    | 514100-482               |
| 30   | 1    | Label - eVRgreen                                      | 333041-001               |




Figure 1. Table 2 Component Pictorial

## Tools Required

1. Wrenches suitable for tightening tubing/pipe fittings.
2. Necessary pipe fitter’s equipment (including threading equipment as needed) and a non-hazardous work space suitable to modify the dispenser vapor line or the vapor vent stack for Pressure Sensor installation.
3. Torx bit for tamper-resistant screws (VR P/N 330020-635).

**NOTE: this bit is required to open and close the enclosure door.**

## Under Dispenser Installation Steps



1. Before installing this device, turn Off, tag/lock out power to the system, including console and submersible pumps.
2. Determine which dispenser is closest to the tank being monitored. Remove that dispenser’s lower sheet metal doors to gain access to the vapor plumbing.
3. Refer to Pressure Sensor dispenser installation examples in Figure 2 through Figure 6 to locate a suitable port or plumb a suitable fitting for the Pressure Sensor tubing in either the vapor return shear valve or in the

vapor return line. **NOTE: In ISD installations, the pressure port used must be below the vapor flow meter outlet.**

4. Install one of the 68CA-4-4 male connectors (item 2 in Table 1) from the kit into the tapped hole.
5. Install Pressure Sensor (item 1 in Table 1) vertically to the dispenser frame or piping using the 2-inch conduit clamp, rubber shim, and necessary bolts, nuts, and washers from the included Universal Sensor Mounting kit. Wrap the rubber shim (item 10 in Table 1) around the sensor before inserting it into the clamp. Also make sure the sensor cable outlet is facing up and the pressure sensing port tube in the base of the sensor is facing down.
6. Attach one end of the 62CA-4 union (item 3 in Table 1) to the pressure sensing port in the base of the Pressure Sensor.
7. Install the remaining 68CA-4-4 male connectors (item 2 in Table 1) from the kit into each of the three ports in the 3-way calibration valve (item 13 in Table 1).
8. Measure, fabricate, and install a 1/4" OD copper tube (item 12 in Table 1) that runs between the 62CA-4 union in the base of the sensor and the center port of the 3-way calibration valve.
9. Measure, fabricate, and install a 1/4" OD copper tube that runs between the 1/4" tube end of the male connector fitting installed beneath the shear valve mechanism and the right port on the 3-way valve, being careful not to create any potential liquid traps (Note 3-way valve orientation in Figure 6).
10. Screw the 59CA-4 plug, item 4, from the kit onto the left port's male connector. Make sure the valve's handle is set to connect the sensor to the vapor return line and not to the capped (ambient) port.

**Important!** All plumbing's pitch to drain should be 1/4" vertical per 12" horizontal to eliminate liquid traps.

11. Route the cable from Pressure Sensor to the Pressure Sensor junction box in the dispenser. Observing polarity, connect the sensor wiring to the field wiring from console and cap with wire nuts (see Figure 7) - OR - terminate the wiring in the TLS RF transmitter (W2). In wireless installations, the wiring is not sealed and does not run back to the TLS console and Steps 12, 13 and 14 ARE NOT REQUIRED.
12. Seal wire nuts in epoxy sealant following the instructions in Figure 8.
13. Push the epoxy sealed bag into the junction box. Replace and tighten the junction box cover.
14. Terminate field wiring into TLS Console and connect to Smart Sensor Module (TLS-3XX - Figure 9). Note: observe polarity! The cable length between the console and sensor must not exceed the distance stated in the TLS-3XX Site Prep manual (P/N 576013-879).

Note: Intrinsically safe devices must be installed in accordance with Article 504 of the National Electrical Code, ANSI/NFPA 70, for installation in the United States, or Section 18 of the Canadian Electrical Code for installations in Canada.

This intrinsically safe Pressure Sensor P/N 331946-001, has only been evaluated for connection to a UL listed TLS-3XX Liquid Level Gauge / Leak Detector.

Conductors of different intrinsically safe circuits run in the same cable/conduit must have at least 0.01 inch (0.25 mm) of insulation.

15. After the Pressure Sensor is installed, pressurize the tank ullage space and vapor piping to at least 2 inches WC and test for leaks using leak detection solution.
16. Replace lower dispenser sheet metal doors onto dispensers.




Figure 2. Example Pressure Sensor Install In Shear Valve Port - Preferred Non-ISD Installation (Without Vapor Flow Meter)




Figure 3. Example Pressure Sensor Install In Vapor Return Line - Non-ISD Installation (Without Vapor Flow Meter)




Figure 4. Example Pressure Sensor Install In Shear Valve Port - Preferred ISD Installation (With Vapor Flow Meter Above Shear Valve)






Figure 5. Example Pressure Sensor Install In Horizontal Access Fitting Or Vapor Return Line - ISD Installation (With Vapor Flow Meter Below Shear Valve)




Figure 6. Example Pressure Sensor Install Below Vertical Access Fitting Or Vapor Return Line - ISD Installation (With Vapor Flow Meter Below Shear Valve)




Figure 7. Field wiring Pressure Sensor - Observe Polarity

**Instructions:**

NOTE: When temperature is below 50°F (10°C), keep resin in a warm place prior to mixing (e.g., in an inside pocket next to body).

1. Open epoxy sealant package, and remove resin pak.
2. Holding resin pak as shown in A, bend pak along long length.
3. As shown in B, firmly squeeze the RED SIDE of the resin, forcing it through the center seal and into BLACK SIDE.
4. Mix thoroughly to a uniform color by squeezing contents back and forth 25-30 times.
5. Squeeze mixed, warm resin into one end of bag and cutoff other end.
6. Slowly insert wiring connections into sealing pack until they fit snugly against the opposite end as shown in C.
7. Twist open end of bag and use tie wrap to close it off and position the tie wrapped end up until the resin jells.

**CAUTION:** Epoxy sealant is irritating to eyes, respiratory system, and skin. Can cause allergic skin reaction. Contains: epoxy resin and Cycloaliphatic epoxy-carboxylate.

**Precautions:** Wear suitable protective clothing, gloves, eye, and face protection. Use only in well ventilated areas. Wash thoroughly before eating, drinking, or smoking.

**NOTE: Not required for wireless installations!**

Figure 8. Epoxy sealing field wiring




Figure 9. Connecting Pressure Sensor to TLS-3XX Smart Sensor Interface Module

## Vapor Vent Stack Installation Step

1. Before installing this device, perform all required safety procedures to gain access inside the vapor vent stack.
2. Determine which vapor vent stack line is closest to the tank being monitored. Select this line for the addition of the pressure sensor.

**CAUTION: Installation of the pressure sensor on the vapor vent stack is only allowed at facilities equipped with a “Veeder-Root Vapor Polisher” or “Franklin Fueling System Healy Clean Air Separator.”**

3. Locate a suitable port in an existing Schedule 40 piping fitting (tee, cross, etc.) or plumb a suitable Schedule 40 pipe fitting (tee, cross, etc.) into the vapor vent stack line (maximum length of copper tubing limited by dimension in Figure 10).
4. Install the pressure sensor (item 1 in Table 2) vertically onto the center of the composite panel (item 3 in Table 2) using a 2-inch conduit clamp, rubber shim, and necessary bolts, nuts, and washers included in the kit. Be sure the top symbol on the panel is facing upwards (see Figure 11). Wrap the rubber shim (item 22 in Table 2) around the sensor before inserting it into the clamp. Also make sure the sensor cable outlet is facing up

and the pressure sensing port tube in the base of the sensor is facing down. Locate the pressure sensor in the clamp, but leave the conduit clamp screw somewhat loose for later sensor height adjustment.

5. Install two 169CA-4-4 male elbows (item 4 in Table 2) into each end of the 3-way calibration valve (item 11 in Table 2) as shown (see Figure 11).
6. Install one 68CA-4-4 male connector (item 5 in Table 2) into the center port of the 3-way calibration valve, and then directly attach it to the pressure sensor inlet port (see Figure 7).
7. Screw the 59CA-4 plug (item 6 in Table 2) onto the left port's male elbow (see Figure 11).
8. Install the two plastic enclosure mounting plates to the back of the enclosure. Use the four short flat-head screws included in the enclosure hardware bag.
9. Install the composite panel into the enclosure (item 2 in Table 2) such that the sensor cable outlet is facing up and the pressure sensing port tube in the base of the sensor is facing down. The top symbol on the panel should be facing upward. Use the four short screws included in the enclosure hardware bag.
10. Make sure that the white flanged porous vent (factory installed - item 17 in Table 2) is still securely installed into the hole in the bottom of the enclosure (see Figure 11).
11. Insert the S-bend 1/4" OD copper tube (item 9 in Table 2) into the right-side male elbow of the 3-way calibration valve, but do not fully tighten the compression nut (see Figure 11).
12. Locate the 62CABH-4 bulkhead union (item 7 in Table 2) and remove the compression nut and the adjustable nut then place a large washer (item 8 in Table 2) against the fixed, integral body nut. Slide the compression nut that was removed onto the bottom portion of the S-bend tube.
13. Partially insert the bulkhead union into the bottom center hole in the enclosure. Slide a large washer over the body, and thread the adjustable nut back onto the body.
14. Insert the bottom portion of the S-bend tube into the bulkhead union and fully tighten the bulkhead union adjustable nut against the large washer and enclosure wall. Adjust the pressure sensor vertically in the shim / conduit clamp to make sure the S-bend tube is fully inserted into the union and male elbow.
15. Fully tighten the compression nuts to connect the S-bend tube to the union and to the male elbow. Tighten the sensor conduit clamp screw to secure the sensor in its final vertical position (see Figure 11).
16. Mount the plastic enclosure onto the vapor vent stack or suitable rigid structure ABOVE the vapor vent stack port using two conduit clamps (for 2" or 3" pipe), bolts, nuts, and washers included, or use other customer supplied suitable mounting hardware (Example: Unistrut®). Leave the mounting hardware somewhat loose for later enclosure height adjustment (see Figure 10).
17. Measure, fabricate, and install customer supplied pipe and pipe fittings between the vapor vent stack port and within a few inches of the bulkhead union in the bottom of the enclosure.
18. Install one 68CA-4-4 male connector (item 5 in Table 2) onto the top of the new pipe (see View A-A, Figure 10).
19. Measure, fabricate, and install 1/4" OD copper tubing (item 10 in Table 2) between the bulkhead union and the male connector. Adjust the enclosure vertically on vent pipe to make sure the copper tube is fully inserted into the bulk head union and male connector.
20. Fully tighten the compression nuts to secure the fabricated tube to the bulkhead union and to the male connector. Tighten the enclosure mounting hardware to secure the enclosure in its final vertical position.

Note: **Important!** All plumbing's pitch to drain should be 1/4" vertical per 12" horizontal to eliminate any potential liquid traps.




Figure 10. Locating Pressure Sensor Enclosure in Vapor Vent Stack




Figure 11. Mounting Pressure Sensor Assembly onto Composite Panel

21. Make sure the valve's handle is set to connect the sensor to the vapor vent stack and not to the capped (ambient) port.
22. Install two tamper-resistant screws from the enclosure hardware bag into the two holes on the enclosure door (if not already installed) using a Torx bit for tamper-resistant screws. Discard any remaining items in the enclosure hardware bag.
23. When direct wiring to a TLS console, install 1/2" electrical conduit from the conduit hub in the bottom of the enclosure to the customer supplied weather-proof junction box (see Figure 10). For wireless installations, using the TLS RF, Steps 23 - 27 are not required.
24. Route the cable from the pressure sensor to the junction box under the enclosure. Observing polarity, connect the sensor wiring to the field wiring from console and cap with wire nuts (see Figure 10).
25. Seal wire nuts in epoxy sealant following the instructions in Figure 8.
26. Push the epoxy sealed bag into the junction box. Replace and tighten the junction box cover.

27. Terminate field wiring into TLS Console and connect to Smart Sensor Module (TLS console - Figure 9). Note: observe polarity! The cable length between the console and sensor must not exceed the distance stated in the TLS-3XX Site Prep manual (P/N 576013-879).

Note: Intrinsically safe devices must be installed in accordance with Article 504 of the National Electrical Code, ANSI/NFPA 70, for installation in the United States, or Section 18 of the Canadian Electrical Code for installations in Canada.

This intrinsically safe Pressure Sensor (P/N 331946-001), has only been evaluated for connection to a UL listed TLS-3XX Liquid Level Gauge / Leak Detector.

Conductors of different intrinsically safe circuits run in the same cable/conduit must have at least 0.01 inch (0.25 mm) of insulation.

28. After the Pressure Sensor is installed, pressurize the tank ullage space and vapor piping to at least 2 inches WC and test for leaks using leak detection solution.
29. Close the enclosure door and secure by threading the tamper-resistant screws into the enclosure body using a Torx bit for tamper-resistant screws.
30. Affix the eVRgreen label (item 30 in Table 2) to the enclosure door as desired.





# Carbon Canister Vapor Polisher

## Installation and Maintenance Guide



# Notice

---

Veeder-Root makes no warranty of any kind with regard to this publication, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Veeder-Root shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this publication.

Veeder-Root reserves the right to change system options or features, or the information contained in this publication as approved by ARB.

This publication contains proprietary information which is protected by copyright. All rights reserved. No part of this publication may be modified or translated to another language without the prior written consent of Veeder-Root. Contact TLS Systems Technical Support for additional troubleshooting information at 800-323-1799.

## **DAMAGE CLAIMS / LOST EQUIPMENT**

Thoroughly examine all components and units as soon as they are received. If any cartons are damaged or missing, write a complete and detailed description of the damage or shortage on the face of the freight bill. The carrier's agent must verify the inspection and sign the description. Refuse only the damaged product, not the entire shipment.

Veeder-Root must be notified of any damages and/or shortages within 30 days of receipt of the shipment, as stated in our Terms and Conditions.

## **VEEDER-ROOT'S PREFERRED CARRIER**

1. Contact Veeder-Root Customer Service at 800-873-3313 with the specific part numbers and quantities that were missing or received damaged.
2. Fax signed Bill of Lading (BOL) to Veeder-Root Customer Service at 800-234-5350.
3. Veeder-Root will file the claim with the carrier and replace the damaged/missing product at no charge to the customer. Customer Service will work with production facility to have the replacement product shipped as soon as possible.

## **CUSTOMER'S PREFERRED CARRIER**

1. It is the customer's responsibility to file a claim with their carrier.
2. Customer may submit a replacement purchase order. Customer is responsible for all charges and freight associated with replacement order. Customer Service will work with production facility to have the replacement product shipped as soon as possible.
3. If "lost" equipment is delivered at a later date and is not needed, Veeder-Root will allow a Return to Stock without a restocking fee.
4. Veeder-Root will NOT be responsible for any compensation when a customer chooses their own carrier.

## **RETURN SHIPPING**

For the parts return procedure, please follow the appropriate instructions in the "General Returned Goods Policy" pages in the "Policies and Literature" section of the Veeder-Root **North American Environmental Products** price list. Veeder-Root will not accept any return product without a Return Goods Authorization (RGA) number clearly printed on the outside of the package.

## **FOR INSTALLATIONS IN THE STATE OF CALIFORNIA**

Please refer to the California Air Resources Board Vapor Recovery Certification Phase II EVR Executive Order web site ([www.arb.ca.gov/vapor/eo-evrphaseII.htm](http://www.arb.ca.gov/vapor/eo-evrphaseII.htm)) for the latest manual revisions pertaining to Executive Order VR 203 (VST Phase II EVR System) and VR 204 (VST Phase II EVR System Including ISD System).

**Introduction**

- Contractor Certification Requirements ..... 1
- Related Documents ..... 1
- Safety Precautions ..... 2
- Before You Begin ..... 4
- Veeder-Root Parts ..... 5

**Standard Vent Stack Installation Procedure ..... 6**

**Alternate Vent Stack Installations**

- Alternate Vent Stack Installations ..... 13
- Offset Mount Installations ..... 14
- Flat Mounting..... 14

**Test Port Installation**

- Standard Installation Procedure ..... 17
- Alternate Lowering of the Upper Test Port ..... 17

**Maintenance**

- Sensor Housing Kit (P/N 330020-644) ..... 18
- Filter Kit (P/N 330020-645) ..... 19
- Valve Enclosure Assembly Kit (P/N 330020-643) ..... 20
- Thermal Probe Kit (P/N 330020-653) ..... 22

## Figures

- Figure 1. Typical direct wired installation example ..... 7
- Figure 2. Installing CCVP onto bracket ..... 8
- Figure 3. Inlet plumbing detail and classified area definition ..... 9
- Figure 4. Locating the CCVP vapor valve connector..... 10
- Figure 5. Field wiring CCVP vapor valve - direct-wired CCVP only ..... 10
- Figure 6. Epoxy sealing CCVP vapor valve field wiring connections - direct-wired CCVP only ..... 11
- Figure 7. Attaching CCVP vapor valve wiring to TLS-350 console - direct-wired CCVP only ..... 11
- Figure 8. Through canopy w/extended plumbing ..... 13
- Figure 9. Vent stack mounting..... 13
- Figure 10. Offset mount on a 2" or 3" pipe ..... 15
- Figure 11. Offset mount on a supported riser..... 16
- Figure 12. Optional lowering of upper test port ..... 17
- Figure 13. Removing sensor housing assembly..... 18
- Figure 14. Replacing sensor housing assembly..... 18
- Figure 15. Accessing the valve filter and o-ring..... 19
- Figure 16. Replacing the valve filter and o-ring ..... 19
- Figure 17. Removing vapor valve assembly..... 20
- Figure 18. Replacing vapor valve assembly..... 21
- Figure 19. CCVP thermal probe ..... 22
- Figure 20. Preparing the thermal probe cable for the protective boot ..... 23
- Figure 21. Positioning the tie wrap over the probe cable's protective boot ..... 23

## Tables

|          |                                   |   |
|----------|-----------------------------------|---|
| Table 1. | CCVP 2" Installation Kit .....    | 5 |
| Table 2. | CCVP 3" Installation Kit .....    | 5 |
| Table 3. | CCVP Replacement Parts Kits ..... | 5 |

## Introduction

This manual contains instructions to install a Veeder-Root Carbon Canister Vapor Polisher (CCVP) into a gasoline tank vent pipe.

### Contractor Certification Requirements

| Veeder-Root Contractor Certification Requirements  | Installer Certification <sup>6</sup> | ATG Technician Certification <sup>7</sup>   | VR Vapor Products Certification <sup>8</sup> |
|--|--------------------------------------|---|--|
| Install <sup>1</sup> ISD   | X                                    | X   | X  |
| Install PMC  | X                                    | X   | X  |
| Install CCVP   | X                                    | X   | X  |
| Install Wireless ISD/PMC   | X                                    | X   | X  |
| Installation Checkout <sup>2</sup>   |                                      | X   | X  |
| ATG Startup <sup>3</sup> / Training <sup>4</sup> / Service <sup>5</sup>  |                                      | X   | X  |
| ISD Startup / Training / Service   |                                      |   | X  |
| PMC Startup / Training / Service   |                                      |   | X  |
| CCVP Startup / Training / Service  |                                      |   | X  |
| Wireless ISD/PMC Startup / Training / Service  |                                      |   | X  |
| Install Pressure Sensor (ATG)  | X                                    | X   | X  |
| Maintain Pressure Sensor (ATG)   |                                      | X   | X  |
| Calibrate Pressure Sensor (ATG)  |                                      | X   | X  |
| Clear ATG Pressure Sensor Alarm (ATG)  |                                      | X   | X  |
| Clear ISD/PMC Alarms (ISD/PMC)   |                                      |   | X  |
| <sup>1</sup> Perform wiring and conduit routing; equipment mounting<br><sup>2</sup> Inspect wiring and conduit routing; equipment mounting<br><sup>3</sup> Turn power on, program and test the systems<br><sup>4</sup> Provide supervised field experience in service techniques and operations<br><sup>5</sup> Troubleshoot and provide routing maintenance |                                      | <sup>6</sup> UST Monitoring Systems – Installer (Level 1)<br><sup>7</sup> Certified UST Monitoring Technician<br><sup>8</sup> VR Vapor Products |  |











**Warranty Registrations** may only be submitted by selected Distributors. Certified installers are required to provide the GDF operator with the completed Equipment Warranty Notice, form 577013-868, for their records.

### Related Documents

- 576013-879 TLS-3XX Series Consoles Site Prep Manual
- 577013-949 In-Station Diagnostics Install, Setup & Operation Manual
- 577013-948 Pressure Management Control Install, Setup and Operation Manual
- 576013-858 Direct Burial Cable Installation Guide
- 577013-964 TLS RF Wireless 2 System (W2) Installation Manual
- 331940-012 TLS RF System Control Drawing

## Safety Precautions

The following safety symbols may be used throughout this manual to alert you to important safety hazards and precautions.

|  |  |
|--|--|
|  <p><b>EXPLOSIVE</b><br/>Fuels and their vapors are extremely explosive if ignited.</p>   |  <p><b>FLAMMABLE</b><br/>Fuels and their vapors are extremely flammable.</p>  |
|  <p><b>ELECTRICITY</b><br/>High voltage exists in, and is supplied to, the device. A potential shock hazard exists.</p>   |  <p><b>TURN POWER OFF</b><br/>Live power to a device creates a potential shock hazard. Turn Off power to the device and associated accessories when servicing the unit.</p>                           |
|  <p><b>READ ALL RELATED MANUALS</b><br/>Knowledge of all related procedures before you begin work is important. Read and understand all manuals thoroughly. If you do not understand a procedure, ask someone who does.</p> |  <p><b>USE SAFETY BARRICADES</b><br/>Unauthorized people or vehicles in the work area are dangerous. Always use safety cones or barricades, safety tape, and your vehicle to block the work area.</p> |
|  <p><b>WARNING</b><br/>Heed the adjacent instructions to avoid damage to equipment, property, environment or personal injury.</p>  |  <p><b>WEAR EYE PROTECTION</b><br/>Wear eye protection when working with pressurized fuel lines or epoxy sealant to avoid possible eye injury.</p>   |
|  <p><b>INJURY</b><br/>Careless or improper handling of materials can result in bodily injury.</p>   |  <p><b>GLOVES</b><br/>Wear gloves to protect hands from irritation or injury.</p>   |

**! WARNING**

This product is to be installed and operated in the highly combustible environment of a gasoline station where flammable liquids and explosive vapors may be present.

**ATTEMPTING TO SERVICE TANK MONITORS AND EQUIPMENT WITHOUT PROPER TRAINING CAN CAUSE DAMAGE TO PROPERTY, ENVIRONMENT, RESULTING IN PERSONAL INJURY OR DEATH.**

The following hazards exist:

1. Electrical shock resulting in serious injury or death may result if power is on during installation and the device is improperly installed.
2. Product leakage could cause severe environmental damage or explosion resulting in death, serious personal injury, property loss and equipment damage.

Observe the following precautions:

1. Read and follow all instructions in this manual, including all safety warnings.
2. Comply with all applicable codes including: the National Electrical Code; federal, state, and local codes; and other applicable safety codes.
3. Before installing this device, turn Off, tag/lock out power to the system, including console and submersible pumps.
4. To protect yourself and others from being struck by vehicles, block off your work area during installation or service.
5. Substitution of components may impair intrinsic safety.



---

## Before You Begin

---

- Comply with all recommended safety practices identified by OSHA (Occupational Safety and Health Administration) and your employer.
- The canister can only be installed in systems with a vapor recovery vent stack fitted with a UL Listed pressure/vacuum (P/V) valve that complies with California Air Resources Board (CARB) requirements and operates between -8 and +6 inches water column. The outlet of the carbon canister vapor valve has the same classified area requirements as the P/V valve per figure 3 and is subject to approval by the local authority having jurisdiction.
- Where separate intrinsically safe circuits are installed in the same raceway they must be segregated in accordance with Article 504 of the NEC.
- Review and comply with all the safety warnings in the installation manuals and any other national, state or local requirements.
- Consult figure 4 along with the National Electrical Code and the compliance section of 576013-879 TLS-3XX Series Consoles Site Prep Manual before installing the CCVP into the hazardous location. If the Carbon Canister is being wired directly to a TLS console, a 2-conductor, 18 AWG shielded cable must be installed in intrinsically safe conduit from the intrinsically safe wiring compartment of the TLS console to the carbon canister. Use of direct burial cable may be subject approval by the local authority having jurisdiction. See manual 576013-858 for a complete listing of required materials and an overview of direct burial installations.
- Use only UL certified Gas/TFE yellow Teflon tape on all fittings. Do not use pipe dope to seal pipe threads or fittings in and out of the CCVP.
- Customer supplied vent riser and vent riser fittings shall be standard full weight (ASTM Schedule 40) wrought iron or steel.
- Vapor polisher installation kit provides either 2" tee (Form Number 861290-002) or 3" reducing tee with bushing (Form Number 861290-003) to reduce to 1/2" NPT. Customer supplied reducing tee must not reduce from 2" or 3" to less than 1/2" NPT. If tee reduces to larger than 1/2" use appropriate bushing to reduce the tee to 1/2" NPT.
- For new or rebuilt sites, it is recommended that the installation design specify a threaded fitting for joining the vent pipes to the underground piping system.
- Modification to plumbing in the inlet flow path (i.e., excessive bends) to the CCVP can result in non-compliance with local codes (ARB Exhibit 11 test) and may adversely affect performance if these installation guidelines are not followed. No liquid traps permitted.
- Vent riser threads shall be in accordance with the standard for pipe threads, general purpose (inch) ANSI/ASME B1.20.1-1983.
- The CCVP outlet shall be not less than 12 feet from grade.
- The CCVP outlet shall be located at least 15 feet from powered ventilation air intake devices.
- The CCVP must be mounted vertically.
- The structure to which the CCVP is mounted must be plumb and perpendicular to grade and independently supported and comply with all applicable codes.
- Offset piping and inlet piping to the CCVP shall be installed to avoid bends. No liquid traps permitted.
- Figures and illustrations in this manual represent typical installations and due to site variation, cannot represent all installation situations. Final installation must comply with instructions provided in this manual and all required codes per the jurisdiction having authority.

## Veeder-Root Parts

---

- Veeder-Root Carbon Canister Vapor Polisher, Form No. 861290-002.

**Table 1. CCVP 2" Installation Kit**

| Item | Qty. | Description                      | P/N        |
|------|------|----------------------------------|------------|
| 1    | 1    | Carbon Canister                  | 332761-002 |
| 2    | 1    | Inlet Piping Kit                 | 330020-638 |
| 3    | 1    | 2" Mounting Bracket Kit          | 330020-647 |
| 4    | 1    | Group - 2" Pipe and Reducing Tee | 332954-002 |
| 5    | 1    | CCVP Installation Instructions   | 577013-920 |

- Veeder-Root Carbon Canister Vapor Polisher, Form No. 861290-003.

**Table 2. CCVP 3" Installation Kit**


| Item | Qty. | Description                             | P/N        |
|------|------|---|------------|
| 1    | 1    | Carbon Canister                         | 332761-002 |
| 2    | 1    | Inlet Piping Kit                        | 330020-638 |
| 3    | 1    | 3" Mounting Bracket Kit                 | 330020-648 |
| 4    | 1    | Group - 3" Pipe, Reducing Tee & Bushing | 332954-003 |
| 5    | 1    | CCVP Installation Instructions          | 577013-920 |

- Veeder-Root CCVP replacement parts kits. Note: Replacement part kits are not included with new canister assemblies and must be ordered separately, as needed. See the maintenance section of this manual for details.

**Table 3. CCVP Replacement Parts Kits**

| Item | Qty. | Description                  | P/N        |
|------|------|------------------------------|------------|
| 1    | 1    | Valve Enclosure Assembly Kit | 330020-643 |
| 2    | 1    | Sensor Housing Kit           | 330020-644 |
| 3    | 1    | Filter Kit                   | 330020-645 |
| 4    | 1    | Temperature Probe Kit        | 330020-653 |

## Standard Vent Stack Installation Procedure

1. This procedure requires Veeder-Root installation kits and parts. When using customer provided parts refer also to the alternate vent stack installation procedures.
2. The TLS-3XX Site Prep Manual, P/N 576013-879, must be consulted for the proper installation of a direct-wired carbon canister into hazardous locations. The TLS RF Wireless 2 System (W2) Installation Manual (P/N 577013-964) and document 331940-012, must be consulted for the proper installation of a wireless carbon canister into hazardous locations.
3. During the installation, all required national, state and local safety codes must be followed.
4. The CCVP contains an integral vapor valve that operates in conjunction with the pressure/vacuum (P/V) vent. Location of the vapor valve outlet must conform to the same requirements as the P/V vent. Reference Article 514 of the National Electrical code (NEC) and NFPA 30/30A.
5. Do not install the CCVP on unsupported vent pipes. For all customer supplied supports or strut assemblies, wind loading must comply with all required local, state and national codes and shall be rated for 88 pounds (minimum) static load.
6.  **IMPORTANT! To ensure that the canister outlet is 12 feet (minimum) above grade, the CCVP mounting bracket must be positioned according to dimensions shown in Figure 1 and the U-bolts tightly clamped to the support structure before mounting the canister. The mounting bracket must be centered in line with the outlet of the tee before installing the CCVP.**
7. Following all required national, state, local and site safety precautions, carefully hang the CCVP's notched support tabs onto the top two side studs of its mounting bracket (Step 1 in Figure 2), swing the canister down until all of the slots in the canister's side mounting tabs seat against the studs in the bracket (Step 2 in Figure 2), then tighten the six side nuts to secure the canister onto its bracket (Step 3 in Figure 2).
8. Figure 3 shows important Class I Div 1, Group D and Class I Div 2, Group D radius spheres and operability test valve handle positions of the installed canister.
9. For installations using the TLS RF Wireless System, skip to Step 15. For installations using a direct-wired CCVP, go to Step 10.
10. Install weather tight junction box, seal off and conduit per all NEC, state and local codes (see example installation in Figure 1).
11. Connect the two-pin connector of the 6-foot cable provided in the installation kit to the CCVP vapor valve, observing plug polarities (see Figure 4). The other end of this cable is passed through a kit supplied cord grip in the upper junction box.
12. Connect the white wire of the two conductor cable from the vapor valve to the positive sensor wire from the TLS console smart sensor interface module (see Figure 5). Connect the black wire on the two conductor cable to the negative sensor wire from the TLS console smart sensor interface module.
13. Following the instructions in Figure 6, seal the wire nuts of each of the two cable connections in the epoxy pack provided.
14. Attach CCVP vapor valve field wiring to the smart sensor interface module in the TLS console as shown in Figure 7.
15. Connect all lower fittings, valve and tubing between the vent pipe and the lower manifold on the CCVP (see Figure 3).
16. See the Test Port Installation section to install a test port for the Exhibit 12 test.
17. Confirm ball valve is in the open, canister to vent stack position (per Figure 3), then insert the clevis pin and secure with the hitch pin.
18. A passing pressure decay test, in accordance with CARB TP-201.3, must be completed after the CCVP is installed (see Exhibit 4 of VR 203 / VR 204).
19. A passing operability test must be completed in accordance with the procedures defined in VR 203 / VR 204 Exhibit 11 & 12.




Figure 1. Typical direct wired installation example




Figure 2. Installing CCVP onto bracket




Figure 3. Inlet plumbing detail and classified area definition




Figure 4. Locating the CCVP vapor valve connector




Figure 5. Field wiring CCVP vapor valve - direct-wired CCVP only

### A

### B

### C

Make sure that the ends of the cable sheathing are submerged in sealant

Tie wrap

Wire nuts

**INSTRUCTIONS:**

NOTE: When temperature is below 50°F (10°C), keep resin in a warm place prior to mixing (e.g., in an inside pocket next to body).

1. Open epoxy sealant package, and remove resin pak.
2. Holding resin pak as shown in A, bend pak along long length.
3. As shown in B, firmly squeeze the RED SIDE of the resin, forcing it through the center seal and into BLACK SIDE.
4. Mix thoroughly to a uniform color by squeezing contents back and forth 25-30 times.
5. Squeeze mixed, warm resin into one end of bag and cutoff other end.
6. Slowly insert wiring connections into sealing pack until they fit snugly against the opposite end as shown in C.
7. Twist open end of bag and use tie wrap to close it off and position the tie wrapped end up until the resin jells.

**CAUTION:** Epoxy sealant is irritating to eyes, respiratory system, and skin. Can cause allergic skin reaction. Contains: epoxy resin and Cycloaliphatic epoxy-carboxylate.

**Precautions:** Wear suitable protective clothing, gloves, eye, and face protection. Use only in well ventilated areas. Wash thoroughly before eating, drinking, or smoking.

920-10.eps

Figure 6. Epoxy sealing CCVP vapor valve field wiring connections - direct-wired CCVP only




Figure 7. Attaching CCVP vapor valve wiring to TLS-350 console - direct-wired CCVP only



## Alternate Vent Stack Installations



### IMPORTANT!

When a canister is not installed directly to a vent pipe, it is the responsibility of the site owner(s) to:

1. Provide suitably rated mounting locations designed for 88 pounds (minimum) static load.
2. Provide adequate wind loading per all applicable local codes.
3. Follow all recommendations providing an unrestricted flow path into the canister that is free of liquid traps and minimizes the number of bends and turns in the piping. Any departure from the specified installation procedures, must conform to all local code requirements per the jurisdiction having authority.
4. All standard vent stack installation procedures and applicable codes, etc., apply.

Additional requirements are as follows:

- CCVP outlet shall be located not less than 5 feet above the canopy, see NFPA 30: 2008, clause 5.6.3.
- The total length of the tubing (installed horizontally and vertically) between the 3-way valve and the CCVP can not exceed 12 feet. Horizontal lengths shall have a minimum slope of 1/8-inch per foot back to the 3-way valve to drain.
- The horizontal length of tubing between the vent stack and the 3-way valve must not exceed 15 inches. If a horizontal length of more than 15 inches is required, follow the offset riser mounting installation procedures. No liquid traps permitted.
- Customer can supply the following inlet piping materials:
  - 5/8" O.D. x 0.065 wall thickness hard temper copper tubing. Alternatively, customer supplied standard full weight (ASTM Schedule 40) wrought iron or steel pipe (1/2" I.D. minimum) can be substituted subject to applicable codes.
  - ASTM Schedule 40 wrought iron or steel, 2" or 3" vent riser pipe and pipe fittings
- Vapor Polisher installation kit provides either 2" tee (Form Number 861290-002) or 3" reducing tee with bushing (Form Number 861290-003) to reduce to 1/2" NPT. Customer supplied reducing tee must not reduce from 2" or 3" to less than 1/2" NPT. If tee reduces to larger than 1/2" use appropriate bushing to reduce the tee to 1/2" NPT.
- 3-way valve from the inlet piping kit must be used.

Follow the standard installation procedures when installing vapor polishers in configurations similar those in Figure 8 and Figure 9. All installations of this type must comply with NFPA 30/30A and NFPA 70 and are subject to the approval of the local authority having jurisdiction.

### Alternate Vent Stack Installations




Figure 8. Through canopy w/extended plumbing




Figure 9. Vent stack mounting

---

## Offset Mount Installations

---

An offset mount is any installation where the CCVP is not mounted on the P/V vent stack. The CCVP can be mounted to a flat surface, or installed on an offset riser, that is plumbed to the vent stack (see Figure 10 and Figure 11).

The horizontal length of standard inlet piping between the vent stack and the 3-way valve must not exceed 15 inches. If a horizontal length of more than 15 inches is required, use 2-inch minimum pipe. No liquid traps permitted.

The manifold pipe between the vent riser and canister must not exceed 100 feet in length and must be at least 2-inch schedule 40 pipe with no liquid traps present and slope 1/8-inch per foot back to the vent riser to drain. To prevent the CCVP inlet piping from supporting the offset piping weight, provide additional support as required. Offset piping must be capped and comply with applicable local codes.

Flexible connections may be required by local jurisdiction having authority when offset mounting.

Flexible connections between the CCVP's offset piping and the vent riser are allowable if required by the local authority having jurisdiction to meet seismic requirements.

- Should the flex connection be installed such that it is not supported, the slope of the flex connection from the CCVP back to the vent riser shall be greater than the 1/8-inch per foot slope required for the rest of the piping.
- The flexible connector must be UL approved for a service station above-ground application.
- The local contractor is responsible to provide all necessary schedule 40 piping, pipe fittings and pipe cap.
- The Hazardous Location Area Classification shown for the CCVP in Figure 3 must be considered from the point of origin for all offset mountings.

## FLAT MOUNTING

1. The bracket in the installation kit must be used.
2. The mounting point must comply with all applicable codes.
3. The mounting method must be sufficiently rated for 88 pounds as per applicable building codes.
4. If bolting the mounting bracket to the mounting surface, use a minimum of 4 bolts.




Figure 10. Offset mount on a 2" or 3" pipe




Figure 11. Offset mount on a supported riser

## Test Port Installation

### Standard Installation Procedure

1. Remove 1/4-inch plug from upper manifold.
2. Install customer supplied schedule 40, 1/4-inch male-to-male with 90 degree elbow NPT fitting by applying Teflon™ tape to the threads and tighten 1/4 turn past snug.
3. Install the outlet test port cap by applying Teflon™ tape to the threads and tighten the cap 1/4 turn past snug.
4. Perform the CCVP integrity test (VR-203 & VR-204 Exhibit 11).

### Alternate Lowering of the Upper Test Port

In some installations it may be desirable to have the upper test port more accessible. The steps below describe this procedure.

1. Refer to Figure 12 to install optional piping necessary to lower the CCVP's operability (upper) test port.
2. Use schedule 40, 1/4-inch pipe and pipe fittings (customer supplied) - install per all applicable codes.
3. Perform the CCVP integrity test (VR-203 & VR-204 Exhibit 11).




Figure 12. Optional lowering of upper test port

## Maintenance

### Sensor Housing Kit (P/N 330020-644)

1. Remove the three #25 torx screws holding the sensor housing assembly to the vapor valve assembly (see Figure 13).
2. Pull the sensor housing assembly straight out (unplugging it).
3. Align the replacement sensor housing assembly's connector with the connector in the vapor valve assembly and push in the assembly until it seats against the vapor valve assembly (see Figure 14).
4. Replace the three #25 torx screws in the sensor housing assembly cover until tight.




Figure 13. Removing sensor housing assembly




Figure 14. Replacing sensor housing assembly

## Filter Kit (P/N 330020-645)

1. Remove the four 1/4-20 x 1 inch hex key bolts from the top of the vapor valve filter housing (see Figure 15).
2. Swing the housing top back and remove the filter plate from its seat and the o-ring from its groove in the vapor valve filter housing's lower half (see Figure 16).
3. Install a new o-ring in the groove and insert a new filter plate into its seat in the lower half of the housing, close the cover and screw in the four 1/4-20 hex key bolts until tight.
4. Perform the CCVP integrity and flow test (VR-203 & VR-204 Exhibit 11).




Figure 15. Accessing the valve filter and o-ring




Figure 16. Replacing the valve filter and o-ring



## Valve Enclosure Assembly Kit (P/N 330020-643)




Figure 17. Removing vapor valve assembly

1. Remove the cables from the two connectors on the rear of the vapor valve assembly.
2. Remove the four 1/4-20 x 1 inch hex key bolts from the top of the vapor valve filter housing (see Figure 17).
3. Remove the hitch clip from the long clevis pin in the front hinge of the vapor valve assembly and vapor valve filter housing (see Figure 18).
4. Push the long clevis pin out and free of the hinge bores and lift up the vapor valve assembly. Be careful not to damage the filter in the vapor valve filter housing.
5. Place the new vapor valve assembly onto the vapor valve filter housing and push the long clevis pin through the hinge bores. Insert the hitch pin in the hole in the end of the clevis pin.
6. Screw in the four 1/4-20 hex key bolts until tight.
7. Reconnect the two cables to the two connectors on the vapor valve assembly.
8. Perform the CCVP integrity and flow test (VR-203 & VR-204 Exhibit 11).




Figure 18. Replacing vapor valve assembly

## Thermal Probe Kit (P/N 330020-653)




Figure 19. CCVP thermal probe

1. Cut the tie wrap around the thermal probe's protective boot and remove and set aside the boot. Remove the thermal probe cable connector from the back of the vapor valve assembly (see Figure 19).
2. Using a 9/16-inch open-end wrench, remove the thermal probe from the top of the CCVP.
3. Install and tighten the replacement thermal probe into its port in top of the CCVP.
4. Route the thermal probe connector cable through the opening in the top of the CCVP as shown in the above figure and attach the cable connector to the top port on the rear of the vapor valve assembly.
5. Make a small bend in the thermal probe cable no more than one inch above the probe hex nut (see Figure 20).
6. Slide the boot over the bend of the cable and push it down over the probe's hex nut until it rests on the top of the CCVP. Get a tie wrap from the kit and position it around the end of the boot just under the probe's hex nut and tighten it (see Figure 21).
7. Perform the CCVP integrity and flow test (VR-203 & VR-204 Exhibit 11).




Figure 20. Preparing the thermal probe cable for the protective boot





Figure 21. Positioning the tie wrap over the probe cable's protective boot



# Pressure Management Control

## Install, Setup, & Operation Manual

*For Veeder-Root Vapor Polishers*



# Notice

---

Veeder-Root makes no warranty of any kind with regard to this publication, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Veeder-Root shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this publication.

Veeder-Root reserves the right to change system options or features, or the information contained in this publication as approved by ARB.

This publication contains proprietary information which is protected by copyright. All rights reserved. No part of this publication may be modified or translated to another language without the prior written consent of Veeder-Root. Contact TLS Systems Technical Support for additional troubleshooting information at 800-323-1799.

## **DAMAGE CLAIMS / LOST EQUIPMENT**

Thoroughly examine all components and units as soon as they are received. If any cartons are damaged or missing, write a complete and detailed description of the damage or shortage on the face of the freight bill. The carrier's agent must verify the inspection and sign the description. Refuse only the damaged product, not the entire shipment.

Veeder-Root must be notified of any damages and/or shortages within 30 days of receipt of the shipment, as stated in our Terms and Conditions.

## **VEEDER-ROOT'S PREFERRED CARRIER**

1. Contact Veeder-Root Customer Service at 800-873-3313 with the specific part numbers and quantities that were missing or received damaged.
2. Fax signed Bill of Lading (BOL) to Veeder-Root Customer Service at 800-234-5350.
3. Veeder-Root will file the claim with the carrier and replace the damaged/missing product at no charge to the customer. Customer Service will work with production facility to have the replacement product shipped as soon as possible.

## **CUSTOMER'S PREFERRED CARRIER**

1. It is the customer's responsibility to file a claim with their carrier.
2. Customer may submit a replacement purchase order. Customer is responsible for all charges and freight associated with replacement order. Customer Service will work with production facility to have the replacement product shipped as soon as possible.
3. If "lost" equipment is delivered at a later date and is not needed, Veeder-Root will allow a Return to Stock without a restocking fee.
4. Veeder-Root will NOT be responsible for any compensation when a customer chooses their own carrier.

## **RETURN SHIPPING**

For the parts return procedure, please follow the appropriate instructions in the "General Returned Goods Policy" pages in the "Policies and Literature" section of the Veeder-Root **North American Environmental Products** price list. Veeder-Root will not accept any return product without a Return Goods Authorization (RGA) number clearly printed on the outside of the package.

## **WARRANTY**

**Please see next page.**

©Veeder-Root 2012. All rights reserved.

# Warranty

---

This warranty applies only when the product is installed in accordance with Veeder-Root's specifications by Veeder-Root certified installers. This warranty will not apply to any product which has been subjected to misuse, negligence, accidents, systems that are misapplied or are not installed per Veeder-Root specifications, modified or repaired by unauthorized persons, or damage related to acts of God. Veeder-Root is not liable for incidental, consequential, or indirect damages or loss, including, without limitation, personal injury, death, property damage, environmental damages, cost of labor, clean-up, downtime, installation and removal, product damages, loss of product, or loss of revenue or profits. This warranty applies to the initial purchaser and any subsequent purchaser for the duration of the warranty period. **THE WARRANTY CONTAINED HEREIN IS EXCLUSIVE AND THERE ARE NO OTHER EXPRESS, IMPLIED, OR STATUTORY WARRANTIES. WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY EXCLUDED.**

## **TLS-350R, TLS-350 PLUS, TLS-350J AND TLS-300I/C, AND TLS2 MONITORING SYSTEMS**

We warrant that this product shall be free from defects in material and workmanship and is compliant with all applicable performance standards and specifications for which it has been certified, for a period of one (1) year from the date of installation when proof of date of installation is provided or twenty-four (24 months) from the date of manufacture when proof of date of installation is not provided. During the warranty period, we or our representative will repair or replace the product, if determined by us to be defective, at the location where the product is in use and at no charge to the purchaser. **LAMPS, FUSES, AND LITHIUM BATTERIES ARE NOT COVERED UNDER THIS WARRANTY.**

If "Warranty" is purchased as part of the Fuel Management Service, Veeder-Root will maintain the equipment for the life of the contract in accordance with the written warranty provided with the equipment. A Veeder-Root Fuel Management Services Contractor shall have free site access during Customer's regular working hours to work on the equipment. Veeder-Root has no obligation to monitor federal, state or local laws, or modify the equipment based on developments or changes in such laws.

## **CARBON CANISTER VAPOR POLISHER**

We warrant that this product shall be free from defects in material and workmanship and is compliant with all applicable performance standards and specifications for which it has been certified, for a period of one (1) year from the date of installation when proof of the date of installation is provided or twenty-four (24 months) from the date of manufacture when proof of date of installation is not provided. We will repair or replace the product if the product is returned to us; transportation prepaid by user, within the warranty period, and is determined by us to be defective. The user must contact the Veeder-Root Customer Service for specific detailed information concerning the failed component return to ensure proper processing. **LAMPS, FUSES, AND LITHIUM BATTERIES ARE NOT COVERED UNDER THIS WARRANTY.**

## **MODULES, KITS, OTHER COMPONENTS (PARTS PURCHASED SEPARATE OF A COMPLETE CONSOLE)**

We warrant that this product shall be free from defects in material and workmanship and is compliant with all applicable performance standards and specifications for which it has been certified, for a period of one (1) year from the date of installation when proof of the date of installation is provided or fifteen (15) months from the date of manufacture when proof of date of installation is not provided. We warrant that the lithium batteries (excluding EVR BATTERY PACK) shall be free from defects in material and workmanship for a period of three (3) months from date of invoice. We will repair or replace the product if the product is returned to us; transportation prepaid by user, within the warranty period, and is determined by us to be defective. **LAMPS AND FUSES ARE NOT COVERED UNDER THIS WARRANTY.**



---

## **EVR BATTERY PACK**

We warrant that this product shall be free from defects in material and workmanship and is compliant with all applicable performance standards and specifications for which it has been certified, for a period of one (1) year from the date of installation when proof of the date of install is provided or fifteen (15) months from the date of manufacture when proof of date of installation is not provided. **The replacement EVR Battery Pack warranty period will be the REMAINING warranty period of the original EVR Battery Pack. LAMPS, FUSES, AND LITHIUM BATTERIES OTHER THAN THE EVR BATTERY PACK, ARE NOT COVERED UNDER THIS WARRANTY.**

|  |    |
|--|----|
| <b>Introduction</b>                                  |    |
| Site Requirements .....                              | 1  |
| Contractor Certification Requirements .....          | 1  |
| Related Manuals .....                                | 2  |
| Safety Precautions .....                             | 2  |
| <b>Installation</b>                                  |    |
| Vapor Pressure Sensor .....                          | 3  |
| Carbon Canister Vapor Polisher .....                 | 3  |
| Installing TLS Console Modules - General Notes ..... | 3  |
| Circuit Directory .....                              | 4  |
| Smart Sensor Interface Module .....                  | 5  |
| NVMEM203 Board .....                                 | 5  |
| <b>Setup</b>   |    |
| Introduction .....                                   | 6  |
| Smart Sensor Setup - Vapor Pressure Sensor .....     | 6  |
| Smart Sensor Setup - Vapor Polisher .....            | 7  |
| ATM Pressure Sensor Setup .....                      | 7  |
| PMC Setup .....                                      | 9  |
| <b>Operation</b>                                     |    |
| Alarms .....   | 10 |
| Overview of TLS console Interface.....               | 10 |
| Alarm Posting .....                                  | 10 |
| PMC Alarm Summary .....                              | 11 |
| Wireless Related Sensor Alarms .....                 | 11 |
| PMC Status Report .....                              | 12 |
| Viewing PMC Reports Via RS-232 Connection .....      | 12 |
| Connecting Laptop to Console .....                   | 12 |
| Connecting Laptop to Console .....                   | 13 |
| Sending Console Commands.....                        | 16 |
| <b>Diagnostics</b>                                   |    |
| Automatic Control .....                              | 22 |
| Manual control .....                                 | 22 |
| PMC Diagnostic Menus .....                           | 22 |
| <b>Troubleshooting</b>                               |    |
| PMC Setup .....                                      | 25 |
| PMC Sensor Faults .....                              | 25 |
| Wireless Related Sensor Alarms .....                 | 26 |
| VP Emission Alarm .....                              | 26 |
| Example Smart Sensor reports .....                   | 26 |
| Operability Test Procedures .....                    | 26 |

## Figures

|            |  |    |
|------------|--|----|
| Figure 1.  | TLS console Interface Module Bays .....                                | 4  |
| Figure 2.  | Smart Sensor Setup - Vapor Pressure Sensor .....                       | 6  |
| Figure 3.  | Smart Sensor Setup - Vapor Polisher .....                              | 7  |
| Figure 4.  | PMC Setup .....  | 9  |
| Figure 5.  | TLS console alarm interface .....                                      | 10 |
| Figure 6.  | TLS console alarm example .....  | 11 |
| Figure 7.  | PMC Status Report .....  | 12 |
| Figure 8.  | Connecting laptop to TLS console for serial communication .....        | 13 |
| Figure 9.  | Connection Description window .....                                    | 14 |
| Figure 10. | Connect To window .....  | 14 |
| Figure 11. | Console comm port settings printout example .....                      | 15 |
| Figure 12. | HyperTerminal main window .....  | 16 |
| Figure 13. | Vapor Valve Status Report - Serial to PC Format .....                  | 17 |
| Figure 14. | Smart Sensor Sub Alarm History Report - Serial to PC Format.....       | 18 |
| Figure 15. | Vapor Processor Status Report - Serial to PC Format .....              | 18 |
| Figure 16. | Priority Alarm History Report - Serial to PC Format .....              | 19 |
| Figure 17. | Non-Priority Alarm History Report - Serial to PC Format .....          | 20 |
| Figure 18. | Vapor Polisher Runtime Diagnostic Report - Serial to PC Format .....   | 20 |
| Figure 19. | PMC Daily Vapor Polisher Diagnostic Report - Serial to PC Format ..... | 21 |
| Figure 20. | SmartSensor Diagostic Menus .....                                      | 23 |
| Figure 21. | PMC Diagnostic Menus .....   | 24 |

## Tables

|          |  |    |
|----------|--|----|
| Table 1. | Related Manuals .....                                      | 2  |
| Table 2. | PMC Alarm Summary .....                                    | 11 |
| Table 3. | Serial Commands for PMC Diagnostic Reports .....           | 17 |
| Table 4. | Vapor Polisher Runtime Diagnostic Report Event Codes ..... | 21 |
| Table 5. | Smart Sensor Device Fault Summary .....                    | 25 |

# Introduction

This manual provides instructions to install, setup, and operate the components of Veeder-Root Pressure Management Control (PMC) equipment. The PMC feature is an option for the TLS console platform, and as such, many of the installation/setup/operation instructions for non-PMC specific tasks are covered in TLS-3XX supplied literature. Do not use this manual when PMC is installed with ISD. Use the ISD Setup & Operation Manual, VR204 Section 12.

## Site Requirements

Below are the requirements for all PMC installations:

- V-R TLS-350R/EMC w/BIR, TLS-350 Plus/EMC Enhanced, TLS-350/EMC and ProMax consoles with ECPU2 - install as per TLS-3XX Site Prep manual, setup following instructions in TLS-3XX System Setup Manual.
- A flash memory board (NVMEM203) for PMC software storage - installed on the ECPU2 board in place of the console's 1/2 Meg RAM board - install as per TLS-350 Series Board and Software Replacement Manual, no setup required.
- Vapor Pressure Sensor and Smart Sensor Module- install and connect following instructions in the Vapor Pressure Sensor Installation Guide.
- Carbon Canister Vapor Polisher - install and connect following instructions in the Carbon Canister Vapor Polisher Installation and Maintenance Guide.
- An RS-232 Port will be available for use by contractor or government inspectors.

## Contractor Certification Requirements

| Veeder-Root Contractor Certification Requirements  | Installer Certification <sup>6</sup> | ATG Technician Certification <sup>7</sup>   | VR Vapor Products Certification <sup>8</sup> |
|--|--------------------------------------|---|--|
| Install <sup>1</sup> ISD   | X                                    | X   | X  |
| Install PMC  | X                                    | X   | X  |
| Install CCVP   | X                                    | X   | X  |
| Install Wireless ISD/PMC   | X                                    | X   | X  |
| Installation Checkout <sup>2</sup>   |                                      | X   | X  |
| ATG Startup <sup>3</sup> / Training <sup>4</sup> / Service <sup>5</sup>  |                                      | X   | X  |
| ISD Startup / Training / Service   |                                      |   | X  |
| PMC Startup / Training / Service   |                                      |   | X  |
| CCVP Startup / Training / Service  |                                      |   | X  |
| Wireless ISD/PMC Startup / Training / Service  |                                      |   | X  |
| Install Pressure Sensor (ATG)  | X                                    | X   | X  |
| Maintain Pressure Sensor (ATG)   |                                      | X   | X  |
| Calibrate Pressure Sensor (ATG)  |                                      | X   | X  |
| Clear ATG Pressure Sensor Alarm (ATG)  |                                      | X   | X  |
| Clear ISD/PMC Alarms (ISD/PMC)   |                                      |   | X  |
| <sup>1</sup> Perform wiring and conduit routing; equipment mounting<br><sup>2</sup> Inspect wiring and conduit routing; equipment mounting<br><sup>3</sup> Turn power on, program and test the systems<br><sup>4</sup> Provide supervised field experience in service techniques and operations<br><sup>5</sup> Troubleshoot and provide routing maintenance |                                      | <sup>6</sup> UST Monitoring Systems – Installer (Level 1)<br><sup>7</sup> Certified UST Monitoring Technician<br><sup>8</sup> VR Vapor Products |  |

**Warranty Registrations** may only be submitted by selected Distributors. Certified installers are required to provide the GDF operator with the completed Equipment Warranty Notice, form 577013-868, for their records.

## Related Manuals





The manuals in Table 1 below are shipped with the equipment on the V-R Tech Docs CD-ROM and will be needed to install specific equipment.

**Table 1. Related Manuals**

| V-R Manual   | Part Number                   |
|--|-------------------------------|
| TLS-3XX Site Prep Manual   | 576013-879                    |
| Vapor Pressure Sensor For Vent Stacks Installation Guide (For Sensor P/N 861190-X0X) | IOM 21 VR-203 & IOM 27 VR-204 |
| Pressure Sensor Installation Guide (For Sensor P/N 331946-001)                       | IOM 13 VR-203 & VR-204        |
| TLS-3XX Series Consoles System Setup Manual  | 576013-623                    |
| TLS-3XX Series Consoles Operator's Manual  | 576013-610                    |
| Serial Comm Modules Installation Guide   | 577013-528                    |
| TLS-350 Series Board and Software Replacement Manual                                 | 576013-637                    |
| Carbon Canister Vapor Polisher Installation and Maintenance Guide                    | 577013-920                    |
| In-Station Diagnostics and PMC Troubleshooting Guide                                 | 577013-819                    |
| TLS RF Wireless 2 System (W2) Installation and Maintenance Guide                     | 577013-964                    |

## Safety Precautions

The following symbols may be used throughout this manual to alert you to important safety hazards.

|   |  |   |  |
|---|--|---|--|
|  | <p><b>ELECTRICITY</b><br/>High voltage exists in, and is supplied to, the device. A potential shock hazard exists.</p>   |  | <p><b>TURN POWER OFF</b><br/>Live power to a device creates a potential shock hazard. Turn Off power to the device and associated accessories when servicing the unit.</p> |
|  | <p><b>READ ALL RELATED MANUALS</b><br/>Knowledge of all related procedures before you begin work is important. Read and understand all manuals thoroughly. If you do not understand a procedure, ask someone who does.</p> |  | <p><b>WARNING</b><br/>Heed the adjacent instructions to avoid equipment damage or personal injury.</p>   |

| <b>⚠ WARNING</b>  |  |
|---|--|
|  | <p><b>The console contains high voltages which can be lethal. It is also connected to low power devices that must be kept intrinsically safe.</b></p> <p><b>Turn power off at the circuit breaker. Do not connect the console AC power supply until all devices are installed.</b></p> |
|  | <p><b>FAILURE TO COMPLY WITH THE FOLLOWING WARNINGS AND SAFETY PRECAUTIONS COULD CAUSE DAMAGE TO PROPERTY, ENVIRONMENT, RESULTING IN SERIOUS INJURY OR DEATH.</b></p>  |

## Installation

This section discusses the installation and wiring of the hardware required to enable the TLS console to perform pressure management of the site's gasoline vapor polisher equipment:

- Vapor Pressure Sensor
- Carbon Canister Vapor Polisher
- Smart Sensor Interface Module
- NVMEM203 board
- Multiport Card - only required for sites with TLS console controlled vapor processor
- I/O Combination Module - only required for sites with non-TLS console controlled vapor processor



All field wiring, its type, its length, etc., used for TLS console sensors must conform to the requirements outlined in the Veeder-Root TLS-3XX Site Prep manual (P/N 576013-879) and to additional field wiring requirements specified in related connected components, such as for Pressure Sensors.

### Vapor Pressure Sensor

---

Install one vapor pressure sensor as detailed in the applicable Pressure Sensor Installation Guide shown in Table 1.

### Carbon Canister Vapor Polisher

---

Install one Carbon Canister Vapor Polisher following the instructions in the Carbon Canister Vapor Polisher Installation and Maintenance Guide (P/N 577013-920).

### Installing TLS Console Modules - General Notes

---

TLS consoles have three bays in which interface modules can be installed; Comm bay, Power bay and Intrinsically-Safe bay (ref. Figure 1). Probe Interface modules and Smart Sensor modules are installed in the Intrinsically-Safe bay and the Mod Bus module is installed in the Comm bay.

**In all cases, the position of the modules, their respective connectors and the devices wired to the connectors must be recorded to prevent improper replacement during installation or service. A circuit directory for Power and I.S. bay Interface Modules is adhered to the back of the right-hand door for this purpose.**



Switch off power to the TLS console before you install modules and connect sensor wiring.




Figure 1. TLS console Interface Module Bays



**CAUTION!** During programming, module positions and the devices wired to each module are identified and stored in memory. If a connector is removed and reinstalled on a different module after programming, or if an entire module with its connector is removed and reinstalled in a different module slot, the TLS console will not identify correctly the data being received.

### Module Position

1. Record on the circuit directory the type of module in each slot location.
2. If a system contains multiple modules of a single type (i.e., two Smart Sensor Modules), they may be swapped between their respective slot locations, **however, the connectors must remain with their original locations, not with the original modules.**

### Connector Position

1. Identify all connectors according to their slot location using the self-adhesive numbering labels furnished with each module. Accurately record on the circuit directory the location of each device wired to the connector **as you attach wires** to the module.
2. Once a device has been wired to certain terminals on a connector and the system has been programmed, the wires from that device may not be relocated to other terminals without reprogramming the system.

### Grounding Probe and Sensor Shields

Connect probe and sensor cable shields to ground at the console only. Do not ground both ends of the shield.

## CIRCUIT DIRECTORY

A circuit directory is adhered to the inside of the right-hand door. It should be filled out by the installer as the module's connectors are being wired.

The following information should be recorded for each slot:

- **Module Type:** record what type of module has been installed in the slot, e.g., Smart Sensor Module.
- **Position Record:** record the physical location and/or type of device wired to each terminal of the module connector in the slot, e.g., VPS: FP1.

## **Smart Sensor Interface Module**

---

Verify that a Smart Sensor Interface Module with Atmospheric Sensor (P/N 332250-001) is installed in the TLS console. Connect the field wiring from the Vapor Pressure Sensor (VPS) to the Smart Sensor Interface Module as instructed in the VPS installation manual. The Carbon Canister Vapor Polisher will also be connected to the Smart Sensor Interface Module.

## **NVMEM203 Board**

---

Verify that a NVMEM203 board is installed in the TLS console (ref. Figure 2-14 in the V-R TLS-3XX Series Consoles Troubleshooting Manual P/N 576013-818, Rev J or later). This board contains flash EEPROM and RAM needed to run PMC software and store PMC reports. No setup is required.



# Setup

## Introduction

This section describes how to perform PMC setup using the TLS console's front panel buttons and display. The procedures in this manual follow standard TLS console setup programming input, i.e., keypad/display interaction. If necessary, refer to Section 2 of the TLS-3XX System Setup manual (P/N 576013-623) to review entering data via the front panel keypads.

All PMC-related equipment must be installed in the site and connected to the TLS console prior to beginning the setups covered in this section. As with all TLS connections, you cannot change sensor wiring or module slots after programming or the console may not operate properly. Reference the section entitled "Connecting Probe/Sensor Wiring to Consoles" in the TLS-3XX Site Prep and Installation manual (P/N 576013-879) for rewiring precautions.

## Smart Sensor Setup - Vapor Pressure Sensor

The Smart Sensor Interface Module is installed in the Intrinsically-Safe bay of the TLS console. This module monitors the Vapor Pressure Sensor. Figure 2 diagrams the Smart Sensor setup procedure.




Figure 2. Smart Sensor Setup - Vapor Pressure Sensor

## Smart Sensor Setup - Vapor Polisher

The Smart Sensor Interface Module is installed in the Intrinsically-Safe bay of the TLS console. This module monitors the Vapor Polisher. Figure 3 diagrams the Smart Sensor setup procedure.




Figure 3. Smart Sensor Setup - Vapor Polisher

## ATM Pressure Sensor Setup

The ATM Pressure Sensor is factory installed in the SmartSensor / Press module and preassigned to channel 8. At least one SmartSensor / Press module, which contains the ATM Pressure Sensor, must be installed in the console. You must configure at least one ATM Pressure Sensor for use by the Vapor Polisher or a PMC Set-up Fail will occur. NOTE: if more than one SmartSensor / Press module is installed, only one ATM Pressure Sensor needs to be configured.

Look in console and note the slot position of the SmartSensor / Press module. Enter the Setup Mode and press the FUNCTION key until you see the message:

```
SMARTSENSOR SETUP
PRESS <STEP> TO CONTINUE
```

Press STEP until you see the message:

```
SS CONFIG - MODULE n
SLOT x - X X X X X X X X
```

Where *x* is the slot number containing the SmartSensor / Press module. Press the → key to move the cursor to the last (8th) X. Press CHANGE and the message below should appear:

```
SLOT x - X X X X X X X 8
PRESS <STEP> TO CONTINUE
```

Press STEP:

```
ENTER SMARTSENSOR LABEL
s 8:
```

NOTE: In the example above, the ATM P sensor position is 8 but it could be 16, 32, or 40 depending on the SmartSensor's module number.

Press CHANGE and enter a label:

```
ENTER SMARTSENSOR LABEL
s 8: (ATMP Sensor Label)
```

Press ENTER to accept your label:

```
s 8: (ATMP Sensor Label)
PRESS <STEP> TO CONTINUE
```

Press STEP:

```
s 8: SELECT SS CATEGORY
UKNOWN
```

Press CHANGE until you see the message:

```
s 8: SELECT SS CATEGORY
ATM P SENSOR
```

Press ENTER to accept the category. Press STEP, then BACKUP to return to the configuration display for Smart Sensor module 1:

```
SS CONFIG - MODULE 1
SLOT x - X X X X X X X X
```

This completes the ATM Pressure Sensor configuration.

# PMC Setup

Figure 4 diagrams the PMC setup programming.




Figure 4. PMC Setup

# Operation

## Alarms

### OVERVIEW OF TLS CONSOLE INTERFACE

The TLS console is continuously monitoring the vapor recovery system and PMC sensors for alarm conditions. During normal operation when the TLS console and monitored PMC equipment is functioning properly and no alarm conditions exist, the "ALL FUNCTIONS NORMAL" message will appear in the system status (bottom) line of the console display, and the green Power light will be On (see Figure 5).




Figure 5. TLS console alarm interface

If an alarm condition occurs the system displays the condition type and its location. If more than one condition exists, the display will continuously cycle through the appropriate alarm messages. The system automatically prints an alarm report showing the alarm type, its location and the date and time the alarm condition occurred.

Alarm posting causes the TLS console-based system to activate indicator lights, an audible alarm, and an automatic strip paper printout documenting the alarm.

### ALARM POSTING

Displayed messages alert you to the type of alarm. Printed messages show the type of alarm and the time it was posted (see Figure 6). Alarms are logged into the Priority Alarm History and warnings are logged in the Non-Priority Alarm History in the TLS.




Figure 6. TLS console alarm example

## PMC Alarm Summary

Table 2 contains a listing of the PMC generated alarms including a brief description of each and associated front panel indicator.

Table 2. PMC Alarm Summary

| Displayed Message | Description   | Light Indicator | Suggested Troubleshooting <sup>1</sup>   |
|-------------------|---|-----------------|--|
| VP EMISSION WARN  | Mass emission exceeded the certified daily threshold.   | Yellow          | Ensure Polisher is in Automatic Mode. Resolve any Vapor Valve Sensor Fault Alarms. |
| VP EMISSION FAIL  | 2nd consecutive mass emission failure   | Red             |  |
| PMC SETUP FAIL    | PMC is not configured or missing components.  | Red             | Ensure that all required components are installed and operational.                 |
| PMC SENSOR FAULT  | Component used by PMC has failed or reported an error condition. See Troubleshooting section for complete description of sensors and associated conditions that can cause a sensor fault. | Red             | Check for Smart Sensor Device Alarm or Fault.                                      |

<sup>1</sup>Refer to the Troubleshooting Section of this manual and the ISD/PMC Troubleshooting Guide 577013-819.

## Wireless Related Sensor Alarms

The TLS RF Wireless 2 System (W2) features two-way communication utilizing a client/server architecture. When the Veeder-Root Polisher Vapor Valve uses this type of technology, the following alarm may occur:

| Displayed Message | Description   | Light Indicator | Suggested Troubleshooting        |
|-------------------|---|-----------------|----------------------------------|
| BATTERY WARNING   | Vapor Valve transmitter reports battery status as 'Replace' for 24 hours. | Yellow          | Remove and replace battery pack. |

## PMC Status Report

Figure 7 below shows the procedure to view the PMC Status Report.




Figure 7. PMC Status Report

## Viewing PMC Reports Via RS-232 Connection

### CONNECTING LAPTOP TO CONSOLE

Connect your laptop to the TLS console's RS-232 or Multiport module using one of the methods shown in the examples in Figure 8 below.




Figure 8. Connecting laptop to TLS console for serial communication

### CONNECTING LAPTOP TO CONSOLE

1. Open your laptop's serial communication program, e.g., HyperTerminal. You can typically find HyperTerminal under: Start/Programs/Accessories/Communications.



2. After opening the terminal software program, ignore (cancel) any modem/dialing related request windows since you will be directly connecting to the console via serial communications. When the Connection Description window appears (Figure 9), enter a connection name, e.g., TLSDIRECT, and click the OK button.




Figure 9. Connection Description window

3. After clicking the OK button, you may see a repeat of the modem/dialing windows, in which case ignore (cancel) them all.
4. When the Connect To window appears (Figure 10), depending on your connection method, select either COM1 (if RS-232 port on laptop), USB-Serial Controller (if using USB port on laptop), or Serial I/O PC Card (if using PCMCIA port on laptop) in the 'Connect using' drop down box, then click OK button.



Figure 10. Connect To window



5. Next you should see the 'Port Settings' window.

**IMPORTANT! The settings of the laptop's com port must match those of the console's com port to which you are connected.**

- a. Go to the console front panel press the MODE key until you see:

```

SETUP MODE
PRESS <FUNCTION> TO CONT
    
```

- b. Press the FUNCTION key until you see the message:

```


COMMUNICATIONS SETUP
PRESS <STEP> TO CONTINUE
    
```

- c. Press the STEP key until you see the message:

```

PORT SETTINGS
PRESS <ENTER>
    
```

- d. Press the PRINT key to printout the port settings for all communication modules installed in the console. Figure 11 shows an example port settings printout with the RS-232 module installed. Using the console port settings in the example below, your HyperTerminal 'Port Settings' window entries would be Bits per second - 2400, Data bits - 7, Parity - Odd, Stop Bits - 1. For the 'Flow Control' entry select None. Click OK.



**Figure 11. Console comm port settings printout example**

In the example port settings printout above, the RS-232 Security Code is disabled. If the code was enabled you would see a 6-digit number which you will need to enter to access the console (refer to the 'Sending Console Commands' paragraph below for more information).

6. After entering your port settings, the program's main window appears (Figure 12).




Figure 12. HyperTerminal main window

### SENDING CONSOLE COMMANDS

Table 3 shows important PMC console commands. The <SOH> shown in the table means that you must press and hold the **Ctrl** key while you press the **A** key.

For example, let's say you want to see the Vapor Polisher Runtime Diagnostic Report.



Note: If you want to see the characters of the command as you type them in, click on File menu, then select Properties/Settings (tab)/ASCII Setup and click the check box for 'Echo typed characters locally', then click OK to close the window(s) and return to the main screen.

If the RS-232 Security Code is disabled - press and hold the Ctrl key while you press the A key, then type in IV8000. If the RS-232 Security Code is enabled (e.g., 000016) you must enter the security code before the command - press and hold the Ctrl key while you press the A key, then type in 000016IV8000.

You will see the typed command on the screen: ⓂIV8000 followed by the response (report) from the console. The Ⓜ symbol indicates CtrlA and the ♥ symbol indicates the end of the response.

If the console recognizes the command the response displays as soon as the command is typed in.

If the console does not recognize the command you would see something like ⓂIV80000Ⓜ9999FF1B♥ which indicates the console did not recognize the command.

All responses (Reports) can be printed or saved to a file. See the terminal program's help file for instructions.

**Table 3. Serial Commands for PMC Diagnostic Reports**

| Report Type   | Serial Command (PC to Console)*   |
|---|---|
| Vapor Valve Status Report<br>(See example Figure 13)              | <SOH>IB6100   |
| Smart Sensor Sub Alarm History Report (See example Figure 14)     | <SOH>IB6200   |
| Vapor Processor Status Report (See example Figure 15)             | <SOH>IV8200   |
| Priority Alarm History Report (See example Figure 16)             | <SOH>I11200   |
| Non-Priority Alarm History Report (See example Figure 17)         | <SOH>I11100   |
| Vapor Polisher Runtime Diagnostic Report (See example Figure 18)  | <SOH>IV8000   |
| Daily Vapor Polisher Diagnostic Report<br>(See example Figure 19) | <SOH>IV8800yyyyymmddnnnn<br>Where yyyy=year number,<br>mm=month number (01=January,<br>02=February, etc.),<br>dd=day of the month;<br>nnnn=number of records<br>after the date entered<br>(9999=all). |

\*<SOH> = Control A. For more information on TLS console serial commands, refer to the V-R Serial Interface Manual.

Figure 13 shows an example Vapor Valve Status report.

```

IB6100
FEB 4, 2008 1:09 PM
s 2:Vapor valve

VAPOR VALVE
SERIAL NUMBER      123456
VALVE POSITION:     OPEN
OPEN CAP:          CHARGED
CLOSE CAP:         CHARGED
AMBNT TEMP:        65.08 F
OUTLET TMP:        75.05 F
SENSOR FAULTS:
NONE
    
```

**Figure 13. Vapor Valve Status Report - Serial to PC Format**

The IB6100 command reports the current state of the Vapor Valve Components. The current position of the valve is reported as Open or Closed. The Capacitors are used to move the valve and are reported as Charged or Discharged. Outlet Temperature is the Canister thermal probe temperature. Ambient Temperature is the temperature at the Vapor Valve ambient temperature sensor. Sensor Faults are the active faults reported by the Vapor Valve. The IB6100 (Figure 13) command only provides active Sensor Fault conditions. Use the IB6200 command to see archived fault conditions (Figure 14).

```

IB6200
SEP 19, 2008  1:05 PM

<Site Name>
<Site Address>
<Site Address>
<Site Address>

SMART SENSOR SUB ALARM HISTORY

ID  TYPE  ALARM TYPE          SUB ALARM                STATE  DATE    TIME
 9   14   SENSOR FAULT ALARM  TEMPERATURE RANGE FAULT CLEAR  9-19-08 11:50AM
 9   14   SENSOR FAULT ALARM  TEMPERATURE RANGE FAULT ALARM  9-19-08 11:46AM
    
```

**Figure 14. Smart Sensor Sub Alarm History Report - Serial to PC Format**

Figure 15 shows an example Vapor Processor Status Report.

```

IV8200
DEC  8, 2010  4:29 AM

<Site Name>
<Site Address>
<Site Address>
<Site Address>

VAPOR PROCESSOR STATUS REPORT

PMC VERSION: 01.04

ASSESSMENT TIME: DEC  7, 2010 11:59 PM

VAPOR PROCESSOR TYPE: VEEDER-ROOT POLISHER

PMC MONITORING TEST PASS/FAIL THRESHOLDS
VAPOR PROCESSOR MASS EMISSION FAIL          PERIOD  BELOW  ABOVE
                                           1DAYS   ----   0.32 LBS/1KG

EFFLUENT EMISSIONS TEST : PASS      (0.00 LBS/1KG)

DAILY THROUGHPUT  :    6989 GALS
    
```

**Figure 15. Vapor Processor Status Report - Serial to PC Format**

Figure 16 shows an example Priority Alarm History Report.

```

I11100
DEC 9, 2010 4:20 AM

<Site Name>
<Site Address>
<Site Address>
<Site Address>

PRIORITY ALARM HISTORY
ID CATEGORY DESCRIPTION ALARM TYPE STATE DATE TIME
T 2 TANK 91 OCTANE PROBE OUT CLEAR 12-08-10 7:55PM
T 2 TANK 91 OCTANE PROBE OUT ALARM 12-08-10 7:07PM
T 2 TANK 91 OCTANE OVERFILL ALARM CLEAR 11-17-10 11:46AM
T 2 TANK 91 OCTANE OVERFILL ALARM ALARM 11-17-10 11:45AM
    
```

**Figure 16. Priority Alarm History Report - Serial to PC Format**

Figure 17 shows an example Non-Priority Alarm History Report.

```

I11200
DEC 9, 2010 4:20 AM

<Site Name>
<Site Address>
<Site Address>
<Site Address>

NON-PRIORITY ALARM HISTORY
ID CATEGORY DESCRIPTION ALARM TYPE STATE DATE TIME
T 3 TANK DIESEL LOW TEMP WARNING CLEAR 12-08-10 3:00PM
T 3 TANK DIESEL LOW TEMP WARNING ALARM 12-08-10 3:00PM
T 3 TANK DIESEL HIGH PRODUCT ALARM CLEAR 12-08-10 3:00PM
T 3 TANK DIESEL HIGH PRODUCT ALARM ALARM 12-08-10 2:56PM
SYSTEM PRINTER ERROR CLEAR 11-17-10 10:51AM
SYSTEM PAPER OUT CLEAR 11-17-10 10:51AM
SYSTEM PAPER OUT ALARM 11-17-10 10:50AM
SYSTEM PRINTER ERROR ALARM 11-17-10 10:50AM
    
```

**Figure 17. Non-Priority Alarm History Report - Serial to PC Format**

Figure 18 shows an example Vapor Polisher Runtime Diagnostic Report and Table 4 explains the IV8000 report's event codes.

```

IV8000
FEB 4, 2008 1:01 PM
948-16.eps

TLS_350 UST
VEEDER-ROOT TEST LAB
125 POWDER FOREST DR
SIMSBURY, CT 06070

VAPOR POLISHER
VALVE EVENT PRESSURE
DATE-TIME "WC EVENT CODE
1-31-08 3:44PM -0.700 OPEN PURGE
1-31-08 3:47PM 0.038 CLOSE FORCE PURGE
1-31-08 3:51PM -0.255 OPEN PURGE
1-31-08 8:08PM -0.300 CLOSE PURGE Hi P
2-01-08 1:59PM -0.300 OPEN PURGE
2-01-08 2:18PM -0.263 OPEN PURGE
2-01-08 2:33PM -0.289 OPEN PURGE
2-04-08 11:22AM -0.560 NO EVENT
2-04-08 11:28AM -0.560 OPEN PURGE
2-04-08 11:48AM -0.300 OPEN PURGE
2-04-08 12:28PM -0.263 OPEN PURGE
2-04-08 12:42PM -0.299 OPEN PURGE
    
```

**Figure 18. Vapor Polisher Runtime Diagnostic Report - Serial to PC Format**

**Table 4. Vapor Polisher Runtime Diagnostic Report Event Codes**

| Event Code        | Cause  | Event Code        | Cause  |
|-------------------|--|-------------------|--|
| NO EVENT          | The valve changed state outside of the carbon canister algorithm.  | CLOSE NEAR FULL   | Canister load is between 80 and 100% and pressure is <1.05.  |
| CLOSE TEST        | Manual operation of the valve  | CLOSE EMPTY       | Excess purging is complete.  |
| OPEN TEST         | Manual operation of the valve  | OPEN PURGE        | Canister load is >0% and pressure <-0.25   |
| CLOSE PURGE HI P  | The canister state is in excess purge and the pressure is >0.5.  | OPEN EXCESS PURGE | Canister load is 0%, Excess purge is incomplete, pressure <-1.5, time is between 6AM and 4PM.  |
| CLOSE PURGE TIME  | The canister state is in excess purge and the time is outside 6AM to 4PM.  | OPEN FILL         | Canister valve is open for loading: <ul style="list-style-type: none"> <li>When pressure is greater than or equal to 0.75 IWC and Canister load is less than 80%.</li> <li>Pressure is greater than or equal to 1.3 IWC and Canister load is greater than 80% and below emission limit.</li> </ul> |
| CLOSE FORCE PURGE | Canister is in startup period. Loading with pressures <+1.05 is not allowed until startup period is complete.              | CLOSE LIMIT       | Valve closed because canister has reached allowable extended capacity loading limit.   |
| CANISTER EMPTY    | Canister load equals 0% after having loaded to more than 1%. No valve state change.  | CLOSE CVLD TEST   | Valve closed to collect data for ISD containment leak test.  |
| CANISTER FULL     | No valve state change. The canister load passed from below 95% to/thru the 100% point and not yet at day's emission limit. |                   |  |

Figure 19 shows an example PMC Daily Vapor Polisher Diagnostic Report.

```

IV8800
OCT 2, 2008 2:53 PM

PMC DAILY VAPOR POLISHER DIAGNOSTIC

          LOAD  PRGE  MIN%  MAX%  SELF  EMISSION
DATE/TIME  HRS   HRS   LOAD  LOAD  TEST  TEST
08-10-02 13:58:58  3.1  2.5   15   69   WARN  FAIL
    
```

**Figure 19. PMC Daily Vapor Polisher Diagnostic Report - Serial to PC Format**



## Diagnostics

### Automatic Control

---

If PMC mode is in AUTOMATIC, PMC will control flow through the canister using a vapor control valve. The control algorithms will monitor tank pressure, atmospheric pressure, vapor temperature and carbon temperature to monitor carbon canister loading. When the pressure is positive, the valve is opened to relieve the pressure and begin loading the canister. Purging occurs when the valve is open and the UST pressure is negative. The valve will close when the canister has either reached capacity or the canister is empty after purging.

### Manual control


---

If PMC mode is in MANUAL, the diagnostic menu allows the valve to be opened (ON) or closed (OFF) manually. This feature is to support testing operation (see Exhibit 11 of VR 203) of the valve without waiting for canister to reach loading or purging thresholds. When set to Manual mode, the system will reset to Automatic mode after 4 hours. The current UST ullage space vapor pressure will also be available through the diagnostic menu.

### PMC Diagnostic Menus

---

The Smart Sensor (see Figure 20) and PMC (see Figure 21) diagnostic menus below are viewed from the TLS Console front panel.



```

SS COMM DIAG
-----
s 1: AFM1  FP1-2
SAMPLES READ    58
SAMPLES USED    54
PARITY ERR      0
PARTIAL READ    0
COMM ERR        0
RESTARTS        0
  
```

948-1.eps

```

SS CONSTANTS DIAG
-----
s 1: AFM1  FP1-2

VAPOR PRESSURE
SERIAL NUMBER    1007
PROTOCOL VERSION 0
  
```

```

SS CHANNEL DIAG
-----
s 1: AFM1  FP1-2
YY-MM-DD HH:MM:SS
C00 B50B 3D68 00E0 0000
C04 0000 03EF 0000 0004
C08 0A3C 3D68 5693 0081
C12 80C4 80A4 0104 2579
C16 0000 0000 00A3 03D6
C20 0709 0032 04C9 880F
  
```

Figure 20. SmartSensor Diagnostic Menus




Figure 21. PMC Diagnostic Menu

# Troubleshooting

## PMC Setup

This warning occurs when the PMC setup is not complete.

### DIAGNOSTIC CHECKLIST

| Procedure |  |
|-----------|--|
| STEP 1.   | Gasoline tanks configured? <input type="checkbox"/>  |
| STEP 2.   | ATM sensor configured and enabled? <input type="checkbox"/>  |
| STEP 3.   | Vapor valve installed and configured? <input type="checkbox"/>   |
| STEP 4.   | On the TLS press the MODE key until the DIAGNOSTIC MODE menu is displayed (this will cause a TLS console System Self-Test). <input type="checkbox"/> |
| STEP 5.   | If alarm does not clear, contact Veeder-Root Technical Support at (800) 323-1799.  |

## PMC Sensor Faults

Table 5 contains a listing of the Smart Sensor Device generated alarms including their cause and suggested troubleshooting. TLS Console PMC alarms may be interspersed amongst non-PMC alarms, please see TLS Series manuals for more information.

**Table 5. Smart Sensor Device Fault Summary**

| Fault Message                          | Devices                                  | Cause   | Suggested Troubleshooting   |
|--|--|---|---|
| Communication Alarm                    | Vapor Valve, Pressure Sensor, Tank Probe | Device not communicating with Smart Sensor Module | Check wiring and connections from the Smart Sensor board to the device in alarm.  |
| Smart Sensor Fault Valve Command Fault | Vapor Valve                              | Valve will not move when commanded                | Check installation of all Vapor Valve components including Thermal Probe and Vapor Sensor Assembly. Refer to manual 577013-920. |
| Smart Sensor Fault Cap Not Holding     |  | Capacitor not holding charge                      |   |
| Smart Sensor Fault Cap Not Charging    |  | Capacitor not charging                            |   |
| Smart Sensor Fault Temperature Range   |  | Temperature out of range                          |   |

## Wireless Related Sensor Alarms

The TLS RF Wireless 2 System (W2) features two-way communication utilizing a client/server architecture. When the Veeder-Root Polisher Vapor Valve uses this type of technology, the following alarm may occur:

| Displayed Message | Description   | Light Indicator | Suggested Troubleshooting        |
|-------------------|---|-----------------|----------------------------------|
| BATTERY WARNING   | Vapor Valve transmitter reports battery status as 'Replace' for 24 hours. | Yellow          | Remove and replace battery pack. |

## VP Emission Alarm

In the event that a VP EMISSION WARNING is present when the valve is in Automatic mode for 24 hours and there are no PMC Sensor Fault alarms on the system, notify Veeder-Root Technical Support.

## Example Smart Sensor reports

```

IB6100
FEB 4, 2008 1:09 PM
s 2:Vapor valve

VAPOR VALVE
SERIAL NUMBER      123456
VALVE POSITION:     OPEN
OPEN CAP:          CHARGED
CLOSE CAP:         CHARGED
AMBNT TMP:         65.08 F
OUTLET TMP:        75.05 F
SENSOR FAULTS:
VALVE COMMAND FAULT
    
```

```

IB6100
FEB 4, 2008 1:09 PM
s 2:Vapor valve

VAPOR VALVE
SERIAL NUMBER      123456
VALVE POSITION:     OPEN
OPEN CAP:          CHARGED
CLOSE CAP:         CHARGED
AMBNT TMP:         65.08 F
OUTLET TMP:        75.05 F
SENSOR FAULTS:
CAP NOT HOLDING
    
```

```

IB6100
FEB 4, 2008 1:09 PM
s 2:Vapor valve

VAPOR VALVE
SERIAL NUMBER      123456
VALVE POSITION:     OPEN
OPEN CAP:          CHARGED
CLOSE CAP:         CHARGED
AMBNT TMP:         65.08 F
OUTLET TMP:        75.05 F
SENSOR FAULTS:
CAP NOT CHARGING
    
```

```

IB6100
FEB 4, 2008 1:09 PM
s 2:Vapor valve

VAPOR VALVE
SERIAL NUMBER      123456
VALVE POSITION:     OPEN
OPEN CAP:          CHARGED
CLOSE CAP:         CHARGED
AMBNT TMP:         65.08 F
OUTLET TMP:        75.05 F
SENSOR FAULTS:
TEMPERATURE RANGE
    
```

```


IB6100
FEB 4, 2008 1:09 PM
s 2:Vapor valve

VAPOR VALVE
SERIAL NUMBER      123456
VALVE POSITION:     OPEN
BATTERY:           FULL
OPEN CAP:          CHARGED
CLOSE CAP:         CHARGED
AMBNT TMP:         65.08 F
OUTLET TMP:        75.05 F
SENSOR FAULTS:
TEMPERATURE RANGE
    
```

'Wireless' vapor valve example

## Operability Test Procedures

Refer to Exhibit 11 and Exhibit 12 of VR 203 and VR 204 for applicable operability test requirements for the Vapor Polisher.



# INSTALLATION MANUAL

HIRT VCS 100 VAPORTEK®  
VAPOR PROCESSOR AND INDICATOR PANEL

FOR EXECUTIVE ORDERS VR-203 & VR-204

**HIRT COMBUSTION ENGINEERS, INC.**

3659 San Gabriel River Parkway · Pico Rivera, Ca 90660

P.O. Box 6816 · Pico Rivera, CA 90661

Tel: (562)692-1490 · Fax: (562)692-7413 · E-mail: [HirtVCS@AOL.com](mailto:HirtVCS@AOL.com)

## Table of Contents

| <u>Section</u>                             | <u>Page</u> |
|--|-------------|
| 1. Introduction                            | 1           |
| 2. Safety/Warnings                         | 1           |
| 3. Contractor Requirements                 | 1           |
| 4. Hirt VCS 100 Processor Overview         | 2           |
| 4.1 Theory of Operation                    |             |
| 4.2 How the Processor Operates             |             |
| 4.3 Indicator Panel Function               |             |
| 4.4 Dimensions, Weight, Specifications     |             |
| 4.5 Processor Components                   |             |
| 5. Installation of Processor               | 6           |
| 6. Installation of Indicator Panel         | 10          |
| 7. Connection of Electrical and Vapor Pipe | 11          |
| 8. Start-Up                                | 15          |
| 9. Maintenance Instructions                | 20          |
| 10. Repair and Replacement of Components   | 20          |
| 11. Product Warranty                       | 21          |



## 1. INTRODUCTION

This Manual contains the operation, installation, interconnection, start-up, and maintenance instructions for the VCS 100 Vaportek® processor and Indicator Panel. Note, these instructions are written to give the best installation in a sequence easiest for the installer. If there are any instructions in this manual which seem impossible, impractical, or questionable for your installation, call the Hirt Customer Service Department at (562) 692-6970 and ask for information regarding your local Hirt representative. Note, this manual should be retained for future reference.

## 2. SAFETY/WARNINGS

**WARNING:** Improper installation, adjustment, alteration, service or maintenance can cause property damage, injury, or death. Read instructions thoroughly before installing or servicing this equipment.

**WARNING:** When gasoline vapor abatement system (i.e. processor) is in operation, temperature inside can exceed 2,000°F. To prevent burn hazard, do not contact any part of the gasoline vapor abatement system except controls. Do not remove protective covers while gasoline vapor abatement system is in operation.

## 3. CONTRACTOR REQUIREMENTS

To prevent from voiding the product warranty, all contractors who install, startup, and/or repair the VCS 100 Vaportek® system must be a Hirt VCS 100 certified technician. To attend a VCS 100 training session, call Hirt Customer Service at (562) 692-6970 or send an email request to HirtVCS@aol.com. Once Hirt training is successfully completed, the technician will receive a wallet size proof of certification card.

Technicians should carry the card while on the jobsite. Hirt maintains a list of active certified installers and companies. Technician certification can be verified by calling or emailing Hirt Combustion Engineers, Inc.

Note to Contractors/Technicians: Contractors should always verify the training and certification requirements with the local Air Quality Management District (District) before beginning installation of CARB EVR systems. The District inspector may request to see your certification card(s) on-site for confirmation.

## 4. HIRT VCS 100 PROCESSOR OVERVIEW

### 4.1 THEORY OF OPERATION

The processor continuously measures the pressure of the vapor in the storage tanks. When that pressure is negative, the processor remains de-energized and completely inactive. At any time when the pressure in the storage tank vapor becomes positive, the processor energizes its turbine, which extracts vapor from the storage tanks and sends that vapor into its thermal oxidizer where that vapor is destroyed. The processor continues to extract vapor until the pressure of the vapor is returned to negative, whereupon the processor turns itself off. It remains off unless or until the pressure again becomes positive.

### 4.2 PROCESSOR MECHANIZATION

The processor is connected to the storage tanks via the tank vapor vents, or another vapor pipe. The processor contains a vacuum sensor/switch, turbine, spark igniter, pilot, flame safeguard, vapor valve, and a thermal oxidizer.

When the vacuum sensor/switch measures that the pressure in the storage tank is negative, it remains open, thus not energizing the processor. In this condition the processor is inert and has zero effect on the remainder of the dispensing facility or its Phase I/II vapor recovery systems.

When the vacuum sensor/switch measures that the pressure of the vapor in the storage tanks is positive, the switch closes thereby energizing the turbine and activating the flame safeguard. The flame safeguard generates a spark at the pilot tip (i.e. spark igniter). The vapor is forced by the turbine from the storage tanks into the pilot and hence into the spark igniter. Only ignition of the pilot can cause the flame safeguard's relay to close\*. Only when pilot ignition is present and the flame safeguard relay is closed does the vapor valve open admitting vapor to the thermal oxidizer. Note that if the pilot does not ignite, the main vapor valve does not open, thus unprocessed vapor from the thermal oxidizer cannot be vented to the atmosphere. In the thermal oxidizer, the vapor is converted into CO<sub>2</sub> and H<sub>2</sub>O and then vented to the atmosphere.

\*This electrical interlock, built into the flame safeguard, is required by the California State Fire Marshal, ETL, American Gas Association specification 1-97, and ANSI Z21.20

### 4.3 INDICATOR PANEL FUNCTION

For both the ISD equipped and non-ISD versions, the processors' electrical power source comes thru the Hirt Indicator Panel. The panel allows the station operator to determine the current state of the processor and whether or not the processor is operating properly. The panel includes a POWER switch with an integral POWER (green) lamp, a PROCESSING (green) lamp, and an MALFUNCTION (red) lamp.

During normal operation, the POWER switch is on, the POWER lamp is on, the PROCESSING lamp is lit intermittently, and the MALFUNCTION lamp is extinguished. The PROCESSING lamp is wired so it will light when the main valve is open and thermal oxidation is occurring.

The MALFUNCTION lamp is wired to the vacuum sensor/switch and a timing module. If the UST pressure is positive for at least 1 hour, then the vacuum sensor/switch will be closed and the timing module will light the MALFUNCTION lamp. The MALFUNCTION lamp indicates a leak in the vapor recovery system or possibly a malfunction of the Hirt VCS 100 processor. The MALFUNCTION lamp will extinguish after the leaks or processor malfunction is corrected and the processor has restored the UST ullage to a nominal  $-0.40''$  w.c.

#### 4.4 PROCESSOR DIMENSIONS, WEIGHT, AND SPECIFICATIONS

MODEL: VCS 100 Vaportek®


SERVICE: Outdoor, non hazardous area

ELECTRICAL: 120 VAC, 3 Ampere, intermittent



VAPOR PIPE CONNECTION: ¾" NPT

WEIGHT: 80 lbs.

OVERALL DIMENSIONS: 18" wide X 18" deep x 38" high (without legs)



#### 4.5. PROCESSOR INTERNAL COMPONENTS



## 5. INSTALLATION OF PROCESSOR

### 5.1 PRE-INSTALLATION SITE REQUIREMENTS

Selection of processor location should be based on the following requirements and considerations:

- 5.1.1 Non-Hazardous area.
- 5.1.2 A minimum horizontal distance of 20 ft. from any fuel transfer point (i.e. nozzles or storage tank drop tubes).
- 5.1.3 A minimum horizontal distance of 20 ft. from pressure/vacuum valve.
- 5.1.4 Processor must be located so there is a 2 ft. clearance on all sides for maintenance.
- 5.1.5 Remote from wheel traffic, foot traffic, and valuable ground level space.
- 5.1.6 Ease of pipe run to processor from underground storage tanks(s). Typically the processor connects to the storage tank vent pipes. However, the processor can be connected to any tank fitting except for the dispenser's vapor return pipe. Note, the vapor piping must slope 1/8" per foot to prevent condensate from blocking vapor path. A slope of 1/4" per foot is recommended. (See section 7.2.2 and FIGURE 8)
- 5.1.7 Ease of conduit run to Indicator Panel.
- 5.1.8 Do not locate processor on property easement. Consult local authority, such as City Hall, to determine width of set back from property line.

The preferred location for the processor is on the roof of the building to which the vent pipes attach. Many other locations are also practical such as ground mount, canopy mount, roof mount on a remote building, and satellite mount as noted in Figures 1 through 4.

Note, Satellite Vapor Pipe (Figure 4) arrangement is for situations where it is impractical to connect processor to storage tank vent pipes. It features a high pipe loop to insure that a storage tank overfill should not allow liquid gasoline to be sent to the processor. For this configuration, the storage tank vent pipes still need to be manifolded together and connected to at least one P/V Valve.

FIGURE 1: Ground Mount







FIGURE 2: Canopy Mount









## 5.2 ASSEMBLY OF LEGS TO PROCESSOR

Please refer to FIGURE 5, the processor general arrangement drawing, for the following instructions.




Ground level mount requires the use of the 48" Legs, and canopy or roof mount will require the 5" or longer Legs. If Legs not already purchased, see your local Hirt distributor.

- 5.2.1 Bolt appropriate Legs to Base of processor. Be sure to use the bolts, lock washers, and nuts provided with the Legs. Note that Legs attach behind corner angle brackets of Base, See FIGURE 6 for details.
- 5.2.2 Bolt feet to concrete, deck plate, and/or solid non-flammable structure. Note, concrete mount will require the use of (4) 1/4" DIA. X 3" RED HEAD wedge anchors (i.e. 2.5" embedment).

**WARNING:** Do not block 1.5" air gap between processor Shell and Base. This gap allows combustion air to reach thermal oxidizer. Also, keep the processor area free and clear from combustibles, keep a minimum clearance of 2 ft. all the way around processor.

## 6. INSTALLATION OF INDICATOR PANEL



Install the Indicator Panel at a location chosen for the following considerations:

- 6.1 Indoors
- 6.2 Access by attendant.
- 6.3 In view of attendant.
- 6.4 Ease of conduit run to station's main electrical panel.
- 6.5 Ease of conduit run to processor location.
- 6.6 Ease of conduit run to In Station Diagnostic System (ISD) if required

## 7. CONNECTION OF ELECTRICAL AND VAPOR PIPE


Remove Processor's Weather Cover, Shell, and electrical panel lid prior to performing the following steps.

### 7.1 ELECTRICAL POWER SUPPLY AND ISD WIRING

- 7.1.1 Note that the power to the Hirt Indicator Panel and VCS 100 processor comes through the station master switch and the emergency pump shutdown switch. See FIGURE 7.
- 7.1.2 Note, wire numbers 9, 10, & 11, and Switch Contact (Hirt P/N E88) are added when system connected to Veeder Root ISD system. Be sure to use the correct size insulated female disconnects (3/16" tab size) provided when connecting to relay inside Hirt Indicator Panel. Use of oversize female disconnect can cause nuisance ISD alarms.
- 7.1.3 Wire size should be per local electrical code for an eight (8) ampere, 120 VAC load. Be sure to include circuit protection per local code. Also, system must be electrically grounded in accordance with local codes, or in the absence of local codes, with the current edition of the National Electrical Code, ANSI/NFPA70.
- 7.1.4 Conduit access to the processor is through the bottom of the processor's electrical panel. Be sure to use a sealed cable fitting approved for use in Class I, Groups C and D, Division 2 areas where the conduit enters the panel.


# Figure 7

## FIELD WIRING FOR VCS 100 WITH V/R ISD




## 7.2 GASOLINE VAPOR SUPPLY

- 7.2.1 A vapor pipe is needed to connect the processor to the ullage of all the gasoline storage tanks. Use 2" NPT galvanized pipe for runs up to 300 ft. Usually the vapor pipe connects to the vent pipes, however, any connection to the ullage of the storage tanks, other than direct connection to the dispenser's vapor return pipe, is acceptable. See FIGURE 8.



- 7.2.2 Vapor pipe must rise continuously from storage tank ullage connection to processor connection, and it needs to be supported to prevent trapping liquid in droops or sags in the pipe. Pipe slope must be at least 1/8" per foot, but a slope of 1/4" per foot is recommended. **Also be sure to put a pipe support close to the processor to prevent placing undue stress on the Turbine.** Excessive force on Turbine can cause its seals to fail, and any leaks will require Turbine replacement.
- 7.2.3 Vapor pipe configuration must prevent liquid gasoline from reaching processor. Acceptable solutions include locating the processor 12 ft. above grade, connecting the vapor pipe to the top of the vent pipes, and installing a 12 ft. high loop. See FIGURES 1, 2, 3, and 4.
- 7.2.4 Vapor pipe connection at the processor is with (3) 3/4" NPT nipples, (1) 3/4" NPT lockable ball valve, (1) 3/4" NPT union, and (1) 3/4" NPT to 2" NPT bell reducer. Note: The ball valve is installed in the vapor pipe at the processor for maintenance and repair. The ball valve is to be left in the locked open position (Opened to UST Ullage) during normal operation. Failure to leave valve in an open position may result in a processor malfunction. Note, use no more than a 12" length of 3/4" piping components. See FIGURE 9 for details.


FIGURE 9: Typical Piping Connection to Processor



**CAUTION:** Hold processor internal pipe train with backing wrench to prevent twisting pipe train while connecting vapor piping.

7.2.5 If the ullage of the tanks is not already interconnected underground, then manifold the vent pipes together with 2" galvanized pipe at a minimum of 12 ft. above grade. See FIGURE 10 below. Note that at least (1) P/V Valve must remain connected to the manifold.

FIGURE 10: Typical Vent Pipe Manifold



## 8. START-UP


If all instructions thus far have been followed, the Vaportek® system should start itself and run automatically. Proceed with the following steps:

- 8.1 Check to see that nozzles are on their hangers and vapor hoses are connected. Check also to see that gasoline storage tank fittings (fill caps, dry breaks, drop tubes, drain valves, etc.) are seated and sealing.
- 8.2 At the Indicator Panel, turn the POWER switch ON. The green lamp on the switch should light, and the processor should have electrical power now. The green PROCESSING lamp will be lit intermittently (only when the processor is energized), and the red MALFUNCTION lamp should remain extinguished.

**WARNING:** The processor (pilot and main burner) is automatic. It will cycle its thermal oxidizer ON if vacuum diminishes in the vapor spaces and OFF if there is sufficient vacuum. Therefore use caution when working close to the thermal oxidizer. It may come ON without notice. A mirror is recommended for looking down the stack.

- 8.3 Check the pressure in storage tanks.
  - 8.3.1 If UST ullage pressure is negative (vacuum), then proceed with step 8.6.
  - 8.3.2 If the storage tank pressure is positive, check to see that turbine is running and either there is a flame at pilot burner tip or a spark. If not, reset thermal switch inside processor's electrical panel, by depressing (red) pushbutton, see FIGURE 7, Field Wiring Drawing. Turbine and spark should come on. If so, proceed with step 8.4. If turbine is not running or sparking is not present, refer to Hirt VCS 100 Troubleshooting Manual.
- 8.4 Within 1 hour, the processor pilot and main burner stages should ignite. Once a vacuum of approximately -0.40" w.c. is generated, the processor should shutoff. This indicates that the processor is completely functional and controlling itself automatically. If so, go to step 8.8. If the stages don't ignite within 1 hour or if your work schedule is such that waiting 1 hour is inconvenient then continue with the following step 8.5.

8.5 The turbine in the processor should be running and the igniter/sensor probe sparking but the pilot will not be ignited. Failure of the pilot to ignite is probably because the station's vapor piping is full of air. To purge this air and replace it with vapor, use 2 short pieces of wire and jump the circuit from terminal [1] to [6] and [6] to [7] at the terminal strip inside the electrical panel inside the processor.





Note on the ELECTRICAL SCHEMATIC that a [1] to [6] jumper energizes the turbine, ignition module, and pilot solenoid. A [6] to [7] jumper energizes the main solenoid.

As soon as the air is purged from the vapor piping, approximately 15 minutes, the pilot and main stages will both ignite. **As soon as pilot and main ignite, the 2 jumpers must be removed.** If so, go to step 8.8.


If the stages do not ignite after 15 minutes, go to step 8.7.

8.6 The processor will not turn on if the vacuum sensor/switch is satisfied. Therefore, any air in the vapor piping will need to be purged so the processor stages can ignite when storage tank vacuum decays. To purge this air and replace it with vapor, use 2 short pieces of wire and jump the circuit from Terminal [1] to [6] and [6] to [7] at the terminal strip inside the electrical panel inside the processor. Note on the ELECTRICAL SCHEMATIC that a [1] to [6] jumper energizes the turbine, igniter, and pilot solenoid. A [6] to [7] jumper energizes the main solenoid. As soon as the air is purged from the vapor piping, approximately 15 minutes, the pilot and main stages will both ignite. As soon as pilot and main ignite, the 2 jumpers must be removed. If so, go to step 8.8. If the stages do not ignite after 15 minutes, go to step 8.7.

8.7 If the pilot and main do not ignite after the jumpers have been connected for 15 minutes, it is probably because there is an air leak in the vapor piping and air is entering as fast as it is being purged.


First remove the jumper wires. To find leak(s), conduct ARB test procedure TP-201.3 and Exhibit 4 (Items to consider when conducting TP-201.3). Check the pipe fittings, vent riser manifold, PV valve, storage tank fill tube caps, dry break gaskets and cover cap gaskets, hoses, nozzles, and vapor valves – any place where air could be entering the UST ullage space. Correct leaks and then go back to step 8.3.

- 8.8 Check setting of Pilot Needle Valve adjustment. The valve is used to adjust the length of the (2) tongues of flame at the pilot burner. The ideal pilot flames are approximately 1" long, blue in color, with yellow tips. One flame tongue licks the Spark Probe/Rod. The factory setting for the Pilot Needle Valve is 2 1/4 turns open. A small adjustment may be necessary to achieve the ideal flame length. If required, adjust the black knob on the Needle Valve more open or closed until ideal flame setting is achieved. See FIGURE 11.



- 8.9 Installation and start-up are now complete. Turn off power to processor. Replace lid on electrical panel, Shell, and Weather Cover. If desired, the station owner can add padlocks to prevent tampering, see FIGURE 12 below. **Ensure the 3/4" ball valve at the processor inlet is in the locked open position (Opened to UST Ullage).** Turn on power to processor. The processor is now in normal, automatic mode.

FIGURE 12



## **9. MAINTENANCE INSTRUCTIONS**

The Hirt VCS 100 Vaportek® vapor processor must be inspected and tested annually. The technician must perform the Hirt VCS 100 Operability Test Procedure (reference Executive Order VR 203/204, Exhibit 13) and complete the Hirt VCS 100 Annual Inspection Checklist. See Section 3 of the Installation, Operation, and Maintenance Manual for requirements. The Annual Inspection Checklist is to be left with the site's maintenance records.

## **10. REPAIR AND REPLACEMENT OF COMPONENTS**

Any Hirt VCS 100 Vaportek® system components which have failed cannot be repaired. Failed components must be replaced. In order to maintain the product warranty, use only genuine Hirt replacement parts. Each component comes with its own written instructions covering replacement and testing to insure proper installation and operation.

## 11. PRODUCT WARRANTY

- This product has a 12 month warranty, which becomes effective at time of installation. This warranty applies to the initial purchaser and any subsequent purchasers, during the warranty period.
- This product is warranted to meet all the applicable performance standards and specifications, for the duration of the warranty period.
- Liability under any implied or expressed warranty is limited to replacement of the product.
- HCE is not responsible for improperly installed or misuse of the product.
- HCE cannot be held responsible for damage to the product or its equipment due to acts of nature, vandalism, or neglect.
- HCE products are warranted to be free of defects in material and workmanship.
- In the event of a warranty claim, the purchaser must obtain a Return Authorization Number prior to returning product. All shipping costs are the responsibility of the customer.
- HCE shall repair or replace, at its option, any HCE component which proves to be defective.
- The cost of labor for any field repair, removal, replacement, or diagnosis is not covered by this warranty.
- The liability of HCE is limited solely and specifically to this warranty.
- HCE shall not be liable for any special, collateral, or consequential damages arising from this warranty, the use of this equipment or from any order accepted pursuant thereto.
- The use of parts not authorized by HCE voids the warranty.
- Installation, start-up, service, or repairs of this product by personnel not certified HCE voids the above described warranty.

# INSTALLATION INSTRUCTIONS for HEALY SYSTEMS, INC. CLEAN AIR SEPARATOR

The Model 9961 or 9961H, Healy Systems Clean Air Separator (CAS) consists of a 400 gallon steel vapor processor vessel that contains a fuel resistant bladder to hold excess gasoline vapors that may develop in gasoline storage tanks during idle periods of gasoline dispensing facility operation. Models and Drawings with a "H" suffix apply to horizontal CAS installations and those without a "H" suffix apply to vertical CAS installations. The CAS assembly weighs approximately 800 pounds which makes it necessary to have a power assisted lifting device available at the installation site to remove the CAS from the transportation vehicle and place it on the required concrete pad (see drawing 9900-9945 or 9900-9945H). The pad (level within 1/8"/foot) is located within 100 feet to the gasoline storage tank vent lines. The pad is a requirement of this installation. **DO NOT PLACE THE CLEAN AIR SEPARATOR DIRECTLY ON THE GROUND OR ASPHALT SURFACE.** NOTICE: The installer is responsible to ensure that the installation meets the latest edition requirements of NFPA 30A, Chapter 10. No electrical connections are required. The CAS securement method shown in drawing 9900-9945 or 9900-9945H shall be approved by the local authority having jurisdiction with respect to wind and seismic loading. Installer shall not loosen, rotate or remove factory installed fittings or flange as this may damage factory seals and void warranty.

In addition to the vapor processor vessel, there is a hardware kit that contains the following:

- 4 Locking 1" NPT Ball Valves
- 4 Pad locks (keyed alike)
- 1 Breather Assembly, Healy Model 9948
- 1 Float Check Valve Assembly, Model 9466G

Reference the appropriate Healy Systems installation drawing (9900-9942, 9900-9942H, 9900-9971, 9900-9971H, 9900-9972, 9900-9972H, 9900-9973 or 9900-9973H of this manual) for placement of the above parts for the vent stack configuration required by the local Authority Having Jurisdiction (AHJ) for the Underground Storage Tank (UST) system. **A flexible connection between the Clean Air Separator and the vent line(s) is allowable if required by the local Authority Having Jurisdiction (AHJ) to meet seismic requirements. Should the flex connection be installed such that it is not supported, the slope of the flex connection shall be greater than the 1/8"/foot slope required for the rest of the one inch galvanized piping.** The local contractor is responsible to provide all necessary, galvanized piping, non-hardening, UL classified pipe joint compound and plumbing fittings. Additional Pressure/Vacuum (P/V) vent valves to complete installation are not included in the hardware kit. Healy is not responsible for the warranty of any other P/V vent valve purchased to complete installation.

The CAS arrives at the site assembled and tested. All plumbing shall be done using 1" galvanized steel pipe (Schedule 40) and approved nipples, as called out in the installation drawing appropriate for the site installation. Mounting hardware shall be galvanized or stainless steel. Careful attention must be paid to the installation drawing appropriate for the site installation to assure proper operation of the bladder system. Do not inflate the bladder assembly after installation.

It is important that the CAS be secured to the concrete pad as shown in drawing 9900-9945 or 9900-9945H of this manual to prevent any unintentional repositioning of the CAS as the connecting plumbing to the vent system is accomplished.

## OPERATION AND PURGING

### NORMAL OPERATION:


- There are four ball valves on the CAS. Each ball valve is to be installed so as to allow opening and closing with nothing obstructing the full range (90°) of movement. In normal operation, only the valve (A) at the top of the CAS shall be open – the other three valves (B, C and D) shall be closed. All four valves shall be locked in the above positions. The two plugs (E and F) should be installed using a non-hardening, UL classified pipe joint compound and tightened to 60 ft-lbs.

### DRAINING THE BLADDER:

- Any liquid coming over from the vent system would have collected above the valve (A) in the riser pipe before going into the bladder. An inspection of the need to drain the bladder is easily made by removing the plug (E) at the tee on the bottom plumbing of the CAS. Before removing this plug, open the valve (B) above the tee to release any liquid into the piping below. Wait approximately 30 seconds and then close the valve (B). Now, remove the plug (E) at the tee on the bottom plumbing of the CAS – be sure to have a container suitable for gasoline available to catch fluid. If liquid in excess of 16 ounces (473 ml) drains out, the bladder should also be drained.
- Should it be necessary to drain the bladder:
  1. Close the upper ball valve (A) (usually open) leading to the gasoline storage tank vent lines.
  2. Open the valve (C) that goes to the internal syphon tube. Be sure the other three ball valves (A, B and D) that connect to the vent lines and CAS are closed.
  3. Remove the plug (E) from the bottom tee and connect an explosion proof evacuation pump capable of handling liquid. Have a liquid tight, container suitable for gasoline positioned to receive any fluid that may exit the system and start the pump. If no liquid returns within 30 seconds, the bladder is dry – discontinue pumping, remove the pump, replace the plug (E) and return the ball valves to their normal, locked, positions.


### DRAINING THE CAS:

- Should it be necessary to drain the CAS (between the bladder and steel wall):
  1. Close the ball valve at the top (A) of the CAS and also the two valves (B and C) on the vertical risers.
  2. Remove the plug (E) in the bottom tee and place a metal container below the pipe opening.
  3. Carefully open the ball valve (D) at the bottom of the CAS – observe that the container that is being drained into does not overflow – empty container as required until fluid no longer comes from the pipe when the valve is open.
  4. Close the ball valve (D) and replace the plug (E) into the tee.
  5. Return all ball valves to their normal locked positions.




SECTION @ CAS SLAB  
SCALE = 3/4" = 1'-0"

**CRITERIA**  
 SOIL BEARING 1000 psf  
 BASIC WIND SPEED 100mph  
 SEISMIC  $S_s = 2g$   
 $S_m = 1g$   
 MIN. CONCRETE COMP STRENGTH,  $f'_c = 2500$  psi  
 MIN. REINF. YIELD STRENGTH,  $f_y = 40000$  psi



BASE PLAN  
SCALE = 3/4" = 1'-0"

NOTE:  $\Delta$  WHERE ICC-ES ACCEPTANCE CRITERIA IS NOT REQUIRED,  
 5/8" X 6" HILTI KWIK BOLT 3 @ 4" EMBEDMENT MIN.  
 CAN BE USED (PER ESR-1385 REPORT, ISSUED 09/01/04).



TYPICAL HOLD DOWN CLIP  
SCALE = NONE

|     |   |        |          |          |
|-----|---|--------|----------|----------|
| 7   | ADDED CAS DIMENSIONS, REVISED CRITERIA LIST           | -      | TF<br>MB | 01/02/08 |
| 6   | KB-TZ SS WAS KB3, ESR-1917 WAS ESR-1385, ADDED NOTE 1 | -      | TF<br>MB | 12/21/07 |
| REV | DESCRIPTION   | ECN NO | BY       | DATE     |




|  |   |                               |
|--|---|-------------------------------|
| The information disclosed herein includes proprietary rights of Franklin Fueling Systems, Inc. Neither this drawing nor the information disclosed thereon may be reproduced or transferred to other documents, or used or disclosed to others for any purpose, except as specifically authorized in writing by Franklin Fueling Systems. This drawing must be returned to Franklin Fueling Systems upon request. | MATERIAL:   |                               |
|  | DO NOT SCALE DRAWING                                  | .XX ± .02                     |
|  | STANDARD INCH TOLERANCES (UNLESS OTHERWISE SPECIFIED) | .XXX ± .005<br>ANGULAR ± 1/2° |
|  | SPECIAL DIST:   |                               |

|   |                   |                      |              |
|---|-------------------|----------------------|--------------|
| TITLE:<br>CLEAN AIR SEPARATOR MOUNTING SLAB DETAILS |                   |                      |              |
| DRAWN:<br>JWH                                       | DATE:<br>07/31/02 | DRW NO:<br>9900-9945 | SUFFIX:      |
| APPRVL:   | DATE:             | SCALE: 1/8           | SHEET 1 OF 1 |



DRW NO: 9900-9945H



SECTION @ CAS SLAB

**CRITERIA**


SOIL BEARING 1000 psf  
 BASIC WIND SPEED 100mph  
 SEISMIC  $S_s=2g$   
 $S_{st}=1g$   
 MIN. CONCRETE COMP STRENGTH,  $f'_c = 2500$  psi  
 MIN. REINF. YIELD STRENGTH,  $f_y = 40000$  psi

The information disclosed hereon includes proprietary rights of Franklin Fueling Systems, Inc. Neither this drawing nor the information disclosed thereon may be reproduced or transferred to other documents, or used or disclosed to others for any purpose, except as specifically authorized in writing by Franklin Fueling Systems. This drawing must be returned to Franklin Fueling Systems upon request.

**MATERIAL:**

DO NOT SCALE DRAWING .XX ± .02  
 STANDARD INCH TOLERANCES .XXX ± .005  
 (UNLESS OTHERWISE SPECIFIED) ANGULAR ± 1/2°

**SPECIAL DIST:**



BASE PLAN

NOTE:  $\Delta$  WHERE ICC-ES ACCEPTANCE CRITERIA IS NOT REQUIRED,  
 5/8" X 6" HILTI KWIK BOLT 3 @ 4" EMBEDMENT MIN.  
 CAN BE USED (PER ESR-1385 REPORT, ISSUED 09/01/04).

| REV | DESCRIPTION   | ECN NO | BY       | DATE     |
|-----|---|--------|----------|----------|
| 5   | ADDED CAS DIMENSIONS, REVISED CRITERIA LIST           | -      | TF<br>MB | 01/02/08 |
| 4   | KB-TZ SS WAS KB3, ESR-1917 WAS ESR-1385, ADDED NOTE 1 | -      | TF<br>MB | 12/21/07 |




**Franklin Fueling Systems**

Madison, WI 53718

TITLE: CLEAN AIR SEPARATOR HORIZONTAL MOUNTING SLAB DETAILS

|             |                |                   |              |
|-------------|----------------|-------------------|--------------|
| DRAWN: TF   | DATE: 05/22/07 | DRW NO: 9900-9945 | SUFFIX: H    |
| APPRVL: MDB | DATE: 06/05/07 | SCALE: 3/4"=1'    | SHEET 1 OF 1 |



**NOTICE**


DRAWINGS ARE TWO DIMENSIONAL REPRESENTATION OF TYPICAL CLEAN AIR SEPARATOR (CAS) INSTALLATION. ACTUAL CAS INSTALLATIONS WILL VARY SLIGHTLY FROM THE REPRESENTATION SHOWN.

INSTALLER SHALL NOT LOOSEN, ROTATE OR REMOVE FACTORY INSTALLED FITTINGS OR FLANGE AS THIS MAY DAMAGE FACTORY SEALS AND VOID WARRANTY.

- NOTE:**
- 1 - ALL BALL VALVES (B.V.) TO BE UL LISTED AND HAVE PADLOCK FEATURE.
  - 2 - PASSIVE PRESSURE CONTROL-NO ELECTRICAL POWER REQUIRED.
  - 3 - AIR BREATHER MUST BE INSTALLED AT A MINIMUM HEIGHT OF 12' ABOVE GRADE.
  - 4 - VENT LINE TIE IN CAN BE INSTALLED ANYWHERE ALONG THE VENT STACK LINE PROVIDED THAT PIPE SLOPE IS MAINTAINED AND THE CHECK VALVE IS IN THE CORRECT VERTICAL INSTALLATION.
  - 5 - ONLY GALVANIZED PIPE IS TO BE USED FOR PIPING CONNECTIONS
- △** - A FLEXIBLE CONNECTION BETWEEN THE CLEAN AIR SEPARATOR AND THE VENT LINE(S) IS ALLOWABLE IF REQUIRED BY THE LOCAL AUTHORITY HAVING JURISDICTION (AHJ) TO MEET SEISMIC REQUIREMENTS. SHOULD THE FLEX CONNECTION BE INSTALLED SUCH THAT IT IS NOT SUPPORTED, THE SLOPE OF THE FLEX CONNECTION SHALL BE GREATER THAN THE 1/8" PER FOOT SLOPE REQUIRED FOR THE REST OF THE ONE INCH GALVANIZED PIPING.

|  |           |   |                               |
|--|-----------|---|-------------------------------|
| The information disclosed herein includes proprietary rights of Franklin Fueling Systems, Inc. Neither this drawing nor the information disclosed thereon may be reproduced or transferred to other documents, or used or disclosed to others for any purpose, except as specifically authorized in writing by Franklin Fueling Systems. This drawing must be returned to Franklin Fueling Systems upon request. |           | <b>MATERIAL:</b>                                      |                               |
| DO NOT SCALE DRAWING   | .XX ± .02 | STANDARD INCH TOLERANCES (UNLESS OTHERWISE SPECIFIED) | .XXX ± .005<br>ANGULAR ± 1/2° |
| SPECIAL DIST:  |           |   |                               |

|  |              |          |          |          |
|--|--------------|----------|----------|----------|
| 15   | ADDED NOTE 6 | 401666   | TF       | 03/20/08 |
| REV  | DESCRIPTION  | ECN NO   | BY       | DATE     |
| <b>Franklin Fueling Systems</b><br>Madison, WI 53718       |              |          |          |          |
| <b>TITLE:</b><br>CLEAN AIR SEPARATOR VERTICAL INSTALLATION |              |          |          |          |
| DRW NO:  | DATE:        | DATE:    | DATE:    | SUFFIX:  |
| 9900-9942  | 05/14/02     | 06/05/07 | 06/05/07 |          |
| ACAD HLY   | SCALE:       | N.T.S.   | SHEET 1  | OF 1     |



**NOTICE**

DRAWINGS ARE TWO DIMENSIONAL REPRESENTATION OF TYPICAL CLEAN AIR SEPARATOR (CAS) INSTALLATION. ACTUAL CAS INSTALLATIONS WILL VARY SLIGHTLY FROM THE REPRESENTATION SHOWN.

INSTALLER SHALL NOT LOOSEN, ROTATE OR REMOVE FACTORY INSTALLED FITTINGS OR FLANGE AS THIS MAY DAMAGE FACTORY SEALS AND VOID WARRANTY.

- NOTE:**
- 1 - ALL BALL VALVES (B.V.) TO BE UL LISTED AND HAVE PADLOCK FEATURE.
  - 2 - PASSIVE PRESSURE CONTROL-NO ELECTRICAL POWER REQUIRED.
  - 3 - AIR BREATHER MUST BE INSTALLED AT A MINIMUM HEIGHT OF 12' ABOVE GRADE.
  - 4 - VENT LINE TIE IN CAN BE INSTALLED ANYWHERE ALONG THE VENT STACK LINE PROVIDED THAT PIPE SLOPE IS MAINTAINED AND THE CHECK VALVE IS IN THE CORRECT VERTICAL INSTALLATION.
  - 5 - ONLY GALVANIZED PIPE IS TO BE USED FOR PIPING CONNECTIONS
- △ - A FLEXIBLE CONNECTION BETWEEN THE CLEAN AIR SEPARATOR AND THE VENT LINE(S) IS ALLOWABLE IF REQUIRED BY THE LOCAL AUTHORITY HAVING JURISDICTION (AHJ) TO MEET SEISMIC REQUIREMENTS. SHOULD THE FLEX CONNECTION BE INSTALLED SUCH THAT IT IS NOT SUPPORTED, THE SLOPE OF THE FLEX CONNECTION SHALL BE GREATER THAN THE 1/8" PER FOOT SLOPE REQUIRED FOR THE REST OF THE ONE INCH GALVANIZED PIPING.


| 8   | ADDED NOTE 6   | 401666            | TF            | 03/20/08     |
|---|----------------|-------------------|---------------|--------------|
| REV   | DESCRIPTION    | EON NO            | BY            | DATE         |
| <b>Franklin Fueling Systems</b><br><small>Madison, WI 53718</small> |                |                   |               |              |
| <b>TITLE: CLEAN AIR SEPARATOR VERTICAL INSTALLATION (1 VENT)</b>    |                |                   |               |              |
| DRAWN: JWH  | DATE: 05/14/02 | DRW NO: 9900-9971 | SUFFIX:       |              |
| APPRVL: MDB   | DATE: 06/05/07 | ACAD HLY          | SCALE: N.T.S. | SHEET 1 OF 1 |

The information disclosed hereon includes proprietary rights of Franklin Fueling Systems, Inc. Neither this drawing nor the information disclosed thereon may be reproduced or transferred to other documents, or used or disclosed to others for any purpose, except as specifically authorized in writing by Franklin Fueling Systems. This drawing must be returned to Franklin Fueling Systems upon request.

**MATERIAL:**

|   |                |
|---|----------------|
| DO NOT SCALE DRAWING                                  | .XX ± .02      |
| STANDARD INCH TOLERANCES (UNLESS OTHERWISE SPECIFIED) | .XXX ± .005    |
|   | ANGULAR ± 1/2° |

**SPECIAL DIST:**



**NOTICE**

DRAWINGS ARE TWO DIMENSIONAL REPRESENTATION OF TYPICAL CLEAN AIR SEPARATOR (CAS) INSTALLATION. ACTUAL CAS INSTALLATIONS WILL VARY SLIGHTLY FROM THE REPRESENTATION SHOWN.

INSTALLER SHALL NOT LOOSEN, ROTATE OR REMOVE FACTORY INSTALLED FITTINGS OR FLANGE AS THIS MAY DAMAGE FACTORY SEALS AND VOID WARRANTY.

- NOTE:**
- 1 - ALL BALL VALVES (B.V.) TO BE UL LISTED AND HAVE PADLOCK FEATURE.
  - 2 - PASSIVE PRESSURE CONTROL-NO ELECTRICAL POWER REQUIRED.
  - 3 - AIR BREATHER MUST BE INSTALLED AT A MINIMUM HEIGHT OF 12' ABOVE GRADE ON 1" PIPE.
  - 4 - VENT LINE TIE IN CAN BE INSTALLED ANYWHERE ALONG THE VENT STACK LINE PROVIDED THAT PIPE SLOPE IS MAINTAINED AND THE CHECK VALVE IS IN THE CORRECT VERTICAL INSTALLATION.
  - 5 - ONLY GALVANIZED PIPE IS TO BE USED FOR PIPING CONNECTIONS
  - 6 - HCAS TO SLOPE SLIGHTLY TOWARD CONDENSATE DRAIN. PITCH SLAB WITHIN 1/8" INCH/FOOT TOWARD CONDENSATE DRAIN END OR SHIM HCAS FOR PROPER VESSEL DRAINAGE.
- △** - A FLEXIBLE CONNECTION BETWEEN THE CLEAN AIR SEPARATOR AND THE VENT LINE(S) IS ALLOWABLE IF REQUIRED BY THE LOCAL AUTHORITY HAVING JURISDICTION (AHJ) TO MEET SEISMIC REQUIREMENTS. SHOULD THE FLEX CONNECTION BE INSTALLED SUCH THAT IT IS NOT SUPPORTED, THE SLOPE OF THE FLEX CONNECTION SHALL BE GREATER THAN THE 1/8" PER FOOT SLOPE REQUIRED FOR THE REST OF THE ONE INCH GALVANIZED PIPING.

BALL VALVE P/N 996123  
 LOCK P/N 996124  
 KEY P/N 996125


The information disclosed hereon includes proprietary rights of Franklin Fueling Systems, Inc. Neither this drawing nor the information disclosed thereon may be reproduced or transferred to other documents, or used or disclosed to others for any purpose, except as specifically authorized in writing by Franklin Fueling Systems. This drawing must be returned to Franklin Fueling Systems upon request.

**MATERIAL:**

|   |                |
|---|----------------|
| DO NOT SCALE DRAWING                                  | .XX ± .02      |
| STANDARD INCH TOLERANCES (UNLESS OTHERWISE SPECIFIED) | .XXX ± .005    |
|   | ANGULAR ± 1/2° |
| SPECIAL DIST:   |                |

|  |              |           |         |          |
|--|--------------|-----------|---------|----------|
| 7  | ADDED NOTE ? | 401666    | TF      | 03/20/08 |
| REV  | DESCRIPTION  | ECN NO    | BY      | DATE     |
| <b>Franklin Fueling Systems</b><br>Madison, WI 53718         |              |           |         |          |
| <b>TITLE:</b><br>CLEAN AIR SEPARATOR HORIZONTAL INSTALLATION |              |           |         |          |
| DRAWN:   | DATE:        | DRW NO:   | SUFFIX: |          |
| TF   | 05/23/07     | 9900-9942 | H       |          |
| APPRVL:  | DATE:        | SCALE:    | SHEET   |          |
| MDB  | 06/05/07     | N.T.S.    | 1 OF 1  |          |

DRW NO: 9900-9972



**NOTICE**

DRAWINGS ARE TWO DIMENSIONAL REPRESENTATION OF TYPICAL CLEAN AIR SEPARATOR (CAS) INSTALLATION. ACTUAL CAS INSTALLATIONS WILL VARY SLIGHTLY FROM THE REPRESENTATION SHOWN.


INSTALLER SHALL NOT LOOSEN, ROTATE OR REMOVE FACTORY INSTALLED FITTINGS OR FLANGE AS THIS MAY DAMAGE FACTORY SEALS AND VOID WARRANTY.

- NOTE:**
- 1 - ALL BALL VALVES (B.V.) TO BE UL LISTED AND HAVE PADLOCK FEATURE.
  - 2 - PASSIVE PRESSURE CONTROL-NO ELECTRICAL POWER REQUIRED.
  - 3 - AIR BREATHER MUST BE INSTALLED AT A MINIMUM HEIGHT OF 12" ABOVE GRADE.
  - 4 - VENT LINE TIE IN CAN BE INSTALLED ANYWHERE ALONG THE VENT STACK LINE PROVIDED THAT PIPE SLOPE IS MAINTAINED AND THE CHECK VALVE IS IN THE CORRECT VERTICAL INSTALLATION.
  - 5 - ONLY GALVANIZED PIPE IS TO BE USED FOR PIPING CONNECTIONS
- △** - A FLEXIBLE CONNECTION BETWEEN THE CLEAN AIR SEPARATOR AND THE VENT LINE(S) IS ALLOWABLE IF REQUIRED BY THE LOCAL AUTHORITY HAVING JURISDICTION (A.H.J) TO MEET SEISMIC REQUIREMENTS. SHOULD THE FLEX CONNECTION BE INSTALLED SUCH THAT IT IS NOT SUPPORTED, THE SLOPE OF THE FLEX CONNECTION SHALL BE GREATER THAN THE 1/8" PER FOOT SLOPE REQUIRED FOR THE REST OF THE ONE INCH GALVANIZED PIPING.

|   |              |           |         |                     |          |
|---|--------------|-----------|---------|---------------------|----------|
| 8   | ADDED NOTE 6 | 401666    | TF      | MDB                 | 03/20/08 |
| REV   | DESCRIPTION  | ECN NO    | BY      | DATE                |          |
| <b>Franklin Fueling Systems</b><br><small>Madison, WI 53718</small> |              |           |         |                     |          |
| TITLE: CLEAN AIR SEPARATOR VERTICAL INSTALLATION (2 VENT)           |              |           |         |                     |          |
| DRAWN:  | DATE:        | DRW NO:   | SUFFIX: |                     |          |
| JWH   | 05/14/02     | 9900-9972 |         |                     |          |
| APPRVL:   | DATE:        | ACAD HLY  | SCALE:  | N.T.S. SHEET 1 OF 1 |          |
| MDB   | 06/05/07     |           |         |                     |          |

|   |   |                               |
|---|---|-------------------------------|
| <p>The information disclosed hereon includes proprietary rights of Franklin Fueling Systems, Inc. Neither this drawing nor the information disclosed thereon may be reproduced or transferred to other documents, or used or disclosed to others for any purpose, except as specifically authorized in writing by Franklin Fueling Systems. This drawing must be returned to Franklin Fueling Systems upon request.</p> | <b>MATERIAL:</b>                                      |                               |
|   | DO NOT SCALE DRAWING                                  | .XX ± .02                     |
|   | STANDARD INCH TOLERANCES (UNLESS OTHERWISE SPECIFIED) | .XXX ± .005<br>ANGULAR ± 1/2' |
|   | SPECIAL DIST:   |                               |

ARB Approved ID# 17 - Healy Clean Air Separator Model 9961 and 9961H - Executive Orders VR-203 and VR-204 17-8



**NOTICE**

DRAWINGS ARE TWO DIMENSIONAL REPRESENTATION OF TYPICAL CLEAN AIR SEPARATOR (CAS) INSTALLATION. ACTUAL CAS INSTALLATIONS WILL VARY SLIGHTLY FROM THE REPRESENTATION SHOWN.

INSTALLER SHALL NOT LOOSEN, ROTATE OR REMOVE FACTORY INSTALLED FITTINGS OR FLANGE AS THIS MAY DAMAGE FACTORY SEALS AND VOID WARRANTY.


- NOTE:**
- 1 - ALL BALL VALVES (B.V.) TO BE UL LISTED AND HAVE PADLOCK FEATURE.
  - 2 - PASSIVE PRESSURE CONTROL-NO ELECTRICAL POWER REQUIRED.
  - 3 - AIR BREATHER MUST BE INSTALLED AT A MINIMUM HEIGHT OF 12' ABOVE GRADE ON 1" PIPE.
  - 4 - VENT LINE TIE IN CAN BE INSTALLED ANYWHERE ALONG THE VENT STACK LINE PROVIDED THAT PIPE SLOPE IS MAINTAINED AND THE CHECK VALVE IS IN THE CORRECT VERTICAL INSTALLATION.
  - 5 - ONLY GALVANIZED PIPE IS TO BE USED FOR PIPING CONNECTIONS
  - 6 - HCAS TO SLOPE SLIGHTLY TOWARD CONDENSATE DRAIN. PITCH SLAB WITHIN 1/8 INCH/FOOT TOWARD CONDENSATE DRAIN END OR SHIM HCAS FOR PROPER VESSEL DRAINAGE.
- ▲ - A FLEXIBLE CONNECTION BETWEEN THE CLEAN AIR SEPARATOR AND THE VENT LINE(S) IS ALLOWABLE IF REQUIRED BY THE LOCAL AUTHORITY HAVING JURISDICTION (AHJ) TO MEET SEISMIC REQUIREMENTS. SHOULD THE FLEX CONNECTION BE INSTALLED SUCH THAT IT IS NOT SUPPORTED, THE SLOPE OF THE FLEX CONNECTION SHALL BE GREATER THAN THE 1/8" PER FOOT SLOPE REQUIRED FOR THE REST OF THE ONE INCH GALVANIZED PIPING.

BALL VALVE P/N 996123  
 LOCK P/N 996124  
 KEY P/N 996125

The information disclosed hereon includes proprietary rights of Franklin Fueling Systems, Inc. Neither this drawing nor the information disclosed thereon may be reproduced or transferred to other documents, or used or disclosed to others for any purpose, except as specifically authorized in writing by Franklin Fueling Systems. This drawing must be returned to Franklin Fueling Systems upon request.

|   |                |
|---|----------------|
| <b>MATERIAL:</b>                                      |                |
| DO NOT SCALE DRAWING                                  | XX ± .02       |
| STANDARD INCH TOLERANCES (UNLESS OTHERWISE SPECIFIED) | .XXX ± .005    |
| SPECIAL DIST:   | ANGULAR ± 1/2" |

|   |                          |                             |                     |                |          |
|---|--------------------------|-----------------------------|---------------------|----------------|----------|
| 7   | ADDED NOTE 7             | 401666                      | TF                  | MDB            | 03/20/08 |
| REV   | DESCRIPTION              | ECN NO                      | BY                  | DATE           |          |
| <b>Franklin Fueling Systems</b><br><small>Madison, WI 53718</small>         |                          |                             |                     |                |          |
| <b>TITLE:</b><br>CLEAN AIR SEPARATOR HORIZONTAL INSTALLATION (1 VENT VALVE) |                          |                             |                     |                |          |
| <b>DRAWN:</b><br>TF   | <b>DATE:</b><br>05/22/07 | <b>DRW NO:</b><br>9900-9971 | <b>SUFFIX:</b><br>H |                |          |
| <b>APPRVL:</b><br>MDB   | <b>DATE:</b><br>06/05/07 | <b>SCALE:</b><br>N.T.S.     | <b>SHEET</b><br>1   | <b>OF</b><br>1 |          |



**NOTICE**

DRAWINGS ARE TWO DIMENSIONAL REPRESENTATION OF TYPICAL CLEAN AIR SEPARATOR (CAS) INSTALLATION. ACTUAL CAS INSTALLATIONS WILL VARY SLIGHTLY FROM THE REPRESENTATION SHOWN.


INSTALLER SHALL NOT LOOSEN, ROTATE OR REMOVE FACTORY INSTALLED FITTINGS OR FLANGE AS THIS MAY DAMAGE FACTORY SEALS AND VOID WARRANTY.

- NOTE:**
- 1 - ALL BALL VALVES (B.V.) TO BE UL LISTED AND HAVE PADLOCK FEATURE.
  - 2 - PASSIVE PRESSURE CONTROL-NO ELECTRICAL POWER REQUIRED.
  - 3 - AIR BREATHER MUST BE INSTALLED AT A MINIMUM HEIGHT OF 12' ABOVE GRADE.
  - 4 - VENT LINE TIE IN CAN BE INSTALLED ANYWHERE ALONG THE VENT STACK LINE PROVIDED THAT PIPE SLOPE IS MAINTAINED AND THE CHECK VALVE IS IN THE CORRECT VERTICAL INSTALLATION.
  - 5 - ONLY GALVANIZED PIPE IS TO BE USED FOR PIPING CONNECTION
- △** - A FLEXIBLE CONNECTION BETWEEN THE CLEAN AIR SEPARATOR AND THE VENT LINE(S) IS ALLOWABLE IF REQUIRED BY THE LOCAL AUTHORITY HAVING JURISDICTION (AHJ) TO MEET SEISMIC REQUIREMENTS. SHOULD THE FLEX CONNECTION BE INSTALLED SUCH THAT IT IS NOT SUPPORTED, THE SLOPE OF THE FLEX CONNECTION SHALL BE GREATER THAN THE 1/8" PER FOOT SLOPE REQUIRED FOR THE REST OF THE ONE INCH GALVANIZED PIPING.

|  |              |                                  |              |          |
|--|--------------|----------------------------------|--------------|----------|
| 8  | ADDED NOTE 6 | 401666                           | TF           | 03/20/08 |
| REV  | DESCRIPTION  | ECN NO                           | BY           | DATE     |
| <b>Franklin Fuelling Systems</b>                   |              | <small>Molokai, HI 53718</small> |              |          |
| TITLE:   |              | DRAWING NO:                      |              |          |
| CLEAN AIR SEPARATOR VERTICAL INSTALLATION (3 VENT) |              | 9900-9973                        |              |          |
| DRAWN:   | DATE:        | APPROVED:                        | DATE:        | SUFFIX:  |
| JWH  | 05/14/02     | MDB                              | 06/05/07     |          |
| SPECIAL DIST:                                      |              | SCALE:                           | SHEET 1 OF 1 |          |
|  |              | ACAD HLY                         | N.T.S.       |          |

The information disclosed hereon includes proprietary rights of Franklin Fuelling Systems, Inc. Neither this drawing nor the information disclosed thereon may be reproduced or transferred to other documents, or used or disclosed to others for any purpose, except as specifically authorized in writing by Franklin Fuelling Systems, Inc. This drawing must be returned to Franklin Fuelling Systems upon request.

|   |                |
|---|----------------|
| MATERIAL:   |                |
| DO NOT SCALE DRAWING                                  | .XX ± .02      |
| STANDARD INCH TOLERANCES (UNLESS OTHERWISE SPECIFIED) | .XXX ± .005    |
|   | ANGULAR ± 1/2° |



**NOTICE**

DRAWINGS ARE TWO DIMENSIONAL REPRESENTATION OF TYPICAL CLEAN AIR SEPARATOR (CAS) INSTALLATION. ACTUAL CAS INSTALLATIONS WILL VARY SLIGHTLY FROM THE REPRESENTATION SHOWN.

INSTALLER SHALL NOT LOOSEN, ROTATE OR REMOVE FACTORY INSTALLED FITTINGS OR FLANGE AS THIS MAY DAMAGE FACTORY SEALS AND VOID WARRANTY.

**NOTE:**

- 1 - ALL BALL VALVES (B.V.) TO BE UL LISTED AND HAVE PADLOCK FEATURE.
  - 2 - PASSIVE PRESSURE CONTROL-NO ELECTRICAL POWER REQUIRED.
  - 3 - AIR BREATHER MUST BE INSTALLED AT A MINIMUM HEIGHT OF 12' ABOVE GRADE ON 1" PIPE.
  - 4 - VENT LINE TIE IN CAN BE INSTALLED ANYWHERE ALONG THE VENT STACK LINE PROVIDED THAT PIPE SLOPE IS MAINTAINED AND THE CHECK VALVE IS IN THE CORRECT VERTICAL INSTALLATION.
  - 5 - ONLY GALVANIZED PIPE IS TO BE USED FOR PIPING CONNECTIONS.
  - 6 - HCAS TO SLOPE SLIGHTLY TOWARD CONDENSATE DRAIN. PITCH SLAB WITHIN 1/8 INCH/FOOT TOWARD CONDENSATE DRAIN END OR SHIM HCAS FOR PROPER VESSEL DRAINAGE.
- △** - A FLEXIBLE CONNECTION BETWEEN THE CLEAN AIR SEPARATOR AND THE VENT LINE(S) IS ALLOWABLE IF REQUIRED BY THE LOCAL AUTHORITY HAVING JURISDICTION (AHJ) TO MEET SEISMIC REQUIREMENTS. SHOULD THE FLEX CONNECTION BE INSTALLED SUCH THAT IT IS NOT SUPPORTED, THE SLOPE OF THE FLEX CONNECTION SHALL BE GREATER THAN THE 1/8" PER FOOT SLOPE REQUIRED FOR THE REST OF THE ONE INCH GALVANIZED PIPING.


BALL VALVE P/N 996123  
LOCK P/N 996124  
KEY P/N 996125

The information disclosed hereon includes proprietary rights of Franklin Fueling Systems, Inc. Neither this drawing nor the information disclosed thereon may be reproduced or transferred to other documents, or used or disclosed to others for any purpose, except as specifically authorized in writing by Franklin Fueling Systems. This drawing must be returned to Franklin Fueling Systems upon request.

|   |                |
|---|----------------|
| MATERIAL:   |                |
| DO NOT SCALE DRAWING                                  | .XX ± .02      |
| STANDARD INCH TOLERANCES (UNLESS OTHERWISE SPECIFIED) | .XXX ± .005    |
| SPECIAL DIST:   | ANGULAR ± 1/2° |

|                               |               |  |                      |              |
|-------------------------------|---------------|--|----------------------|--------------|
| 7                             | ADDED NOTE 7  | 401666   | TF                   | 03/20/08     |
| REV                           | DESCRIPTION   | ECN NO   | BY                   | DATE         |
|                               |               | TITLE:<br>CLEAN AIR SEPARATOR HORIZONTAL INSTALLATION (2 VENT VALVE) |                      |              |
|                               |               | DRAWN: TF<br>DATE: 05/22/07  | DRW NO:<br>9900-9972 | SUFFIX:<br>H |
| APPRVL: MDB<br>DATE: 06/05/07 | SCALE: N.T.S. | SHEET 1  | OF 1                 |              |





**NOTICE**

DRAWINGS ARE TWO DIMENSIONAL REPRESENTATION OF TYPICAL CLEAN AIR SEPARATOR (CAS) INSTALLATION. ACTUAL CAS INSTALLATIONS WILL VARY SLIGHTLY FROM THE REPRESENTATION SHOWN.

INSTALLER SHALL NOT LOOSEN, ROTATE OR REMOVE FACTORY INSTALLED FITTINGS OR FLANGE AS THIS MAY DAMAGE FACTORY SEALS AND VOID WARRANTY.

- NOTE:**
- 1 - ALL BALL VALVES (B.V.) TO BE UL LISTED AND HAVE PADLOCK FEATURE.
  - 2 - PASSIVE PRESSURE CONTROL-NO ELECTRICAL POWER REQUIRED.
  - 3 - AIR BREATHER MUST BE INSTALLED AT A MINIMUM HEIGHT OF 12' ABOVE GRADE ON 1" PIPE.
  - 4 - VENT LINE TIE IN CAN BE INSTALLED ANYWHERE ALONG THE VENT STACK LINE PROVIDED THAT PIPE SLOPE IS MAINTAINED AND THE CHECK VALVE IS IN THE CORRECT VERTICAL INSTALLATION.
  - 5 - ONLY GALVANIZED PIPE IS TO BE USED FOR PIPING CONNECTIONS
  - 6 - HCAS TO SLOPE SLIGHTLY TOWARD CONDENSATE DRAIN. PITCH SLAB WITHIN 1/8 INCH/FOOT TOWARD CONDENSATE DRAIN END OR SHIM HCAS FOR PROPER VESSEL DRAINAGE.
- △ - A FLEXIBLE CONNECTION BETWEEN THE CLEAN AIR SEPARATOR AND THE VENT LINE(S) IS ALLOWABLE IF REQUIRED BY THE LOCAL AUTHORITY HAVING JURISDICTION (AHJ) TO MEET SEISMIC REQUIREMENTS. SHOULD THE FLEX CONNECTION BE INSTALLED SUCH THAT IT IS NOT SUPPORTED, THE SLOPE OF THE FLEX CONNECTION SHALL BE GREATER THAN THE 1/8" PER FOOT SLOPE REQUIRED FOR THE REST OF THE ONE INCH GALVANIZED PIPING.

BALL VALVE P/N 996123  
 LOCK P/N 996124  
 KEY P/N 996125

The information disclosed hereon includes proprietary rights of Franklin Fueling Systems, Inc. Neither this drawing nor the information disclosed thereon may be reproduced or transferred to other documents, or used or disclosed to others for any purpose, except as specifically authorized in writing by Franklin Fueling Systems, Inc. This drawing must be returned to Franklin Fueling Systems upon request.

**MATERIAL:**

|   |                |
|---|----------------|
| DO NOT SCALE DRAWING                                  | .XX ± .02      |
| STANDARD INCH TOLERANCES (UNLESS OTHERWISE SPECIFIED) | .XXX ± .005    |
|   | ANGULAR ± 1/2° |
| SPECIAL DIST:   |                |

|  |                       |                                   |                  |          |
|--|-----------------------|-----------------------------------|------------------|----------|
| 7  | ADDED NOTE 7          | 401666                            | TF               | 03/20/08 |
| REV  | DESCRIPTION           | ECN NO                            | BY               | DATE     |
| <b>Franklin Fueling Systems</b><br>Madison, WI 53718                     |                       |                                   |                  |          |
| <b>TITLE:</b> CLEAN AIR SEPARATOR HORIZONTAL INSTALLATION (3 VENT VALVE) |                       |                                   |                  |          |
| <b>DRAWN:</b>  | <b>DATE:</b> 05/22/07 | <b>DRW NO:</b> 9900-9973          | <b>SUFFIX:</b> H |          |
| <b>APPRVL:</b>   | <b>DATE:</b> 06/05/07 | <b>SCALE:</b> N.T.S. SHEET 1 OF 1 |                  |          |

# Clean Air Separator


## Bladder Field Replacement




## Important Safety Messages


Franklin Fueling Systems (FFS) equipment is designed to be installed in association with volatile hydrocarbon liquids such as gasoline. Installing or working on this equipment means working in an environment in which these highly flammable liquids may be present. Working in such a hazardous environment presents a risk of severe injury or death if these instructions and standard industry practices are not followed. Read and follow all instructions thoroughly before installing or working on this, or any other related, equipment.


As you read this guide, please be aware of the following symbols and their meanings:


**Warning**  This symbol identifies a warning. A warning sign will appear in the text of this document when a potentially hazardous situation may arise if the instructions that follow are not adhered to closely. A potentially hazardous situation may involve the possibility of severe bodily harm or even death.

**Caution**  This is a caution symbol. A caution sign will appear in the text of this document when a potentially hazardous environmental situation may arise if the instructions that follow are not adhered to closely. A potentially hazardous environmental situation may involve the leakage of fuel from equipment that could severely harm the environment.

---



**Warning**  **Follow all applicable codes governing the installation and servicing of this product and the entire system. Always lock out and tag electrical circuit breakers while installing or servicing this equipment and any related equipment. A potentially lethal electrical shock hazard and the possibility of an explosion or fire from a spark can result if the electrical circuit breakers are accidentally turned on during installation or servicing. Please refer to the Installation and Owner's Manual for this equipment, and the appropriate documentation for any other related equipment, for complete installation and safety information.**

**Warning**  **Follow all federal, state and local laws governing the installation of this product and its associated systems. When no other regulations apply, follow NFPA codes 30A and 70 from the National Fire Protection Association. Failure to follow these codes could result in severe injury, death, serious property damage and/or environmental contamination.**

**Warning**  **Always secure the work area from moving vehicles. The equipment in this manual is usually mounted underground, so reduced visibility puts service personnel working on this equipment in danger from moving vehicles entering the work area. To help eliminate these unsafe conditions, secure the area by using a service truck to block access to the work environment, or by using any other reasonable means available to ensure the safety of service personnel.**

**Warning**  **Use circuit breakers for multiple disconnect to turn off power and prevent feedback from other dispensers.**

**Note:** Persons doing this bladder replacement must be trained by a FFS Field service engineer before attempting this procedure.




**Figure 1: Clean Air Separators: Component Locations**

**Replacement Bladder Part# 9943**

1. Close valves A & B, then disconnect piping from the Clean air Separator (CAS).
2. **It is highly recommended that Vertical Clean Air Separators be placed horizontally prior to repair.** (A powered lifting device will be needed).

**Note:** Lower the vertical CAS slowly and place cushioning (i.e. cardboard) under it to prevent scarring the surface.

3. Remove the syphon tube.
4. Deflate the bladder to ease its removal and to prevent damage during removal.

**Warning**  **Explosion potential. Assume gasoline vapors are present. Use an intrinsically safe or explosion-proof vacuum source to deflate the bladder.**

5. Remove the (8) 3/4" bolts securing the flange. Be aware that a thread-locking compound was used on the threads, and more force will be required to remove them.

**Note:** Account for all parts removed and reinstall in the same order.

6. Carefully remove bladder from the Clean Air Separator.

7. Remove the (6) 1/4-20 bolts from the bladder flange (9940).
8. Inspect bladder flange and nipple to ensure there are no sharp edges that could create a hole in the bladder.
9. Replace bladder by fitting the new bladder's end opening around the flange (Figure 2).



**Figure 2: Place Bladder on Flange**

10. Lower the Clamp Ring with lubricated O-ring to hold the bladder in position.
11. Install the (6) 1/4-20 bolts securing the clamp ring and bladder to the bladder flange.

**Note:** Using a couple 1" 1/4-20 bolts can help hold the flange components in position while the other bolts are secured.

12. Tighten all (6) screws to 65-88 in-lbs using torque wrench set to break at 80 in-lbs

13. Inflate bladder to 2" of water column and check for leaks in accordance with CARB exhibit 4.
14. Deflate bladder and fold into thirds lengthwise.
15. Feed bladder into the Clean Air Separator. Take care not to damage bladder as you feed it into CAS. Support the flange end so no additional stress is put on the bladder as you feed the bladder into the CAS. Best to use 2 people during this step
16. Align marks and secure the flange using the (8) ¾" bolts. Apply Loctite\* to bolts.



**Figure 3: Align Marks**

17. Torque bolts to 80 ft/pounds.

18. Inflate bladder to 2" of water column and install syphon tube (Figure 4).



**Figure 4: Install Syphon Tube**

19. Reinstall the Clean Air Separator per ARB Approved IOM - EO VR-203 and VR-204. Test the Clean Air Separator in accordance with Exhibit 14.

\* Loctite is a registered trademark of Henkel Corporation



**Franklin Fueling Systems**

[www.franklinfueling.com](http://www.franklinfueling.com)

3760 Marsh Road • Madison, WI 53718, U.S.A.  
 Tel: +1 608 838 8786 • Fax: +1 608 838 6433  
 Tel: USA & Canada 1 800 225 9787 • Tel: México 001 800 738 7610

**Franklin Fueling Systems GmbH**  
 Rudolf-Diesel-Strasse 20 • 54516 Wittlich, GERMANY  
 Tel: +49-6571-105-380 • Fax: +49-6571-105-510



# Installation & Maintenance Manual

*Green Machine*<sup>™</sup> - PMC / ISD - California

Revision 1.12



**Vapor Systems Technologies, Inc.**

650 Pleasant Valley Drive  
Springboro, Ohio 45066  
(937) 704-9333 PH  
(937) 704-9443 FX  
[www.vsthose.com](http://www.vsthose.com)

# Table of Contents

|   |           |
|---|-----------|
| Table of Contents.....                                    | 2         |
| Table of Figures.....                                     | 5         |
| About VST.....  | 6         |
| <b>1 This Document.....</b>                               | <b>7</b>  |
| 1.1 Safety Icons .....                                    | 7         |
| 1.2 Table of Terms & Abbreviations .....                  | 8         |
| <b>2 Safety .....</b>                                     | <b>9</b>  |
| <b>3 Green Machine Description .....</b>                  | <b>10</b> |
| 3.1 Green Machine Theory of Operation.....                | 10        |
| 3.2 Regulations & Jurisdiction .....                      | 12        |
| 3.3 Green Machine Dimensions & Weight .....               | 13        |
| 3.4 Green Machine Replacement Components.....             | 13        |
| 3.5 How the Green Machine is Shipped.....                 | 13        |
| <b>Installation .....</b>                                 | <b>16</b> |
| <b>4 Snapshot of Site Requirements.....</b>               | <b>16</b> |
| 4.1 Pre-Installation Site Survey.....                     | 17        |
| <b>5 Contractor Supplied Components.....</b>              | <b>18</b> |
| 5.1 Contractor Supplied - Vapor Piping Components .....   | 18        |
| 5.2 Contractor Supplied - Electrical Components .....     | 18        |
| <b>6 Ground Mount Installation.....</b>                   | <b>19</b> |
| 6.1 Protecting the Green Machine .....                    | 19        |
| 6.2 Ground-Mount Location .....                           | 20        |
| 6.3 Installing the Green Machine on the Concrete Pad..... | 20        |
| 6.4 After an Earthquake .....                             | 22        |
| <b>7 Roof-Top Installation.....</b>                       | <b>25</b> |
| <b>8 Canopy-Top Installation .....</b>                    | <b>26</b> |
| <b>9 Vent-Stack Mount Installation.....</b>               | <b>27</b> |
| <b>10 Vapor Piping .....</b>                              | <b>29</b> |
| 10.1 Vapor Piping Installation Instructions.....          | 31        |

|           |   |           |
|-----------|---|-----------|
| 10.2      | Vapor Piping Post Installation .....  | 32        |
| 10.3      | Vapor Piping Bill of Material - Contractor Supplied.....  | 32        |
| <b>11</b> | <b>Electrical .....</b>   | <b>33</b> |
| 11.1      | Electrical Requirements.....  | 34        |
| 11.2      | Electrical Safety .....   | 34        |
| 11.3      | Electrical Installation Code Requirements .....   | 35        |
| 11.4      | Electrical Components .....   | 36        |
| 11.5      | Electrical Installation Procedures .....  | 37        |
| 11.5.1    | VST Control Panel Field Wiring Procedure.....   | 37        |
| 11.5.2    | VST Control Panel Terminal Block Wire Numbers & Descriptions .....                                | 38        |
| 11.5.3    | TLS-350 4-Relay Module: <i>Machine</i> RUN and Overfill Alarm Output Relay Wiring Procedure ..... | 40        |
| 11.5.4    | VST Control Panel to the TLS-350 Intrinsically Safe (I.S.) Bay Wiring Procedure .....             | 41        |
| 11.5.5    | RS422 to RS232 Adapter to TLS-350 RS32 Port Connections.....                                      | 42        |
| 11.5.6    | GDF ESO to the VST Control Panel Wiring Procedure.....  | 45        |
| 11.5.7    | VST Control Panel to Safety Disconnect Switch Wiring Procedure.....                               | 45        |
| 11.5.8    | Safety Disconnect Switch to Internal Junction Box Wiring Procedure.....                           | 46        |
| 11.5.9    | HC Sentry Wiring Procedure .....  | 46        |
| <b>12</b> | <b>VST Control Panel.....</b>   | <b>58</b> |
| 12.1      | Start up Screen and Function Buttons .....  | 59        |
| 12.1.1    | Main Screen Overview .....  | 59        |
| 12.2      | The Green Machine ON Screen .....   | 60        |
| 12.2.1    | Green Machine in the ON Mode .....  | 60        |
| 12.2.2    | Green Machine in the PURGE Mode: .....  | 60        |
| 12.3      | Green Machine OFF Screen.....   | 61        |
| 12.4      | TLS-350 Operations Overview.....  | 61        |
| 12.4.1    | TLS-350 4-Relay Module Information .....  | 62        |
| 12.4.2    | TLS Intrinsically Safe (I.S.) Bay Information.....  | 62        |
| 12.5      | Overfill Alarm.....   | 63        |
| 12.6      | Motor Fault.....  | 64        |
| 12.7      | VST Control Panel Test Buttons .....  | 64        |
| <b>13</b> | <b>Green Machine Pre Start-Up Testing.....</b>  | <b>65</b> |
| 13.1      | Check PMC/ISD Settings on the TLS-350.....  | 65        |
| 13.2      | Green Machine Post-Installation Start-Up Tests .....  | 65        |
| 13.3      | Functionality Test .....  | 66        |
| <b>14</b> | <b>Leak Test.....</b>   | <b>68</b> |
| 14.1      | Determination of VST Green Machine Activation Pressure-Exhibit 9 .....                            | 74        |
| 14.2      | VST Green Machine Annual Compliance Test – Exhibit 15 .....                                       | 74        |



**15 Green Machine Start-Up Procedure .....75**

**16 Green Machine Operation .....76**

    16.1 Veeder-Root TLS-350 .....76

**TLS-350 Troubleshooting.....77**

**17 TLS Warnings and Alarms (PMC & ISD) .....77**

    17.1 TLS-350 PMC Alarms - Troubleshooting Summary .....78

    17.2 TLS-350 ISD Alarms - Troubleshooting Summary.....79

**Maintenance.....81**

**18 Overview .....81**

**19 Rubber Flange Sleeve Replacement .....82**

    19.1 Removing the Rubber Flange Sleeve.....83

    19.2 Replacing the Rubber Flange Sleeve.....83

**Annual Green Machine Inspections and Replacements .....84**

## Table of Figures

|   |    |
|---|----|
| Figure 1: <i>Green Machine</i> GDF Layout .....   | 11 |
| Figure 2: <i>Green Machine</i> Isometric View (1 of 2) .....  | 14 |
| Figure 3: <i>Green Machine</i> Isometric View (2 of 2) .....  | 15 |
| Figure 4: Location & Dimensions .....   | 21 |
| Figure 5: Mounting Pad Plan View.....   | 23 |
| Figure 6: 6” Mounting Pad Details.....  | 24 |
| Figure 7: Vent Stack Installation .....   | 28 |
| Figure 8: Vapor Piping Overview .....   | 29 |
| Figure 9: <i>Green Machine</i> Connections.....   | 30 |
| Figure 10: VST Control Panel Field Wiring Numbers and Descriptions .....                                  | 39 |
| Figure 11: RS422 to RS232 Adapter to TLS-350 Connection - Option A Direct Connection .....                | 42 |
| Figure 12: VST <i>Green Machine</i> Control Panel Front View.....   | 43 |
| Figure 13: VST <i>Green Machine</i> Control Panel Top View of Adapter .....                               | 43 |
| Figure 14: RS422 to RS232 Adapter to TLS-350 Connection - Option B Using a Port Combiner .....            | 44 |
| Figure 15: VST Control Panel Wiring Diagram .....   | 47 |
| Figure 16: Field Wiring the VST Control Panel, Option 1 .....   | 48 |
| Figure 17: Field Wiring the TLS-350 4-Relay Module for the ESO, GM Run, and Overfill Alarm, Option 1..... | 49 |
| Figure 18: Field Wiring the VST Control Panel, Option 2 .....   | 50 |
| Figure 19: Field Wiring the TLS-350 4-Relay Module for the ESO, GM Run, and Overfill Alarm, Option 2..... | 51 |
| Figure 20: Safety Disconnect Switch Field Wiring Diagram .....  | 52 |
| Figure 21: <i>Green Machine</i> Junction Box Field Wiring Diagram.....                                    | 53 |
| Figure 22: Vacuum Pump Motor Wiring Diagram.....  | 54 |
| Figure 23: HC Sentry Interface Cable Connections .....  | 55 |
| Figure 24: Field Wiring the TLS-350 Interstitial Sensor Interface Module – I.S. Bay .....                 | 56 |
| Figure 25: HC Sentry to TLS-350 Connections.....  | 57 |
| Figure 26: VST <i>Green Machine</i> Control Panel, Front View .....                                       | 58 |
| Figure 27: Startup Screen and Function Buttons .....  | 59 |
| Figure 28: <i>Green Machine</i> ON Screen.....  | 60 |
| Figure 29: <i>Green Machine</i> OFF screen.....   | 61 |
| Figure 30: Overfill Alarm Screen .....  | 63 |
| Figure 31: Motor Fault Screen.....  | 64 |
| Figure 32: Functionality Test Screen.....   | 66 |
| Figure 33: <i>Green Machine</i> Operation Diagram .....   | 67 |
| Figure 34: Leak Check Fixture .....   | 70 |
| Figure 35: <i>Green Machine</i> Inlet and Outlet Valves Closed, and Leak Check Fixture Attached.....      | 71 |
| Figure 36: <i>Green Machine</i> Controller .....  | 72 |
| Figure 37: TLS-350 Front Panel.....   | 76 |
| Figure 38: Vacuum Pump Coupling Replacement.....  | 82 |

## **About VST**



Vapor Systems Technologies, Inc. began in 1989 with the vision of **One Company – One Integrated Solution**.

Today, that philosophy is still in place and getting stronger. Recognizing that a healthier environment is a need and not an option, VST has dedicated its undivided attention to the ever-changing, stringent regulations that govern fugitive

vapors at gasoline dispensing facilities (GDF). To this challenge, VST is committed to a continual R&D campaign of developing the most current, technologically advanced solutions to service not only the United States, but also the world.

VST specializes in the development, engineering, and manufacturing of products that are sold into the GDF segment of the petroleum industry. The VST focus provides our customers and users with exceptional products, services, and innovative solutions for improving the fueling-station experience as well as the world's air quality.

VST's product offering includes curb pump and vapor recovery hoses, safety breakaways, nozzles, and emission-control system - *Green Machine*. The ENVIRO-LOC™ vapor-recovery product offering represents the most innovative concept in the industry for trapping fugitive vapors from the front end (vehicle refueling) to the back end (vent risers) of the GDF site.

### **Notice**

Vapor Systems Technologies, Inc. shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this publication.

No part of this publication may be translated to another language without the prior written consent of Vapor Systems Technologies, Inc.

# 1 This Document

## 1.1 Safety Icons

|   |   |   |   |
|---|---|---|---|
|    | <p><b>ELECTRICITY</b><br/>A potential shock hazard exists. High voltage is supplied to and exists in this device.</p>   |    | <p><b>TURN POWER OFF</b><br/>Turn power off to the device and its accessories when installing and servicing the unit. Live power creates a potential spark hazard.</p>  |
|    | <p><b>EXPLOSIVE</b><br/>Gasoline and its vapors are extremely explosive if ignited.</p>                                 |    | <p><b>NO POWER TOOLS</b><br/>Sparks from electric power tools can ignite gasoline and its vapors.</p>   |
|    | <p><b>FLAMMABLE</b><br/>Gasoline and its vapors are extremely flammable.</p>  |    | <p><b>NO PEOPLE IN THE AREA</b><br/>Unauthorized people in the work area during installation and service of the device create a potential for personal injury.</p>  |
|  | <p><b>NO SMOKING</b><br/>Gasoline and its vapors can be ignited by sparks and embers of burning cigarettes.</p>         |  | <p><b>READ ALL RELATED MATERIALS</b><br/>Read, understand, and follow all instructions, warnings, and requirements before you begin work.</p>   |
|  | <p><b>NO OPEN FLAMES</b><br/>Open flames from sources like lighters and matches can ignite gasoline and its vapors.</p> |  | <p><b>USE SAFETY BARRICADES</b><br/>Unauthorized people in the work area during installation and service of the device create a potential for personal injury. Therefore, always isolate your work area by using safety cones, barricades, etc.</p> |
|  | <p><b>PINCH RISK</b><br/>Stay clear. Keeps hands and tools away from rotating machinery and moving parts.</p>           |  | <p><b>ROTATING MACHINERY</b><br/>Stay clear. Keep hands and tools away from rotating machinery.</p>   |

## 1.2 Table of Terms & Abbreviations

|                   |   |
|-------------------|---|
| <b>ASC:</b>       | Authorized Service Contractor   |
| <b>AQMD:</b>      | Air Quality Management Districts  |
| <b>ATG:</b>       | Automatic Tank Gauge  |
| <b>CAPCOA:</b>    | California Air Pollution Control Office Association                       |
| <b>CARB:</b>      | California Air Resources Board  |
| <b>CDFA:</b>      | California Department of Food & Agriculture                               |
| <b>CVLD:</b>      | Continuous Vapor Leakage Detection, another name for Vapor Leak Detection |
| <b>EO:</b>        | Executive Order   |
| <b>ESO:</b>       | Emergency Shut Off  |
| <b>EVR:</b>       | Enhanced Vapor Recovery   |
| <b>GDF:</b>       | Gasoline Dispensing Facility  |
| <b>GM:</b>        | <i>Green Machine</i>  |
| <b>HC:</b>        | Hydrocarbon   |
| <b>ISD:</b>       | In-Station Diagnostics  |
| <b>MAG Probe:</b> | A type (brand) of Tank Inventory Probe                                    |
| <b>NEC:</b>       | National Electric Code  |
| <b>NFPA:</b>      | National Fire Protection Association                                      |
| <b>ORVR:</b>      | ON-Board Refueling Vapor Recovery   |
| <b>OSHA:</b>      | Occupational Safety Health Administration                                 |
| <b>Permeate:</b>  | Air return to atmosphere  |
| <b>PMC:</b>       | Pressure Management Control   |
| <b>PTO:</b>       | Permit to Operate   |
| <b>P/V Valve:</b> | Pressure Vacuum Valve   |
| <b>TLS:</b>       | Tank Level System   |
| <b>Ullage:</b>    | Vapor space above liquid in a UST   |
| <b>UST:</b>       | Underground Storage Tank  |
| <b>VOC:</b>       | Volatile Organic Compounds  |
| <b>VST:</b>       | Vapor Systems Technologies, Inc.  |
| <b>WC:</b>        | Water Column  |

## 2 Safety



- The *Green Machine* will be installed near locations where highly flammable and explosive gasoline vapors may be present.
- Installation of the *Green Machine* must comply with the National Electric Code, federal, state, and local codes, as well as other applicable safety codes.
- Use extreme caution due to the risk of fire or explosion, which could result in serious injury or even death.



- If you are working in an area where vehicle traffic may occur, always block off the work area during installation, testing, and service to protect yourself and others.
- Do not use power tools that can generate sparks if there is a risk of flammable or explosive vapors being present.



- Read and understand all materials related to installing, testing, and operating the *Green Machine* prior to installation.

**CAUTION: ALL SERVICEABLE / REPLACEMENT PARTS MUST BE OBTAINED FROM VST TO MAINTAIN SUITABILITY FOR A DIVISION 2 LOCATION.**

### 3 Green Machine Description

#### 3.1 Green Machine Theory of Operation

- The VST *Green Machine* does not interact directly with the other balance system hardware. It is in place to control the pressure in the UST to within limits specified by CARB.
- Under conditions where the GDF is operational and the balance system hardware is functioning normally, the inherent ORVR compatibility of the balance system (when using VST's ENVIRO-LOC nozzle) will produce a predominately negative gauge pressure in the ullage space of the UST. Under these conditions, the *Green Machine* will typically not need to operate.
- During periods of less activity, such as the GDF being shut down overnight, winter fuels being present or other conditions that promote the pressurization of the ullage space, the *Green Machine* will operate as needed to control the pressure in the ullage space to an accepted level. The *Green Machine* will turn on at an ullage pressure of +0.20 inches of water. Currently, the *Green Machine* unit is monitored and controlled through the TLS-350 PMC or ISD software and the VST Control Panel.
- When the UST pressure increases to above +0.20 inches of water, a TLS-350 AUX contact closes. The AUX contact is connected to the VST Control Panel, which is the mechanism that starts the *Green Machine*. The VST Control Panel manages the operation of the *Green Machine* including the ON, PURGE, and OFF cycles.
- These preset pressure measurements control the UST pressure below atmospheric pressure. The pressure data is provided to the TLS-350 for system monitoring functions.
- The TLS-350 monitors the UST pressure via a pressure sensor located in a dispenser.  
**See Figure 1.**




Figure 1: Green Machine GDF Layout



### 3.2 Regulations & Jurisdiction



**Be sure to read and understand all site requirements before beginning an installation.**

- Under vapor recovery rules, air pollution control districts have primary authority for regulating GDF's.
- Before modifying the facility, GDF operators should contact the local air district for specific information on local vapor-recovery requirements.
- Contact information for local air pollution control districts is available on the air district permit to operate (PTO) and/or the California Air Pollution Control Officers Association (CAPCOA) website at <http://www.capcoa.org>.
- “The area inside the *Green Machine* cover has been evaluated as a Class I, Division 2 hazardous area as defined by the National Electric Code /NFPA 70 Article 514 table 514.3(B)(1) and verified by Intertek.”

#### **CAUTION**

Always obtain approval from the local authority having jurisdiction.

Installation of the *Green Machine* must comply with (if applicable):

- CARB CP-201
- VST EVR E.O.
- Fire Marshal
- Water Board
- Local Air Pollution District
- ICC
- NEC
- NFPA 30 and 30A
- UL
- Any other applicable federal, state, and local codes

### 3.3 Green Machine Dimensions & Weight

| Description  | Dimensions   | Weight                                     |
|--|--|--|
| <i>Green Machine</i>   | L-39" x W-27" x H-43"<br>Height includes 18" legs    | 225 lbs.<br>w/o Cover<br>w/o Control Panel |
| <i>Green Machine</i><br>Aluminum Cover                         | L-39" x W-27" x H-25"<br>(one-piece unit)            | 24 lbs.                                    |
| <i>Green Machine</i><br>Fire-Resistant Enclosure<br>(Optional) | L-41" x W-27" x H-36"<br>(side panels are removable) | 100 lbs.                                   |

### 3.4 Green Machine Replacement Components

**CAUTION: ALL SERVICEABLE/REPLACEMENT PARTS MUST BE OBTAINED FROM VST TO MAINTAIN SUITABILITY FOR A DIVISION 2 LOCATION.**

| Part # | Description            |
|--------|------------------------|
| GM-004 | Coupling Rubber Sleeve |

### 3.5 How the Green Machine is Shipped


The *Green Machine* is shipped with the following:

- *Green Machine* - VST-GM-CS1-100
  - Aluminum Cover
  - Control Panel
  - 4 Steel Legs
  - 16 3/8" bolts / washers / nuts  
(to attach the legs to the *Green Machine* base)
  - HC Sentry Interface Module with 24 VDC power supply
  - HC Sentry Interface Cable
- Bolted to a skid
- Owner package with warranty paperwork to be filled out and returned to VST.

#### Shipping Check

When you open the container:

- Verify that all the items are in the shipping container.
- Visually inspect all the items for any obvious damage.



TITLE: ISO ASSEMBLY VIEW, G.M., CALIFORNIA SCALE: N/A  
FILENAME: 6533-001

Figure 2: Green Machine Isometric View (1 of 2)




Figure 3: Green Machine Isometric View (2 of 2)

## Installation

### 4 Snapshot of Site Requirements

|   |
|---|
| <b>Local Air Pollution Control District</b>   |
| <ul style="list-style-type: none"> <li>GDF must contact the local air pollution control district for specific local vapor recovery requirements.</li> </ul>   |
| <b>Common Requirements</b>  |
| <ul style="list-style-type: none"> <li>The <i>Green Machine</i> must be protected from damage.</li> <li>VST recommends an 18" perimeter around the <i>Green Machine</i> for maintenance and testing.</li> <li>The <i>Green Machine</i> must be located at least 10' from the property line unless a variance is obtained from the local authority.</li> <li>The <i>Green Machine</i> must be located within 100' of the vent risers.</li> </ul> |
| <b>Ground-Mount Location</b>  |
| <ul style="list-style-type: none"> <li>Obtain approval from the local jurisdiction for the <i>Green Machine</i> to be placed on the ground.</li> </ul>  |
| <b>Vent Riser Mount</b>   |
| <ul style="list-style-type: none"> <li>Obtain approval from the local jurisdiction for the <i>Green Machine</i> to be placed on the vent riser support structure.</li> <li>The support structure must be of adequate strength to support the <i>Green Machine</i>.</li> </ul>   |
| <b>Roof-Mount Location</b>  |
| <ul style="list-style-type: none"> <li>Obtain approval from the local jurisdiction for the <i>Green Machine</i> to be placed on the roof.</li> <li>Structure must be strong enough to hold the weight of the <i>Green Machine</i>.</li> <li>The height of the <i>Green Machine</i> must allow for the proper vapor-piping slope.</li> </ul>   |
| <b>Canopy-Mount Location</b>  |
| <ul style="list-style-type: none"> <li>Obtain approval from the local jurisdiction for the <i>Green Machine</i> to be placed on the canopy.</li> <li>Structure must be strong enough to hold the weight of the <i>Green Machine</i>.</li> <li>All safety and code concerns have been addressed.</li> </ul>  |
| <b>UST Manifolding</b>  |
| <ul style="list-style-type: none"> <li>UST's must be manifolded either below grade or at the vent risers.</li> <li>Only a single vent is required.</li> </ul>   |
| <b>Dispensers</b>   |
| <ul style="list-style-type: none"> <li>The dispenser vapor piping must be sized adequately to meet the maximum pressure drop requirement. A minimum one-inch (1") nominal internal diameter for the vapor down pipe is recommended.</li> </ul>  |
| <b>UST Fuel Level Management</b>  |
| <ul style="list-style-type: none"> <li>Must be able to access an Overfill Alarm contact with the VST Control Panel <i>Green Machine</i> Controller.</li> </ul>  |

**Snapshot of Site Requirements, cont.**

|   |
|---|
| <b>VST Control Panel</b>  |
| <ul style="list-style-type: none"> <li>VST Control Panel completely powers the <i>Green Machine</i> via one 115VAC, 20-amp breaker.</li> </ul>  |
| <ul style="list-style-type: none"> <li>The VST Control Panel must be installed inside the GDF electrical room.</li> </ul>   |
| <ul style="list-style-type: none"> <li>The VST Control Panel is UL approved.</li> </ul>   |
| <b>Vent Risers</b>  |
| <ul style="list-style-type: none"> <li>Only 1 vent riser is required for the installation of the <i>Green Machine</i>.</li> </ul>   |
| <ul style="list-style-type: none"> <li>Recommended slope of ¼" per foot on all vapor-piping connecting the <i>Green Machine</i> to the vent risers or to any other UST connection. (VST requires a minimum of 1/8" per foot minimum slope for all vapor piping.)</li> </ul> |
| <ul style="list-style-type: none"> <li>Any type of trap, other than the ARB-approved liquid-condensate trap (regardless of the <i>Green Machine</i> location), is not permitted in any vapor lines connected to the <i>Green Machine</i>.</li> </ul>                        |
| <ul style="list-style-type: none"> <li>A 5' radius around the vent riser P/V valve is a Class I, Div. 2 hazardous area as defined in NFPA 70.</li> </ul>  |
| <b>Veeder-Root Controls</b>   |
| <ul style="list-style-type: none"> <li>Must have TLS-350 with appropriate Veeder-Root software installed.</li> </ul>  |
| <b>CARB Requirements</b>  |
| <ul style="list-style-type: none"> <li>Executive Order: VR-203/204.</li> </ul>  |

**4.1 Pre-Installation Site Survey**

- VST created a "*Green Machine* Pre-Installation Site Survey" as a guide to help certified installers and troubleshooters in the planning of a *Green Machine* installation.
- The "*Green Machine* Pre-Installation Site Survey" is to be completely filled out in advance of an installation so that installation problems and delays are reduced or avoided.
- You will find the "*Green Machine* Pre-Installation Site Survey" on our website at [www.vsthose.com](http://www.vsthose.com).

## 5 Contractor Supplied Components

### 5.1 Contractor Supplied - Vapor Piping Components

| Quantity    | Component(s)   |
|-------------|--|
| 2           | 1" diameter straight tee's with caps                             |
| 2           | 1" diameter unions   |
| 2           | 1" diameter locking ball valves                                  |
| 1           | Straight tee (sized to match existing vent riser)                |
| 1           | 1" x 2" galvanized reducer bushing                               |
| 1           | Straight tee with cap (sized to match new vent riser)            |
| 1           | Rain cap (on new vent riser)                                     |
| As required | 1" diameter pipe, elbows, and misc. pipe fittings                |
| 5           | <u>Locks</u> : 2- cover, 2-locking ball vales, 1-control cabinet |

### 5.2 Contractor Supplied - Electrical Components

| Component(s)   |
|--|
| <ul style="list-style-type: none"> <li>• Wires</li> </ul>                    |
| <ul style="list-style-type: none"> <li>• Conduits</li> </ul>                 |
| <ul style="list-style-type: none"> <li>• Fittings</li> </ul>                 |
| <ul style="list-style-type: none"> <li>• Seal-Offs</li> </ul>                |
| <ul style="list-style-type: none"> <li>• Safety Disconnect Switch</li> </ul> |
| <ul style="list-style-type: none"> <li>• Optional 115 VAC Outlet</li> </ul>  |
| <ul style="list-style-type: none"> <li>• 115 VAC relay</li> </ul>            |

## 6 Ground Mount Installation

### 6.1 Protecting the Green Machine

- Take measures to protect the *Green Machine* and external vapor piping from damage in areas near vehicle traffic with guards, such as concrete-filled bollards or guardrails.
  - Check local codes for protective-device guidelines before setting the bollards or guardrails.
- A fence should not be required since there is a lockable cover on the *Green Machine* with lockable hasps to prevent tampering. The contractor will provide the locks for the hasps.
- VST requires a lockable ball valve be used at both the inlet and outlet connections at the *Green Machine*.
  - VST does not include any locks or lockable valves for the *Green Machine*; therefore, the contractor must provide them.
  - Lockable ball valves used in this application must be compatible with gasoline and gasoline vapor. For further requirements, consult the lockable-valve installation instructions provided by the manufacturer.
  - Some local jurisdictions may require that the lockable Safety Disconnect Switch, ball valves, and the cover be locked.
- The *Green Machine* standard aluminum cover and the optional 2-hour Fire Resistant Enclosure are both designed and built to withstand snow accumulation, rain, and landscaping sprinklers.



## 6.2 Ground-Mount Location

| Ground Mount Requirements |  |
|---------------------------|--|
|                           | <ul style="list-style-type: none"> <li>The <i>Green Machine</i> must be protected from damage.</li> </ul>  |
|                           | <ul style="list-style-type: none"> <li>VST recommends an 18" perimeter around the <i>Green Machine</i> for maintenance and testing.</li> </ul>   |
|                           | <ul style="list-style-type: none"> <li>The <i>Green Machine</i> must be located at least 10' from the property line unless a variance is obtained from the local authority.</li> </ul>   |
|                           | <ul style="list-style-type: none"> <li>The <i>Green Machine</i> must be located within 100' of the vent risers.</li> </ul>   |
|                           | <ul style="list-style-type: none"> <li>The local jurisdiction must allow the <i>Green Machine</i> to be placed on the ground.</li> </ul>   |
|                           | <ul style="list-style-type: none"> <li>To minimize the installation cost and to maximize operating efficiency, locate the <i>Green Machine</i> adjacent to the existing vent risers.</li> </ul>  |
|                           | <ul style="list-style-type: none"> <li>A new air outlet vent riser connected to the <i>Green Machine</i> must be installed to release air to the atmosphere.</li> </ul>  |
|                           | <ul style="list-style-type: none"> <li>VST requires setting the <i>Green Machine</i> on a concrete pad with the recommended following minimum dimensions:               <ul style="list-style-type: none"> <li>6" concrete pad</li> <li>3'6" long x 2'6" wide</li> </ul> </li> </ul> |
|                           | <ul style="list-style-type: none"> <li>Follow the local jurisdiction's building codes:               <ul style="list-style-type: none"> <li>VST does not provide any hardware to install the <i>Green Machine</i> on the pad.</li> </ul> </li> </ul>                                 |

## 6.3 Installing the Green Machine on the Concrete Pad

|    |  |
|----|--|
| 1. | After the concrete has properly cured, install the expansion anchor bolts according to the manufacturer's recommendations.   |
| 2. | VST recommends using the HILTI KWIK TZ (KB-TZ) BOLT, KB-TZ 3/8" x 5", approved equal for seismic and non-seismic installations.  |
| 3. | Since seismic regulations may be different by location, VST has not included a specific drawing for this application. For seismic design reference, <a href="http://www.us.hilti.com">www.us.hilti.com</a> . |
| 4. | The contractor or design engineer is responsible for sizing the expansion anchors and the concrete pad to meet specifications required by local jurisdictions.   |
| 5. | After the appropriate anchor bolts have been installed, position the <i>Green Machine</i> onto the anchor bolts in the cement slab.  |
| 6. | Bolt the <i>Green Machine</i> into place (according to the manufacturer recommended installation guidelines) with 3/8" galvanized lock washers and bolts that are included with the expansion bolt.          |
| 7. | VST CANNOT BE RESPONSIBLE FOR DAMAGE CAUSED BY IMPROPER GREEN MACHINE FOUNDATION SUPPORT.  |




Figure 4: Location & Dimensions

## **6.4 After an Earthquake**

- Insure the *Green Machine* unit is:
  - Level
  - All piping fittings are leak free by conducting a Leak Test as outlined in this document.
  - All the electrical fitting and connections are tight.




Figure 5: Mounting Pad Plan View




Figure 6: 6" Mounting Pad Details

## 7 Roof-Top Installation

| Roof Top Installation Requirements   |
|--|
| <ul style="list-style-type: none"> <li>The <i>Green Machine</i> must be protected from damage.</li> </ul>  |
| <ul style="list-style-type: none"> <li>VST recommends an 18" perimeter around the <i>Green Machine</i> for maintenance and testing.</li> </ul>   |
| <ul style="list-style-type: none"> <li>The <i>Green Machine</i> must be located at least 10' from the property line unless a variance is obtained from the local authority.</li> </ul>   |
| <ul style="list-style-type: none"> <li>The <i>Green Machine</i> must be located within 100' of the vent risers.</li> </ul>   |
| <ul style="list-style-type: none"> <li>The local jurisdiction must allow the <i>Green Machine</i> to be placed on the roof.</li> </ul>   |
| <ul style="list-style-type: none"> <li>The <i>Green Machine</i> may be installed on a station's roof provided the structure can support the weight of the <i>Green Machine</i>.</li> </ul>   |
| <ul style="list-style-type: none"> <li>The height of the <i>Green Machine</i> must allow for the proper vapor-piping slope.</li> </ul>   |
| <ul style="list-style-type: none"> <li>Due to a variety of roof construction designs, VST cannot recommend how the <i>Green Machine</i> should be mounted on the roof; however, the <i>Green Machine</i> must be installed at a height allowing the piping inlet and outlets to be above or through the building parapet.</li> </ul> |
| <ul style="list-style-type: none"> <li>The <i>Green Machine</i> may be secured to a steel structure attached to the roof.</li> </ul>   |
| <ul style="list-style-type: none"> <li>A new air outlet vent riser connected to the <i>Green Machine</i> must be installed to release air to the atmosphere.</li> </ul>  |
| <ul style="list-style-type: none"> <li>All safety and code concerns should be taken into consideration prior to a rooftop installation.</li> </ul>   |
| <ul style="list-style-type: none"> <li>VST CANNOT BE RESPONSIBLE FOR DAMAGE CAUSED BY IMPROPER <i>GREEN MACHINE</i> FOUNDATION SUPPORT.</li> </ul>   |

## 8 Canopy-Top Installation

| Canopy Top Installation Requirements   |
|--|
| <ul style="list-style-type: none"> <li>The <i>Green Machine</i> must be protected from damage.</li> </ul>  |
| <ul style="list-style-type: none"> <li>VST recommends an 18" perimeter around the <i>Green Machine</i> for maintenance and testing.</li> </ul>   |
| <ul style="list-style-type: none"> <li>The <i>Green Machine</i> must be located at least 10' from the property line unless a variance is obtained from the local authority.</li> </ul>     |
| <ul style="list-style-type: none"> <li>The <i>Green Machine</i> must be located within 100' of the vent risers.</li> </ul>   |
| <ul style="list-style-type: none"> <li>The local jurisdiction must allow the <i>Green Machine</i> to be placed on the canopy.</li> </ul>   |
| <ul style="list-style-type: none"> <li>The <i>Green Machine</i> may be installed on a station's roof provided the structure can support the weight of the <i>Green Machine</i>.</li> </ul> |
| <ul style="list-style-type: none"> <li>The height of the <i>Green Machine</i> must allow for the proper vapor-piping slope.</li> </ul>   |
| <ul style="list-style-type: none"> <li>Due to a variety of canopy construction designs, VST cannot recommend how the <i>Green Machine</i> should be mounted on the canopy.</li> </ul>      |
| <ul style="list-style-type: none"> <li>The <i>Green Machine</i> may be secured to a steel structure attached to the roof.</li> </ul>   |
| <ul style="list-style-type: none"> <li>A new air outlet vent riser connected to the <i>Green Machine</i> must be installed to release air to the atmosphere.</li> </ul>                    |
| <ul style="list-style-type: none"> <li>All safety and code concerns should be taken into consideration prior to a canopy installation.</li> </ul>  |
| <ul style="list-style-type: none"> <li>VST CANNOT BE RESPONSIBLE FOR DAMAGE CAUSED BY IMPROPER <i>GREEN MACHINE</i> FOUNDATION SUPPORT.</li> </ul>   |

## 9 Vent-Stack Mount Installation

| Vent Stack Installation Requirements  |
|---|
| <ul style="list-style-type: none"> <li>The <i>Green Machine</i> must be protected from damage.</li> </ul>   |
| <ul style="list-style-type: none"> <li>VST recommends an 18" perimeter around the <i>Green Machine</i> for maintenance and testing.</li> </ul>  |
| <ul style="list-style-type: none"> <li>The <i>Green Machine</i> must be located at least 10' from the property line unless a variance is obtained from the local authority.</li> </ul>  |
| <ul style="list-style-type: none"> <li>The <i>Green Machine</i> must be located within 100' of the vent risers.</li> </ul>  |
| <ul style="list-style-type: none"> <li>The local jurisdiction must allow the <i>Green Machine</i> to be placed on the canopy.</li> </ul>  |
| <ul style="list-style-type: none"> <li>The <i>Green Machine</i> may be installed elevated next to existing vent risers provided there is an existing structure that can support the weight of the <i>Green Machine</i>, or a structure can be installed to support the weight of the <i>Green Machine</i>.</li> </ul>   |
| <ul style="list-style-type: none"> <li>Due to a variety of construction designs, VST cannot recommend how the <i>Green Machine</i> should be installed or mounted on vent riser supports; however, the structure that supports the <i>Green Machine</i> must be designed and installed at a height allowing the piping inlet and outlets to connect to the existing vent risers.</li> </ul> |
| <ul style="list-style-type: none"> <li>A new air outlet vent riser connected to the <i>Green Machine</i> must be installed to release air to the atmosphere.</li> </ul>   |
| <ul style="list-style-type: none"> <li>The <i>Green Machine</i> must not be installed within 5' of a P/V valve opening.</li> </ul>  |
| <ul style="list-style-type: none"> <li>A Registered Design Engineer is responsible for designing the support structure, support base, all required hardware and bolting connections, and the support structure foundation to meet seismic specifications that may be required by local jurisdictions.</li> </ul>  |
| <ul style="list-style-type: none"> <li>VST CANNOT BE RESPONSIBLE FOR DAMAGE CAUSED BY IMPROPER <i>GREEN MACHINE</i> FOUNDATION SUPPORT.</li> </ul>  |






Figure 7: Vent Stack Installation

# 10 Vapor Piping




Figure 8: Vapor Piping Overview

Vapor Piping (continued)

- There are 2 piping connections to be made to the *Green Machine*:
  - Vapor inlet/return to the UST vapor-piping system.
  - Air outlet to atmosphere.
- The *Green Machine* piping connections are 1" diameter National Pipe Thread (NPT).




Figure 9: *Green Machine* Connections

---

## 10.1 Vapor Piping Installation Instructions

1. Install the vapor air inlet/return piping as shown in **Figure 9** from the vapor inlet/return connections on the *Green Machine* to an existing vent riser.
  - The existing vent riser must be modified by adding a tee for connecting the existing vent riser to the *Green Machine*.
  - The new tee must be installed to allow for slope from the *Green Machine* to the existing vent riser.
  - If there are multiple-grade UST's and multiple vent risers, VST recommends connecting the *Green Machine* to the lowest octane vent riser.
  
2. Install piping as shown in **Figure 9** from the vapor air outlet to a new vent riser.
  - The new vent riser may be installed next to the existing vent riser.
  - The piping from the *Green Machine* to the new vent riser MUST slope AWAY from the *Green Machine*.
  - Install the new dedicated vent riser so that the discharge opening is a minimum of 12-feet above grade and a minimum of 1" diameter.
  - A rain cap or equivalent must be installed on the new air outlet vent riser. Equivalent: If a PV vent valve is used the internal components must be removed to allow open venting to the atmosphere.
  - Install a tee with a cap at the bottom of the new air outlet vent riser to provide for drainage.
  
3. If flexible piping is required by the local authority to meet seismic requirements, install the flexible piping between the *Green Machine* locking ball and the vent riser(s).
  - The slope of the flex connection from the *Green Machine* back to the vent riser must be greater than 1/8" per foot slope.
  - The flexible connector must be UL approved for a service station above-ground application.
  - Support the flexible piping per manufacturer's recommendation.
  - The local contractor is responsible for providing all necessary galvanized piping, non-hardening pipe-joint compound, and plumbing fittings.
  
4. Make sure the gasoline UST tanks vapor piping is manifolded either above ground or below ground.
  
5. Local jurisdictions require that locks be installed on the cover of the *Green Machine*, on the Safety Disconnect Switch, and on the valves to prevent unauthorized tampering of the equipment.
  - Under normal operation, the valves must be locked in the open position.

## 10.2 Vapor Piping Post Installation

- After all piping has been installed; make sure the 2 lockable ball valves are in the closed position.
- Make sure all the pipe connections are tight.
- Make sure there is proper slope from the *Green Machine* to the vent risers.
- Make sure there are no traps between the *Green Machine* and the vent risers.
- If flex piping is used, make sure the flexible piping is adequately supported.
- All connections to the *Green Machine* must be galvanized pipe.

## 10.3 Vapor Piping Bill of Material - Contractor Supplied

| Quantity    | Component(s)  |
|-------------|---|
| 2           | 1" diameter straight tee's with caps                            |
| 2           | 1" diameter unions  |
| 2           | 1" diameter locking ball valves                                 |
| 1           | Straight tee (sized to match existing vent riser)               |
| 1           | 1" x 2" galvanized reducer bushing                              |
| 1           | Straight tee with cap (sized to match new vent riser)           |
| 1           | Rain cap (on new vent riser)                                    |
| As required | 1" diameter pipe, elbows, and misc. pipe fittings               |
| 5           | <u>Locks:</u> 2- cover, 2-locking ball vales, 1-control cabinet |

## 11 Electrical

- The VST Control Panel and the electrical junction box inside the *Green Machine* arrive from the factory pre-wired.
- The contractor is responsible for supplying all wires, conduits, fittings, seal-offs, and the safety disconnect-switch.
- Lockable safety disconnect-switch as required by the NEC:
  - Must include an interlock device and wired per included drawings.
  - Must be installed within eye-sight of the *Green Machine*.
  - Must not be installed within 3-feet of the *Green Machine*.
  - Consult the NEC for restrictions, location, and type of disconnect.
  - Not provided by VST.
- The *Green Machine* is installed in a Class I, Division 2 hazardous location and therefore requires electrical seal-offs when connecting to ordinary, non-hazardous electrical locations. Consult the NEC and NFPA for installation instructions.
- All wiring (115 VAC and 24VDC) to be TFFN or THHN with 600V insulation.
- All wiring must be gasoline and oil resistant.
- The contractor is responsible for sizing the wire, cable, and conduit according to the NEC.
- All power (115 VAC and 24VDC), the neutral, and the ground wires connected to the *Green Machine* will be disconnected when:
  - The Emergency Shut-Off (ESO) is activated.
  - The safety disconnect-switch is opened.
  - The VST Control Panel breaker is switched OFF at the main distribution panel breaker.
  - The disconnect switch on the VST Control Panel is turned OFF.

## 11.1 Electrical Requirements

| VST Control Panel Power Requirements |         |         |                     |           |                                       |
|--------------------------------------|---------|---------|---------------------|-----------|---------------------------------------|
| Equipment                            | Phase   | Voltage | Amperage            | Frequency | Fuse/Breaker Size                     |
| Main power                           | 1-Phase | 115 VAC | 20                  | 60-Hz     | 20 amp breaker                        |
| Vacuum Pump Motor                    | 1-Phase | 115 VAC | 8.8<br>(See note 1) | 60-Hz     | 10 amp breaker                        |
| Control Valves                       | 1-Phase | 115 VAC | 1.0                 | 60-Hz     | 5 amp fuse<br>(3 each)                |
| 24VDC Power supply                   | 1-Phase | 115 VAC | 4.0                 | 60-Hz     | 4 amp fuse                            |
| HC Sentry Module                     | 1-Phase | 115 VAC | <1.0                | 60-Hz     |                                       |
| <i>Green Machine</i><br>Controller   |         | 24VDC   |                     |           | Protected by<br>24VDC power<br>supply |

NOTE 1: The 8.8 amp listed is only for the ½ HP, 115 VAC, 1-PH Leeson motor

## 11.2 Electrical Safety



- The *Green Machine* uses lethal voltages and operates in areas where gasoline vapor may be present.
- Serious injury or death from electrical shock, fire, or explosion may result if the power is ON during installation, testing, or maintenance.
- Be sure to use Lockout/Tag-Out procedures when working on or installing the *Green Machine* or while working on electrical components.
- Always power OFF any electrical components connected to the *Green Machine*. **The *Green Machine* can start automatically.**
- Do not use tools that can generate sparks if there is risk of flammable or explosive vapors being present.
- Read and understand all materials related to installing, testing, and operating the *Green Machine* prior to installation.

### **11.3 Electrical Installation Code Requirements**

- According to NFPA 30:
  - “Electrical wiring and electrical utilization equipment shall be a type specified by and be installed in accordance with NFPA 70. Electrical wiring and electrical utilization equipment shall be approved for the locations in which they are installed.”
- All electrical wiring and electrical utilization equipment must be installed to meet federal, state, and local codes.
- Flexible electrical conduit connections to the *Green Machine* may be required by local jurisdictions to meet seismic code requirements.
- Following such procedures may be required by local, state, and national authorities.
  - The *Green Machine must be installed* in accordance with the National Electric Code (NEC), NFPA 70, and with the Automotive and Marine Service Station Code (NFPA 30A).
  - Intrinsically safe devices must be installed in accordance with Article 504 of the National Electrical Code, ANSI/NFPA 70, for installation in the United States.
  - According to NFPA 30A and the California Fire Code:  
“Electrically energized vapor-recovery equipment shall be directly connected to and controlled by the emergency pump shut off in Section 5202.4.7.”



**11.4 Electrical Components**

| Existing Components  | VST Supplied Components  | Contractor Supplied Components   |
|--|--|--|
| <ul style="list-style-type: none"> <li>• 115 VAC Main Electrical Panel</li> </ul>  | <ul style="list-style-type: none"> <li>• VST Control Panel</li> </ul>  | <ul style="list-style-type: none"> <li>• Safety Disconnect Switch with an Interlock</li> </ul>     |
| <ul style="list-style-type: none"> <li>• TLS-350 with:               <ul style="list-style-type: none"> <li>• Comm Board</li> <li>• Relay Board</li> <li>• I.S. Interstitial Module</li> </ul> </li> </ul> | <ul style="list-style-type: none"> <li>• <i>Green Machine:</i> <ul style="list-style-type: none"> <li>• Pre-wired Internal Junction Box</li> </ul> </li> </ul> | <ul style="list-style-type: none"> <li>• All conduit</li> </ul>                                    |
| <ul style="list-style-type: none"> <li>• Emergency Shut Off</li> </ul>   | <ul style="list-style-type: none"> <li>• HC Sentry</li> </ul>  | <ul style="list-style-type: none"> <li>• Electrical Seal-Offs</li> <li>• Wire and Cable</li> </ul> |
|  | <ul style="list-style-type: none"> <li>• HC Sentry Interface Cable</li> </ul>  | <ul style="list-style-type: none"> <li>• 115VAC relay</li> </ul>                                   |

## 11.5 Electrical Installation Procedures

**SAFETY PRECAUTION:**  
**PRIOR TO STARTING ANY ELECTRICAL WORK, VERIFY THE BREAKER INSIDE THE PANEL AND THE VST CONTROL PANEL IS LOCKED OUT/ TAGGED OUT, AND VERIFY THAT THE TLS-350 IS IN THE MANUAL OFF MODE.**

### 11.5.1 VST Control Panel Field Wiring Procedure

- See Figures 16 & 17
- Drill holes in the VST Control Panel for all wiring connections.
- Install the VST Control Panel **only inside** the GDF per NEC regulations. The location may vary within the GDF given the allowable space. When possible, place the VST Control Panel as close to the TLS-350 as possible.
- Install or have available a 115 VAC, 20-amp, single-phase breaker in the main distribution panel.
- Make sure the 20-amp breaker inside the distribution panel is turned **OFF** and follow lockout/tagout safety procedures.
- Install the 115 VAC power, the neutral, and the ground from the main distribution panel to the VST Control Panel.
  - The wire labels are:
    - Terminal block 02011 – 115 VAC (hot)
    - Terminal block 02012 – 115 VAC (neutral)
    - Terminal block GND - Ground (Gnd)

## 11.5.2 VST Control Panel Terminal Block Wire Numbers & Descriptions

Use the terminal blocks and description to field wire the VST Control Panel to the Green Machine and supporting electrical equipment.

**CAUTION: Power to the VST Control Panel maybe supplied by multiple 115 VAC external power sources.**

External power may exist inside the VST Control Panel when:

1. The main 115 VAC power to the panel is turned OFF.
2. The panel ON/OFF switch is turned OFF.
3. The Safety Disconnect is turned OFF.
4. The ESO is activated or not activated.

Terminal Block 02032 - ESO (115 VAC IN)

Terminal Block 02032 - 4-RELAY MODULE (115 VAC OUT)

Terminal Block 02032 - INTERLOCK (115 VAC OUT)

Terminal Block 02023 - INTERLOCK (115 VAC IN)

Terminal Block 02043 - TLS-350 (115 VAC IN)

Terminal block 02044 – OVERFILL (115 VAC IN)



### 11.5.3 TLS-350 4-Relay Module: *Machine* RUN and Overfill Alarm Output Relay Wiring Procedure

**CAUTION:** The GM Run and OVERFILL ALARM output relays inside the TLS-350 4-Relay Module can be powered by a 115 VAC power source inside the VST Control Panel or from an external 115 VAC power source. Refer to the TLS-350 installation manual for connecting to and configuring the correct output relays.

#### GM Run Output Relay:

- See Figures: 16 & 17 for Option 1, and 18 & 19 for Option 2
- GM Run output relay (N.O.) closes and turns on the Green Machine when the UST pressure increases to 0.2" WC.
- The GM Run output relay can be powered from the VST Control Panel as OPTION 1. or from an external 115 VAC power source as OPTION 2.
- **OPTION 1:** If the GM Run output relay is powered from the VST Control Panel, install two wires from the VST Control Panel to the 4-Relay Module.
  - The wire labels are:
    - Terminal block 02032 – 115 VAC IN
    - Terminal block 02043 – 115 VAC OUT
- **OPTION 2:** Install one wire from the VST Control Panel to the 4-Relay Module if the GM Run output relay is powered from an external 115 VAC power source. The external power source may be from the ESO or another external power source.
  - The wire label is:
    - Terminal block 02043 – 115 VAC OUT

#### OVERFILL ALARM Run Output Relay:

- See Figures: 16 & 17 for Option 1, and 18 & 19 for Option 2
- The OVERFILL ALARM output relay (N.O.) shuts down the *Green Machine* when a UST reaches max volume level during a fuel drop.
- The OVERFILL ALARM output relay can be powered from the VST Control Panel as OPTION 1. Or from an external 115 VAC power source as OPTION 2.
- **OPTION 1.** If the OVERFILL ALARM output relay is powered from the VST Control Panel, install two wires from the VST Control Panel to the 4-Relay Module
  - The wire labels are:
    - Terminal block 02032 – 115 VAC IN (May not be required if the 03023 - 115 VAC wire was used in the GM Run output relay circuit as described above).
    - Terminal block 02043 – 115 VAC OUT.
- **OPTION 2.** If the OVERFILL ALARM output relay is powered from an external 115 VAC power source, install one wire from the VST Control Panel to the 4-Relay Module. The external power source may be from the ESO or another external power source.
  - The wire label is:
    - Terminal block 02043 – 115 VAC OUT

## 11.5.4 VST Control Panel to the TLS-350 Intrinsically Safe (I.S.) Bay Wiring Procedure

- **See Figures: 15 & 24**
  - The VST Control Panel uses a current transducer to monitor the vacuum pump motor amperage when the Green Machine is running.
  - If the motor amperage falls below a certain value, a relay closes inside the VST Control Panel, which energizes a relay in the I.S. Bay of the TLS-350.
  - Do not run the wire in any conduit where high voltage is present.
  - Connect the wire to an open liquid sensor channel. If there are not any open channels, an additional module will be required.
  - Program the TLS-350 liquid sensor channel as NORMALLY CLOSED for the channel used (ex. L 8).
  - Give the channel that was used a custom label to identify it as the Green Machine Motor Fault input: “GM Motor Fault.”
  - The TLS will display: “LX: Fuel Alarm” when the GM is in a Motor Fault condition, with “X” being the channel used for the sensor.
  - After the Motor Fault alarm occurs, the printer will show the “GM Motor Fault” label on the automatic printout.
- Install a 2-conductor, shielded, 18 gauge, twisted pair, with a drain wire, cable from the VST Control Panel I.S Bay.
  - Terminate field wiring into TLS Console and connect to Interstitial Sensor Interface Module located in the intrinsically safe wiring compartment of the TLS as shown in Figure 4.  
Note: observe polarity! The cable length between the console and sensor must not exceed 1000 feet.
  - Attach the cable shield to the ground lug closest to the conduit entry inside the I.S. Bay.  
Do not ground both ends of the shield.
  - Terminal block 07022 – (+)
  - Terminal block 07032 – (-)

**CAUTION: Refer to the TLS-350 installation manual for connecting to and configuring the correct output relays.**

**Note: Intrinsically safe devices must be installed in accordance with Article 504 of the National Electrical**

### 11.5.5 RS422 to RS232 Adapter to TLS-350 RS32 Port Connections

- See Figures 11 - 15
- Per ARB Advisory 355, there must be an available RS232 port for the district inspector to use for downloading data from the TLS-350. Check the TLS-350 to see if there are 2 or more available RS232 serial ports. One DB9 female RS232 port will be found on the required Multi-port MODBUS communication card in the TLS-350. Check to see if there is an additional port on another card available. If there are two or more ports available, use Option A for the connections. This is a direct connection from the Adapter to the TLS-350. If there is only one port available, use Option B for the connections. This connection method uses an RS232 Port Combiner to allow sharing of a serial port.
- The RS422 to RS232 adapter is attached to the top of the VST Control Panel. See figures 12 & 13.
- **OPTION A:** Using the 6 foot RS232 (DB9 Male to Male) serial cable supplied with the VST *Green Machine*, connect one end of the serial cable into the RS232 port on the Adapter located on top of the VST Green Machine Control Panel and the other directly to the TLS-350 Multi-port MODBUS card. Secure these connections. If a longer cable is needed it may be ordered, however the cable length should not exceed 50 feet. Finally set the communications setting for the COM 6 in the TLS-350 to 9600 BPS, 8 data bits, 1 stop bit, No parity. See figure 11.




Figure 11: RS422 to RS232 Adapter to TLS-350 Connection - Option A Direct Connection




Figure 12: VST Green Machine Control Panel Front View




Figure 13: VST Green Machine Control Panel Top View of Adapter



- OPTION B:** If there is not an available communications port for the inspector to use, an RS232 Port Combiner must be used to allow sharing of the serial port. This optional TLS-350 Inspector Port Communications Kit, GM-032, containing an RS232 Port Combiner, an RS232 Null Modem DB9 Male to Male cable, an RS232 Straight Through DB9 Male to Male cable and AC adapter for the Port Combiner must be purchased through VST. The inspector may gain access to the TLS-350 through the Port Combiner's open port.
- Using the 6 foot RS232 Null Modem (DB9 Male to Male) serial cable supplied with the VST *Green Machine*, connect one end of the serial cable into the RS232 port on the Adapter located on top of the VST Green Machine Control Panel and the other into the slave connection on the Port Combiner. If a longer cable is needed it may be ordered, however the cable length should not exceed 50 feet. Connect one end of the RS232 Straight Through DB9 Male to Male cable to the Master port on the Port Combiner and the other end directly to the TLS-350 Multi-port MODBUS card. Secure these connections. This leaves the second slave port open for the inspector's use. Install the Null Modem adapter to this port. Finally set the communications setting for the COM 6 in the TLS-350 to: 9600 BPS, 8 data bits, 1 stop bit, No parity. **See figure 14.**
- Attach the port combiner and its power source next to an available outlet close to the TLS-350. Having the port combiner next to the TLS-350 will be a convenience for the inspector.




Figure 14: RS422 to RS232 Adapter to TLS-350 Connection - Option B Using a Port Combiner

### 11.5.6 GDF ESO to the VST Control Panel Wiring Procedure

- **See Figures: 16 & 17 for Option 1, and 18 & 19 for Option 2**
  - The ESO (N.C.), when activated, will turn OFF all power and disconnect the neutral and the ground wires to the *Green Machine*.
  - The ESO wire connecting to the VST Control Panel will be 115 VAC HOT as an external power source.
- Install one wire from the VST Control Panel to the ESO control system output relay.
- The wire label is:
  - Terminal block 02032 - ESO (115 VAC HOT).

CAUTION: "Electrically energized vapor-recovery equipment shall be directly connected to and controlled by the emergency pump shut off in Section 5202.4.7".

NOTE: The Green Machine will not operate if the ESO is not connected to the VST Control Panel.

### 11.5.7 VST Control Panel to Safety Disconnect Switch Wiring Procedure

- **See Figures 15 & 20**
- Install 8 wires from the VST Control Panel to the Safety Disconnect Switch
  - 2 wires connect to the interlock switch located in the Safety Disconnect Switch
    - The terminal block label is:
      - Terminal block 02032 - INTERLOCK (+) 115VAC
      - Terminal block 02023 - INTERLOCK (-) 115 VAC
      - Note: The Green Machine will not operate if this circuit is not complete.
  - 5 wires connect to the Safety Disconnect Switch:
    - L1 is for the Vacuum Pump power:
      - Wire number 02052 - VAC PUMP MOTOR (115 VAC HOT).
      - Requires a 10 amp fast acting fuse.
    - L2 is for the V1 Control Valves:
      - Wire number 02062 - V1 VALVES (115 VAC HOT).
      - Requires a 5 amp fast acting fuse.
    - L3 is for the V2 Control Valves:
      - Wire number 02072 - V2 VALVES (115 VAC HOT).
      - Requires a 5 amp fast acting fuse.
    - L4 is for the V5 Control Valves:
      - Wire number 02074 - V5 VALVES (115 VAC HOT).
      - Requires a 5-amp, fast-acting fuse.
    - One ground wire: GND.
  - 1 wire passes through the safety-disconnect switch without any connections:
    - 1 neutral wire.

### 11.5.8 Safety Disconnect Switch to Internal Junction Box Wiring Procedure

- **See Figures 15 & 21**
- Install 6 wires
  - 6 wires connect to the *Green Machine* Internal Junction Box.
  - L1 is for the Vacuum Pump power:
    - Wire number 02052 - VAC PUMP MOTOR (115 VAC HOT).
  - L2 is for the V1 Control Valves:
    - Wire number 02062 - V1 VALVES (115 VAC HOT).
  - L3 is for the V2 Control Valves:
    - Wire number 02072 - V2 VALVES (115 VAC HOT).
  - L4 is for the V5 Control Valves:
    - Wire number 02074 - V5 VALVES (115 VAC HOT).
  - One neutral wire: 02042 - Neutral.
  - One ground wire: Gnd.

### 11.5.9 HC Sentry Wiring Procedure

- Install a 2-conductor, 24 gauge (minimum), twisted pair, with a drain wire, shielded cable from the VST Control Panel to the HC Sentry Interface Module.
  - **See Figures 15 & 23**
- Install the HC Sentry Interface Cable from the HC Sentry to the TLS-350 Multiport Card/Communication Port.
  - **See Figures 15 & 23**




Figure 15: VST Control Panel Wiring Diagram




Figure 16: Field Wiring the VST Control Panel, Option 1




Figure 17: Field Wiring the TLS-350 4-Relay Module for the ESO, GM Run, and Overfill Alarm, Option 1




Figure 18: Field Wiring the VST Control Panel, Option 2




Figure 19: Field Wiring the TLS-350 4-Relay Module for the ESO, GM Run, and Overfill Alarm, Option 2






Figure 20: Safety Disconnect Switch Field Wiring Diagram




Figure 21: Green Machine Junction Box Field Wiring Diagram




Figure 22: Vacuum Pump Motor Wiring Diagram




Figure 23: HC Sentry Interface Cable Connections




Figure 24: Field Wiring the TLS-350 Interstitial Sensor Interface Module – I.S. Bay





Figure 25: HC Sentry to TLS-350 Connections

## 12 VST Control Panel

The VST Control Panel is designed to manage the operation of the *Green Machine* based on input from the TLS-350, which is managing the UST vapor pressure. **Figure 26** shows the front of the Control Panel with the following items:

- The *Green Machine* controller:
  - Operates the *Green Machine* based on UST vapor pressure
- The electrical Power ON/OFF disconnect switch:
  - The electrical switch provides a means to turn OFF and disconnect the “main” power from the Control Panel.
  - CAUTION: THIS CONTROL PANEL MAY HAVE FOUR (4) 115 VAC POWER SUPPLY. CONNECTION POINTS IDENTIFIED BY YELLOW TERMINAL BLOCK AND HOT WIRES INSIDE THE CONTROL PANEL. FAILURE TO DISCONNECT THE FOUR POWER SUPPLY CONNECTION POINTS BEFORE SERVICING COULD RESULT IN DEATH OR SERIOUS INJURY.
  - Can be locked in the OPEN or CLOSED position (lockout/tagout procedures).



**Figure 26:** VST *Green Machine* Control Panel, Front View

## 12.1 Start up Screen and Function Buttons




Figure 27: Startup Screen and Function Buttons

### 12.1.1 Main Screen Overview

- The *Green Machine* will always power up in the Main Screen
- The *Green Machine* will always be in the NORMAL OPERATING mode unless there is an Overfill Alarm or a test is being conducted.
- The *Green Machine* Modes:

|                           |  |
|---------------------------|--|
| ON Mode                   | Screen display: <i>Green Machine</i> ON  |
| PURGE Mode                | Screen display: <i>Green Machine</i> ON  |
| As required, the OFF Mode | Screen display: <i>Green Machine</i> OFF |

- Function Buttons

|    |  |
|----|--|
| F1 | To start the Leak Test   |
| F2 | To start the Functionality Test  |
| F3 | To start the GM Continuous Monitor Test  |
| F4 | To start the <i>Green Machine</i> Annual Compliance Test   |
| F5 | <ul style="list-style-type: none"> <li>To terminate testing &amp; return the <i>Green Machine</i> to a NORMAL OPERATING mode</li> <li>Reset the Motor Fault</li> </ul> |

- The esc button:
  - Push the esc button the first time to access the Startup screen.
  - Push the esc button a second time to return to the previous screen.
  - The esc button can be used at any time.



## 12.2 The Green Machine ON Screen



Figure 28: Green Machine ON Screen

- The *Green Machine* ON screen indicates the *Green Machine* is in either a ON mode or a PURGE mode. The *Green Machine* ON screen will be shown when the TLS-350 Output Relay (that starts the *Green Machine*) is closed.

### 12.2.1 Green Machine in the ON Mode

The VST Controller is programmed to start the *Green Machine* when the TLS output relay closes. The TLS-350 output relay closes when:

- The *Green Machine* is in the Automatic mode at the TLS-350 and the UST pressure is above 0.2" WC.
- The *Green Machine* is in the Manual ON mode at the TLS-350.

When the *Green Machine* is in the ON mode:

- Gasoline vapors are being pulled into the *Green Machine* from the USTs.
- The UST pressure is decreasing.
- The Vapor Filtration Cartridge is collecting hydrocarbons.
- Clean air is venting to atmosphere.
- There is not an Overfill Alarm condition.
- There is not a Motor Fault.
- Tests are not being conducted.
- After the ON mode is completed, the *Green Machine* will go into the PURGE mode.

### 12.2.2 Green Machine in the PURGE Mode:

The PURGE Mode will be active regardless of the TLS-350 output relay being opened or closed.

- The PURGE mode is controlled by the *Green Machine* VST Controller.

When the *Green Machine* is in the PURGE mode:

- Hydrocarbons are being returned to the UST.
- Zero airflow to atmosphere out of the Clean Air Outlet.
- There is not an Overfill Alarm condition.
- There is not a Motor Fault.
- Tests are not being conducted.
- Normally, when the PURGE mode is completed, the *Green Machine* will return to the Off Mode.

### 12.3 Green Machine OFF Screen



Figure 29: Green Machine OFF screen

- The OFF mode screen will be shown after the PURGE mode is completed, and when the TLS-350 output relay is open.

The TLS-350 output relay is open when:

- The *Green Machine* is in the Automatic mode at the TLS-350 and the UST pressure is below 0.2" WC.
- The *Green Machine* is in the Manual OFF mode at the TLS-350.
- If there is an Overfill Alarm condition:
  - The *Green Machine* will not operate and will remain OFF for 2-hours after the Overfill Alarm clears.

When the *Green Machine* is OFF:

- The Vacuum Pump is not running.
- All valves are closed.
- Clean air is not being vented to atmosphere.
- UST pressure is not reducing.
- Testing can be performed.
- An Overfill Alarm condition may exist.
- A Motor Fault condition may be active.

### 12.4 TLS-350 Operations Overview

- A NORMAL OPERATING mode is when the *Green Machine* is in the Automatic mode at the TLS-350.
- The *Green Machine* cycles through the ON and PURGE modes to reduce UST pressure.

---

### 12.4.1 TLS-350 4-Relay Module Information

- The TLS-350 has two sets of output relays that connect to the VST Control Panel:
  1. The output relay that starts the *Green Machine*.
  2. The OVERFILL ALARM output relay.
  
- Output relay that starts the *Green Machine*
  - The *Green Machine* is in the Automatic mode or the Manual ON mode at the TLS-350.
  - In the Automatic mode: This output relay is open when the UST pressure is below 0.2” WC and closed when the UST pressure is above 0.2” WC.
  - In the Manual ON mode: This relay will remain closed.
  - In the Manual OFF mode: This relay will remain open.
  
- OVERFILL ALARM output relay
  - The OVERFILL ALARM output relay is normally open when there is not an OVERFILL ALARM condition.
  - If there is an OVERFILL ALARM, the OVERFILL ALARM output relay closes which will keep the *Green Machine* from operating.
  - In an OVERFILL ALARM condition, the *Green Machine* will not operate in the AUTOMATIC mode, MANUAL ON mode, or in any test conditions.
  - The *Green Machine* will remain OFF for 2-hours after the OVERFILL ALARM clears.
  - See the OVERFILL ALARM summary in this document for more information.

### 12.4.2 TLS Intrinsically Safe (I.S.) Bay Information

- The TLS-350 Intrinsically Safe (I.S.) Bay should have an Interstitial Sensor Interface Module installed with an open channel/port for use with the *Green Machine*. If an open channel/port is not available, an interstitial sensor interface module will need to be purchased and installed in the Intrinsically Safe Bay per Veeder-Root instructions in Section 12 – “Installing TLS Console Modules”.
  
- The Current Sensor will connect the open relay through an intrinsically safe barrier located in the VST control panel.
  
- When the Vacuum Pump Motor Faults:
  - The relay will close and post an ALARM to the TLS.
  - Will not shutdown the GDF.
  - Will not have to Clear Test After Repair.

## 12.5 Overfill Alarm



Figure 30: Overfill Alarm Screen

Whenever there is a UST gasoline Overfill Alarm at the station, the TLS-350 is configured to alarm.

1. The Veeder Root TLS-350 Fuel Management System has a Tank Overfill Alarm output relay wired to the VST Control Panel.
  - An overfill condition exists when during a fuel drop, the gasoline level in the UST exceeds the Overfill Alarm setting, which is usually between 90-95% capacity of the UST.
2. When an overfill occurs, the OVERFILL ALARM output relay closes at the TLS-350.
3. The VST Control Panel Controller senses when the Overfill Alarm output relay closes:
  - The *Green Machine* will turn OFF if it is running.
  - Prevents the *Green Machine* from starting if it is not running.
4. When the gasoline level drops below the Overfill Alarm level:
  - The TLS-350 Overfill Alarm output relay opens and the alarm clears.
  - A VST Control Panel 2-hour overfill timer starts to countdown.
5. When the 2-hour overfill time elapses, the *Green Machine* will PURGE for 15-minutes
6. When the PURGE mode ends, the *Green Machine* goes into a NORMAL OPERATING mode provided the *Green Machine* is in the Automatic mode at the TLS-350.

An Overfill Alarm condition:

- Blocks the testing function buttons.
- Ends any tests that may be running.
- Ends the ON mode or PURGE mode during a NORMAL OPERATING cycle.

## 12.6 Motor Fault




Figure 31: Motor Fault Screen

The VST Control Panel is equipped with a current transducer that samples the vacuum pump motor current during the Purge cycle.

1. If the motor current is below set a value for at least 60 seconds a motor fault is created.
  - The motor fault closes an intrinsically safe relay contact inside the VST Control Panel that is connected to the TLS-350 intrinsically safe (I.S.) bay via an intrinsically safe circuit.
  - The Green Machine will turn OFF and remain OFF until the F5 button is pushed.
  - A Motor Fault is then displayed on the controller.
2. Once a motor fault has occurred, the fault can be cleared by pressing F5 on the VST Control Panel controller.
3. When the motor fault is reset via F5, the Green Machine will automatically go into the purge cycle.
4. After the purge cycle is successfully completed without a motor current fault, the Green Machine is now able to go into the Run cycle if the TLS is providing the signal to do so.

**CAUTION:** With the motor fault active, the Green Machine will remain OFF until the F5 button is pushed.

## 12.7 VST Control Panel Test Buttons

- **F1 - Leak Test**
  - Refer to this manual for the testing procedure.
- **F2 - Functionality Test**
  - Refer to this manual for the test procedure.
- **F3 - GM Continuous Monitor Test**
  - Refer to the VR-203 and VR-204 Exhibit 15 for the testing procedure.
- **F4 - Annual Compliance Test (GM Bag Test)**
  - Refer to the VR-203 and VR-204 Exhibit 15 for the testing procedure.

## 13 Green Machine Pre Start-Up Testing

### 13.1 Check PMC/ISD Settings on the TLS-350

- Prior to starting the *Green Machine*, make sure the proper Veeder-Root software for the *Green Machine* has been installed on the TLS-350: PMC = 1.04 or higher; ISD = 1.05 or higher.
- See **PMC only** parameter settings in Veeder-Root manual:
  - Smart sensor setup
  - Output relay setup
  - PMC setup
- See **ISD** parameter settings in Veeder-Root manual:
  - Smart sensor setup
  - EVR/ISD setup
  - Output relay setup
  - PMC setup

### 13.2 Green Machine Post-Installation Start-Up Tests

- During post-installation testing, the *Green Machine* will use outside air, not gasoline vapor from the USTs, to conduct these tests.
  - Functionality Test
  - Leak Test
- VST *Green Machine* Annual Compliance Tests, Exhibit 15:
  - GM Bag Test - uses gasoline vapor from the USTs
  - Continuous Monitor Test
- During post-installation testing, the *Green Machine* will use gasoline vapor from the USTs to conduct this test.
  - Determination of VST *Green Machine* Activation Pressure - VR-203/204, Exhibit 9.


### 13.3 Functionality Test

#### Purpose of the Test

- To verify that the valves and the Vacuum Pump are operating properly.

#### Preparation

- Put the *Green Machine* in the Manual OFF mode at the TLS-350.
- Push the F5 button to make sure no other tests are running.
- The *Green Machine* is now OFF and will not operate.
- Make sure power is **ON** to the VST Control Panel.
- Close the two valves between the *Green Machine* and the vent risers, and remove the caps from both of the tees.




**Figure 32: Functionality Test Screen**

#### Testing Procedures

- Push the F2 button to start the Functionality Test (**See Figure 32**)
  - The *Green Machine* will RUN for 60-seconds then PURGE for 60-seconds, (this is one cycle).
  - The *Green Machine* will continue to cycle 5-times or until the F5 button is pushed to end the test.
  - There are 5-cycles to provide enough time to conduct the test.
  - Pushing the F5 button will cancel the test and the screen will show *Green Machine OFF*.

2. During the 60-second RUN mode: **(See Figure 33)**
  - Place your hand over the tee opening at the vapor inlet and feel for suction
  - Next, place your hand over the tee opening at the air outlet and feel for air blowing
3. During the 60-second PURGE cycle: **(See Figure 33)**
  - After the PURGE cycle has begun, place your hand over the tee opening at the vapor inlet and feel for air blowing. The blowing air will reduce to zero flow soon after the PURGE cycle begins.
  - Next, place your hand over the tee opening at the air outlet and feel for zero airflow.
4. If all the conditions hold true for the above test, the valves and the Vacuum Pump are working as expected.
5. Continuous airflow during the PURGE cycle would indicate a leak in the *Green Machine* internal system:
  - Push the F5 button to end the Functionality Test and the screen will show *Green Machine OFF*.
  - Conduct a Leak Test, as shown in this IOM, to find where the leak is occurring.
6. After 5-cycles are complete, the Functionality Test has ended:
  - The *Green Machine* Controller will automatically go back to the *Green Machine OFF* screen.
  - Open the two ball valves between the *Green Machine* and the vent risers, and replace the caps on the two tees.
  - Put the *Green Machine* in the Manual ON mode at the TLS-350.

**CAUTION: DO NOT PUT THE GREEN MACHINE IN THE MANUAL ON MODE AT THE TLS-350 UNTIL THE VALVES BETWEEN THE GREEN MACHINE AND THE VENT RISERS ARE OPENED. PUTTING THE GREEN MACHINE IN THE MANUAL ON MODE, WHEN THE VALVES ARE CLOSED, WILL NOT ALLOW THE GREEN MACHINE TO OPERATE PROPERLY AND MAY CAUSE DAMAGE TO INTERNAL COMPONENTS.**



**Figure 33: Green Machine Operation Diagram**



## 14 Leak Test

### Purpose and Applicability

- The purpose of the Leak Test is to insure that all of the tubing fittings and tubes located inside the VST *Green Machine* are leak free.
- The leak test will be required only at installation, during certain troubleshooting, and any time after the *Green Machine* plumbing, fittings, or connections have been loosened or adjusted.

### Principle and Summary of Test Procedure

- The *Green Machine* is configured in the MANUAL OFF operating mode and the solenoid valves are set such that all internal *Green Machine* piping and connections can be pressurized with nitrogen. Once pressurized, all piping and connections are checked by applying a soapy solution. Any nitrogen escaping from leaks will cause the soapy solution to bubble. The absence of bubbles indicates that the piping and connections are free of leaks.

### Equipment and Supplies

- Cylinder of compressed nitrogen gas with regulator capable of establishing an outlet pressure of less than 20 psi.
- VST Leak Test Fixture (See **Figure 34**).
- Soapy solution that will produce visible bubbles when exposed to nitrogen gas leaking from piping and connections.

### Pre-Test Requirements

- Close the manual inlet and outlet valves at the *Green Machine*, and remove a cap from one of the tees (See **Figure 35**). Only one open tee is required for this test.
- Install the Leak Test Fixture in the empty 1" pipe tee on the *Green Machine* as shown in **Figure 35**.
- Ensure that the shut-off valve on the VST Leak Test Fixture is closed, and then connect the nitrogen source. Set the nitrogen regulator to approximately 5 psi outlet pressure, making sure that it does not exceed a maximum of 20 psi outlet pressure.
- The leak check is conducted with 1.0 to 2.0 PSI nitrogen.

### Test Procedure

1. Manually turn off the VST *Green Machine* as follows:
  - On the TLS Console front panel, use the 'mode key' to scroll to 'DIAG MODE' and then use the function and step keys to view the 'VAPOR PROCESSOR MODE' menu.
2. From the 'VAPOR PROCESSOR MODE' menu, change the vapor processor mode of operation from automatic to manual mode. From the 'VAPOR PROCESSOR STATE' menu, verify the VP STATE is in the "off" mode. The processor shall be in the off mode for the duration of the test.

### **CAUTION:**

If by chance the TLS is in the Auto Mode during the Leak Check Test, the PLC, after the F1 button is pushed, will control the *Green Machine* as indicated in Step 1 above. After the F5 button is pushed or the 30-minute timer times out, the PLC will convert back to a Normal Operating Mode and the *Green Machine* will start automatically if the UST pressure is above + 0.2"WC. Since this test is conducted with either the *Green Machine* inlet and outlet valve closed, starting the *Green Machine* automatically will NOT ALLOW THE GREEN MACHINE TO OPERATE PROPERLY AND MAY CAUSE DAMAGE TO INTERNAL EQUIPMENT.


3. Make sure power is ON to the VST Control Panel
4. At the VST Control Panel (**See Figure 36**), press the F1 button to disable running the vacuum pump and to open all of the control valves. The vacuum pump will remain off until one of the following conditions is met:
  - The F5 button is pushed OR
  - The PLC internal timer times out at 30 minutes
  - If additional time is needed to conduct the Leak Test, push the F1 button again to re-start the 30 minute timer.
5. Slowly and carefully pressurize the *Green Machine* to between 1.0 and 2.0 psi as follows:
  - Make sure the shut-off valve on the Leak Test Fixture is fully closed.
  - Make sure the Leak Test Fixture pressure regulator is fully closed.
  - Slowly open the valve on the test fixture to pressurize the *Green Machine* at 1.0 to 2.0 PSI nitrogen.

**CAUTION:**


**PRESSURIZING THE *Green Machine* OVER A MAXIMUM OF 5.0 PSI MAY CAUSE DAMAGE TO THE *Green Machine* O-RINGS AND/OR PUMP SEALS, WHICH WILL VOID ALL WARRANTIES OF THE *Green Machine*.**

6. With the *Green Machine* pressurized between 1.0 to 2.0 PSI nitrogen, spray a soapy solution on each fitting to check for bubbles:
  - If bubbles do not appear, the connection is tight.
  - If bubbles do appear, tighten the leaking fitting 1/8" turn (maximum) and re-check for leaks.
  - If the fitting cannot be tightened so that the connection is leak free, replace the 45° flare tube assembly that is leaking with a new tube assembly.
7. Continue this process until all the internal tube fittings have been checked and found leak free.
8. Once this test is complete and all the piping fittings are leak free, remove the compressed nitrogen connection to the Leak Test Fixture.

9. Remove the Leak Test Fixture and Re-install the 1" pipe plug.
10. Open the manual inlet and outlet valves at the *Green Machine*.
11. After the testing is completed, push the F5 button on the VST Control Panel to put the PLC back to normal operating mode. If the F5 button is not pushed, the PLC will convert back to normal operating mode 30 minutes after the F1 button was pushed.
12. Use the TLS-350 to put the *Green Machine* back into the **Automatic** mode.



**Figure 34: Leak Check Fixture**



GM Installed Leak Test Fixture-A

Vapor Inlet/Return  
1" Piping

Air Outlet  
1" Piping

Figure 35: Green Machine Inlet and Outlet Valves Closed, and Leak Check Fixture Attached



GM CS1 Main Screen-F

Figure 36: Green Machine Controller

### Alternative Test Procedures

This procedure shall be conducted as specified. Modifications to this test procedure shall not be used to determine compliance unless prior written approval has been obtained from the ARB Executive Officer, pursuant to Section 14 of Certification Procedure CP-201.

**Data Form for Recording Results of  
VST Green Machine Leak Check Test**

| <b>Site Information</b>   |  |
|---|--|
| GDF Name:   |  |
| GDF Address:  |  |
| District Permit #:  |  |
| <b>Pre-Test Procedures</b>  |  |
| Inlet and outlet valves closed for test?  | <i>Comments</i>  |
|   | <input type="checkbox"/> Yes <input type="checkbox"/> No |
| Processor set to MANUAL OFF mode for test?  | <input type="checkbox"/> Yes <input type="checkbox"/> No |
| VST Controller set to TEST mode (F1) for test?  | <input type="checkbox"/> Yes <input type="checkbox"/> No |
| <b>Test Results</b>   |  |
| Test conducted at a pressure between 1.0 and 2.0 psi?   | <i>Comments</i>  |
|   | <input type="checkbox"/> Yes <input type="checkbox"/> No |
| Leaks identified during test?<br><i>If yes, describe leak location and corrective action taken.</i> | <input type="checkbox"/> Yes <input type="checkbox"/> No |
| Leaks present at conclusion of test?  | <input type="checkbox"/> Yes <input type="checkbox"/> No |
| <b>Post-Test Procedures</b>   |  |
| Inlet and outlet valves opened after test?  | <i>Comments</i>  |
|   | <input type="checkbox"/> Yes <input type="checkbox"/> No |
| Pipe plug replaced after test?  | <input type="checkbox"/> Yes <input type="checkbox"/> No |
| Processor returned to AUTOMATIC mode after test?  | <input type="checkbox"/> Yes <input type="checkbox"/> No |
| VST Controller set to NORMAL mode (F5) after test?  | <input type="checkbox"/> Yes <input type="checkbox"/> No |
| <b>Technician Information</b>   |  |
| VST Certified Technician Name:  |  |
| VST Certification Number:   |  |
| Certification Expiration Date:  |  |
| Test Company:   |  |
| Date Test Conducted:  |  |

**14.1 Determination of VST Green Machine Activation Pressure-Exhibit 9**

- See VR-203 and VR-204 Exhibit 9 and follow instructions.

**14.2 VST Green Machine Annual Compliance Test – Exhibit 15**

- Emissions Compliance Test (GM Bag Test)
- VST Continuous Monitor Test

## 15 Green Machine Start-Up Procedure

- Use the following start-up procedure when initially starting or re-starting after maintenance or testing.

| <b>START-UP PROCEDURE</b>  |  |
|--|--|
| 1.   | <ul style="list-style-type: none"> <li>• Make sure the plugs are installed on the 2 tees at the <i>Green Machine</i>.</li> </ul>   |
| 2.   | <ul style="list-style-type: none"> <li>• Make sure the 2 valves are locked in the OPEN position at the <i>Green Machine</i>.</li> </ul>  |
| 3.   | <ul style="list-style-type: none"> <li>• Make sure power is on to the VST Control Panel.</li> </ul>  |
| 4.   | <ul style="list-style-type: none"> <li>• Make sure the pressure sensor in the dispenser is operational.</li> </ul>   |
| 5.   | <ul style="list-style-type: none"> <li>• Make sure that the GDF is vapor tight. (TP 201.3 and Exhibit 4).</li> </ul>   |
| 6.   | <ul style="list-style-type: none"> <li>• After the TLS is installed and configured for the <i>Green Machine</i> and all EVR equipment has been installed, the <i>Green Machine</i> can become operational.</li> <li>• Put the TLS in the <b>AUTOMATIC MODE</b>.</li> <li>• Make sure the VST Control Panel is operational.</li> <li>• If the pressure is above +0.2" WC, the TLS Auxiliary relays will close and the <i>Green Machine</i> will start.</li> <li>• If the pressure is below +0.2" WC, the <i>Green Machine</i> will not start because the UST system-pressure is below the high-pressure threshold.</li> </ul> |
| 7.   | <ul style="list-style-type: none"> <li>• If the pressure is above 0.2"WC and the Green Machine does not start automatically, see the Green Machine Troubleshooting Manual.</li> </ul>  |
| <p><b>NOTE: All exhibits can be found in Executive Order VR-203 and VR-204</b></p> |  |

**CAUTION:** Locking ball valve handles at the *Green Machine* inlet and outlet must not be removed.



## 16 Green Machine Operation

### 16.1 Veeder-Root TLS-350

- The *Green Machine* is controlled by a Veeder-Root (VR) TLS-350.
- VST does not provide the TLS-350 controller or the software required by the TLS-350.
- The TLS-350 operates the *Green Machine* using 3 Modes:
  1. Automatic Mode - Used for normal operation.
  2. Manual OFF Mode - The *Green Machine* is OFF and will not run regardless of UST pressure.
  3. Manual ON Mode:
    - CAUTION: Used for maintenance and testing only.
    - The *Green Machine* will continue to cycle and PURGE regardless of UST pressure.




Figure 37: TLS-350 Front Panel

## **TLS-350 Troubleshooting**

### **17 TLS Warnings and Alarms (PMC & ISD)**

- During normal operation when the system is functioning properly and no warning or alarm conditions exist, the “**ALL FUNCTIONS NORMAL**” message will appear in the system status (bottom) line of the console display.
- If a warning or alarm condition occurs, the system displays the condition type and its location.
- If more than one warning or alarm condition exists, the display will alternately flash the appropriate messages.
- The system automatically prints an alarm report showing the warning or alarm type, its location, and the date and time the warning or alarm condition occurred.
- Warning and alarm posting causes the TLS-350 to activate:
  - Warning lights
  - Failure-Alarm indicator lights
  - Audible alarm
  - Automatic strip paper printout documenting the warning or alarm

**17.1 TLS-350 PMC Alarms - Troubleshooting Summary**

| Displayed Message | Description   | Light Indicator | Suggested Troubleshooting   |
|-------------------|---|-----------------|---|
| VP EMISSION WARN  | Mass emission exceeded the certified daily threshold.   | Yellow          | <ul style="list-style-type: none"> <li>• Troubleshooting Manual <a href="http://www.vsthose.com">www.vsthose.com</a>.</li> <li>• Exhibit 9</li> </ul> |
| VP EMISSION FAIL  | 2 <sup>nd</sup> Consecutive mass emission failure.  | Red             |   |
| PMC SETUP FAIL    | PMC is not configured or missing components.  | Red             | <ul style="list-style-type: none"> <li>• See ISD Troubleshooting Manual, P/N 577013-819</li> </ul>  |
| PMC SENSOR FAULT  | Component used by PMC has failed or reported an error condition. See Troubleshooting section for complete description of sensors and associated conditions that can cause a sensor fault. | Red             | <ul style="list-style-type: none"> <li>• Troubleshooting Manual <a href="http://www.vsthose.com">www.vsthose.com</a>.</li> <li>• Exhibit 9</li> </ul> |

## 17.2 TLS-350 ISD Alarms - Troubleshooting Summary

| Displayed Message                    | ISD Monitoring Category | Light Indicator | Description  | Suggested Troubleshooting <sup>1</sup>  |
|--------------------------------------|-------------------------|-----------------|--|---|
| ISD VAPOR LEAKAGE WARN               | Containment             | Yellow          | Containment system leaks at 2 times the TP-201.3 standard.                               | <ul style="list-style-type: none"> <li>Exhibit 4</li> <li>TP-201.3 (or equivalent test procedure)</li> </ul>  |
| ISD VAPOR LEAKAGE FAIL <sup>2</sup>  | Containment             | Red             | 8 <sup>th</sup> Consecutive Failure of Pressure Integrity (Vapor Leak) Test              |   |
| ISD GROSS PRESSURE WARN              | Containment             | Yellow          | 95 <sup>th</sup> percentile of 7-days' ullage pressure exceeds 1.3 IWC.                  | <ul style="list-style-type: none"> <li>Exhibit 9</li> <li>Exhibit 10</li> </ul>   |
| ISD GROSS PRESSURE FAIL <sup>2</sup> | Containment             | Red             | 8 <sup>th</sup> Consecutive Failure of Gross Containment Pressure Test                   |   |
| ISD DEGRD PRESSURE WARN              | Containment             | Yellow          | 75 <sup>th</sup> percentile of 30-days' ullage pressure exceeds 0.3 IWC.                 |   |
| ISD DEGRD PRESSURE FAIL <sup>2</sup> | Containment             | Red             | 31 <sup>st</sup> Consecutive Failure of Degradation Pressure Test                        |   |
| FLOW COLLECT WARN                    | Collection              | Yellow          | Vapor collection flow performance is less than 50%.                                      | <ul style="list-style-type: none"> <li>Exhibit 5</li> <li>Exhibit 6</li> <li>Exhibit 17</li> <li>TP-201.4 (or equivalent test procedure)</li> </ul> |
| FLOW COLLECT FAIL <sup>2</sup>       | Collection              | Red             | 2 <sup>nd</sup> Consecutive Failure of Vapor Collection Flow Performance Monitoring Test |   |
| VP EMISSION WARN <sup>3,4</sup>      | Processor               | Yellow          | Mass emission exceeded the certified threshold.  | <ul style="list-style-type: none"> <li>Troubleshooting Manual <a href="http://www.vsthose.com">www.vsthose.com</a>.</li> <li>Exhibit 9</li> </ul>   |
| VP EMISSION FAIL <sup>3,4</sup>      | Processor               | Red             | 2 <sup>nd</sup> Consecutive Mass emission test failure.                                  |   |

| Displayed Message           | ISD Monitoring Category | Light Indicator | Description   | Suggested Troubleshooting <sup>1</sup>  |
|-----------------------------|-------------------------|-----------------|---|---|
| ISD SENSOR OUT WARN         | Self-Test               | Yellow          | Failure of Sensor Self-Test                             | <ul style="list-style-type: none"> <li>Confirm ISD sensor &amp; module installation / communication per VR 204 IOM Section 12, Chapter 2</li> </ul> |
| ISD SENSOR OUT FAIL         | Self-Test               | Red             | 8 <sup>th</sup> Consecutive Failure of Sensor Self-Test |   |
| ISD SETUP WARN              | Self-Test               | Yellow          | Failure of Setup Test                                   | <ul style="list-style-type: none"> <li>Confirm EVR/ISD programming per VR 204 IOM Section 12</li> </ul>   |
| ISD SETUP FAIL <sup>2</sup> | Self-Test               | Red             | 8 <sup>th</sup> Consecutive Failure of Setup Test       |   |

**Note: The alarms listed in above table will also activate an audible alarm**

<sup>1</sup>See ISD Troubleshooting Manual P/N 577013-819 found at <http://www.veeder.com/object/577013-819.html> and the VST ISD Troubleshooting Manual found at [http://www.vsthose.com/pdf/Troubleshooting\\_Manual\\_Green\\_Machine.pdf](http://www.vsthose.com/pdf/Troubleshooting_Manual_Green_Machine.pdf)

<sup>2</sup>ISD Shut Down Alarms – see Figure 48 of IOM Section 12

<sup>3</sup>This warning will result in an ISD VP Status Warn

<sup>4</sup>This failure will result in an ISD VP Status Fail

## Maintenance

### 18 Overview

- The Vacuum Pump and Control Valves are the only components with moving parts in the *Green Machine*; therefore it requires very little maintenance.
- Because the system continually monitors itself and notifies you of any problems or situations, it requires very little attention.
- VST recommends annually inspecting the Vacuum Pump Rubber Flange Sleeve.
- If the *Green Machine* is not functioning properly consult the VST *Green Machine* Troubleshooting Manual to determine which component may need to be repaired or replaced.
- Exhibit 15 (*Green Machine* Annual Compliance test) may be used as an indicator of performance.
  - GM Bag Test
  - Continuous Monitoring Test

## 19 Rubber Flange Sleeve Replacement

NOTE: The Rubber Flange Sleeve replacement is done with the motor still attached to the *Green Machine* base.

### Safety



Use lockout / tagout procedures prior to starting work.




Figure 38: Vacuum Pump Coupling Replacement

### 19.1 Removing the Rubber Flange Sleeve

| Figure 38 |  |
|-----------|--|
| 1.        | Disconnect power to the VST Control Panel. (The power, ground, and neutral will be completely disconnected from the <i>Green Machine</i> ).              |
| 2.        | Follow lockout/tagout procedures.  |
| 3.        | Unlock the hasps and remove the cover from the <i>Green Machine</i><br><b>NOTE:</b> The Vacuum Pump and tubing will not be affected by moving the Motor. |
| 4.        | Remove the Fan Guard over the Coupling Flanges.  |
| 5.        | Remove 4 motor mounting bolts from the base plate.   |
| 6.        | Without removing the electrical service from the Motor, slide the Motor away from the Vacuum Pump so the Rubber Flange Sleeve can be removed.            |

### 19.2 Replacing the Rubber Flange Sleeve

| Figure 38 |  |
|-----------|--|
| 1.        | Insert a new coupling sleeve P/N GM-004 and slide the Motor towards the Vacuum Pump so the sleeve is tight between the coupling flanges. |
| 2.        | Re-install and tighten the 4 motor mounting bolts to the base plate.   |
| 3.        | Re-install the fan guard over the coupling flanges.  |
| 4.        | Remove the lock(s) and tags from the lockout/tagout.   |
| 5.        | After the work is completed, turn ON power to the VST Control Panel. The <i>Green Machine</i> is now operational.                        |
| 6.        | At the <i>Green Machine</i> , check to make sure the Vacuum Pump and Motor are running without excessive vibration or noise.             |
| 7.        | Put the cover on the <i>Green Machine</i> and lock the hasps.  |



**Annual Green Machine Inspections and Replacements**

| <b>Annual Green Machine Inspections</b>     |  |  |   |                          |                             |
|---|--|--|---|--------------------------|-----------------------------|
| <b>Component</b>                            | <b>Procedure</b>   | <b>Fail Criteria</b>   | <b>Corrective Action</b>  | <b>Reference Manuals</b> | <b>Authorized Personnel</b> |
| Vacuum Pump Rubber Flange Sleeve            | Visually inspect the Drive Coupling between the Vacuum Pump and the Motor for wear | Rubber debris is found on or around the Vacuum Pump base.  | Replace the Rubber Flange Sleeve                                  | IOM – 18                 | VST ASC Level D             |
| Vacuum Pump                                 | Replace pump every 10 years or 15,000 hours  |  |   | IOM-18                   |                             |
| VST Green Machine Annual Compliance Testing | Exhibit 15   | <p><u>Compliance Bag Test:</u> If the value of the NOVA reading is <math>\geq 17\%</math>, the <i>Green Machine</i> is not in compliance.</p> <p><u>Continuous Monitoring Test:</u> If a motor fault is not found then the <i>Green Machine</i> is not in compliance</p> | Refer to the Green Machine Troubleshooting Manual for maintenance | Exhibit 15               |                             |

# TLS RF Wireless 2 System (W2)

## Installation and Maintenance Guide



# Notice

---

Veeder-Root makes no warranty of any kind with regard to this publication, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Veeder-Root shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this publication.

Veeder-Root reserves the right to change system options or features, or the information contained in this publication as approved by ARB.

This publication contains proprietary information which is protected by copyright. All rights reserved. No part of this publication may be modified or translated to another language without the prior written consent of Veeder-Root.

Contact TLS Systems Technical Support for additional troubleshooting information at 800-323-1799.

## **DAMAGE CLAIMS / LOST EQUIPMENT**

Thoroughly examine all components and units as soon as they are received. If any cartons are damaged or missing, write a complete and detailed description of the damage or shortage on the face of the freight bill. The carrier's agent must verify the inspection and sign the description. Refuse only the damaged product, not the entire shipment.

Veeder-Root must be notified of any damages and/or shortages within 30 days of receipt of the shipment, as stated in our Terms and Conditions.

## **VEEDER-ROOT'S PREFERRED CARRIER**

1. Contact Veeder-Root Customer Service at 800-873-3313 with the specific part numbers and quantities that were missing or received damaged.
2. Fax signed Bill of Lading (BOL) to Veeder-Root Customer Service at 800-234-5350.
3. Veeder-Root will file the claim with the carrier and replace the damaged/missing product at no charge to the customer. Customer Service will work with production facility to have the replacement product shipped as soon as possible.

## **CUSTOMER'S PREFERRED CARRIER**

1. It is the customer's responsibility to file a claim with their carrier.
2. Customer may submit a replacement purchase order. Customer is responsible for all charges and freight associated with replacement order. Customer Service will work with production facility to have the replacement product shipped as soon as possible.
3. If "lost" equipment is delivered at a later date and is not needed, Veeder-Root will allow a Return to Stock without a restocking fee.
4. Veeder-Root will NOT be responsible for any compensation when a customer chooses their own carrier.

## **FCC INFORMATION**

This equipment complies with the requirements in Part 15 of the FCC rules for a Class A computing device. Operation of this equipment in a residential area may cause unacceptable interference to radio and TV reception requiring the operator to take whatever steps are necessary to correct the interference.

## **RETURN SHIPPING**

For the parts return procedure, please follow the appropriate instructions in the "General Returned Goods Policy" pages in the "Policies and Literature" section of the Veeder-Root **North American Environmental Products** price list. Veeder-Root will not accept any return product without a Return Goods Authorization (RGA) number clearly printed on the outside of the package.

## **FOR INSTALLATIONS IN THE STATE OF CALIFORNIA**

Please refer to the California Air Resources Board Vapor Recovery Certification Phase II EVR Executive Order web site ([www.arb.ca.gov/vapor/eo-evrphaseII.htm](http://www.arb.ca.gov/vapor/eo-evrphaseII.htm)) for the latest manual revisions pertaining to Executive Order VR202 (Healy Phase II EVR System Including ISD System), VR 203 (VST Phase II EVR System) and VR 204 (VST Phase II EVR System Including ISD System).

©Veeder-Root 2012. All rights reserved.

|  |           |
|--|-----------|
| <b>Introduction</b>  |           |
| Procedures Contained Within This Manual .....                      | 1         |
| Contractor Certification Requirements .....                        | 2         |
| RF Transmitter Considerations .....                                | 2         |
| Related Documents .....  | 3         |
| Product Marking Information .....                                  | 3         |
| Related Documents .....  | 3         |
| Safety Warnings .....  | 5         |
| Safety Symbols .....   | 5         |
| General Precautions .....  | 6         |
| General Precautions.....   | 6         |
| Special Tools Required .....                                       | 6         |
| National Electrical Code Compliance .....                          | 6         |
| TLS RF-To-TLS Console Wiring.....                                  | 6         |
| TLS RF AC Power Wiring.....  | 7         |
| TLS RF Wireless System Site Layout .....                           | 8         |
| <b>Equipment Dimensions.....</b>                                   | <b>9</b>  |
| <b>Pre-Installation Component Setup and Functional Check .....</b> | <b>11</b> |
| <b>TLS RF Installation</b>   |           |
| Selecting A Location .....   | 14        |
| Mounting the TLS RF .....  | 14        |
| Wiring the TLS RF .....  | 14        |
| <b>ISD Component Installation</b>                                  |           |
| Vapor Flow Meter Installation - Dispenser .....                    | 22        |
| Carbon Canister Vapor Polisher Installation .....                  | 24        |
| Vapor Return Pressure Sensor Installation .....                    | 28        |
| Vent Stack Installation Example .....                              | 28        |
| Connecting Cables To The Transmitter .....                         | 31        |
| Receiver Installation .....  | 33        |
| Repeater Installation .....  | 36        |
| <b>Network Setup</b>   |           |
| Hardware Overview .....  | 38        |
| Identifying Devices in the TLS RF Wireless Site Network .....      | 39        |
| Entering Device Numbers for the Site Network .....                 | 39        |
| Transmitter Device Number.....                                     | 39        |
| TLS RF Device Number .....   | 40        |
| Entering the Site ID Number .....                                  | 40        |
| Site Startup Procedure .....                                       | 41        |
| Initial TLS Console Setup Procedure .....                          | 41        |
| <b>Diagnostics</b>   |           |
| Alarms .....   | 42        |
| Battery Diagnostics .....  | 42        |
| Wireless Sensor Diagnostic Menu (TLS-350 Consoles) .....           | 42        |
| <b>Appendix A: Regulatory Information</b>                          |           |
| Federal Communications Commission Notice .....                     | 1         |
| MODIFICATIONS.....   | 1         |
| CABLES .....   | 1         |

Canadian Notice .....2  
 AVIS CANADIEN .....2  
 Battery Warning .....2  
 Wireless Notices .....2  
 U.S. Regulatory Wireless Notice .....2  
 Canadian Regulatory Wireless Notice .....2  
 System Specifications .....2

**Appendix B: Device DIP Switch Settings**

TLS RF Number Settings .....1  
 Transmitter/Receiver/Repeater DIP Switch Settings .....2

**Appendix C: Lithium Battery Safety Data**

Lithium Battery Disposal Considerations .....1

**Figures**

Figure 1. Example TLS RF Wireless System Site Layout .....8  
 Figure 2. TLS RF Dimensions And Designated Conduit Knockouts .....9  
 Figure 3. Wireless Component Dimensions .....10  
 Figure 4. Connecting Wiring To Device Terminal Blocks .....11  
 Figure 5. Wiring The Battery Cable To The Transmitter.....12  
 Figure 6. Wiring AC Power To The TLS RF .....15  
 Figure 7. Wiring Receiver To The TLS RF .....16  
 Figure 8. Connecting RS-485 Wiring.....17  
 Figure 9. Power Connections To A Daisy Chained TLS RFs .....18  
 Figure 10. RS-485 Cable Connections When Daisy Chaining Two TLS RFs .....19  
 Figure 11. Wiring Data Outputs from TLS RF to TLS Console.....20  
 Figure 12. TLS RF Diagnostic LEDs And Switch Locations .....21  
 Figure 13. Attaching Transmitter To Battery Support Bracket.....22  
 Figure 14. Example VFM Transmitter Installation In Dispenser .....23  
 Figure 15. Example CCVP installation .....25  
 Figure 16. Example CCVP transmitter/battery pack installation in vent stack enclosure.....26  
 Figure 17. Attaching transmitter cable to CCVP vapor valve .....27  
 Figure 18. VRPS Mounted In Universal Enclosure On The Vent Stack .....29  
 Figure 19. Example VRPS Transmitter/battery Pack Installation In The Universal Enclosure .....30  
 Figure 20. Connecting Input Wiring To Transmitter Terminal Blocks .....31  
 Figure 21. Wiring The Transmitter .....32  
 Figure 22. Attaching Mounting Bracket To Receiver Or Repeater .....34  
 Figure 23. Wiring The Receiver .....35  
 Figure 24. Wiring The Repeater .....37  
 Figure 25. Example Site Network Diagram .....38  
 Figure 26. Device Battery Status In TLS-350 SmartSensor Diagnostic Menu .....43  
 Figure B-1. TLS-RF switch settings ..... B-1  
 Figure B-2. DIP switch settings ..... B-2  
 Figure B-3. S1: DIP switch positions 1-3 — (W2) All Devices ..... B-3  
 Figure B-4. S1: DIP switch positions 4-8 — (W2) All Devices ..... B-3  
 Figure B-5. S2: DIP switch positions 1-4 — (W2) CCVP ..... B-4  
 Figure B-6. S2: DIP switch positions 1-4 — (W2) Vapor Flow Meter ..... B-4  
 Figure B-7. S2: DIP switch positions 5-8 — (W2) All Devices ..... B-4

## Tables

|          |  |   |
|----------|--|---|
| Table 1. | Wireless 2 Devices Per TLS Console ..... | 1 |
| Table 2. | Wireless Component Kit Numbers .....     | 1 |

## Introduction

This manual describes site preparation and installation procedures for the Veeder-Root TLS RF Wireless 2 System (W2) for Vapor Recovery monitoring. The TLS RF Wireless 2 System (W2) features two-way communication utilizing a client/server architecture resulting in improved data collection.

Veeder-Root strongly recommends the use of hard wiring for connecting Veeder-Root sensors to the TLS Console. Wired connections provide a robust communication link that is far superior to wireless networks.

A wide variety of devices can be integrated into the TLS RF Wireless 2 System (W2) network depending on the console(s) installed as shown in Table 1. Wireless component kit part numbers are shown in Table 2.

**Table 1. Wireless 2 Devices Per TLS Console**

| Consoles              | Wireless Device  |                                | Total Number of Wireless Devices per TLS console |
|-----------------------|------------------|--------------------------------|--|
|                       | Vapor Flow Meter | Carbon Canister Vapor Polisher |  |
| 8470 TLS-350 Console  |                  |                                | 32   |
| 8482 TLS-350R Console | Up to 32         | 1                              | 32   |

**Table 2. Wireless Component Kit Numbers**

| V-R Kit Order Number | V-R Component Number  |                        |                     |                     |                         |                      |
|----------------------|-----------------------|------------------------|---------------------|---------------------|-------------------------|----------------------|
|                      | RF Console 332242-002 | Transmitter 332235-016 | Repeater 332440-030 | Receiver 332440-029 | Battery Pack 332425-011 | Enclosure 330020-716 |
| 858090-203           | X                     |                        | X                   | X                   |                         |                      |
| 858090-204           | X                     |                        | X                   | X                   |                         |                      |
| 858090-205           |                       | X                      |                     |                     | X                       |                      |
| 330020-716           |                       |                        |                     |                     |                         | X                    |
| 330020-668           | X                     |                        |                     |                     |                         |                      |
| 330020-674           |                       | X                      |                     |                     |                         |                      |
| 330020-670           |                       |                        | X                   |                     |                         |                      |
| 330020-669           |                       |                        |                     | X                   |                         |                      |
| 330020-718           |                       |                        |                     |                     | X                       |                      |

### Procedures Contained Within This Manual

- Mounting the TLS RF and connecting power wiring.
- Installing Receiver, Repeater and Transmitters.

- Connecting the TLS RF to the TLS console.

After installing the TLS RF Wireless System devices, you must configure the sensors in the console following instructions contained in the TLS console's System Setup Manual.

## Contractor Certification Requirements

| Veeder-Root Contractor Certification Requirements                                     | Installer Certification <sup>6</sup> | ATG Technician Certification <sup>7</sup>                 | VR Vapor Products Certification <sup>8</sup> |
|---|--------------------------------------|---|--|
| Install <sup>1</sup> ISD  | X                                    | X   | X  |
| Install PMC   | X                                    | X   | X  |
| Install CCVP  | X                                    | X   | X  |
| Install Wireless ISD/PMC  | X                                    | X   | X  |
| Installation Checkout <sup>2</sup>  |                                      | X   | X  |
| ATG Startup <sup>3</sup> / Training <sup>4</sup> / Service <sup>5</sup>               |                                      | X   | X  |
| ISD Startup / Training / Service  |                                      |   | X  |
| PMC Startup / Training / Service  |                                      |   | X  |
| CCVP Startup / Training / Service   |                                      |   | X  |
| Wireless ISD/PMC Startup / Training / Service   |                                      |   | X  |
| Install Pressure Sensor (ATG)   | X                                    | X   | X  |
| Maintain Pressure Sensor (ATG)  |                                      | X   | X  |
| Calibrate Pressure Sensor (ATG)   |                                      | X   | X  |
| Clear ATG Pressure Sensor Alarm (ATG)   |                                      | X   | X  |
| Clear ISD/PMC Alarms (ISD/PMC)  |                                      |   | X  |
| <sup>1</sup> Perform wiring and conduit routing; equipment mounting                   |                                      | <sup>6</sup> UST Monitoring Systems – Installer (Level 1) |  |
| <sup>2</sup> Inspect wiring and conduit routing; equipment mounting                   |                                      | <sup>7</sup> Certified UST Monitoring Technician          |  |
| <sup>3</sup> Turn power on, program and test the systems                              |                                      | <sup>8</sup> VR Vapor Products                            |  |
| <sup>4</sup> Provide supervised field experience in service techniques and operations |                                      |   |  |
| <sup>5</sup> Troubleshoot and provide routing maintenance                             |                                      |   |  |

**Warranty Registrations** may only be submitted by selected Distributors. Certified installers are required to provide the GDF operator with the completed Equipment Warranty Notice, form 577013-868, for their records.

## RF Transmitter Considerations

Installation of this equipment in wet or below grade locations requires that the installer take steps to ensure that the equipment is mounted above the maximum water level.



**CAUTION! – The Transmitter will not function properly in water. Also, submersion of the Transmitter in water can cause permanent damage to the internal electronics.**

**Wireless 2 devices will not function properly if certain conditions arise such as, but not limited to, the following:**

- **Ambient Interference** – Due to site layout or vehicles parked in the RF transmission path. For example, CSLD will not function if the transmission path is blocked for more than a few minutes.
- **Improper equipment installation** – Keep objects from improperly coming in contact with the antenna. Follow these installation instructions and mount the transmitter in a fixed position to ensure maximum RF connectivity. Antenna orientation is significant in achieving an optimal transmission path.
- **Equipment Sump Parameters** – Sumps intended for use with RF equipment must accommodate the worst case rainfall condition that could reasonably occur. The RF Transmitter and antenna are weatherproof but will not function properly underwater.



TLS System performance will be degraded should any of the above conditions occur and is not covered under the Veeder-Root Product Warranty. Corrective actions to such conditions are the responsibility of the station-site owner. Veeder-Root is not liable for any event that is a result of an improper installation or use of this equipment.

It is important that installers have knowledge of all relevant procedures before installing a wireless system. Read and understand all manuals thoroughly. If you do not understand a procedure, contact a certified contractor or contact Veeder-Root. Each TLS Console has its own setup and installation manuals.

## Related Documents

|   |   |
|---|---|
| IOM 13 VR-203 and VR-204 or IOM 18 VR-202 | Vapor Pressure Sensor Installation Guide                          |
| IOM 15 VR-204                             | ISD Balance Flow Meter Installation Guide                         |
| IOM 14 VR-203 and VR-204                  | Carbon Canister Vapor Polisher Installation and Maintenance Guide |
| 576013-623                                | TLS-3XX System Setup Manual                                       |
| 331940-012                                | TLS RF System Control Drawing                                     |

## Product Marking Information


### RELATED DOCUMENTS

#### **Documents Required to Install Equipment**



This intrinsically safe apparatus is only for use as part of a Veeder-Root Automatic Tank Gauging System (ATG Console with probes and sensors). To install intrinsically safe apparatus, use the specific control drawing that appears on the nameplate of the applicable associated apparatus (ATG Console):

| Equipment   | UL/cUL Control Drawing Document No. |
|---|-------------------------------------|
| <b>Associated Apparatus</b>                                   |                                     |
| TLS-450/8600  | 331940-008                          |
| TLS-350, TLS-350R   | 331940-011                          |
| TLS-300   | 331940-013                          |
| TLS-50 or TLS2 or TLS-IB                                      | 331940-014                          |
| TLS4/8601   | 331940-018                          |
| TLS-XB/8603   | 331940-019                          |
| <b>Intrinsically Safe Apparatus for Wireless Applications</b> |                                     |
| Tank Gauge Accessories  | 331940-012                          |

The control drawings contain information related to the correct installation of the overall intrinsically Safe System. This includes information such as maximum number of apparatus, specific apparatus allowed in the system, maximum cable lengths, references to codes, proper grounding and so on. Control drawings can be found on the accompanying Compact Disk (TECH DOCS CD) or on the internet at [veeder.com](http://veeder.com) under SUPPORT; VR TECHNICAL DOCUMENTS; DRAWINGS.








**Product Label Contents**

|  |   |
|--|---|
|             | I.S. CIRCUIT FOR HAZLOC DEVICE<br>F/N XXXXXX-XXX<br>S/N XXXXXX                        |
| CL I, DIV. 1, GP.D<br>CL I, ZONE 0<br>AEx ia IIA<br>Ex ia IIA<br>TC=T4<br>SECURITE INTRINSEQUE | $-40^{\circ}\text{C} \leq T_a \leq +60^{\circ}\text{C}$<br>MANUAL NO. 577013-964      |
|  |  |

## Safety Warnings





To protect yourself and your equipment, observe the following warnings and important information:




| <b>⚠ WARNING</b>  |   |
|---|---|
|      | <p>This product is to be installed in systems operating near locations where highly combustible fuels or vapors may be present.</p> <p><b>FAILURE TO COMPLY WITH THE FOLLOWING WARNINGS AND SAFETY PRECAUTIONS COULD CAUSE DAMAGE TO PROPERTY, ENVIRONMENT, RESULTING IN SERIOUS INJURY OR DEATH.</b></p> <ol style="list-style-type: none"> <li>1. Read and follow all instructions in this manual, including all safety warnings to protect yourself and others from serious injury, explosion, or electrical shock.</li> <li>2. Comply with all applicable codes including: the National Electrical Code; federal, state, and local codes; and other applicable safety codes.</li> <li>3. To protect yourself and others from being struck by vehicles, block off your work area during installation or service.</li> <li>4. Do not alter or modify any component or substitute components in this kit.</li> <li>5. <b>Warning!</b> Substitution of components may impair intrinsic safety.</li> <li>6. Field wiring to the Probe must not share a conduit with any non-intrinsically safe device's wiring.</li> <li>7. <b>Warning!</b> To prevent ignition of flammable or combustible atmospheres, disconnect battery before servicing.</li> <li>8. Materials used in the construction of this device contain aluminum. Care must be taken to avoid ignition hazards due to impact or friction.</li> <li>9. Before installing or taking the unit into a hazardous area, earth the unit in a safe area to remove any static charge. Then immediately transport the unit to the installation site. Do not rub or clean the unit prior to installation. Cleaning is not required under normal service conditions. Do not rub or clean the unit after installation. If the unit is not fixed to a known earth point when installed, ensure that a separate earth connection is made to prevent the potential of a static discharge. When fitting or removing the unit, use of anti-static footwear or clothing is required.</li> </ol> |

**NOTE** Failure to install this product in accordance with its instructions and warnings will result in voiding of all warranties with this product.

## Safety Symbols

The following safety symbols may be used throughout this manual to alert you to important safety hazards and precautions.

|  |  |
|--|--|
|  <p><b>EXPLOSIVE</b><br/>Fuels and their vapors are extremely explosive if ignited.</p>                                 |  <p><b>FLAMMABLE</b><br/>Fuels and their vapors are extremely flammable.</p>  |
|  <p><b>ELECTRICITY</b><br/>High voltage exists in, and is supplied to, the device. A potential shock hazard exists.</p> |  <p><b>TURN POWER OFF</b><br/>Live power to a device creates a potential shock hazard. Turn Off power to the device and associated accessories when servicing the unit.</p> |

|  |  |
|--|--|
|  <p><b>WARNING</b><br/>Heed the adjacent instructions to avoid damage to equipment, property, environment or personal injury.</p>   |  <p><b>READ ALL RELATED MANUALS</b><br/>Knowledge of all related procedures before you begin work is important. Read and understand all manuals thoroughly. If you do not understand a procedure, ask someone who does.</p> |
|  <p><b>SAFETY BARRICADES</b><br/>Unauthorized people or vehicles in the work area are dangerous. Always use safety cones or barricades, safety tape, and your vehicle to block the work area.</p> |  |

## General Precautions

Retain and follow all product safety and operating instructions. Observe all warnings on the product and in the operating instructions. To reduce the risk of bodily injury, electric shock, fire, or damage to the equipment, observe the following precautions.



**FAILURE TO COMPLY WITH THE FOLLOWING WARNINGS AND SAFETY PRECAUTIONS COULD CAUSE DAMAGE TO PROPERTY, ENVIRONMENT, RESULTING IN SERIOUS INJURY OR DEATH.**

### GENERAL PRECAUTIONS

Heed service markings: Opening or removing the console cover may expose you to electric shock. Servicing of Veeder-Root equipment must be done by Veeder-Root authorized service contractors.

Use product with approved equipment: This product should be used only with Veeder-Root components identified as suitable for use with the TLS RF Wireless System.

Use the correct external power sources: This product should be operated only from the type of power sources indicated on the electrical ratings labels affixed to the components. If you are not sure of the type of power source required, consult your Veeder-Root authorized service contractor.

When not in use, a longer battery life can be achieved by keeping the battery pack in a cool, dry location where the temperature never exceeds 30°C or 86°F and does not go below 10° C or 50° F.

### SPECIAL TOOLS REQUIRED

- #15 Torx screwdriver
- Small blade screwdriver (maximum blade width 3/32")
- Wire strippers

## National Electrical Code Compliance

The following information is for general reference and is not intended to replace recommended National Electric Code (NEC) procedures. It is important for the installer to understand that electrical equipment and wiring located in Class I, Division 1 and 2 installations shall comply with the latest appropriate articles found in the National Electric Code (NFPA 70) and the Code for Motor Fuel Dispensing Facilities and Repair Garages (NFPA 30A), or other local code such as the CEC, Canadian Electrical Code.

## TLS RF-TO-TLS CONSOLE WIRING

### Wire Type

To ensure the best operating systems available, Veeder-Root **REQUIRES** the use of shielded cable.

**Wire Length**

Improper system operation could result in undetected potential environmental and health hazards if the TLS RF-to-TLS Console wire runs exceed 1000 feet. Wire runs must be less than 1000 feet to meet intrinsic safety requirements.

**Splices**

Veeder-Root recommends that a minimum number of splices are used in the wire run between the TLS RF and the TLS Console. Each splice degrades signal strength and could result in poor system performance.

**Wire Gauges - Color coded**

Shielded cable must be used in all installations. TLS RF-to-TLS Console wires must be #14 to #18 AWG stranded copper wire and installed as a Class 1 circuit.

**Alternate Method**

When approved by the local authority having jurisdiction, 22 AWG wire such as Belden 88761 may be suitable in installations with the following provisions:

- Wire run is less than 750 feet
- Capacitance does not exceed 100 pF/foot
- Inductance does not exceed 0.2  $\mu$ H/foot

**TLS RF AC POWER WIRING**

Wires carrying 120 or 240 Vac from the power panel to the TLS RF must be at least #14 AWG copper wire for line, neutral and chassis ground (3); and #12 AWG copper wire for barrier ground (1).

NOTE: Note: See page 36 for details of Repeater Power Wiring.

## TLS RF Wireless System Site Layout

Figure 1 illustrates an example TLS RF Wireless System installation. The Repeater component may be required if the system Receiver, mounted on building's outside wall, has difficulty receiving signals from any of the Transmitters. See page 36 for Repeater installation.




Figure 1. Example TLS RF Wireless System Site Layout

### LEGEND FOR NUMBERED BOXES IN Figure 1

To be installed in accordance with the National Electrical Code, NFPA 70 and the Code for Motor Fuel Dispensing Facilities and Repair Garages (NFPA 30A), or other local codes such as the CEC, Canadian Electrical Code.

**WARNING! Substitution of components may impair intrinsic safety.**

Circuitry within the console barrier forms an intrinsically safe, energy-limited system. This system is intrinsically safe for use in a Class I, Group D hazardous location.

1. Receiver (1 per RF System)
2. RS-485 Cable (Belden #3107A or equiv.)
3. NOTE: Intrinsically safe wiring shall be installed in accordance with Article 504-20 of the NEC, ANSI/ NFPA 70. Max cable length 1000 ft. (304 m). W2 Receiver (1 per RF System)
4. TLS-RF
5. Conduit that enters power wiring knockout.
6. TLS console (Vm = 250 V)
7. 120 or 230 Vac from power panel
8. Non-hazardous area
9. Repeater (1 per RF System)
10. Hazardous area (Class I, Div. 1, Group D)
11. CCVP transmitter/battery enclosure
12. Carbon Canister Vapor Polisher
13. Transmitter
14. Battery Pack
15. Vapor Flow meter
16. Dispenser sump
17. VPRS sensor (w/transmitter/battery in enclosure)



# Equipment Dimensions

Dimensions of the TLS RF are shown in Figure 2.




Figure 2. TLS RF Dimensions And Designated Conduit Knockouts

## LEGEND FOR NUMBERED BOXES IN Figure 2

- |   |                    |
|---|--------------------|
| 1. Designated power wiring knockouts              | 3. RS-485 knockout |
| 2. Designated intrinsically-safe wiring knockouts | 4. RS-232 knockout |




Figure 3. Wireless Component Dimensions

| LEGEND FOR NUMBERED BOXES IN Figure 3                      |                               |
|--|-------------------------------|
| 1. W2 Receiver, W2 Transmitter, and W2 Repeater dimensions | 2. Battery housing dimensions |



## Pre-Installation Component Setup and Functional Check

The steps below describe the process of verifying the Wireless System component functionality; listed steps are only for one TLS RF. If there are more than 8 Sensors installed at the site, refer to Appendix B on how to setup the DIP Switches for auxiliary TLS RF(s).

1. Remove all the hardware from their boxes; lay the TLS RF, Receiver, Repeater, and all the Transmitters on a table.
2. Set Site ID for the Receiver, Repeater, and all the Transmitters (refer to Appendix B on how to set up the Site ID). Typically the Site ID is set to 0 (default). **If there is a nearby wireless site, the Site IDs must be different.**
3. Set all Transmitter's Device Numbers and connect the battery cables to all the Transmitters. Label each Transmitter with its site ID.
  - a. Using a #15 torx driver, remove the cover of the Transmitter.
  - b. Remove the nut from the battery cable cord grip (right side cord grip) and slide it over the non-connector end of the battery cable.
  - c. Make sure the battery/dc power cable is not connected to the battery pack or dc power source at this time. Push the battery cable through the battery cable cord grip bushing and into the Transmitter.
  - d. Strip back the cable jacket and wires as shown in Figure 4.
  - e. Connect the battery pack/dc power cable to the BATTERY terminal block (white to +IN and black to -IN) as shown in Figure 5.
  - f. **Hand tighten both cable entry cord grip nuts to prevent water entry!**
  - g. Replace the cover of the Transmitter, but do not tighten down cover screws at this time.




Figure 4. Connecting Wiring To Device Terminal Blocks

### LEGEND FOR NUMBERED BOXES IN Figure 4

- |  |   |
|--|---|
| 1. Strip back cable and wire jackets the amount shown. | 3. Both wires must be tight in terminals! |
| 2. Use a screwdriver with the proper blade width.      |   |





Figure 5. Wiring The Battery Cable To The Transmitter

**LEGEND FOR NUMBERED BOXES IN Figure 5**

- |  |  |
|--|--|
| 1. S1 DIP switch   | 6. Battery power-in terminals (+IN and –IN). Observe polarity!   |
| 2. Green LED – Unit status.  |  <b>Pay close attention to the polarity of the +15 Vdc. Reversing the connections can cause damage to the TLS RF.</b> |
| 3. Red LED – Radio status.   |  |
| 4. S2 DIP switch   | 7. Cable from battery pack   |
| 5. Red LED – Flashes only when radio is powered on in Diagnostic Mode. |  |

4. Using a #15 torx driver, open the covers of the TLS RF, Repeater and Receiver. Make a temporary ac power cord with a grounded plug on one end. Connect the ac power cord to the TLS RF's input power terminals and ground terminal (refer to Figure 6 and Figure 7). Connect a necessary length of RS-485 cable from the TLS RF's RS-485 terminals to the Receiver's RS-485 terminals (refer to Figure 23). Connect a necessary length of 2-conductor cable from the Receiver's Repeater terminals to the Repeater's Repeater terminals (refer to Figure 24).
5. The steps below are to verify the communication between the TLS RF Unit and the Receiver.
  - a. Plug the TLS RF's ac power cord into a 120/240 Vac outlet. Confirm the Green /Red LEDs (refer to item 2 in Figure 12), are flashing rapidly. This is an indication there is RS-485 network activity between the TLS RF and the Receiver.
  - b. If it is, continue to Step 6.
  - c. If it is not, check PWR LED (refer to item 3 in Figure 12), if not lit; check power wiring. If the wiring is correct, measure the voltage across the twisted pair power wires, it should read +15Vdc. If it is not, the TLS RF is bad.

- d. If the Red LED (refer to item 2 in Figure 12) is not flashing, confirm the TLS RF address is set to Master (refer to Appendix B, Figure B-1 on how to set the TLS RF Device Number). If it is, the TLS RF has failed.
  - e. If the Red LED is flashing and the Green LED is not flashing, the TLS RF is not receiving a response from the Receiver.
  - f. Confirm the Receiver PWR LED is lit (refer to item 1 in Figure 23). If not check the power wiring.
    - If the power wiring is correct, measure across the +15V and GND (refer to item 4 in Figure 23), it should be +15Vdc. If it is not, measure the voltage across the +15V and GND terminals in the TLS RF, it should read +15Vdc. If it does, replace the twisted pair power wires. If it does not, the Receiver is bad.
    - Check the RS-485 Green LED (refer to item 1 (PWR LED) in Figure 23), if it is flashing; it is receiving Data from the TLS RF. If it is not flashing, check the RS-485 cabling between the TLS RF and the Receiver.
    - Check the Red LED (XMIT LED, [item 1 in Figure 23]), if it is flashing; check the cabling. If it is not flashing, the Receiver is at fault; replace the Receiver.
6. This step is to verify to make sure Data from the Transmitter is being received by the TLS RF. Make sure the power to the Repeater is off.
- a. Connect the first Transmitter's battery cable to a battery pack; noting the Red LED should be flashing momentarily then followed by the Green LED (refer to item 2 and 3 in Figure 5). Since there is no Sensor connected, the two LEDs should be flashing. This is an indication a Sensor communication error and is acceptable at this step.  
**TIP - Normal flashing is when an LED turns On for over 1 second and turns Off for over 1 second. Error flashing is when an LED turns On and Off every 1/2 second or less.**
  - b. Go to the TLS RF, open its cover. One of the 8 Red received LEDs should be flashing (refer to item 5 in Figure 12). Observe which LED is lit and compare it against the Transmitter Device Number; they should match. For example, if the Transmitter ID is set to 1, the LED number 1 in the TLS RF should be flashing.
  - c. If the Transmitter Device Number and the LED in the TLS RF do not match, disconnect the Transmitter's battery cable from the battery pack. Move this DIP switches back and forth a few times to make sure they are set properly. Reset this DIP Switch to the correct setting; reconnect the battery cable; confirm that the correct LED is flashing.
  - d. If they still do not match, disconnect the Transmitter's battery cable from the battery pack; change the Transmitter Device Number to different setting and repeat Step 6.
  - e. If resetting the Transmitter to a different Device Number and the LED position in the TLS RF matches; that DIP Switch position is bad, the Transmitter is at fault.
  - f. If resetting the Transmitter to a different Device Number and the LEDs in the TLS RF and the Transmitter are not matched; remove the power from the Transmitter and put it aside.
  - g. Repeat Step 6 with the next Transmitter.
  - h. If both Transmitters have the same problems, it could be the Receiver or the TLS RF.
  - i. In the case where the LED in the TLS RF is not flashing, check the Site ID in the Receiver and the Transmitter to make sure they are correct. If the Site IDs are correct, the Transmitter or the Receiver is at fault. NOTE: Sometimes it is necessary to disconnect the battery cable from the battery pack and wait for 2 minutes and retry again to make sure the connection is established properly.
7. If all the Transmitters have been verified to be working properly, they are now ready to be installed.
8. Unplug the TLS RF, disconnect the temporary power cable and RS-485 cable to the Receiver and close the cover of the TLS RF, but do not tighten the cover screws at this time.
9. Disconnect the temporary RS-485 and 2-conductor cables from the Receiver and replace its cover, but do not tighten at this time. Disconnect the temporary 2-conductor cable from the Repeater and replace its cover, but do not tighten at this time.

## TLS RF Installation

### Selecting A Location

---

#### **WARNING**



Explosive vapors or flammable liquids could be present near locations where fuels are stored or being dispensed. The TLS RF is not explosion proof.

An explosion or fire resulting in serious injury or death, property loss and equipment damage could occur if the console is installed in a volatile, combustible or explosive atmosphere (Class I, Division 1 or 2).

Do not install this unit in a volatile, combustible, or explosive atmosphere.

The TLS RF must be mounted indoors, protected from severe vibration, extremes in temperature and humidity, and other conditions that could harm computerized electronic equipment.

Ensure that the TLS RF is located where neither it nor its associated cabling will be damaged by doors, furniture, etc. Consider the ease of routing wiring, and ducting to the TLS console. Check that the mounting surface is strong enough to support the unit's weight of about 4 pounds.

### Mounting the TLS RF

---

Install the unit's fastening devices to the mounting surface using the hole pattern (6.7" x 5.7") shown in Figure 2. Mounting screws up to 3/16" diameter may be used.

Install metal conduit (1/2-inch I.P.S.) between the upper power side knockout on the unit and the power panel. Figure 2 shows the two designated knockouts (one each on top and bottom) through which power wiring can safely enter the unit.

Also install metal conduit (1/2-inch I.P.S.) between the lower intrinsically-safe wiring knockout on the TLS RF and an intrinsically-safe wiring knockout on the TLS console for device data wiring.

### Wiring the TLS RF

---

#### **WARNING**



The unit contains voltages which can be lethal.

Connecting power wires to a live circuit can cause electrical shock that may result in serious injury or death.

Turn power off at the circuit breaker before connecting wiring to the TLS RF.

Attach conduit from the power panel to the unit's power wiring knockouts only (1 on top and 1 on bottom, ref. Figure 2)

To connect power wiring see Figure 6. To connect Receiver wiring see Figure 7. To daisy chain two TLS RFs, see Figure 9 and Figure 10. To connect TLS RF data output wiring to the TLS console see Figure 6.



**WARNING! Do not apply power to the TLS RF Console until all device wiring is complete. This includes the wiring for the Receiver, Repeater, the probes and additional TLS RF Consoles.**




Figure 6. Wiring AC Power To The TLS RF

**LEGEND FOR NUMBERED BOXES IN Figure 6**

- |   |  |
|---|--|
| <ol style="list-style-type: none"> <li>1. Attach chassis ground wire (#14 AWG) to ground lug.</li> <li>2. Protective earthing conductor (green and yellow). Attach #12AWG barrier ground wire to ground lug. Ground must be the same as the supply and less than 1.0 ohms to ground.</li> <li>3. AC power input wires (#14 AWG) to AC INPUT terminals.</li> <li>4. POWER WIRING NOTES:             <ul style="list-style-type: none"> <li>• Barrier ground must be #12 AWG or larger diameter.</li> <li>• Check to be sure that the electrical resistance between the unit ground lug and a known good earth ground is less than 1 ohm.</li> <li>• Connect the power supply wires in the power panel to a separate dedicated circuit.</li> <li>• Electrical rating power input - 120 Vac or 240 Vac, 50/60 Hz, 2 A max.</li> <li>• See Figure 2 for actual locations of power conduit knockouts into the unit. Power wiring must enter only in one of these knockouts.</li> </ul> </li> </ol> | <ol style="list-style-type: none"> <li>5. Intrinsically-safe side</li> <li>6. Power side</li> <li>7. RS-232 diagnostic port:             <ul style="list-style-type: none"> <li>• Baud rate - 9600</li> <li>• Data length - 8</li> <li>• Parity - None</li> <li>• Stop bits - 1</li> </ul> </li> </ol> |
|---|--|




Figure 7. Wiring Receiver To The TLS RF

**LEGEND FOR NUMBERED BOXES IN Figure 7**

- 1. Connect the shield of the RS-485 cable to the ground lug.
- 2. Cord grip
- 3. RS-485 cable to Receiver
- 4. Power side
- 5. Intrinsically-safe side
- 6. NOTE: Attach one end of RS-485 cable to the RS-485 terminals in the TLS RF and other end to the RS-485 terminals in the Receiver. One twisted pair connects to terminals - and + (RS-485 signals) and the second twisted pair connects to terminals +15 and G (Receiver power).

6 (Cont'd).  
Connect each of the four wires to the same terminals in the Receiver (ref. Figure 23).

NOTE: see Figure 4 for wire connection tips. NOTE: In sites with more than one TLS RF, the Receiver is only connected to the master TLS RF.




Figure 8. Connecting RS-485 Wiring

**LEGEND FOR NUMBERED BOXES IN Figure 8**

- |   |  |
|---|--|
| <p>1. Use small blade screwdriver and loosen terminal by turning top screw over desired terminal counter clockwise. DO NOT raise screw head above top of hole or it may disengage from clamp.</p> | <p>2. Insert 1/4" stripped wire into terminal clamp's side opening and tighten screw clockwise until wire cannot be moved in or out.</p> |
|---|--|




Figure 9. Power Connections To A Daisy Chained TLS RFs

**LEGEND FOR NUMBERED BOXES IN Figure 9**

- |  |  |
|--|--|
| <p>1. POWER WIRING NOTES:</p> <ul style="list-style-type: none"> <li>• Barrier ground must be #12 AWG or larger diameter.</li> <li>• Check to be sure that the electrical resistance - between the unit ground lug and a known good earth ground is less than 1 ohm.</li> <li>• Connect the power supply wires in the power panel to a separate dedicated circuit.</li> <li>• Electrical rating power input - 120 Vac or 240 Vac, 50/60 Hz, 2 A max.</li> <li>• See Figure 2 for actual locations of power conduit knockouts into the unit. Power wiring must enter only in one of these knockouts.</li> </ul> <p>2. AC power input wires (#14 AWG) to AC input terminals.</p> | <p>3. Protective earthing conductor (green and yellow). Attach #12AWG barrier ground wire to ground lug. Ground must be the same as the supply and less than 1.0 ohms to ground.</p> <p>4. Attach chassis ground wire (#14 AWG) to ground lug.</p> <p>5. Connect the shield of the RS-485 cable to the ground lug.</p> <p>6. RS-485 cable from master TLS RF.</p> <p>7. See Figure 10 for connections.</p> |
|--|--|






Figure 10. RS-485 Cable Connections When Daisy Chaining Two TLS RFs

**LEGEND FOR NUMBERED BOXES IN Figure 10**

- |   |   |
|---|---|
| <ol style="list-style-type: none"> <li>1. Master TLS RF</li> <li>2. RS-485 cable to Receiver.</li> <li>3. RS-485 cable to auxiliary TLS RF. Cut the unused twisted pair back to the cable's jacket at each end of the cable. Maximum cable length is 500 feet if a communication grade cable is used.</li> <li>4. Auxiliary TLS RF</li> </ol> | <ol style="list-style-type: none"> <li>5. Connect the shield of the RS-485 cable to the ground lug.</li> <li>6. Connect like colored wires of the twisted pair to like terminals in the auxiliary TLS RF. Each additional TLS RF connects in the same way.</li> </ol> |
|---|---|




Figure 11. Wiring Data Outputs from TLS RF to TLS Console

**LEGEND FOR NUMBERED BOXES IN Figure 11**

Note: Output wiring from the TLS RF to the TLS console is an intrinsically safe circuit.

NOTE: Intrinsically safe wiring shall be installed in accordance with Article 504-20 of the NEC, ANSI/NFPA 70.

1. Received Transmitter data output terminals (1-8).
2. In this example, device output 1 is a CCVP transmitter - Observe polarity. Note: each time a transmission is received from this device, LED 1 (see item 5 in Figure 12) will flash.
3. In this example, device output 2 is a Flow Meter - Observe polarity. Note: each time a transmission is received from this device, LED 2 (see item 5 in Figure 12) will flash.

4. 1/2" i.p.s. conduit to TLS console
5. SmartSensor interface module in TLS console
6. Intrinsically-safe side
7. Power side



Figure 12 locates the diagnostic lights and setup switches in the TLS RF.

Each TLS RF in the site network must have a unique device set number (0,1,2 or 3). The factory default setting is '0'. You must select '0' for the master TLS RF. The site's Receiver must also be connected to the master TLS RF.

If a second TLS RF is required, enter '1' in the auxiliary TLS RF. For additional TLS RFs, enter '2' for the third and '3' for the fourth.




Figure 12. TLS RF Diagnostic LEDs And Switch Locations

**LEGEND FOR NUMBERED BOXES IN Figure 12**

- |  |   |
|--|---|
| <ol style="list-style-type: none"> <li>1. These LEDs flash when there is comm activity on RS-232 port (Red = TX, Green = RX).</li> <li>2. These LEDs flash when there is comm activity on the RS-485 network (between TLS RF and Receiver).</li> <li>3. Red LED is lit when TLS RF is powered on.</li> <li>4. Device time out rotary switch selects the maximum allowed time to wait for communication from Transmitter before a Comm alarm is posted by TLS console (see Appendix B for selections). Position 1 (10 minutes) is the factory default setting.</li> </ol> | <ol style="list-style-type: none"> <li>5. These red LEDs flash when a message is received from a Transmitter in the monitored device set. LED 1 is the device wired to I.S. output terminal 1. LED 2 is the device wired to output terminal 2, etc.</li> <li>6. Red LED flashes when TLS console is polling for device data.</li> <li>7. S2 DIP switches 1-2 enter device set address (seeAppendix B).</li> </ol> |
|--|---|

## ISD Component Installation

### Vapor Flow Meter Installation - Dispenser

1. A Transmitter/battery pack pair must be installed with the Veeder-Root Vapor Flow Meter (VFM) in the dispenser cabinet.
2. Install the VFM in the dispenser following instructions accompanying the VFM.
3. Using two taptite screws from the kit, attach the Transmitter housing to the side of the battery support bracket that has the two circular slots (see Figure 13). Do not tighten screws at this time.
4. Remove the cover from the transmitter. Attach the non-connector end of the cable from the VFM to the transmitter as described in the section below entitled "Connecting Cables To The Transmitter" on page 31, then attach the transmitter/L bracket assembly to the back mounting surface using two #10 taptite screws from the kit.
5. Determine a support location within the dispenser cabinet that will allow you room for the transmitter/battery support bracket. Clamp the bracket to an available support structure (see Figure 14).
6. Rotate the Transmitter antenna as close as possible to a horizontal position then tighten two mounting screws in housing.
7. Insert the battery pack into its support bracket - do not connect the battery cable to the battery pack at this time.
8. Do not replace dispenser sheet metal cover until completing the "Site Startup Procedure".




Figure 13. Attaching Transmitter To Battery Support Bracket

#### LEGEND FOR NUMBERED BOXES IN Figure 13

1. Transmitter
2. #10 x 1/2" taptite screws (2)
3. Battery support bracket




Figure 14. Example VFM Transmitter Installation In Dispenser

**LEGEND FOR NUMBERED BOXES IN Figure 14**

- |                              |   |
|------------------------------|---|
| 1. Base of dispenser cabinet | 5. Transmitter  |
| 2. VFM                       | 6. top of dispenser pedestal                                  |
| 3. VFM cable                 | 7. Battery caution label attached to battery cable (2 places) |
| 4. Battery pack              |   |

## **Carbon Canister Vapor Polisher Installation**

---

1. During the installation, all required National, State and local safety codes must be followed.
2. A Transmitter /battery pack pair must be installed with the Veeder-Root Carbon Canister Vapor Polisher (CCVP) in a weatherproof enclosure mounted on the vent stack (see Figure 15).
3. Install the CCVP sensor following instructions accompanying the sensor.
4. Using two #10 taptite screws from the kit, attach the Transmitter housing to the side of the L bracket from the wireless installation kit - do not attach L bracket/transmitter assembly to the back mounting surface at this time.
5. Get the battery pack mounting bracket from the wireless installation kit and put the threaded connector fitting of the battery housing through the large hole in the bracket.
6. Get the thin hex nut from the kit and screw it onto the battery housing cable connector threaded fitting until snug (see item 3 in Figure 16).
7. Attach the battery housing/bracket assembly to the back mounting surface of the enclosure using two #10 taptite screws from the kit (see item 4 in Figure 16).
8. Remove the cover of the transmitter. Connect the non-connector end of the cable that connects the CCVP to the transmitter as described in the section below entitled "Connecting Cables To The Transmitter" on page 31, then attach the transmitter/L bracket assembly to the back mounting surface using two #10 taptite screws from the kit.
9. Attach the connector end of the CCVP cable to the Carbon Canister's Vapor Valve connector (see Figure 17).
10. Insert the battery pack into its support bracket - do not connect the battery cable to the battery pack at this time.




Figure 15. Example CCVP installation

**LEGEND FOR NUMBERED BOXES IN Figure 15**

1. CCVP transmitter/battery enclosure on vent stack

2. CCVP support bracket




Figure 16. Example CCVP transmitter/battery pack installation in vent stack enclosure

**LEGEND FOR NUMBERED BOXES IN Figure 16**

- |  |   |
|--|---|
| 1. Transmitter   | 5. Battery caution label attached to battery cable (2 places) |
| 2. Battery pack  | 6. Cable from CCVP  |
| 3. Thin hex nut  | 7. Attach Transmitter L bracket using two #10 taptite screws  |
| 4. Attach Battery L bracket using two #10 taptite screws |   |






Figure 17. Attaching transmitter cable to CCVP vapor valve

**LEGEND FOR NUMBERED BOXES IN Figure 17**

- |  |                              |
|--|------------------------------|
| 1. Vapor Valve assembly                            | 3. Cable to CCVP transmitter |
| 2. Cable to CCVP thermal probe (factory installed) | 4. CCVP                      |

## Vapor Return Pressure Sensor Installation

---

### VENT STACK INSTALLATION EXAMPLE

1. A Transmitter/battery pack pair must be installed with the Veeder-Root Vapor Return Pressure Sensor (VRPS) in the Universal Enclosure and mounted on the vent stack (see Figure 18).
2. Install the VRPS sensor in the Universal Enclosure following instructions accompanying the sensor. During the installation, all required National, State and local safety codes must be followed.
3. Using two #10 taptite screws from the Universal Enclosure kit, attach the Transmitter housing to the side of the L bracket from the Universal Enclosure kit - do not attach L bracket/transmitter assembly to the back mounting surface at this time.
4. Get the battery pack mounting bracket from the Universal Enclosure kit and put the threaded connector fitting of the battery housing through the large hole in the bracket.
5. Get the thin hex nut from the kit and screw it onto the battery housing cable connector threaded fitting until snug (see item 4 in Figure 19).
6. Attach the battery housing/bracket assembly to the back mounting surface of the Universal Enclosure using two #10 taptite screws from the kit (see item 5 in Figure 19).
7. Connect the VRPS and battery cables to the VRPS transmitter as described in the section below entitled "Connecting Cables To The Transmitter" on page 31, then attach the transmitter/L bracket assembly to the back mounting surface using two #10 taptite screws from the kit.




Figure 18. VRPS Mounted In Universal Enclosure On The Vent Stack

**LEGEND FOR NUMBERED BOXES IN Figure 18**

- |               |   |
|---------------|---|
| 1. Vent stack | 2. VRPS sensor, wireless transmitter/battery in Universal Enclosure |
|---------------|---|




Figure 19. Example VRPS Transmitter/battery Pack Installation In The Universal Enclosure

**LEGEND FOR NUMBERED BOXES IN Figure 19**

- |                 |   |
|-----------------|---|
| 1. VRPS cable   | 5. Attach Battery L bracket using two #10 taptite screws      |
| 2. VRPS         | 6. Battery caution label attached to battery cable (2 places) |
| 3. Battery pack | 7. Attach Transmitter L bracket using two #10 taptite screws  |
| 4. Thin hex nut | 8. Transmitter  |

## Connecting Cables To The Transmitter

Note: The dip switches in each transmitter must be set to the proper dip switch settings listed in Appendix B. If the dip switches are set incorrectly, this device will fail to operate properly.

1. Using a #15 torx driver, remove the cover of the Transmitter.
2. Make sure the battery/DC power cable is not connected to the battery pack (item 5 in Figure 14) or dc power source at this time.



**WARNING! To prevent ignition of flammable or combustible atmosphere disconnect power before servicing.**

3. Remove the nut from the probe/sensor cable cord grip (left side cord grip) and slide it over the non-connector end of the probe/sensor cable. Push the end of the cable into the Transmitter.
4. Strip back cable jacket and wires as shown in Figure 20.
5. All probe/sensor cables connect to the PROBE terminal block the SAME WAY - the white wire to the PWR terminal and the black wire to the GND terminal as shown in Figure 21.




Figure 20. Connecting Input Wiring To Transmitter Terminal Blocks

### LEGEND FOR NUMBERED BOXES IN Figure 20

- |  |   |
|--|---|
| 1. Strip back cable and wire jackets the amount shown. | 3. Both wires must be tight in terminals! |
| 2. Use a screwdriver with the proper blade width.      |   |

6. Remove the nut from the power cable cord grip (right side cord grip) and slide it over the non-connector end of the power cable. Push the end of the cable into the Transmitter.
7. Strip back cable jacket and wires as shown in Figure 20.
8. Connect power cable wires to the BATTERY terminal block placing the white wire in the +IN terminal and the black wire in the -IN terminal as shown in Figure 21.



9. **Hand tighten both cable entry cord grip nuts to prevent water entry!**




Figure 21. Wiring The Transmitter

**LEGEND FOR NUMBERED BOXES IN Figure 21**

- |  |  |
|--|--|
| 1. Green LED – Unit status.  | 6. Cable from battery or DC power source.                    |
| 2. Red LED – Radio status.   | 7. Cable from probe/sensor.                                  |
| 3. S2 DIP switch.  | 8. PROBE input terminals (PWR and GND).<br>OBSERVE POLARITY! |
| 4. Red LED – Flashes only when radio is powered on in Diagnostic Mode. | 9. S1 DIP switch.  |
| 5. BATTERY power-in terminals (+IN and –IN). Observe polarity!         |  |



**Pay close attention to the polarity of the battery input connections. Reversing the connections can cause damage to the TLS RF.**

10. To assure a water-tight seal between the cover and the enclosure, follow these steps:
  - a. Insert the four cover screws through the cover and then press on the retaining washers to hold the screws in place.
  - b. Make sure that the cover gasket is free of dirt and debris on both sides of the gasket and that the inside of the cover is clean in the gasket area.
  - c. Position the gasket into the cover groove, assuring that it is pressed fully into the groove and sitting completely flat.
  - d. Assemble the cover onto the enclosure, tightening the screws in a couple of turns each. Using an alternating 'X' pattern, continue to tighten the screws until they are all tight.
11. If you haven't done so already, attach the red battery labels from the installation kit onto the power cable below the power cord grip and at the battery pack connector or DC power source.
12. Do not attach the power cable at the battery pack or dc power source until ready to begin the "Site Startup Procedure".

## Receiver Installation

---

1. One Receiver is required per site and it is mounted in the vertical position (antenna up) on the outer wall of the same building housing the TLS RF. The Receiver is attached to its mounting bracket with #10 x 1/2" taptite screws from its install kit (see Figure 22). The L-bracket is then mounted on the outer wall of the building using appropriate fasteners (customer supplied). If the Receiver will be exposed to the weather, attach the L-bracket to the mounting surface inside a weatherproof enclosure. This enclosure is not required when mounting the Receiver under a roof overhang and shielded from the weather.

NOTE: When locating the mounting position, keep in mind that the RS-485 cable connecting the Receiver to the TLS RF must be less than 250 feet in length. Avoid placing the Receiver near motors (e.g., power roof vents), fluorescent lighting (min. 1 foot separation), pumps, welders.

Locate the Receiver on the same side of the building as the transmitters. If additional transmitters are either too far away or on the opposite side of the building, the Repeater can be located either on a structure near the remote transmitter(s) or on the opposite side of the building facing those transmitter(s) - see Repeater installation.



### **The Receiver is only suitable for use in a non-hazardous location.**

2. Run the RS-485 cable (Belden #3107A or equiv.) from the TLS RF through the building's wall to the Receiver. Caulk the cable where it passes through wall openings. Use cable clamps at appropriate intervals to secure the cable to the walls.
3. Note that the Receiver cover label indicates the cord grip to be used for the RS-485 cable from the TLS RF and the cable to the Repeater (if used). Remove the cover of the Receiver and set it aside.
4. Set S1 and S2 DIP settings as desired (ref. Appendix B, Figure B-2). NOTE: set all dip switches prior to attaching the TLS RF RS-485 cable as the dip switches are only read during power up.
5. Slide the nut over the cable. Choose the correct size bushing and slide it over the cable. Dress the cable jacket according to the dimensions in Figure 20. Insert the cable into the appropriate opening at the bottom of the housing. Insert each wire into the appropriate terminal and tighten. Leave a small amount of slack in each wire. Slide the bushing into the bottom of the housing. Hand tighten the nut.
6. Note that there are two twisted pair color-coded wires in the cable (e.g., a white with blue stripe and blue with white stripe pair and a white with orange strip and orange with white stripe pair). One of the pairs is for RS-485 communication (- & + terminals) and the other pair is for Receiver power (+15 Vdc & Gnd). Using Figure 23 as a guide, attach the wires of the two twisted pairs to the RS-485 terminals.

Record which wire attaches to each terminal to help you attach the other end of that wire to the identically marked terminal in the TLS RF.




Figure 22. Attaching Mounting Bracket To Receiver Or Repeater

#### LEGEND FOR NUMBERED BOXES IN Figure 22

- |   |                              |
|---|------------------------------|
| 1. Receiver or Repeater   | 4. #10 x 1/2" taptite screws |
| 2. 0.280" diameter hole (2) – mount this narrow side of bracket to wall or post |                              |
| 3. Mounting bracket.  |                              |

7. Referring to your connection notes in step 5 above, connect the other end of the RS-485 cable to the RS-485 terminal block in the TLS RF (ref. Figure 7 on page 16).
8. If a Repeater is used and powered by the Receiver, push the two wire power cable (to Repeater) through the +15 Vdc cord grip of the Receiver (item 7 in Figure 23).
9. Slide the nut over the cable. Choose the correct size bushing and slide it over the cable. Dress the cable jacket according to the dimensions in Figure 20. Insert the cable into the appropriate opening at the bottom of the housing. Insert each wire into the appropriate terminal and tighten. Leave a small amount of slack in each wire. Slide the bushing into the bottom of the housing. Hand tighten the nut.
10. Attach the dc power cable (white to +15 Vdc and black to GND) to the Repeater terminal block (item 9 in Figure 23).



#### 11. Hand tighten both cable entry cord grip nuts to prevent water entry!

12. To assure a water-tight seal between the cover and the enclosure, follow these steps:
  - a. Insert the four cover screws through the cover and then press on the retaining washers to hold the screws in place.
  - b. Make sure that the cover gasket is free of dirt and debris on both sides of the gasket and that the inside of the cover is clean in the gasket area.
  - c. Position the gasket into the cover groove, assuring that it is pressed fully into the groove and sitting completely flat.
  - d. Assemble the cover onto the enclosure, tightening the screws in a couple of turns each. Using an alternating 'X' pattern, continue to tighten the screws until they are all tight.






Figure 23. Wiring The Receiver

**LEGEND FOR NUMBERED BOXES IN Figure 23**

1. RS-485 Comm Activity:
  - XMIT (Red) LED – flashes when message transmitted to TLS-RF
  - RCV (Green) LED – flashes when message received from TLS-RF
  - PWR (Red) LED – Receiver power on indicator
2. Green LED – Unit status
3. Red LED – Radio status
4. Connect the color pairs of the RS-485/power cable to the same RS-485 terminals in both the Receiver and the master TLS RF (ref. “Connecting RS-485 Wiring” on page 17).
5. S1 DIP switch
6. RS-485 cable - Maximum cable length is 500 feet if a communication grade cable is used.

7. A solid bushing must be installed to seal the Receiver when this cord grip is unused. In sites where a Repeater is powered from the Receiver, the Repeater’s power cable enters through this cord grip and attaches to the Repeater terminal block (item 9).



**HAND TIGHTEN BOTH CABLE ENTRY CORD GRIP NUTS TO PREVENT WATER ENTRY!**

8. S2 DIP switch
9. +15 Vdc power source for the Repeater. If used, connect two wires from item 9 connector in Receiver to item 7 connector in Repeater, see Figure 24.



**Pay close attention to the polarity of the +15 Vdc and GND wires used as Repeater power source. Reversing these connections can cause damage to the TLS RF.**

## Repeater Installation

---

1. Use of a single repeater is optional but may improve system performance when installed correctly. The Repeater should be located closer to the device transmitters to rebroadcast messages to the Receiver. Use the 15 Vdc power source provided in the Receiver to power the Repeater, or use a customer supplied non-interruptible, Class 2, 15 Vdc power source. The most common method of powering the Repeater power is to use the Repeater power terminal block J4 in the Receiver (see item 9 in Figure 23).

When device transmitters are on the opposite side of the building from the Receiver, the Repeater should be mounted on the side of the building facing those transmitters. Mount the Repeater with its transmitter antenna in the up or vertical orientation.

2. The Repeater is attached to its mounting bracket with #10 x 1/2" taptite screws from its install kit (ref. Figure 22 on page 34). The L-bracket is then attached to the outer wall of the building using appropriate fasteners (customer supplied). If the Repeater will be exposed to the weather, attach the L-bracket to the mounting surface inside a weatherproof enclosure. This enclosure is not required when mounting the Repeater under a roof overhang and shielded from the weather.



**The Repeater is only suitable for use in a non-hazardous location.**

3. Set S1 and S2 as desired (refer to Appendix B). NOTE: set all dip switches prior to connecting the +15 Vdc power cable as the dip switches are only read during power up.
4. Note the cover of the Repeater indicates the cord grip to be used for the cable connecting the Repeater to its dc power source (item 5 in Figure 24). Remove the cover of the Repeater and set it aside.
5. Slide the nut over the cable. Choose the correct size bushing and slide it over the cable. Dress the cable jacket according to the dimensions in Figure 20. Insert the cable into the appropriate opening at the bottom of the housing. Insert each wire into the appropriate terminal and tighten. Leave a small amount of slack in each wire. Slide the bushing into the bottom of the housing. Hand tighten the nut.
6. Connect the 2-wire dc power cable to the Repeater terminal block, white to +15 Vdc and black to GND (see item 7 in Figure 24).



**7. Hand tighten both cable entry cord grip nuts to prevent water entry!**

8. To assure a water-tight seal between the cover and the enclosure, follow these steps:
  - a. Insert the four cover screws through the cover and then press on the retaining washers to hold the screws in place.
  - b. Make sure that the cover gasket is free of dirt and debris on both sides of the gasket and that the inside of the cover is clean in the gasket area.
  - c. Position the gasket into the cover groove, assuring that it is pressed fully into the groove and sitting completely flat.
  - d. Assemble the cover onto the enclosure, tightening the screws in a couple of turns each. Using an alternating 'X' pattern, continue to tighten the screws until they are all tight.
9. The other end of the Repeater's dc power cable connects to the Receiver's +15 Vdc output terminal (ref. item 9 in Figure 23), or to a non-interruptible, Class 2, 15 Vdc power source.




Figure 24. Wiring The Repeater

**LEGEND FOR NUMBERED BOXES IN Figure 24**

- 1. Red LED – on when power is applied.
- 2. Green LED – Unit status
- 3. Red LED – Radio status
- 4. S1 DIP switch
- 5. DC Power input cable (from Receiver [item 9 connector - see Figure 23], or dc power source)

- 6. S2 DIP switch
- 7. DC power input terminals - +15 Vdc and ground



**Pay close attention to the polarity of the +15 Vdc and GND wires from the Receiver or DC power source. Reversing these connections can cause damage to the TLS RF.**

# Network Setup

## Hardware Overview

An example TLS RF Wireless System site network illustrating a 32 Transmitter configuration is shown in Figure 25. The maximum number of Transmitters permissible in a site is 32 (requires 4 TLS RFs).




Figure 25. Example Site Network Diagram

### LEGEND FOR NUMBERED BOXES IN Figure 25

- |                     |  |
|---------------------|--|
| 1. Site Network     | 5. Repeater                                |
| 2. Wireless network | 6. Receiver                                |
| 3. VR bus           | 7. TLS RF, one required per 8 Transmitters |
| 4. Transmitters     | 8. TLS console                             |

## Identifying Devices in the TLS RF Wireless Site Network

The Site ID must be identical for all Transmitters, the Repeater, and the Receiver in the site's wireless network. Each Transmitter in the site's wireless network must have a unique Device Number (from 1 – 32). Each TLS RF in the site's network must have a unique Device Number (Master at 0 and Auxiliaries at 1, 2, and/or 3).

All Device Numbers are entered using DIP switches located in each device and are entered in each device before it is installed.

Making up a site network worksheet before actually setting device DIP switches or connecting signal wires will help prevent mistakes when entering Site IDs/Device Numbers or making wiring connections between the TLS RF(s) and the TLS console.

## Entering Device Numbers for the Site Network

### TRANSMITTER DEVICE NUMBER

Each of the transmitters must have a unique Device Number (1 – 32). Enter this number by setting DIP switches 4 – 8 on S1 (see Figure 21 on page 32) in the 'off' position or 'on' position as shown below.

| Device Number | S1 DIP Switch Settings |     |     |     |     | Device Number | S1 DIP Switch Settings |     |     |     |     |
|---------------|------------------------|-----|-----|-----|-----|---------------|------------------------|-----|-----|-----|-----|
|               | 4                      | 5   | 6   | 7   | 8   |               | 4                      | 5   | 6   | 7   | 8   |
| 1             | off                    | off | off | off | on  | 17            | on                     | off | off | off | on  |
| 2             | off                    | off | off | on  | off | 18            | on                     | off | off | on  | off |
| 3             | off                    | off | off | on  | on  | 19            | on                     | off | off | on  | on  |
| 4             | off                    | off | on  | off | off | 20            | on                     | off | on  | off | off |
| 5             | off                    | off | on  | off | on  | 21            | on                     | off | on  | off | on  |
| 6             | off                    | off | on  | on  | off | 22            | on                     | off | on  | on  | off |
| 7             | off                    | off | on  | on  | on  | 23            | on                     | off | on  | on  | on  |
| 8             | off                    | on  | off | off | off | 24            | on                     | on  | off | off | off |
| 9             | off                    | on  | off | off | on  | 25            | on                     | on  | off | off | on  |
| 10            | off                    | on  | off | on  | off | 26            | on                     | on  | off | on  | off |
| 11            | off                    | on  | off | on  | on  | 27            | on                     | on  | off | on  | on  |
| 12            | off                    | on  | on  | off | off | 28            | on                     | on  | on  | off | off |
| 13            | off                    | on  | on  | off | on  | 29            | on                     | on  | on  | off | on  |
| 14            | off                    | on  | on  | on  | off | 30            | on                     | on  | on  | on  | off |
| 15            | off                    | on  | on  | on  | on  | 31            | on                     | on  | on  | on  | on  |
| 16            | on                     | off | off | off | off | 32            | off                    | off | off | off | off |

964-43.eps

## TLS RF DEVICE NUMBER

Each TLS RF in the site network must have a unique Device Number (0 – 3). You must select 0 if it is the only TLS RF in the site, or if it is the TLS RF in a site with multiple TLS RFs that is monitoring the first Device Set (transmitters 1 – 8). You would enter a 1 for the TLS RF monitoring the second Device Number (transmitters 9 – 16), etc. The site's receiver must also be connected to the TLS RF having Device Number '0'. The factory default setting is '0'.

Enter this number by setting DIP switches 1 and 2 on S2 (see Figure 12 on page 21) in the 'off' position or 'on' position as shown below.

| Transmitter Device Number | TLS RF Device Number | S2 DIP switch Settings |     | TLS RF |
|---------------------------|----------------------|------------------------|-----|--------|
|                           |                      | 1                      | 2   |        |
| 1-8                       | 0                    | off                    | off | Master |
| 9-16                      | 1                    | off                    | on  | AUX 1  |
| 17-24                     | 2                    | on                     | off | AUX 2  |
| 25-32                     | 3                    | on                     | on  | AUX 3  |

964-48.eps

## Entering the Site ID Number

All of the site's Transmitters, Repeater and Receiver must have the same Site ID number (0 – 15) entered in S2 DIP switches 5 - 8 (see settings below). The TLS RF does not require a Site ID. The factory default Site ID number for all components is set to 0.

NOTE: You must change the factory set Site ID when another site is nearby. Adjoining sites will experience data reception 'crosstalk' if both are left at the same number.

| Site ID Number | S2 DIP switch Settings |     |     |     | Site ID Number | S2 DIP switch Settings |     |     |     |
|----------------|------------------------|-----|-----|-----|----------------|------------------------|-----|-----|-----|
|                | 5                      | 6   | 7   | 8   |                | 5                      | 6   | 7   | 8   |
| 0              | off                    | off | off | off | 8              | on                     | off | off | off |
| 1              | off                    | off | off | on  | 9              | on                     | off | off | on  |
| 2              | off                    | off | on  | off | 10             | on                     | off | on  | off |
| 3              | off                    | off | on  | on  | 11             | on                     | off | on  | on  |
| 4              | off                    | on  | off | off | 12             | on                     | on  | off | off |
| 5              | off                    | on  | off | on  | 13             | on                     | on  | off | on  |
| 6              | off                    | on  | on  | off | 14             | on                     | on  | on  | off |
| 7              | off                    | on  | on  | on  | 15             | on                     | on  | on  | on  |

964-49.eps

## Site Startup Procedure

---

Depending on the site layout, it is permissible to install RF devices in a variety of locations including dispensers and containment sumps. After all the wireless equipment has been installed, follow the steps below to verify the final setup. For transmitters installed in Dispensers, do not close the dispenser's cover after installing the Transmitter in case signal strength is a problem. Close the dispenser's cover only after the Transmitter passes a second verification process.

1. Turn on power to the TLS RF(s) and leave the covers open.
2. Go to the first Transmitter and connect the power cable to its power source.
3. At the TLS RF you should see one of the 8 red LEDs flashing (item 5 in Figure 12). This is an indication the transmission from the Transmitter is being received. If it is, go to Step 2a. If one of the 8 LEDs is not flashing go to Step 2b.
  - a. Go back to the Transmitter, and if applicable, replace the dispenser's cover. Return to the TLS RF and verify that the same LED is still flashing.
    - i. If it is, disconnect the battery cable from the battery pack and repeat Step 1 on the next Transmitter.
    - ii. If it is not, the Receiver is not picking up the Transmitter's signal. Go back to the Transmitter; remove the dispenser's cover, reorient the antenna or lower the Transmitter, then go back to the TLS RF to verify that the same LED is flashing.
    - iii. If reorienting the antenna or moving the Transmitter doesn't help, disconnect the battery cable from the battery pack and make a note that the signal is not being received at this particular dispenser.
    - iv. Repeat Step 1 with the next Transmitter.
  - b. If applicable, go back to the dispenser, remove the Transmitter's cover; the green LED (item 2 in Figure 5) should be flashing indicating that the sensor is being read. If the green LED is not flashing, check the sensor cable's wiring connections. If the wiring is correct, check Site ID. If it is correct, it means either the Transmitter is bad or there is a problem with the sensor, disconnect the battery cable from the battery pack and continue to Step 1 with the next Transmitter.
4. After verifying that each Transmitter is being received at the TLS RF(s), go around to each Transmitter; reconnect the Transmitters' battery cable to the battery pack. Replace dispenser's cover as appropriate. Go to the TLS console and configure all site sensors. Check for any comm alarms. If none are observed, the startup is complete.

NOTE: If some Transmitters are not being received at the TLS RF, relocating the Receiver and/or the Repeater may improve reception.

## Initial TLS Console Setup Procedure

---



**CAUTION! Failure to follow your applicable startup procedure will result in the probes/sensors not being recognized.**

- **Sites with a New TLS-450/, TLS4 or TLS-XB Only**
  1. Power up all wireless devices.
  2. Power up the TLS RF console and wait about 5 minutes.
  3. Power up the TLS-450 console and wait 5 minutes until the device 'Discover Mode' is Complete.
- **Sites with all Other TLS Consoles**
  1. Power up all wireless devices
  2. Power up both the TLS and TLS RF consoles.

# Diagnostics

## Alarms

---

During normal operation when the TLS Console and monitored PMC and ISD System are functioning properly and no warning or alarm conditions exist, the "ALL FUNCTIONS NORMAL" message will appear in the system status area of the console display. Regardless of the TLS Console in use at this site, record the software part number as well as the software revision.

There is an additional alarm, Battery Status (TLS-350 only), when wireless equipment is used in place of wires. ISD, PMC and Smart Sensor warnings and alarm are the same. If a warning or alarm condition occurs as a result of a failure in the wireless communication hardware the system displays the communication failure for the effected Smart Sensor. If more than one condition exists, the display will alternately flash the appropriate messages. The system automatically prints an alarm report showing the warning or alarm type, its location and the date and time the warning or alarm condition occurred.

Any break in link between transmitter and sensor, or between TLS and TLS RF results in Communication Alarm. All other alarms related to individual sensor types, such as sensor fault alarm, are supported as they are with a wired system. When the Sensor Transmitter has determined the communication with the RF box has failed it will command the Vapor Valve to close. The valve will remain closed until an open command is sent (from the TLS) after communication is reestablished.

## Battery Diagnostics

---

You can get the battery status from the TLS-350 (with software Version 30A or higher). The battery status is displayed for the wireless sensors, from the Smart Sensor Diagnostics (see Figure 26). The wireless sensors's battery status can also be printed from that screen.

The battery status for the wireless sensors is reported as Full, Medium, Low or Replace.

- Full: greater than or equal to 3.4 Volts
- Medium Range: 3.2V to 3.4 Volts
- Low range: 3.0V to 3.2V
- Replace: Below 3.0V

When the Smart Sensor battery reports a status 'Replace' continuously for 24 hours, a Smart Sensor warning will be posted on the TLS to alert the operator that the battery requires replacement. The warning will persist in the TLS until the battery reports 'Medium' or 'Full'. The alarm will clear at that time. This is a low priority TLS warning which will sound the beeper, flash the yellow warning light, post on the two line display, print on the printer and be recorded in the non-priority alarm history. The warning can be accessed remotely and be reported remotely similar to all TLS warnings and alarms. This warning will not appear in the ISD or PMC reports (only sensor failures are recorded in the ISD and PMC reports).

## WIRELESS SENSOR DIAGNOSTIC MENU (TLS-350 CONSOLES)

The Battery Status for all wireless Smart Sensors will be displayed in the menu after the Serial Number (see Figure 26).






Figure 26. Device Battery Status In TLS-350 SmartSensor Diagnostic Menu

## Appendix A: Regulatory Information

### Federal Communications Commission Notice

---

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio or television technician for help.

### MODIFICATIONS

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by Veeder-Root Company may void the authority to operate the equipment.

### CABLES

Connections to this device must be made with shielded cables with metallic RFI/EMI connector hoods in order to maintain compliance with FCC Rules and Regulations.

### DECLARATION OF CONFORMITY FOR PRODUCTS MARKED WITH THE FCC LOGO—UNITED STATES ONLY

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

For questions regarding your product, contact:

Veeder-Root Company  
125 Powder Forest Drive  
Simsbury, CT 06070  
Or, call 1-800-323-1799

For questions regarding this FCC declaration, contact:

Veeder-Root Company  
125 Powder Forest Drive  
Simsbury, CT 06070  
Or, call 1-800-323-1799

To identify this product, refer to the Part, Series, or Model number found on the product.

## Canadian Notice

---

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

### AVIS CANADIEN

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

## Battery Warning

---



**WARNING: The TLS RF Wireless System Battery Pack contains lithium batteries. To reduce the risk of fire or burns, do not disassemble, crush, puncture, short external contacts, or dispose of in fire or water.**



Because of the type of batteries used in TLS RF Wireless System, follow local regulations regarding the safe disposal of the battery. Consult Appendix D of this manual for more information on battery disposal.

## Wireless Notices

---

In some environments, the use of wireless devices may be restricted. Such restrictions may apply aboard airplanes, in hospitals, near explosives, in hazardous locations, etc. If you are uncertain of the policy that applies to the use of this device, please ask for authorization to use it prior to turning it on.

## U.S. Regulatory Wireless Notice

---

**WARNING: Exposure to Radio Frequency Radiation. The radiated output power of this device is below the FCC radio frequency exposure limits. Nevertheless, the device should be used in such a manner that the potential for human contact during normal operation is minimized. To avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to the antenna should be minimized.**

## Canadian Regulatory Wireless Notice

---

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. The term "IC:" before the certification/registration number only signifies that the Industry Canada technical specifications were met.

## System Specifications

---

Note: Not all models described are available in all regions.

# Appendix B: Device DIP Switch Settings

## TLS RF Number Settings

The Dip Switch Locations to set the unique Device number for the TLS RF(s) are shown in the Figure B-1. The TLS RF that monitors the Receiver and Transmitter IDs 1 - 8 is considered the site's master TLS RF and must have its Device ID set to 0 (default).




**CAUTION:** Setting the Device Timeout delay to less than 10 minutes may result in Device Out errors since the transmitter's transmit time intervals are programmable and may have been set to a value greater than the Device Timeout you set here.

### TLS RF

Device Timeout  
(Time to Comm alarm)

| Sw Pos | Delay          |
|--------|----------------|
| 0      | 5 m            |
| 1      | 10 m (default) |
| 2      | 15 m           |
| 3      | 20 m           |
| 4      | 30 m           |
| 5      | 45 m           |
| 6      | 60 m           |
| 7      | 90 m           |
| 8      | 2 h            |
| 9      | 3 h            |
| A      | 4 h            |
| B      | 6 h            |
| C      | 8 h            |
| D      | 12 h           |
| E      | 18 h           |
| F      | 24 h           |



TLS RF Device ID  
0 = Master


| Device ID  | Sw1 | Sw2 | Transmitter IDs |
|------------|-----|-----|-----------------|
| 0 (Master) | off | off | 1 - 8           |
| 1 (Aux 1)  | off | on  | 9 - 16          |
| 2 (Aux 2)  | on  | off | 17 - 24         |
| 3 (Aux 3)  | on  | on  | 25 - 32         |

964 b-1arb.eps

Figure B-1. TLS-RF switch settings

## Transmitter/Receiver/Repeater DIP Switch Settings

DIP switch locations for the Transmitter, Receiver and Repeater are shown in Figure B-2. Device DIP switch settings for these devices are listed in Figure B-3 through Figure B-7 (use the appropriate settings for your software version 1 or 3).



c-2.eps

Figure B-2. DIP switch settings

| All Wireless 2 (W2) Transmitters |     |     |                    |
|----------------------------------|-----|-----|--------------------|
| S1: Positions                    |     |     | Function           |
| 1                                | 2   | 3   |                    |
| OFF                              | OFF | OFF | Enable Transmitter |

c-3.eps

Figure B-3. S1: DIP switch positions 1-3 – (W2) All Devices

| All Wireless 2 (W2) Transmitters |     |     |     |     |                            |  |                     |  |
|----------------------------------|-----|-----|-----|-----|----------------------------|--|---------------------|--|
| S1: Positions                    |     |     |     |     | TRANSMITTER                |  |                     |  |
| 4                                | 5   | 6   | 7   | 8   | Device Number              |  |                     |  |
| OFF                              | OFF | OFF | OFF | ON  | 1 (Master TLS-RF Device 1) |  | Master TLS RF       |  |
| OFF                              | OFF | OFF | ON  | OFF | 2 (Master TLS-RF Device 2) |  | Connects to         |  |
| OFF                              | OFF | OFF | ON  | ON  | 3 (Master TLS-RF Device 3) |  | Receiver            |  |
| OFF                              | OFF | ON  | OFF | OFF | 4 (Master TLS-RF Device 4) |  |                     |  |
| OFF                              | OFF | ON  | OFF | ON  | 5 (Master TLS-RF Device 5) |  |                     |  |
| OFF                              | OFF | ON  | ON  | OFF | 6 (Master TLS-RF Device 6) |  |                     |  |
| OFF                              | OFF | ON  | ON  | ON  | 7 (Master TLS-RF Device 7) |  |                     |  |
| OFF                              | ON  | OFF | OFF | OFF | 8 (Master TLS-RF Device 8) |  |                     |  |
| OFF                              | ON  | OFF | OFF | ON  | 9 (Aux 1 TLS-RF Device 1)  |  | Aux 1 is the second |  |
| OFF                              | ON  | OFF | ON  | OFF | 10 (Aux 1 TLS-RF Device 2) |  | TLS RF Console      |  |
| OFF                              | ON  | OFF | ON  | ON  | 11 (Aux 1 TLS-RF Device 3) |  |                     |  |
| OFF                              | ON  | ON  | OFF | OFF | 12 (Aux 1 TLS-RF Device 4) |  |                     |  |
| OFF                              | ON  | ON  | OFF | ON  | 13 (Aux 1 TLS-RF Device 5) |  |                     |  |
| OFF                              | ON  | ON  | ON  | OFF | 14 (Aux 1 TLS-RF Device 6) |  |                     |  |
| OFF                              | ON  | ON  | ON  | ON  | 15 (Aux 1 TLS-RF Device 7) |  |                     |  |
| ON                               | OFF | OFF | OFF | OFF | 16 (Aux 1 TLS-RF Device 8) |  |                     |  |
| ON                               | OFF | OFF | OFF | ON  | 17 (Aux 2 TLS-RF Device 1) |  | Aux 2 is the third  |  |
| ON                               | OFF | OFF | ON  | OFF | 18 (Aux 2 TLS-RF Device 2) |  | TLS RF Console      |  |
| ON                               | OFF | OFF | ON  | ON  | 19 (Aux 2 TLS-RF Device 3) |  |                     |  |
| ON                               | OFF | ON  | OFF | OFF | 20 (Aux 2 TLS-RF Device 4) |  |                     |  |
| ON                               | OFF | ON  | OFF | ON  | 21 (Aux 2 TLS-RF Device 5) |  |                     |  |
| ON                               | OFF | ON  | ON  | OFF | 22 (Aux 2 TLS-RF Device 6) |  |                     |  |
| ON                               | OFF | ON  | ON  | ON  | 23 (Aux 2 TLS-RF Device 7) |  |                     |  |
| ON                               | ON  | OFF | OFF | OFF | 24 (Aux 2 TLS-RF Device 8) |  |                     |  |
| ON                               | ON  | OFF | OFF | ON  | 25 (Aux 3 TLS-RF Device 1) |  | Aux 3 is the fourth |  |
| ON                               | ON  | OFF | ON  | OFF | 26 (Aux 3 TLS-RF Device 2) |  | TLS RF Console      |  |
| ON                               | ON  | OFF | ON  | ON  | 27 (Aux 3 TLS-RF Device 3) |  |                     |  |
| ON                               | ON  | ON  | OFF | OFF | 28 (Aux 3 TLS-RF Device 4) |  |                     |  |
| ON                               | ON  | ON  | OFF | ON  | 29 (Aux 3 TLS-RF Device 5) |  |                     |  |
| ON                               | ON  | ON  | ON  | OFF | 30 (Aux 3 TLS-RF Device 6) |  |                     |  |
| ON                               | ON  | ON  | ON  | ON  | 31 (Aux 3 TLS-RF Device 7) |  |                     |  |
| OFF                              | OFF | OFF | OFF | OFF | 32 (Aux 3 TLS-RF Device 8) |  |                     |  |

c-4.eps

Figure B-4. S1: DIP switch positions 4-8 – (W2) All Devices

| Wireless 2 (W2) CCVP-Carbon Can Vapor Processor |     |     |     |                                 |    |
|---|-----|-----|-----|---------------------------------|----|
| S2: Positions                                   |     |     |     | Transmitter Interval in Seconds |    |
| 1   | 2   | 3   | 4   | Read                            | TX |
| OFF   | OFF | OFF | OFF | 32                              | 16 |

\* →

\* = Recommended settings

c-7.eps

Figure B-5. S2: DIP switch positions 1-4 – (W2) CCVP

| Wireless 2 (W2) Vapor Flowmeter |    |     |     |                                 |    |
|---------------------------------|----|-----|-----|---------------------------------|----|
| S2: Positions                   |    |     |     | Transmitter Interval in Seconds |    |
| 1                               | 2  | 3   | 4   | Read                            | TX |
| OFF                             | ON | OFF | OFF | 32                              | 32 |

\* →

\* = Required settings

c-9.eps

Figure B-6. S2: DIP switch positions 1-4 – (W2) Vapor Flow Meter

| Wireless 2 (W2) Transmitters, Receiver and Repeater<br>(All Site ID settings must be the same) |     |     |     |             |                       |                       |
|--|-----|-----|-----|-------------|-----------------------|-----------------------|
| S2: Positions  |     |     |     | TRANSMITTER | REPEATER <sup>1</sup> | RECEIVER <sup>1</sup> |
| 5  | 6   | 7   | 8   | Site ID     | Site ID               | Site ID               |
| OFF  | OFF | OFF | OFF | 0           | 0                     | 0                     |
| OFF  | OFF | OFF | ON  | 1           | 1                     | 1                     |
| OFF  | OFF | ON  | OFF | 2           | 2                     | 2                     |
| OFF  | OFF | ON  | ON  | 3           | 3                     | 3                     |
| OFF  | ON  | OFF | OFF | 4           | 4                     | 4                     |
| OFF  | ON  | OFF | ON  | 5           | 5                     | 5                     |
| OFF  | ON  | ON  | OFF | 6           | 6                     | 6                     |
| OFF  | ON  | ON  | ON  | 7           | 7                     | 7                     |
| ON   | OFF | OFF | OFF | 8           | 8                     | 8                     |
| ON   | OFF | OFF | ON  | 9           | 9                     | 9                     |
| ON   | OFF | ON  | OFF | 10          | 10                    | 10                    |
| ON   | OFF | ON  | ON  | 11          | 11                    | 11                    |
| ON   | ON  | OFF | OFF | 12          | 12                    | 12                    |
| ON   | ON  | OFF | ON  | 13          | 13                    | 13                    |
| ON   | ON  | ON  | OFF | 14          | 14                    | 14                    |
| ON   | ON  | ON  | ON  | 15          | 15                    | 15                    |

c-10.eps

<sup>1</sup> Set all remaining dip switches (S2 1-4 and S1 1-8) to OFF for both the Repeater and Receiver.

Figure B-7. S2: DIP switch positions 5-8 – (W2) All Devices

## Appendix C: Lithium Battery Safety Data

This appendix contains the manufacturer supplied Transportation Certificate and Material Safety Data Sheet for the lithium batteries used in the TLS RF Wireless 2 (W2) System.

### **Lithium Battery Disposal Considerations**

---

1. Waste disposal must be in accordance with the applicable regulations.
2. Disposal of the Lithium batteries should be performed by permitted, professional disposal firms knowledgeable in Federal, State or Local requirements of hazardous waste treatment and hazardous waste transportation.
3. Incineration should never be performed by battery users, but by trained professionals in an authorized facility with proper gas and fume containment.
4. Recycling of battery can be done in authorized facility, through licensed waste carrier.










## Material/Product Safety Data Sheet (MSDS-PSDS)



|                                    |   |
|------------------------------------|---|
| <b>LS/LSG/LSH/LST/LSX products</b> | <b>Lithium/Thionyl chloride<br/>single cells and multi-cell battery packs</b> |
| <b>Revision 8 Date 10/2008</b>     |   |

| 1. Identification of the Substance or Preparation and Company                          |   |  |  |  |
|--|---|--|--|--|
| <b>Product</b>   | <b>Primary Lithium/Thionyl chloride unit cells and multi-cell battery packs<br/>(Li-SOCl<sub>2</sub>)</b>                       |  |  |  |
| <b>Production sites</b>  | Saft Ltd.<br>River Drive<br>Tyne & Wear<br>South Shields<br>NE33 2TR – UK<br><br>Ph. :+44 191 456 1451<br>Fax :+44 191 456 6383 | Saft<br>Rue Georges Leclanché<br>BP 1039<br>86060 Poitiers cedex 9<br>France<br><br>Ph. :+33 (0)5 49 55 48 48<br>Fax :+33 (0)5 49 55 48 50 | Saft America Inc<br>313 Crescent Street<br>Valdese<br>NC 28690 – USA<br><br>Ph. :+1 828 874 4111<br>Fax :+1 828 874 2431 | Saft Batteries Co., Ltd<br>Zhuhai Free Trade Zone<br>Lianfeng Road<br>Zhuhai 519030<br>Guangdong Province<br>China<br><br>Ph. : +86 756 881 9318<br>Fax : +86 756 881 9328 |
| <a href="http://www.saftbatteries.com">www.saftbatteries.com</a> (section « Contact ») |   |  |  |  |
| <b>Emergency contact</b><br>Within the USA   | +1 (703) 527 3887<br>+1 (800) 494 9300  | (CHEMTREC US Service Center)   |  |  |

| 2. Hazards Identification   |
|---|
| <p>Do not short circuit, recharge puncture, incinerate, crush, immerse, force discharge or expose to temperatures above the declared operating temperature range of product. Risk of fire or explosion.</p> <p>The Lithium-Thionyl chloride batteries described in this Safety Data Sheet are sealed units which are not hazardous when used according to the recommendations of the manufacturer.</p> <p>Under normal conditions of use, the electrode materials and liquid electrolyte they contain are not exposed to the outside, provided the battery integrity is maintained and seals remain intact. Risk of exposure only in case of abuse (mechanical, thermal, electrical) which leads to the activation of safety valves and/or the rupture of the battery container. Electrolyte leakage, electrode materials reaction with moisture/water or battery vent/explosion/fire may follow, depending upon the circumstances.</p> |

| 3. Composition & Information on Ingredients |         |           |   |  |  |
|---|---------|-----------|---|--|--|
| Ingredient                                  | Content | CAS No.   | CHIP Classification   |  |  |
| Lithium<br>(Li)                             | 3,5-5%  | 7439-93-2 |  |  | <b>F</b> ; R14/15<br><b>C</b> ; R34<br>R14/15, R21, R22, R35,<br>R41, R43<br>S2, S8, S45 |
| Thionyl chloride<br>(SOCl <sub>2</sub> )    | 40-46%  | 7719-09-7 |  |  | <b>C</b> ; R14, R21, R22, R35,<br>R37, R41, R42/43<br>S2, S8, S24, S26, S36,<br>S37, S45 |
|   |         |           |  |  |  |



|  |      |           |   |  |  |
|--|------|-----------|---|--|--|
| Aluminum chloride anhydrous (AlCl <sub>3</sub> ) | 1-5% | 7446-70-0 |  |  | R14, R22, R37, R41, R43. S2, S8, S22, S24, S26, S36, S45 |
| Carbon (C <sub>n</sub> )                         | 3-4% | 1333-86-4 |   |  | NONE KNOWN   |
| <i>Amount varies depending on cell size.</i>     |      |           |   |  |  |





| 4. First Aid Measures    |   |
|--------------------------|---|
| <b>Inhalation</b>        | Remove from exposure, rest and keep warm. In severe cases obtain medical attention.   |
| <b>Skin contact</b>      | Wash off skin thoroughly with water. Remove contaminated clothing and wash before reuse. In severe cases obtain medical attention.  |
| <b>Eye contact</b>       | Irrigate thoroughly with water for at least 15 minutes. Obtain medical attention.   |
| <b>Ingestion</b>         | Wash out mouth thoroughly with water and give plenty of water to drink. Obtain medical attention.   |
| <b>Further treatment</b> | All cases of eye contamination, persistent skin irritation and casualties who have swallowed this substance or been affected by breathing its vapours should be seen by a doctor. |

| 5. Fire Fighting Measures  |   |
|--|---|
| <p>CO<sub>2</sub> extinguishers or, even preferably, copious quantities of water or water-based foam, can be used to cool down burning Li-SOCl<sub>2</sub> cells and batteries, as long as the extent of the fire has not progressed to the point that the lithium metal they contain is exposed (marked by deep red flames). Do not use for this purpose sand, dry powder or soda ash, graphite powder or fire blankets.</p> <p><b>Use only metal (Class D) extinguishers on raw lithium.</b></p> |   |
| <b>Extinguishing media</b>   | Use water or CO <sub>2</sub> on burning Li-SOCl <sub>2</sub> cells or batteries and class D fire extinguishing agent only on raw lithium. |

| 6. Accidental Release Measures   |  |
|--|--|
| <p>Remove personnel from area until fumes dissipate. Do not breathe vapours or touch liquid with bare hands. If the skin has come into contact with the electrolyte, it should be washed thoroughly with water.</p> <p>Sand or earth should be used to absorb any exuded material. Seal leaking battery and contaminated absorbent material in plastic bag and dispose of as Special Waste in accordance with local regulations.</p> |  |



| 7. Handling and Storage |   |
|-------------------------|---|
| <b>Handling</b>         | Do not crush, pierce, short (+) and (-) battery terminals with conductive (i.e. metal) goods. Do not directly heat or solder. Do not throw into fire. Do not mix batteries of different types and brands. Do not mix new and used batteries. Keep batteries in non conductive (i.e. plastic) trays.   |
| <b>Storage</b>          | Store in a cool (preferably below 30°C) and ventilated area, away from moisture, sources of heat, open flames, food and drink. Keep adequate clearance between walls and batteries. Temperature above 100°C may result in battery leakage and rupture. Since short circuit can cause burn, leakage and rupture hazard, keep batteries in original packaging until use and do not jumble them. |
| <b>Other</b>            | Lithium-Thionyl chloride batteries are not rechargeable and should not be tentatively charged. Follow Manufacturers recommendations regarding maximum recommended currents and operating temperature range. Applying pressure on deforming the battery may lead to disassembly followed by eye, skin and throat irritation.   |

| 8. Exposure Controls & Personal Protection  |                               |   |           |    |
|---|-------------------------------|---|-----------|----|
| Occupational exposure standard  | Compound                      | 8hr TWA   | 15min TWA | SK |
|   | Sulfur dioxide                | 1 ppm   | 1 ppm     | -  |
|   | Hydrogen chloride             | 1 ppm   | 5 ppm     | -  |
|  | <b>Respiratory protection</b> | In all fire situations, use self-contained breathing apparatus. |           |    |
|  | <b>Hand protection</b>        | In the event of leakage wear gloves.                            |           |    |
|  | <b>Eye protection</b>         | Safety glasses are recommended during handling.                 |           |    |
|  | <b>Other</b>                  | In the event of leakage, wear chemical apron.                   |           |    |

| 9. Physical and Chemical Properties |   |
|-------------------------------------|---|
| <b>Appearance</b>                   | Cylindrical or prismatic shape                      |
| <b>Odour</b>                        | If leaking, gives off a pungent corrosive odour.    |
| <b>pH</b>                           | Not Applicable                                      |
| <b>Flash point</b>                  | Not applicable unless individual components exposed |
| <b>Flammability</b>                 | Not applicable unless individual components exposed |
| <b>Relative density</b>             | Not applicable unless individual components exposed |
| <b>Solubility (water)</b>           | Not applicable unless individual components exposed |
| <b>Solubility (other)</b>           | Not applicable unless individual components exposed |



| 10. Stability and Reactivity                               |   |
|--|---|
| Product is stable under conditions described in Section 7. |   |
| <b>Conditions to avoid.</b>                                | Heat above 100°C (150°C for the LSH 20-150 cells and the battery packs assembled from them) or incinerate. Deform. Mutilate. Crush. Pierce. Disassemble Recharge. Short circuit. Expose over a long period to humid conditions.   |
| <b>Materials to avoid</b>                                  | Oxidising agents, alkalis, water. Avoid electrolyte contact with aluminum or zinc.  |
| <b>Hazardous decomposition Products</b>                    | Hydrogen (H <sub>2</sub> ) as well as Lithium oxide (Li <sub>2</sub> O) and Lithium hydroxide (LiOH) dust is produced in case of reaction of <i>lithium metal</i> with water.<br>Chlorine (Cl <sub>2</sub> ), Sulfur dioxide (SO <sub>2</sub> ) and Disulfur dichloride (S <sub>2</sub> Cl <sub>2</sub> ) are produced in case of thermal decomposition of <i>thionyl chloride</i> above 140°C.<br>Hydrochloric acid (HCl) and Sulfur dioxide (SO <sub>2</sub> ) are produced in case of reaction of <i>Thionyl chloride</i> with water at room temperature.<br>Hydrochloric acid (HCl) fumes, Lithium oxide, (Li <sub>2</sub> O), Lithium hydroxide (LiOH) and Aluminum hydroxide (Al(OH) <sub>3</sub> ) dust are produced in case of reaction of <i>Lithium tetrachloroaluminate (LiAlCl<sub>4</sub>)</i> with water. |

| 11. Toxicological Information                              |  |
|--|--|
| <b>Signs &amp; symptoms</b>                                | None, unless battery ruptures. In the event of exposure to internal contents, corrosive fumes will be very irritating to skin, eyes and mucous membranes. Overexposure can cause symptoms of non-fibrotic lung injury and membrane irritation. |
| <b>Inhalation</b>  | Lung irritant.   |
| <b>Skin contact</b>  | Skin irritant  |
| <b>Eye contact</b>   | Eye irritant.  |
| <b>Ingestion</b>   | Tissue damage to throat and gastro-respiratory tract if swallowed.   |
| <b>Medical conditions generally aggravated by exposure</b> | In the event of exposure to internal contents, eczema, skin allergies, lung injuries, asthma and other respiratory disorders may occur.  |

| 12. Ecological Information       |   |
|----------------------------------|---|
| <b>Mammalian effects</b>         | None known if used/disposed of correctly. |
| <b>Eco-toxicity</b>              | None known if used/disposed of correctly. |
| <b>Bioaccumulation potential</b> | None known if used/disposed of correctly. |
| <b>Environmental fate</b>        | None known if used/disposed of correctly. |

| 13. Disposal Considerations   |  |
|---|--|
| Do not incinerate, or subject cells to temperatures in excess of 100°C. Such abuse can result in loss of seal, leakage, and/or cell explosion. Dispose of in accordance with appropriate local regulations. |  |



| 14. Transport Information    |  |
|------------------------------|--|
| <b>Label for conveyance</b>  | For the single cell batteries and multi-cell battery packs that are non-restricted to transport (non-assigned to the Miscellaneous Class 9), use lithium batteries inside label.<br>For the single cell batteries and multi-cell battery packs which are restricted to transport (assigned to Class 9), use Class 9 Miscellaneous Dangerous Goods and UN Identification Number labels.<br>In all cases, refer to the product transport certificate issued by the Manufacturer. |
| <b>UN numbers</b>            | UN3090 (shipment of cells and batteries <i>in bulk</i> )<br>UN 3091 (cells and batteries <i>contained in equipment or packed with it</i> )   |
| <b>Shipping names</b>        | Lithium Metal Batteries  |
| <b>Hazard classification</b> | Depending on their lithium metal content, some single cells and small multi-cell battery packs may be non- assigned to Class 9 (Refer to Transport Certificate)  |
| <b>Packing group</b>         | II   |
| <b>Specific dispositions</b> | IATA: A45, A88, A99, P968, P969, P970<br>IMDG: 188, 230, 310, P903<br>ADR/RID: 188, 230, 310, 636, P903, P903a   |
| <b>IMDG Code</b>             | 3090 (Li Batteries) 3091 (Li Batteries contained in equipment or packed with it)   |
| <b>CAS</b>                   |  |
| <b>EmS No.</b>               | F-A, S-I   |
| <b>Marine pollutant</b>      | No   |
| <b>ADR Class</b>             | Class9   |

| 15. Regulatory Information |   |  |  |
|----------------------------|---|--|--|
| <b>Risk phrases</b>        | Lithium<br>(Li)                                     | R14/15<br><br>R21<br>R22<br>R35<br>R41<br>R42/43 | Reacts violently with water, liberating extremely flammable gases.<br>Harmful in contact with skin.<br>Harmful if swallowed.<br>Causes burns.<br>Risk of serious damage to eye.<br>May cause sensitization by inhalation and skin contact.                                     |
|                            | Thionyl chloride<br>(SOCl <sub>2</sub> )            | R14<br>R22<br>R35<br>R37<br>R41<br>R42/43        | Reacts with water.<br>Harmful if swallowed.<br>Causes burns.<br>Irritating to respiratory system.<br>Risk of serious damage to eye.<br>May cause sensitization by inhalation and skin contact.   |
|                            | Aluminum chloride anhydrous<br>(AlCl <sub>3</sub> ) | R14<br>R22<br>R37<br>R41<br>R43                  | Reacts with water.<br>Harmful if swallowed.<br>Irritating to respiratory system.<br>Risk of serious damage to eye.<br>May cause sensitization by skin contact.   |
| <b>Safety phrases</b>      | Lithium<br>(Li)                                     | S2<br>S8<br>S45                                  | Keep out of reach of children<br>Keep away from moisture<br>In case of incident, seek medical attention.   |
|                            | Thionyl chloride<br>(SOCl <sub>2</sub> )            | S2<br>S8<br>S24<br>S26<br><br>S36<br>S37<br>S45  | Keep out of reach of children.<br>Keep away from moisture.<br>Avoid contact with skin.<br>In case of contact with eyes, rinse immediately with plenty of water.<br>Wear suitable protective clothing.<br>Wear suitable gloves.<br>In case of incident, seek medical attention. |



|                                 |  |                                    |   |
|---------------------------------|--|------------------------------------|---|
|                                 | Aluminum chloride anhydrous ( $AlCl_3$ ) | S2<br>S8 S22<br>S24 S26<br><br>S36 | Keep out of reach of children.<br>Keep away from moisture.<br>Do not breathe dust.<br>Avoid contact with skin.<br>In case of contact with eyes, rinse immediately with plenty of water.<br>Wear suitable protective clothing. |
| <b>UK regulatory references</b> | Classified under CHIP                    |                                    |   |

#### 16. Other Information


This information has been compiled from sources considered to be dependable and is, to the best of our knowledge and belief, accurate and reliable as of the date compiled. However, no representation, warranty (either expressed or implied) or guarantee is made to the accuracy, reliability or completeness of the information contained herein.

This information relates to the specific materials designated and may not be valid for such material used in combination with any other materials or in any process. It is the user's responsibility to satisfy himself as to the suitability and completeness of this information for his particular use.

Saft does not accept liability for any loss or damage that may occur, whether direct, indirect, incidental or consequential, from the use of this information. Saft does not offer warranty against patent infringement.

Signature 

Alain Kerouanton  
Lithium Product Manager



# Liquid Condensate Trap Installation, Operations, and Maintenance Manual

## 1. PRE-INSTALLATION NOTES:

**State Water Resources Control Board (SWRCB) Requirements** are listed in California Health and Safety Code, Chapter 6.7 and California Code of Regulations Title 23 Div. 3 Chapter 16. SWRCB Local Guidance Letters LG-113 and LG-169 address in detail these regulatory requirements that apply to Liquid Condensate Traps. Installers should familiarize themselves with these requirements to ensure compliance.

Some of the highlights of the SWRCB requirements are: Vapor condensate traps are permitted as part of the Underground Storage Tank (UST) System and are regulated like any other UST System. Requirements will vary depending on the date of installation, but secondary containment, interstitial monitoring, periodic secondary containment testing, cathodic protection, periodic integrity testing, and overfill prevention may be required. Automatic evacuation of vapor condensate traps are equipped with a suction line (typically connected to a siphon port on the turbine) that can automatically evacuate liquid and return it to the UST. Because the suction line contains liquid product, it is subject to the same regulatory requirements as any other product suction piping on the UST system. Depending on the installation date of the UST and the presence or absence of check valves, secondary containment, interstitial monitoring, or periodic integrity testing of the suction line may be required.

**CAUTION: Always obtain approval from the local authorities having jurisdiction before beginning any work. Installation of the Liquid Condensate Trap must comply with (if applicable):**

- Air Resources Board Certification Procedure CP-201;
- Balance Phase II EVR Executive Orders (EO) VR-203 and 204;
- Veeder-Root Level 1 certification required when installing and wiring LCT liquid sensor to a Veeder-Root tank monitoring system.
- INCON Level 1 certification required when installing and wiring LCT liquid sensor to an INCON tank monitoring system.
- Certified Unified Program Agency (CUPA) – List of CUPAs can be found at ([www.calepa.ca.gov/CUPA/Directory/default.aspx](http://www.calepa.ca.gov/CUPA/Directory/default.aspx));
- Fire Marshall;
- SWRCB;
- Local Air Pollution District;
- International Code Council (ICC) Note: Anyone working on an LCT system must have an ICC certification for UST Service Technician, or UST Installation and Retrofitter;
- NEC;
- NFPA 30 and 30A;
- UL;
- Any other applicable Federal, State and local codes.



## 2 LIQUID CONDENSATE TRAP PHASE II EVR COMPONENTS

Exhibit 1 of VR-203 and 204 lists components required for a Phase II EVR System with a Liquid Condensate Trap. Existing Liquid Condensate Traps may already have some of these components installed. Some of these required components are (reference all Figures):

### Riser Adaptor — INCON Model TSP-K2A

This riser adaptor is to be installed on all risers that are connected to the Liquid Condensate Trap, except for the Liquid Condensate Trap suction tube riser.

### In-Line Filter — Swagelok B-4F2-140 or SS-4F2-140 (or equivalent)

The purpose of the in-line filter is to trap debris and rust particles that are traveling inside the suction line to prevent them from blocking the syphon jet valve at the turbine pump. This in-line filter is installed at the syphon inlet of the turbine pump.

### Stainless Steel Wired Braided Hose or 1/4" Copper Tubing (rated for use with gasoline)

Connects the suction tube to the turbine pump.

### Aluminum or Stainless Steel Insect Screen with Stainless Steel Hose Clamp

This screen can be purchased from almost any hardware store. The specifications are: 18 X 14 mesh for aluminum insect screen and 18 X 18 for stainless steel insect screen. A small section of this screen material is installed over the end of the suction tube inside the Liquid Condensate Trap and secured with a SS hose clamp.

### Liquid Sensor Connection to the UST Monitoring System

Many sites already have existing liquid sensors installed inside the Liquid Condensate Trap. If a liquid sensor does not exist inside the Liquid Condensate Trap then one must be installed.

Any Liquid sensor installed inside the Liquid Condensate Trap must meet the following minimal requirements:

- Provides a visual and audible alarm in case of failure of the evacuation system;
- The audible and visual alarm monitoring system must be installed at a location that is most likely to be heard by the station attendant during normal station operation;
- Set the liquid sensor to the height shown in Figure 5.
- 

### Various Pipe Fittings in 1/4" and 2" Sizes

For adapting the suction line as required, and to add a fuel entry point with a plug or cap to the Liquid Condensate Trap riser.

### **Optional Equipment:**

#### Secondary Syphon Kit — Franklin Fueling Systems Part Number 402507930

For use when two syphon primers are required for one Submersible Turbine Pump (STP). One to syphon the Liquid Condensate Trap, and one for siphoning two or more tanks of like product grade.

### 3. PRIOR TO INSTALLING THE EQUIPMENT LISTED IN EXHIBIT 1 OF THE EO

**WARNING** Highly flammable vapors or liquids may be present in the environment in which this equipment is installed or serviced. Installing or working on this equipment means working in an environment that presents risks of severe injury or death if instructions and standard industry practices are not followed. Follow all applicable codes governing the installation and servicing of this product and the entire system. Always lock out and tag electrical circuit breakers while installing or servicing this equipment and related equipment. Refer to the *Installation and Owner's Manual* of this equipment and any related equipment for complete installation and safety information.

Prior to installing the Liquid Condensate Trap Equipment listed in Exhibit 1 of the EO VR-203 or VR-204, you must flush out the Liquid Condensate Trap to remove any dirt or debris that may have accumulated inside the Liquid Condensate Trap.

Installer will need to document the capacity, in gallons, of the Liquid Condensate Trap on an aluminum 'tag' and attach this tag to the suction riser above the Fuel Entry Port. The capacity could be documented using a metal stamp or metal engraving pen, or a waterproof ink marker on the aluminum tag. A vinyl covered steel cable or a 'zip tie' could be used to attach to the riser. Strips of aluminum can be purchased at most hardware stores.

#### Example LCT Capacity Tag

LCT Capacity - 9.9 Gallons

#### **Flushing the Liquid Condensate Trap and attached Piping:**

Flushing out the Liquid Condensate Trap of any debris is very important to avoid blocking the suction tube, suction line, the in-line filter, and the syphon jet at the turbine pump during liquid evacuation. This process must be performed before installing the required Liquid Condensate Trap Equipment listed in Exhibit 1 of the EO VR-203 or VR-204.

- Use appropriate equipment to flush out the Liquid Condensate Trap of any debris. One method used is:
  - a) Disconnect the suction line from the suction tube at the suction riser to prevent the turbine pump syphon from sucking any debris into the suction line and syphon jet during the flushing process.
  - b) Using a hand pump, pump approximately 5 gallons of fresh gasoline into the Liquid Condensate Trap. Using the same hand pump, reverse the hoses and pump out the gasoline you just added. Repeat this procedure using fresh clean gasoline each time until the gasoline you are removing is clean and clear. This process may require a number of flushes (may be as many as 20 or more) before the gasoline being removed is clean and clear.


Note: Handle gasoline in a safe manner, following industry safety practices and all applicable State regulations and local codes.

- c) With the suction line disconnected from the Liquid Condensate Trap and disconnected at the turbine syphon port, blow compressed air through the suction line to remove any debris and check for any blockages.

**4. INSTALLATION OF THE PHASE II EVR EQUIPMENT LISTED IN EXHIBIT 1 OF EO VR-203 AND 204**


Figures 1 through 3 show a typical layout of a Phase II EVR Liquid Condensate Trap after completion of installing the equipment listed in Exhibit 1 of EO VR-203 and VR-204.

**Figure 1  
Typical Liquid Condensate Trap Installed Below the Transition Sump**




**Figure 2**  
**Typical Liquid Condensate Trap Installed Inside the Transition Sump**

**Note:** A Liquid Condensate Trap installed inside a liquid AND vapor tight transition sump that is monitored with a liquid sensor can be single walled (if installed before July 1, 2004).



**Figure 3**  
**Typical Layout of a Liquid Condensate Trap Installed Inside in a UST System**  
**That Was Installed On or After July 1, 2004 and**  
**After the Installation of the Equipment Listed in Exhibit 1 of**  
**Executive Orders VR-203 and VR-204**



#### 4.1 Installation of Swagelok 140 Micron In-Line Filter (or equivalent).


*Swagelok instructions are used for guidance purposes. Individual manufacturer's installation instructions must be followed.*

Swagelok In-Line filter B-4F2-140 Specifications


Body-----Brass  
Connection-----1/4" Male NPT  
Pore Size -----140 Micron

Apply Teflon tape to the male NPT threads on both ends of the in-line filter. Install the in-line filter with the direction of the arrow pointing towards the syphon jet port on the Submersible Turbine Pump (STP).


**Figure 4  
Top View of STP Sump**



**Figure 4a**  
**Cut Away side view of an STP**



**Figure 4b**  
**In-Line Filter connection to syphon port**



#### 4.1.1 Replacing Micron Filter Element Inside the In-Line Filter Swagelok (or equivalent) instructions are used for guidance purposes. Individual manufacturer's installation instructions must be followed.

If the filter element becomes blocked from debris clean or replace the filter element – Swagelok P/N SS-4F-K4-140. See replacement instructions in Appendix B.

#### 4.2 Installation of INCON TSP-K2A Riser Adaptor

**WARNING** Follow all federal, state and local laws governing the installation of this product and its associated systems. When no other regulations apply, follow NFPA codes 30, 30A and 70 from the National Fire Protection Association. Failure to follow these codes could result in severe injury, death, serious property damage and/or environmental contamination.

**WARNING** Always secure the work area from moving vehicles. The equipment in this guide is usually mounted underground, so reduced visibility puts service personnel working on this equipment in danger from moving vehicles entering the work area. To help eliminate these unsafe conditions, secure the area by using a service truck to block access to the work environment, or by using any other reasonable means available to ensure the safety of service personnel.

#### Procedure

1. Install a close fit 2" threaded nipple (field supplied) into the existing pipe.

2. Install the Reducer Coupling onto the threaded nipple.


Note: Use BOTH Teflon® Tape and a brushed-on thread sealant on all threaded connections to form a vapor-tight seal.

3. Insert the Sensor Cable through the wire grip nut so that the end of the sensor is on the inside of the Reducer Coupling.

4. Make all of the connections and test the sensor.

5. Tape and seal the Plug Cover Assembly into the Reducer Coupling. Make sure that the wire leads through the Wire Grip are loose and do not rotate when tightening the Plug Cover Assembly.


6. Tighten the Wire Grip Nut to 75-100 in. lbs. of torque to secure the cable. Use a torque wrench with McMaster Carr # 5347A148, 1-1/16 inch Open End Head, for Interchangeable-Head Torque Wrench or equivalent.






7. Retest the sensor functionality.

**Figure 5**  
**INCON TSP-K2A Riser Adaptor**



**Figure 5a**  
**INCON TSP-K2A Riser Adaptor**




**4.3 Liquid Sensor** - Installation of a liquid sensor requires technician to meet applicable requirements as specified in the SWRCB Local Guidance Letter 167 (LG 167).

If not already present, install a liquid sensor following the manufacture's installation instructions. Set the liquid sensor two (2) inches from the bottom of the Liquid Condensate Trap. See Figure 6. Then tighten the wire grip nut (of the TSP-K2A) around sensor cable.

At the point where the cable exits the top of the wire grip, place a permanent indicating mark on the sheathing of the cable (e.g. using a waterproof marker such as a Sharpie™) which indicates the sensor is placed two (2) inches above the bottom of the Liquid Condensate Trap (see Figure 5).

When programming the LCT liquid sensor at the UST tank monitoring console, label the sensor with "LCT" in the title, e.g. L10 would be labeled "LCT High Liquid".

**Figure 6**  
**Liquid Sensor Height Setting**



#### 4.4 Installation of Suction Tube Riser, Suction Tube and Screen

**For all installations you must use fuel rated pipe sealant on all threaded connections.**

**For new installations** cut to size and thread a 2 inch galvanized steel riser for the suction tube and install it into a 2 inch bung at the top of the Liquid Condensate Trap.

**For all installations** install a 2 inch Tee fitting for the Fuel Entry Point on top of the 2 inch galvanized steel riser.

Measure the length of the suction tube to ensure it can meet the distance requirement in Figure 7. Cut the suction tube to length. When installing the suction tube, ensure the bottom of the suction tube is no more than 1 inch to 1 1/2 inches from the bottom of the Liquid Condensate Trap.


Cut a piece of 4 inch by 4 inch piece of screen material, either 18 x 14 aluminum mesh or 18 x 18 stainless steel mesh. Wrap it around the end of the suction tube as shown in Figure 7, leaving approximately 1 inch of screen below the end of the suction tube. Tighten the stainless steel hose clamp around the screen securing it approximately 3/8 inch or more from the bottom of the suction tube.

Once the aluminum screen is installed, the suction tube is ready to screw into the bottom of a double-tap bushing.

This double tap bushing, with the suction tube, is then installed into the top of the tee fitting.


Connect the suction line to the top of the double tap bushing using appropriate fittings (Figures 8 thru 8c) and the other end of the suction line connects to the 140 micron in-line filter installed at the turbine syphon port per section 4.1 (Figures 4a and 4b).

**Figure 7**  
**Aluminum Screen and Suction Tube Installation**



- 4.5 **Fuel Entry Point** – On top of the 2 inch galvanized steel pipe install a 2 inch tee, 2 inch nipple, 2 inch elbow, additional 2 to 4 inch nipple (if using cap). Prior to installing cap or plug, conduct Exhibit 16 (VR-203 or VR-204). Install 2 inch cap or plug using pipe thread sealant (all pipe fittings must be galvanized steel.) See figures 8 & 8a, 8b, 8c and 8d.
- 4.6 Conduct TP-201.3, Determination of 2 Inch WC Static Pressure Performance of Vapor Recovery Systems of Dispensing Facilities, and Exhibit 4.


**Figure 8**  
**Assembly of Fuel Entry Point**




5. In the event that the turbine connected to the Liquid Condensate Trap is replaced, Exhibit 16 of Executive Orders VR-203 or VR-204 shall be conducted following replacement of the turbine.

**Figure 8a**

**Assembly of Fuel Entry Point**




**Figure 8b**  
**Assembly of Fuel Entry Point**



**Figure 8c**  
**Additional View Assembly of Fuel Entry Point**





**Figure 8d**

## Various Pipe Fittings



## **TROUBLESHOOTING PROCEDURES FOR LIQUID CONDENSATE TRAP**

**WARNING** Installing or working on this equipment means working in an environment that presents risks of severe injury or death if instructions and standard industry practices are not followed. Obey all applicable codes governing the installation and servicing of this product and the entire system. Always lock out and tag electrical circuit breakers while installing or servicing this equipment and related equipment.

### **1. Test The Turbine Pump For Normal Vacuum Readings:**


- Follow FE Petro syphon jet test procedures. See Appendix A, FFS FE Petro Service Bulletin SB005 “Syphon System Testing” (SB005). When using this test procedure for testing the turbine pump connected to the Liquid Condensate Trap only, perform Steps 1– 4. Do not use a syphon check valve and skip the syphon check valve test (for other turbine pump manufacturers, refer to their test procedure.)
- This will ensure the turbine pump is operating correctly and producing the correct amount of vacuum at the syphon port (minimum vacuum is 16 to 28 inches Hg). Make any necessary repairs to the turbine pump to meet the syphon port minimum vacuum levels.
- If the turbine pump is creating the appropriate amount of vacuum (16 to 28 inches Hg) at the syphon port, remove the test fixture called out in SB005 and install the 140 micron in-line filter.
- Check the vacuum level again with the in-line filter installed using the vacuum gauge in Figure 9. The amount of vacuum should be between 16 to 28 inches Hg.

### **2. Required Troubleshooting Test Equipment**

Install the following Liquid Condensate Trap evacuation troubleshooting equipment:


- 2.1** Ashcroft liquid-filled stainless steel, inches of Hg vacuum gauge, Grainger #2C879, 2C927 or equivalent. Install this gauge before the 140 micron in-line filter so that it is visible from outside the sump. See Figure 9.

**Figure 9**



- 2.2** Install a ¼ inch **full port** ball valve (ball valve) and rotor flow indicator Grainger Model 1AMD7 (or equivalent). The rotor flow indicator provides a visual indication of fuel flow when evacuating the Liquid Condensate Trap. Install this equipment so that it can be viewed from outside the sump. See Figure 10.

**Figure 10**



- 3. With the troubleshooting equipment installed perform the following procedures:**
- a. With the ball valve in the CLOSED position, fill the Liquid Condensate Trap with gasoline using the same method used in the Liquid Condensate Trap Compliance Test Procedure. The liquid sensor should be approximately 2 inches from the bottom of the Liquid Condensate Trap. Start the turbine pump connected to the Liquid Condensate Trap if it is not already running.
  - b. With the ball valve CLOSED, check the vacuum gauge and verify it is reading between 16 to 28 inches Hg of vacuum. If you do not have the correct amount of vacuum then look for a vacuum leak in the system. Check for a blocked in-line filter or syphon jet. See the table titled "If You Experience the Following Conditions".
  - c. OPEN the ball valve and watch for rotation of the rotor flow indicator. Rotation of the rotor flow indicator will indicate the flow of gasoline. The rotor flow indicator will not rotate at a high speed and will not rotate at all if no liquid is flowing through the indicator. The rotor flow indicator provides a visual indication that liquid is being evacuated from the Liquid Condensate Trap. If any air is getting into the syphon system during evacuation the liquid flow rate will change or stop.
  - d. When first opening the ball valve, the vacuum pressure may drop to zero inches of Hg (0" Hg) during priming of the suction line; however the vacuum should rise up to approximately 4 to 5 inches Hg during evacuation. Monitor the rotor flow indicator for steady rotation.

- e. When the Liquid Condensate Trap is almost empty and/or the liquid is below the end of the suction tube the rotor flow indicator will stop then start a few times and then completely stop. This is an indication that air is getting into the system. If the liquid sensor is out of alarm and the Liquid Condensate Trap is empty or almost empty (liquid level is at or below the bottom of the suction tube) you have successfully evacuated the Liquid Condensate Trap.

Note: At this time the vacuum gauge will read near zero inches of Hg (0" Hg) because the suction tube is sucking in air and not liquid.

4. When you have successfully passed this **Troubleshooting** section, remove the troubleshooting equipment and retest the system again using the "Liquid Condensate Trap Compliance Test Procedure" (Exhibit 16 of VR-203 or VR-204).

| <b>IF YOU EXPERIENCE THE FOLLOWING CONDITIONS:</b>  |  |
|---|--|
| <b>Symptom:</b>   | <b>Troubleshooting steps:</b>  |
| The ball valve is open, no rotation of the rotor flow indicator, and high vacuum (16" Hg to 28" Hg)   | <ul style="list-style-type: none"> <li>○ There is a blockage in the piping before the vacuum gauge.</li> <li>○ Check the suction tube and suction line from the bottom of the suction tube to the vacuum gauge.</li> <li>○ Check for kinks or pinches in the suction line.</li> </ul>  |
| The ball valve is open and the rotor flow indicator stops and starts intermittently. This indicates a small vacuum leak or an intermitting blockage   | <ul style="list-style-type: none"> <li>○ Check the screen at the bottom of the suction tube for debris, dirt, rocks, etc.</li> <li>○ Check the in-line filter and/or syphon jet for debris and blockage.</li> <li>○ Check the fittings and connections from the suction tube to the syphon jet for any vacuum leaks.</li> </ul>  |
| <u>With the ball valve open,</u> no rotation of the rotor flow indicator, zero vacuum (0" Hg), <u>and the liquid condensate trap still has liquid above the bottom of the suction tube.</u> | <ul style="list-style-type: none"> <li>○ Check the in-line filter and/or syphon jet for debris and blockage. Small particle of debris (rust particles) can block the in-line filter and/or syphon jet causing the vacuum level to drop to zero.</li> <li>○ Check the in-line filter and/or syphon jet for debris and clean or replace the filter element and/or syphon jet as necessary.</li> <li>○ There may be a vacuum leak somewhere in the system. If you had the correct amount of vacuum before you opened the ball valve, then the vacuum leak is between the ball valve and the end of the suction tube; or the liquid level inside the Liquid Condensate Trap is below the bottom of the suction tube and you are sucking in air.</li> </ul> |
| <u>The ball valve is closed</u> and there is zero inches (0" Hg) of vacuum on the gauge   | <ul style="list-style-type: none"> <li>○ Check the in-line filter and/or syphon jet for debris and blockage. Small particles of debris (rust particles) can block the in-line filter and/or the syphon jet causing the vacuum level to drop to zero.</li> <li>○ Check the in-line filter and/or syphon jet for debris and clean or replace the filter element and/or syphon jet as necessary.</li> <li>○ Check for a vacuum leak between the vacuum gauge and the ball valve.</li> </ul>   |

# Appendix A




SERVICE BULLETIN

SB005 Rev 2


January 20, 2009

## Syphon System Testing

The following procedure illustrates syphon system testing techniques on 4" pumps.



When manifolded tanks are not maintaining equal product levels (i.e., loss of syphon prime) there are several possible causes: the Submersible Turbine Pump (STP) is not generating a vacuum, the syphon check valve is not holding prime when the STP is off, there is a leak in the syphon loop (i.e., tube, fittings, or pipe), there is foreign material blocking the syphon pipe, and/or the syphon system was not properly installed (i.e., the syphon bar is not sloped, the syphon pipes are too short, the tanks are different diameters, the tanks are on different planes, etc.).

**Warning**  Highly flammable vapors or liquids may be present in the environment in which this equipment is installed or serviced. Installing or working on this equipment means working in an environment that presents risks of severe injury or death if instructions and standard industry practices are not followed. Follow all applicable codes governing the installation and servicing of this product and the entire system. Always lock out and tag electrical circuit breakers while installing or servicing this equipment and related equipment. Refer to the *Installation and Owner's Manual* of this equipment and any related equipment for complete installation and safety information.

### Vacuum Testing Procedure

1. Turn off the power at the load center, then lock out and tag the circuit breaker.
2. Install a test fixture into the syphon line as shown in Figure 1.
3. Run the STP with the dispenser nozzles and valve "A" closed, and with valve "B" open. The normal vacuum reading should be 20-28" Hg. If the vacuum is normal, continue with Step 4. If there isn't any vacuum or it is somewhat less than 20" Hg, there is the possibility of blockage in the STP syphon passages.

**Note:** Vacuum readings should be taken without any product delivery. Also, check if the Pump Motor Assembly is producing correct pressures.

4. To remedy abnormal vacuum conditions, remove the 3/8" plug from the manifold discharge head (see Figure 3) and unscrew the brass Syphon Jet using a large standard screwdriver. Pull the Syphon Jet out and clean it, making sure that the Syphon Jet only allows for downward flow when installed. Before reinstalling the Syphon Jet, ensure that the Syphon Port and the Vapor Return Tube have open passages by using a stiff wire or other similar device to check. Replace or reinstall the Syphon Jet and 3/8" plug. Check for normal vacuum. If the passages are clear and the vacuum is still abnormal, check the STP Extractable O-rings for damage and make sure that the Vapor Return Tube is not pinched. To check the Vapor Return Tube, remove the STP Extractable and repair as necessary (see Figure 2). If the condition has been corrected, continue with the next step to test the remaining syphon system. If abnormal vacuum conditions continue, contact FFS Petro Technical Support.


- Run the submersible with dispenser nozzles and valve "A" closed, but leave valve "B" open. When the vacuum reading reaches 20-28" Hg, shut the submersible off. The vacuum should hold for at least 15 minutes. If this worked, continue with the next step. If the vacuum does not hold, the Syphon Check Valve is not holding or the Test Fixture fittings may be loose. Providing the Test Fixture fittings are tight, remove the Syphon Check Valve and clean or replace it. Repeat this step until the problem has been corrected, then continue with the next step.

**Note:** Syphon Check Valves may hold at high vacuum, but may fail under low vacuum. Test the Syphon Check Valve at a lower vacuum by bleeding off the vacuum and re-testing at 5" Hg.


- Run the STP with valves "A" and "B" both open and the dispenser nozzles closed. Normal priming should take approximately 5-10 minutes. When first priming with both valves open, the vacuum gage will indicate 0" Hg. After awhile, vacuum will begin to show. For every inch of mercury vacuum shown, the product level in the syphon pipes is about 1-½ feet above the tank fluid level. When air is being removed from the syphon system, the vacuum gauge needle will bounce. This bouncing should stabilize as more air is removed. If not, this would be a good indication that there is a leak in the syphon system. This air may also be visible if using a Test Fixture with clear tubing. The air would indicate that there is a leak in the syphon line between the tanks or the possibility of foreign material blocking the syphon pipe. Repair any leaks or blockage and repeat this step. If there is no evidence of air, then continue with the next step.

- Close valve "B" and then shut off the STP. The gauge should hold constant for 30-40 minutes after the submersible is turned off. The vacuum may increase if the syphon system wasn't fully primed before closing the valve. If the vacuum drops, there is a leak in the syphon line between the tanks or the possibility of foreign material blocking the syphon pipe. Repair any leaks or blockages and then repeat this step.

**Note:** If there is a leak in the syphon line, product will drain out of the horizontal pipes before vacuum gauge readings indicate a leak.



**Figure 2**  
(STP Extractable)



**Figure 3**  
(Top View of STP)

Contact FFS Technical Support for any assistance


**Franklin Fueling Systems** • 3760 Marsh Rd. • Madison, WI 53718 USA  
Tel: +1 608 838 8786 • 800 225 9787 • Fax: +1 608 838 6433 • [www.franklinfueling.com](http://www.franklinfueling.com)

Page 2 of 2



## APPENDIX B

### Swagelok F-Series In-Line Filter Service Instructions



#### Disassembly

1. Loosen male and female bodies and disassemble.
2. If replacing the filter element, remove and discard used element.

#### Reassembly

3. Before reassembling the filter, be certain that all components are clean.
4. Align the new filter element parallel to the filter bore of the female body. Position the open end of the element towards the body and press in place.
5. Lubricate the gasket with a thin film of system-compatible lubricant. Place gasket on male body seal surface.
6. Place the spring in to the male body.
7. Thread the male and female bodies together, and tighten finger-tight.
8. Tighten the bodies to the proper torque as shown in the table below.
9. Test the filter for proper operation and leak-tight sealing.

| Size and Series        | Torque, in.-lb. (N-m) |          |                                    |
|------------------------|-----------------------|----------|------------------------------------|
|                        | Standard Assembly     |          | Unplated Gasket<br>Stainless Steel |
|                        | Stainless Steel       | Brass    |                                    |
| 1F, 2F, 3F-MM          | 135 (15)              | 125 (14) | —                                  |
| 4F, 6F-MM              | 350 (40)              | 325 (36) | 500 (56)                           |
| 6F, 8F, 10F-MM, 12F-MM | 500 (56)              | 450 (50) | 800 (90)                           |

# Vapor Pressure Sensor for Vent Stacks

## Installation Guide



# Notice

---

Veeder-Root makes no warranty of any kind with regard to this publication, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Veeder-Root shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this publication.

Veeder-Root reserves the right to change system options or features, or the information contained in this publication as approved by ARB.

This publication contains proprietary information which is protected by copyright. All rights reserved. No part of this publication may be modified or translated to another language without the prior written consent of Veeder-Root. Contact TLS Systems Technical Support for additional troubleshooting information at 800-323-1799.

## **DAMAGE CLAIMS / LOST EQUIPMENT**

Thoroughly examine all components and units as soon as they are received. If any cartons are damaged or missing, write a complete and detailed description of the damage or shortage on the face of the freight bill. The carrier's agent must verify the inspection and sign the description. Refuse only the damaged product, not the entire shipment.

Veeder-Root must be notified of any damages and/or shortages within 30 days of receipt of the shipment, as stated in our Terms and Conditions.

## **VEEDER-ROOT'S PREFERRED CARRIER**

1. Contact Veeder-Root Customer Service at 800-873-3313 with the specific part numbers and quantities that were missing or received damaged.
2. Fax signed Bill of Lading (BOL) to Veeder-Root Customer Service at 800-234-5350.
3. Veeder-Root will file the claim with the carrier and replace the damaged/missing product at no charge to the customer. Customer Service will work with production facility to have the replacement product shipped as soon as possible.

## **CUSTOMER'S PREFERRED CARRIER**

1. It is the customer's responsibility to file a claim with their carrier.
2. Customer may submit a replacement purchase order. Customer is responsible for all charges and freight associated with replacement order. Customer Service will work with production facility to have the replacement product shipped as soon as possible.
3. If "lost" equipment is delivered at a later date and is not needed, Veeder-Root will allow a Return to Stock without a restocking fee.
4. Veeder-Root will NOT be responsible for any compensation when a customer chooses their own carrier.

## **RETURN SHIPPING**

For the parts return procedure, please follow the appropriate instructions in the "General Returned Goods Policy" pages in the "Policies and Literature" section of the Veeder-Root **North American Environmental Products** price list. Veeder-Root will not accept any return product without a Return Goods Authorization (RGA) number clearly printed on the outside of the package.

## **INSTALLATION IN THE STATE OF CALIFORNIA**

Please refer to the California Air Resources Board Vapor Recover Certification Phase II EVR Executive Order web site ([www.arb.ca.gov/vapor/eo-evrphasell.htm](http://www.arb.ca.gov/vapor/eo-evrphasell.htm)) for the latest manual revisions pertaining to Executive Order VR 203 (VST Phase II EVR System) and VR 204 (VST Phase II EVR System Including ISD System).

©Veeder-Root 2013. All rights reserved.

**Introduction**

Contractor Certification Requirements ..... 1  
 Product Marking Information ..... 1  
     Related Documents ..... 1  
 Safety Warnings ..... 3  
 Safety Symbols ..... 3  
 Related Manuals ..... 4  
 Before You Begin ..... 4  
 Veeder-Root Parts ..... 5  
 Tools Required ..... 7

**Vapor Vent Stack Installation** ..... 8

**Figures**

Figure 1. Locating Pressure Sensor Enclosure in Vapor Vent Stack .....9  
 Figure 2. Mounting Pressure Sensor Assembly onto Composite Panel ..... 11  
 Figure 3. Field wiring Pressure Sensor - Observe Polarity ..... 12  
 Figure 4. Epoxy sealing field wiring ..... 12

**Tables**

Table 1. Pressure Sensor Installation Kit Form Number 861190-00X  
 for UL/cUL approved pressure sensor .....5  
 Table 2. Kit - Pressure Sensor Drying Tube (P/N 330020-717) .....5  
 Table 3. Kit - Vapor Pressure Sensor Site Start-Up Install ISD (P/N 330020-715) .5  
 Table 4. Kit - Universal Enclosure (P/N 330020-716) .....6

## Introduction

A Vapor Pressure Sensor monitors the pressure in a vapor containment system located at a product fueling site. The purpose of this sensor is to detect pressure leakage as well as overpressure conditions that are both considered vapor containment faults. To accomplish this, the pressure sensor is installed the vapor vent stack.

Reference Figure 1 and Figure 2 in this manual. Each Vapor Vent Line must have an enclosure with the Vapor Pressure Sensor mounted inside. Additional customer supplied hardware is required to complete this type of vapor monitoring installation.

### Contractor Certification Requirements

| Veeder-Root Contractor Certification Requirements  | Installer Certification <sup>6</sup> | ATG Technician Certification <sup>7</sup>   | VR Vapor Products Certification <sup>8</sup> |
|--|--------------------------------------|---|--|
| Install <sup>1</sup> ISD   | X                                    | X   | X  |
| Install PMC  | X                                    | X   | X  |
| Install CCVP   | X                                    | X   | X  |
| Install Wireless ISD/PMC   | X                                    | X   | X  |
| Installation Checkout <sup>2</sup>   |                                      | X   | X  |
| ATG Startup <sup>3</sup> / Training <sup>4</sup> / Service <sup>5</sup>  |                                      | X   | X  |
| ISD Startup / Training / Service   |                                      |   | X  |
| PMC Startup / Training / Service   |                                      |   | X  |
| CCVP Startup / Training / Service  |                                      |   | X  |
| Wireless ISD/PMC Startup / Training / Service  |                                      |   | X  |
| Install Pressure Sensor (ATG)  | X                                    | X   | X  |
| Maintain Pressure Sensor (ATG)   |                                      | X   | X  |
| Calibrate Pressure Sensor (ATG)  |                                      | X   | X  |
| Clear ATG Pressure Sensor Alarm (ATG)  |                                      | X   | X  |
| Clear ISD/PMC Alarms (ISD/PMC)   |                                      |   | X  |
| <sup>1</sup> Perform wiring and conduit routing; equipment mounting<br><sup>2</sup> Inspect wiring and conduit routing; equipment mounting<br><sup>3</sup> Turn power on, program and test the systems<br><sup>4</sup> Provide supervised field experience in service techniques and operations<br><sup>5</sup> Troubleshoot and provide routing maintenance |                                      | <sup>6</sup> UST Monitoring Systems – Installer (Level 1)<br><sup>7</sup> Certified UST Monitoring Technician<br><sup>8</sup> VR Vapor Products |  |

**Warranty Registrations** may only be submitted by selected Distributors. Certified installers are required to provide the GDF operator with the completed Equipment Warranty Notice, form 577013-868, for their records.

### Product Marking Information


#### RELATED DOCUMENTS

##### **Documents Required to Install Equipment**



This intrinsically safe apparatus is only for use as part of a Veeder-Root Automatic Tank Gauging System (ATG Console with probes and sensors). To install intrinsically safe apparatus, use the specific control drawing that appears on the nameplate of the applicable associated apparatus (ATG Console):

| Associated Apparatus | UL/cUL Control Drawing Number |
|----------------------|-------------------------------|
| TLS-350, TLS-350R    | 331940-011                    |

The control drawings contain information related to the correct installation of the overall intrinsically Safe System. This includes information such as maximum number of apparatus, specific apparatus allowed in the system, maximum cable lengths, references to codes, proper grounding and so on. Control drawings can be found on the accompanying Compact Disk (TECH DOCS CD) or on the internet at [veeder.com](http://veeder.com) under SUPPORT; VR TECHNICAL DOCUMENTS; DRAWINGS.









**Product Label Contents**

|  |  |  |
|--|--|--|
|  <p>CL I, DIV. 1, GP.D<br/>CL I, ZONE 0<br/>AEx ia IIA<br/>Ex ia IIA<br/>TC=T4<br/>SECURITE INTRINSEQUE</p> | <p>I.S. CIRCUIT FOR HAZLOC SENSOR<br/>F/N 86119X-XXX<br/>S/N XXXXXX<br/>-40°C ≤ Ta ≤ +60°C<br/>MANUAL NO. 577014-019</p> |  <p>2466<br/>LISTED</p> |
|--|--|--|

## Safety Warnings





To protect yourself and your equipment, observe the following warnings and important information:







|  <b>WARNING</b>  |  |
|---|--|
|      | <p>This product is to be installed in systems operating near locations where highly combustible fuels or vapors may be present.</p> <p><b>FAILURE TO COMPLY WITH THE FOLLOWING WARNINGS AND SAFETY PRECAUTIONS COULD CAUSE DAMAGE TO PROPERTY, ENVIRONMENT, RESULTING IN SERIOUS INJURY OR DEATH.</b></p> <ol style="list-style-type: none"> <li>1. Read and follow all instructions in this manual, including all safety warnings to protect yourself and others from serious injury, explosion, or electrical shock.</li> <li>2. Comply with all applicable codes including: the National Electrical Code; federal, state, and local codes; and other applicable safety codes.</li> <li>3. To protect yourself and others from being struck by vehicles, block off your work area during installation or service.</li> <li>4. Do not alter or modify any component or substitute components in this kit.</li> <li>5. <b>Warning!</b> Substitution of components may impair intrinsic safety.</li> <li>6. Field wiring to the Sensor must not share a conduit with any non-intrinsically safe device's wiring.</li> <li>7. <b>Warning!</b> To prevent ignition of flammable or combustible atmospheres, disconnect power before servicing.</li> <li>8. Before installing or taking the unit into a hazardous area, earth the unit in a safe area to remove any static charge. Then immediately transport the unit to the installation site. Do not rub or clean the unit prior to installation. Cleaning is not required under normal service conditions. Do not rub or clean the unit after installation. If the unit is not fixed to a known earth point when installed, ensure that a separate earth connection is made to prevent the potential of a static discharge. When fitting or removing the unit, use of anti-static footwear or clothing is required.</li> <li>9. Materials used in the construction of this device do not contain, by mass, more than 10% in total of aluminum, magnesium, zirconium and titanium or 7.5% in total of magnesium, titanium and zirconium.</li> </ol> |

**NOTE** Failure to install this product in accordance with its instructions and warnings will result in voiding of all warranties with this product.

## Safety Symbols

The following safety symbols may be used throughout this manual to alert you to important safety hazards and precautions.

|  |  |
|--|--|
|  <p><b>EXPLOSIVE</b><br/>Fuels and their vapors are extremely explosive if ignited.</p>                                 |  <p><b>FLAMMABLE</b><br/>Fuels and their vapors are extremely flammable.</p>  |
|  <p><b>ELECTRICITY</b><br/>High voltage exists in, and is supplied to, the device. A potential shock hazard exists.</p> |  <p><b>TURN POWER OFF</b><br/>Live power to a device creates a potential shock hazard. Turn Off power to the device and associated accessories when servicing the unit.</p> |

|   |  |
|---|--|
|  <p><b>WARNING</b><br/>Heed the adjacent instructions to avoid damage to equipment, property, environment or personal injury.</p>                  |  <p><b>USE SAFETY BARRICADES</b><br/>Unauthorized people or vehicles in the work area are dangerous. Always use safety cones or barricades, safety tape, and your vehicle to block the work area.</p>                       |
|  <p><b>WEAR EYE PROTECTION</b><br/>Wear eye protection when working with pressurized fuel lines or epoxy sealant to avoid possible eye injury.</p> |  <p><b>INJURY</b><br/>Careless or improper handling of materials can result in bodily injury</p>  |
|  <p><b>GLOVES</b><br/>Wear gloves to protect hands from irritation or injury</p>   |  <p><b>READ ALL RELATED MANUALS</b><br/>Knowledge of all related procedures before you begin work is important. Read and understand all manuals thoroughly. If you do not understand a procedure, ask someone who does.</p> |

## Related Manuals

IOM19 VR-203 and VR-204    TLS RF Wireless 2 System (W2) Installation and Maintenance Guide  
576013-879                      TLS-3XX Site Prep Manual

## Before You Begin

- Review and comply with all the health and safety warnings in the installation manuals and any other national or local requirements.
- When direct wiring to a TLS console, a 2-conductor, 18 AWG, or equivalent, shielded cable must be installed in intrinsically safe conduit from the dispenser or from the vapor vent stack to the TLS console.
- The Pressure Sensor must be installed in a VERTICAL position with the sensing port pointing down. The Tygon tubing connecting the vapor pressure sensor to the drying tube must be attached to the down port of the drying tube. **The 'up' port must be left open to atmosphere.**
- For all connections requiring sealant, use only UL classified yellow Gas/TFE Teflon tape.
- Customer supplied pipe and pipe fittings shall be standard full-weight (ASTM Schedule 40, or equivalent) wrought iron or steel.
- Customer supplied copper tubing shall be soft tempered, 1/4-inch O.D., with a minimum wall thickness of 0.0265 inches.
- Pipe threads shall be in accordance with the Standard for Pipe Threads, General Purpose (Inch) ANSI/ASME B1.20.1-1983, or equivalent.



## Veeder-Root Parts

**Table 1. Pressure Sensor Installation Kit Form Number 861190-00X for UL/cUL approved pressure sensor**

| Item | Qty. | Description                             | P/N        |
|------|------|---|------------|
| 1    | 1    | Pressure sensor assembly                | 8611X0-X0X |
| 2    | 1    | Warranty registration form              | 576047-146 |
| 3    | 1    | Warranty card                           | 577013-868 |
| 4    | 1    | Union 62CA-4, brass 1/4" tube size      | 514100-431 |
| 5    | 1    | Sealing pack                            | 514100-304 |
| 6    | 2    | Wire nut                                | 576008-461 |
| 7    | 2    | Tie wrap                                | 510901-337 |
| 8    | 1    | Shim                                    | 332061-001 |
| 9    | 1    | Installation manual                     | 577014-019 |
| 10   | 1    | Kit - vapor pressure sensor drying tube | 330020-717 |

**Table 2. Kit - Pressure Sensor Drying Tube (P/N 330020-717)**

| Item | Qty. | Description                            | P/N        |
|------|------|--|------------|
| 1    | 1    | Drying tube - non-indicating desiccant | 514100-424 |
| 2    | 36"  | Tubing - Tygon fuel and lube           | 514110-425 |
| 3    | 4    | Tie wrap                               | 510901-337 |
| 4    | 2    | Self-adhesive mount - tie wrap         | 576008-437 |

**Table 3. Kit - Vapor Pressure Sensor Site Start-Up Install ISD (P/N 330020-715)**

| Item | Qty. | Description  | P/N        |
|------|------|--|------------|
| 1    | 4    | Male connector 68CA-4-4, brass 1/4" tube to 1/4" pipe                            | 514100-430 |
| 2    | 1    | Plug 59CA-4, brass 1/4" tube size  | 514100-432 |
| 3    | 1    | Universal Mount Kit (assorted screws, clamps, brackets, bolts, washers and nuts) | 330020-012 |
| 4    | 1    | Cord grip  | 331028-001 |
| 5    | 1    | Ball valve, 3-way, 1/4"  | 576008-649 |
| 6    | 36"  | Tube - soft copper, 1/4" OD  | 332151-001 |

**Table 3. Kit - Vapor Pressure Sensor Site Start-Up Install ISD (P/N 330020-715)**

| Item | Qty. | Description  | P/N        |
|------|------|--|------------|
| 7    | 2    | Male elbow 169CA-4-4, brass 1/4" tube to 1/4" pipe | 579066-001 |
| 8    | 1    | Bulkhead union 62CABH-4, brass 1/4" tube size      | 514100-476 |
| 9    | 2    | Washer, 0.469 x 1.125 x 0.063", zinc               | 510904-573 |
| 10   | 1    | Tube - copper, 1/4" OD, short S bend               | 333006-001 |

**Table 4. Kit - Universal Enclosure (P/N 330020-716)**

| Item | Qty. | Description                              | P/N        |
|------|------|--|------------|
| 1    | 1    | Enclosure, NEMA 4X-modified              | 333004-001 |
| 2    | 1    | Vent plug, porous, flanged, 0.17 x 0.42" | 514100-477 |
| 3    | 1    | Label - Veeder-Root                      | 333042-001 |
| 4    | 1    | Label - eVRgreen                         | 333041-001 |
| 5    | 1    | Panel, composite, modified               | 333005-001 |
| 6    | 1    | Cord grip bushing                        | 330787-004 |
| 7    | 2    | Conduit clamp, 3", steel, std duty       | 514100-482 |
| 8    | 1    | Conduit hub                              | 576010-715 |
| 9    | 2    | Hex bolt - steel, 1/4-20 x 0.75"         | 026-620-1  |
| 10   | 2    | Washer, flat, 1/4", zinc                 | 514100-374 |
| 11   | 2    | Hex nut w/lock washer, 1/4-20            | 511000-251 |
| 12   | 2    | Conduit clamp, 2", steel - std duty      | 514100-478 |
| 13   | 1    | Fitting, cap plug                        | 027-213-1  |
| 14   | 1    | Mounting bracket, Receiver               | 332315-001 |
| 15   | 1    | Mounting bracket, Battery                | 332295-002 |
| 16   | 1    | Panel nut, 7/8-16 x 1/4 thick            | 514100-475 |
| 17   | 6    | Screw, #10-32 x 1/2 Taptite              | 510500-400 |
| 18   | 1    | Label - universal enclosure kit          | 333263-001 |
| 19   | 1    | Group - cord grip, 1/2" NPT              | 331028-001 |
| 20   | 1    | Cord grip bushing                        | 330787-002 |

## Tools Required

---

1. Wrenches suitable for tightening tubing/pipe fittings.
2. Necessary pipe fitter's equipment (including tube bending and threading equipment as needed) and a non-hazardous work space suitable to modify the vapor vent stack for Vapor Pressure Sensor installation.
3. Torx bit for tamper-resistant screws (V-R P/N 330020-635).

**NOTE: this bit is required to open and close the enclosure door.**

## Vapor Vent Stack Installation

1. Before installing this device, perform all required safety procedures to gain access inside the vapor vent stack.
2. Determine which vapor vent stack line is closest to the tank being monitored. Select this line for the addition of the pressure sensor.
3. Locate a suitable port in an existing Schedule 40 piping fitting (tee, cross, etc.) or plumb a suitable Schedule 40 pipe fitting (tee, cross, etc.) into the vapor vent stack line (maximum length of copper tubing limited by dimension in Figure 1).
4. Install the vapor pressure sensor (item 1 in Table 1) vertically onto the center of the composite panel (item 5 in Table 4). Insert the sensor in the 2-inch conduit clamp using necessary bolts, nuts, and washers included in the universal mounting kit (item 3 of Table 3). Be sure the top symbol on the panel is facing upwards (see Figure 2). Wrap the rubber shim (item 8 in Table 3) around the sensor before inserting it into the clamp. Also make sure the sensor cable outlet is facing up and the pressure sensing port tube in the base of the sensor is facing down. Locate the pressure sensor in the clamp, but leave the conduit clamp screw somewhat loose for later sensor height adjustment.
5. Install two 169CA-4-4 male elbows (item 7 in Table 3) into each end of the 3-way calibration valve (item 5 in Table 3) as shown (see Figure 2).
6. Install one 68CA-4-4 male connector (item 1 in Table 3) into the center port of the 3-way calibration valve, and then directly attach it to the vapor pressure sensor inlet port (center) (see Figure 2).
7. Screw the 59CA-4 plug (item 2 in Table 3) onto the left port's male elbow (see Figure 2).
8. Install the two plastic enclosure mounting plates to the back of the enclosure. Use the four short flat-head screws included in the enclosure hardware bag.
9. Install the composite panel into the enclosure (item 5 in Table 4) such that the sensor cable outlet is facing up and the pressure sensing port tube in the base of the sensor is facing down. The top symbol on the panel should be facing upward. Use the four short screws included in the enclosure hardware bag.
10. Make sure that the white flanged porous vent (factory installed - item 2 in Table 4) is still securely installed into the hole in the bottom of the enclosure (see Figure 2).
11. Insert the S-bend 1/4" OD copper tube (item 10 in Table 3) into the right-side male elbow of the 3-way calibration valve, but do not fully tighten the compression nut (see Figure 2).
12. Locate the 62CABH-4 bulkhead union (item 8 in Table 3) and remove the compression nut and the adjustable nut then place a large washer (item 9 in Table 3) against the fixed, integral body nut. Slide the compression nut that was removed onto the bottom portion of the S-bend tube.
13. Partially insert the bulkhead union into the bottom center hole in the enclosure. Slide a large washer over the body, and thread the adjustable nut back onto the body.
14. Insert the bottom portion of the S-bend tube into the bulkhead union and fully tighten the bulkhead union adjustable nut against the large washer and enclosure wall. Adjust the pressure sensor vertically in the shim / conduit clamp to make sure the S-bend tube is fully inserted into the union and male elbow.
15. Fully tighten the compression nuts to connect the S-bend tube to the union and to the male elbow. Tighten the sensor conduit clamp screw to secure the sensor in its final vertical position (see Figure 2).




Figure 1. Locating Pressure Sensor Enclosure in Vapor Vent Stack

16. Get the contents of the pressure sensor drying tube kit (Table 2). Thread a tie wrap (item 3) through the slots in each of the self-adhesive mounts (item 4). Place the top mount against the large cap on one end of the tube and tighten the tie wrap until it is against the tube cap but you can still rotate the tube. Place the second mount against the other end cap of the tube, again pulling the tie wrap through the mount until it is against the tube cap but you can still rotate the tube.

Remove the two soft plastic seals from each end port of the drying tube. Get the Tygon tubing (item 2) from the kit and attach one end of the tubing to one end of the drying tube. Slide the tubing onto the drying tube as far as you can (snug). Referring to Figure 2, position the drying tube vertically in the enclosure with the open port of the tube up, and estimate the length needed to loop from the bottom of the drying tube up to the vent port (off center) of the Vapor Pressure Sensor. Cut the Tygon tubing at the estimated length (approximately a foot or so). Remove the paper cover from the self-adhesive base of the two tie wrap mounts and stick the drying tube to the inside of the enclosure as shown in Figure 2. Pull each of the tie wraps snug and cut off the excess. Attach the other end of the Tygon tubing to the vent port (off center) of the Vapor Pressure Sensor. NOTE: the upper port of the drying tube must remain open and be oriented up as shown in Figure 2.

17. Mount the plastic enclosure onto the vapor vent stack or suitable rigid structure ABOVE the vapor vent stack port using two conduit clamps (for 2" or 3" pipe), bolts, nuts, and washers included, or use other customer supplied suitable mounting hardware (Example: Unistrut®). Leave the mounting hardware somewhat loose for later enclosure height adjustment (see Figure 1).
18. Measure, fabricate, and install customer supplied pipe and pipe fittings between the vapor vent stack port and within a few inches of the bulkhead union in the bottom of the enclosure.
19. Install one 68CA-4-4 male connector (item 1 in Table 3) onto the top of the new pipe (see View A-A, Figure 1).
20. Measure, fabricate, and install ¼" OD copper tubing (item 6 in Table 3) between the bulkhead union and the male connector. Adjust the enclosure vertically on vent pipe to make sure the copper tube is fully inserted into the bulk head union and male connector.
21. Fully tighten the compression nuts to secure the fabricated tube to the bulkhead union and to the male connector. Tighten the enclosure mounting hardware to secure the enclosure in its final vertical position.

Note: **Important!** All plumbing's pitch to drain should be ¼" vertical per 12" horizontal to eliminate any potential liquid traps.

22. Make sure the valve's handle is set to connect the sensor to the vapor vent stack as shown in Figure 2 and not to the capped (vent) port.
23. Install two tamper-resistant screws from the enclosure hardware bag into the two holes on the enclosure door (if not already installed) using a Torx bit for tamper-resistant screws. Discard any remaining items in the enclosure hardware bag.
24. When direct wiring to a TLS console, install ½" electrical conduit from the conduit hub in the bottom of the enclosure to the customer supplied weather-proof junction box (see Figure 1). For wireless installations, using the TLS RF, Steps 24 - 27 are not required.
25. Route the cable from the pressure sensor to the junction box under the enclosure. Observing polarity, connect the sensor wiring to the field wiring from console and cap with wire nuts (see Figure 1).
26. Seal wire nuts in epoxy sealant following the instructions in Figure 4.
27. Push the epoxy sealed bag into the junction box. Replace and tighten the junction box cover.
28. Terminate field wiring into TLS 350R console and connect to a Smart Sensor Module. Note: observe polarity! The cable length between the console and sensor must not exceed the distance stated in the applicable console's Site Prep manual.

29. After the Pressure Sensor is installed, pressurize the tank ullage space and vapor piping to at least 2 inches WC and test for leaks using leak detection solution.
30. Close the enclosure door and secure by threading the tamper-resistant screws into the enclosure body using a Torx bit for tamper-resistant screws.
31. Affix the eVRgreen label (item 4 in Table 4) to the enclosure door as desired.




Figure 2. Mounting Pressure Sensor Assembly onto Composite Panel




Figure 3. Field wiring Pressure Sensor - Observe Polarity

**A**

**B**

**C**

797-6.eps

**Instructions:**

NOTE: When temperature is below 50°F (10°C), keep resin in a warm place prior to mixing (e.g., in an inside pocket next to body).

1. Open epoxy sealant package, and remove resin pak.
2. Holding resin pak as shown in A, bend pak along long length.
3. As shown in B, firmly squeeze the RED SIDE of the resin, forcing it through the center seal and into BLACK SIDE.
4. Mix thoroughly to a uniform color by squeezing contents back and forth 25-30 times.
5. Squeeze mixed, warm resin into one end of bag and cutoff other end.
6. Slowly insert wiring connections into sealing pack until they fit snugly against the opposite end as shown in C.
7. Twist open end of bag and use tie wrap to close it off and position the tie wrapped end up until the resin jells.

**CAUTION:** Epoxy sealant is irritating to eyes, respiratory system, and skin. Can cause allergic skin reaction. Contains: epoxy resin and Cycloaliphatic epoxy-carboxylate.

**Precautions:** Wear suitable protective clothing, gloves, eye, and face protection. Use only in well ventilated areas. Wash thoroughly before eating, drinking, or smoking.

NOTE: Not required for wireless installations!

Figure 4. Epoxy sealing field wiring



