

# Spout Test Plug

Part Number: VST-STP-100

VST Liquid Removal Test Procedure for Phase II Coaxial EVR  
Balance Dripleless Nozzles



**Vapor Systems Technologies, Inc.**

650 Pleasant Valley Drive  
Springboro, Ohio 45066 (USA)

Toll Free: 1-888-878-4673

Phone: 937-704-9333

Fax: 937-704-9443

[www.vsthose.com](http://www.vsthose.com)

## GENERAL INFORMATION


This tool is utilized and required in the Liquid Removal Test Procedure found in the VST California Air Resources Board (CARB) Executive Orders VR-203 and VR-204 Exhibit 5.

Reference Executive Order VR-203 or VR-204 Exhibit 5 for complete details of proper use and testing procedures.


**NOTE:** Always lightly lubricate O-rings with petroleum jelly prior to use.

**CAUTION:** Make sure VST's spout plug is installed and the dispenser is de-activated..

**Executive Orders VR-203 and VR-204, Exhibit 5** may be found at [www.vsthose.com](http://www.vsthose.com) or [www.arb.ca.gov](http://www.arb.ca.gov)



**Nozzle spout plug O-rings**



**Plug properly inserted into VST nozzle spout.  
Both plug and O-rings seated into nozzle spout**